

AD-A185 013


VIC (VECTOR-IN-COMMANDER) INPUT PREPROCESSOR (VIP)
REFERENCE MANUAL (U) ARMY TRADOC ANALYSIS COMMAND FORT
LEAVENWORTH KS M CHENault AUG 97 TRAC-F-TM-1087


1/1

UNCLASSIFIED

F/G 12/5

NL





MICROCOPY RESOLUTION TEST CHART
NATIONAL BUREAU OF STANDARDS-1963-A

DTIC FILE COPY

②

AD-A185 013

Technical Memorandum TRAC-F-TM-1087
August 1987

TRADOC Analysis Command-Fort Leavenworth (TRAC-FLVN)
Operations Directorate
Ft. Leavenworth, Kansas 66027-5200

VIC INPUT PREPROCESSOR (VIP)
REFERENCE MANUAL

Compiled and Edited by

SP4 M. Chenault

ACN 48722

DTIC
ELECTE
SEP 18 1987
S D

DISTRIBUTION STATEMENT A
Approved for public release
Distribution Unlimited

The views, opinions, and/or findings contained in this report are not to be construed as an official Department of the Army position, policy, or decision unless so designated by authorized documents issued and approved by the Department of the Army.

87 9 15 076

ADA185013

SECURITY CLASSIFICATION OF THIS PAGE

Form Approved
OMB No. 0704-0188

REPORT DOCUMENTATION PAGE

1a. REPORT SECURITY CLASSIFICATION UNCLASSIFIED		1b. RESTRICTIVE MARKINGS	
2a. SECURITY CLASSIFICATION AUTHORITY		3. DISTRIBUTION/AVAILABILITY OF REPORT Approved for public release; distribution is unlimited	
2b. DECLASSIFICATION/DOWNGRADING SCHEDULE		5. MONITORING ORGANIZATION REPORT NUMBER(S)	
4. PERFORMING ORGANIZATION REPORT NUMBER(S) TRAC-F-TM-1087		7a. NAME OF MONITORING ORGANIZATION	
6a. NAME OF PERFORMING ORGANIZATION TRAC-FLVN	6b. OFFICE SYMBOL (if applicable) ATRC-FOC	7b. ADDRESS (City, State, and ZIP Code)	
6c. ADDRESS (City, State, and ZIP Code) Commander TRAC-FLVN (ATTN: ATRC-FOC) Ft Leavenworth, KS 66027-5200		9. PROCUREMENT INSTRUMENT IDENTIFICATION NUMBER	
8a. NAME OF FUNDING/SPONSORING ORGANIZATION	8b. OFFICE SYMBOL (if applicable)	10. SOURCE OF FUNDING NUMBERS	
8c. ADDRESS (City, State, and ZIP Code)		PROGRAM ELEMENT NO.	PROJECT NO.
		TASK NO.	WORK UNIT ACCESSION NO.
11. TITLE (Include Security Classification) VIC Input Preprocessor (VIP) Reference Manual			
12. PERSONAL AUTHOR(S) SP4 M. Chenault			
13a. TYPE OF REPORT Final Report	13b. TIME COVERED FROM 4-87 TO 8-87	14. DATE OF REPORT (Year, Month, Day) August 1987	15. PAGE COUNT 69
16. SUPPLEMENTARY NOTATION			
17. COSATI CODES		18. SUBJECT TERMS (Continue on reverse if necessary and identify by block number)	
FIELD	GROUP	SUB-GROUP	
19. ABSTRACT (Continue on reverse if necessary and identify by block number) VIC Input Preprocessor (VIP) was conceived as a necessity to reduce the time required to develop scenarios for the combat model, Vector-In-Commander (VIC). As such, VIP works primarily with the second and third largest of the VIC input files: the global ground module (.GG), of which VIP provides all the unit data, and the ground maneuver module (.GM), of which VIP provides the tactical area data. In addition, the following modules receive at least part of their input from a VIP-generated output file. The logistic module (.LO) receives the node network information from VIP. The minefield module (.MF) receives the minefield location and density from VIP. The terrain and barriers module (.TB) receives the barrier information from VIP. Another major function of VIP is the ability to create and alter maps as per user specifications. Map coordinates as well as map scale are entirely user defined. There exist separate files which contain not only all major and minor roads, but also rivers, streams, and rail-ways which are also user selectable.			
20. DISTRIBUTION/AVAILABILITY OF ABSTRACT <input checked="" type="checkbox"/> UNCLASSIFIED/UNLIMITED <input type="checkbox"/> SAME AS RPT. <input type="checkbox"/> DTIC USERS		21. ABSTRACT SECURITY CLASSIFICATION UNCLASSIFIED	
22a. NAME OF RESPONSIBLE INDIVIDUAL SP4 M. Chenault		22b. TELEPHONE (Include Area Code) (913) 684-3193	22c. OFFICE SYMBOL ATRC-FOC

19. Continuation

VIP is a graphics-based software package which contains a wide variety of routines to create a flexible user environment. User menus can be moved, redefined, and redrawn with no loss in operating procedures. Personal color schemes can be created, changed, and saved at any point during VIP execution. The package also contains many routines for the creation of slides, either text slides or graphic slides. In many ways, VIP is a generic menu-driven graphics package which does not have to be exclusively bound to VIC.



Accession For	
NTIS CRA&I	<input checked="" type="checkbox"/>
DTIC TAB	<input type="checkbox"/>
Unannounced	<input type="checkbox"/>
Justification	
By	
Distribution/	
Availability Codes	
Dist	Avail and/or Special
A-1	

INSTRUCTIONS FOR PREPARATION OF REPORT DOCUMENTATION PAGE

GENERAL INFORMATION

The accuracy and completeness of all information provided in the DD Form 1473, especially classification and distribution limitation markings, are the responsibility of the authoring or monitoring DoD activity.

Because the data input on this form will be what others will retrieve from DTIC's bibliographic data base or may determine how the document can be accessed by future users, care should be taken to have the form completed by knowledgeable personnel. For better communication and to facilitate more complete and accurate input from the originators of the form to those processing the data, space has been provided in Block 22 for the name, telephone number, and office symbol of the DoD person responsible for the input cited on the form.

All information on the DD Form 1473 should be typed.

Only information appearing on or in the report, or applying specifically to the report in hand, should be reported. If there is any doubt, the block should be left blank.

Some of the information on the forms (e.g., title, abstract) will be machine indexed. The terminology used should describe the content of the report or identify it as precisely as possible for future identification and retrieval.

NOTE: Unclassified abstracts and titles describing classified documents may appear separately from the documents in an unclassified context, e.g., in DTIC announcement bulletins and bibliographies. This must be considered in the preparation and marking of unclassified abstracts and titles.

The Defense Technical Information Center (DTIC) is ready to offer assistance to anyone who needs and requests it. Call Data Base Input Division, Autovon 284-7044 or Commercial (202) 274-7044.

SECURITY CLASSIFICATION OF THE FORM

In accordance with DoD 5200.1-R, Information Security Program Regulation, Chapter IV Section 2, paragraph 4-200, classification markings are to be stamped, printed, or written at the top and bottom of the form in capital letters that are larger than those used in the text of the document. See also DoD 5220.22-M, Industrial Security Manual for Safeguarding Classified Information, Section II, paragraph 11a(2). This form should be unclassified, if possible.

SPECIFIC BLOCKS

Block 1a. Report Security Classification: Designate the highest security classification of the report. (See DoD 5220.1-R, Chapters I, IV, VII, XI, Appendix A.)

Block 1b. Restricted Marking: Enter the restricted marking or warning notice of the report (e.g., CNWDI, RD, NATO).

Block 2a. Security Classification Authority: Enter the commonly used markings in accordance with DoD 5200.1-R, Chapter IV, Section 4, paragraph 4-400 and 4-402. Indicate classification authority.

Block 2b. Declassification / Downgrading Schedule: Indicate specific date or event for declassification or the notation, "Originating Agency Determination Required" or "OADR." Also insert (when applicable) downgrade to _____ on _____ (e.g., Downgrade to Confidential on 6 July 1983). (See also DoD 5220.22-M, Industrial Security Manual for Safeguarding Classified Information, Appendix II.)

NOTE: Entry must be made in Blocks 2a and 2b except when the original report is unclassified and has never been upgraded.

Block 3. Distribution/Availability Statement of Report: Insert the statement as it appears on the report. If a limited distribution statement is used, the reason must be one of those given by DoD Directive 5200.20, Distribution Statements on Technical Documents, as supplemented by the 18 OCT 1983 SECDEF Memo, "Control of Unclassified Technology with Military Application." The Distribution Statement should provide for the broadest distribution possible within limits of security and controlling office limitations.

Block 4. Performing Organization Report Number(s): Enter the unique alphanumeric report number(s) assigned by the organization originating or generating the report from its research and whose name appears in Block 6. These numbers should be in accordance with ANSI STD 239.23-74, "American National Standard Technical Report Number." If the Performing Organization is also the Monitoring Agency, enter the report number in Block 4.

Block 5. Monitoring Organization Report Number(s): Enter the unique alphanumeric report number(s) assigned by the Monitoring Agency. This should be a number assigned by a DoD or other government agency and should be in accordance with ANSI STD 239.23-74. If the Monitoring Agency is the same as the Performing Organization, enter the report number in Block 4 and leave Block 5 blank.

Block 6a. Name of Performing Organization: For in-house reports, enter the name of the performing activity. For reports prepared under contract or grant, enter the contractor or the grantee who generated the report and identify the appropriate corporate division, school, laboratory, etc., of the author.

Block 6b. Office Symbol: Enter the office symbol of the Performing Organization.

Block 6c. Address: Enter the address of the Performing Organization. List city, state, and ZIP code.

Block 7a. Name of Monitoring Organization: This is the agency responsible for administering or monitoring a project, contract, or grant. If the monitor is also the Performing Organization, leave Block 7a. blank. In the case of joint sponsorship, the Monitoring Organization is determined by advance agreement. It can be either an office, a group, or a committee representing more than one activity, service, or agency.

Block 7b. Address: Enter the address of the Monitoring Organization. Include city, state, and ZIP code.

Block 8a. Name of Funding/Sponsoring Organization: Enter the full official name of the organization under whose immediate funding the document was generated, whether the work was done in-house or by contract. If the Monitoring Organization is the same as the Funding Organization, leave 8a blank.

Block 8b. Office Symbol: Enter the office symbol of the Funding/Sponsoring Organization.

Block 8c. Address: Enter the address of the Funding/Sponsoring Organization. Include city, state and ZIP code.

Block 9. Procurement Instrument Identification Number: For a contractor grantee report, enter the complete contract or grant number(s) under which the work was accomplished. Leave this block blank for in-house reports.

Block 10. Source of Funding (Program Element, Project, Task Area, and Work Unit Number(s)): These four data elements relate to the DoD budget structure and provide program and/or administrative identification of the source of support for the work being carried on. Enter the program element, project, task area, work unit accession number, or their equivalents which identify the principal source of funding for the work required. These codes may be obtained from the applicable DoD forms such as the DD Form 1498 (Research and Technology Work Unit Summary) or from the fund citation of the funding instrument. If this information is not available to the authoring activity, these blocks should be filled in by the responsible DoD Official designated in Block 22. If the report is funded from multiple sources, identify only the Program Element and the Project, Task Area, and Work Unit Numbers of the principal contributor.

Block 11. Title: Enter the title in Block 11 in initial capital letters exactly as it appears on the report. Titles on all classified reports, whether classified or unclassified, must be immediately followed by the security classification of the title enclosed in parentheses. A report with a classified title should be provided with an unclassified version if it is possible to do so without changing the meaning or obscuring the contents of the report. Use specific, meaningful words that describe the content of the report so that when the title is machine-indexed, the words will contribute useful retrieval terms.

If the report is in a foreign language and the title is given in both English and a foreign language, list the foreign language title first, followed by the English title enclosed in parentheses. If part of the text is in English, list the English title first followed by the foreign language title enclosed in parentheses. If the title is given in more than one foreign language, use a title that reflects the language of the text. If both the text and titles are in a foreign language, the title should be translated, if possible, unless the title is also the name of a foreign periodical. Transliterations of often used foreign alphabets (see Appendix A of MIL-STD-847B) are available from DTIC in document AD-A080 800.

Block 12. Personal Author(s): Give the complete name(s) of the author(s) in this order: last name, first name, and middle name. In addition, list the affiliation of the authors if it differs from that of the performing organization.

List all authors. If the document is a compilation of papers, it may be more useful to list the authors with the titles of their papers as a contents note in the abstract in Block 19. If appropriate, the names of editors and compilers may be entered in this block.

Block 13a. Type of Report: Indicate whether the report is summary, final, annual, progress, interim, etc.

Block 13b. Time Covered: Enter the inclusive dates (year, month, day) of the period covered, such as the life of a contract in a final contractor report.

Block 14. Date of Report: Enter the year, month, and day, or the year and the month the report was issued as shown on the cover.

Block 15. Page Count: Enter the total number of pages in the report that contain information, including cover, preface, table of contents, distribution lists, partial pages, etc. A chart in the body of the report is counted even if it is unnumbered.

Block 16. Supplementary Notation: Enter useful information about the report in hand, such as: "Prepared in cooperation with..." "Translation at (or by)..." "Symposium..." If there are report numbers for the report which are not noted elsewhere on the form (such as internal series numbers or participating organization report numbers) enter in this block.

Block 17. COSATI Codes: This block provides the subject coverage of the report for announcement and distribution purposes. The categories are to be taken from the "COSATI Subject Category List" (DoD Modified), Oct 65, AD-624 000. A copy is available on request to any organization generating reports for DoD. At least one entry is required as follows:

Field - to indicate subject coverage of report.

Group - to indicate greater subject specificity of information in the report.

Sub-Group - if specificity greater than that shown by Group is required, use further designation as the numbers after the period (.) in the Group breakdown. Use only the designation provided by AD-624 000.

Example: The subject "Solid Rocket Motors" is Field 21, Group 08, Subgroup 2 (page 32, AD-624 000).

Block 18. Subject Terms: These may be descriptors, keywords, posting terms, identifiers, open-ended terms, subject headings, acronyms, code words, or any words or phrases that identify the principal subjects covered in the report, and that conform to standard terminology and are exact enough to be used as subject index entries. Certain acronyms or "buzz words" may be used if they are recognized by specialists in the field and have a potential for becoming accepted terms. "Laser" and "Reverse Osmosis" were once such terms.

If possible, this set of terms should be selected so that the terms individually and as a group will remain UNCLASSIFIED without losing meaning. However, priority must be given to specifying proper subject terms rather than making the set of terms appear "UNCLASSIFIED." Each term on classified reports must be immediately followed by its security classification, enclosed in parentheses.

For reference on standard terminology the "DTIC Retrieval and Indexing Terminology" DRIT-1979, AD-A068 500, and the DoD "Thesaurus of Engineering and Scientific Terms (TEST) 1968, AD-672 000, may be useful.

Block 19. Abstract: The abstract should be a pithy, brief (preferably not to exceed 300 words), factual summary of the most significant information contained in the report. However, since the abstract may be machine-searched, all specific and meaningful words and phrases which express the subject content of the report should be included, even if the word limit is exceeded.

If possible, the abstract of a classified report should be unclassified and consist of publicly releasable information (Unlimited), but in no instance should the report content description be sacrificed for the security classification.

NOTE: An unclassified abstract describing a classified document may appear separately from the document in an unclassified context e.g., in DTIC announcements or bibliographic products. This must be considered in the preparation and marking of unclassified abstracts.

For further information on preparing abstracts, employing scientific symbols, verbalizing, etc., see paragraphs 2.1(n) and 2.3(b) in MIL-STD-847B.

Block 20. Distribution / Availability of Abstract: This block must be completed for all reports. Check the applicable statement: "unclassified / unlimited," "same as report," or, if the report is available to DTIC registered users "DTIC users."

Block 21. Abstract Security Classification: To ensure proper safeguarding of information, this block must be completed for all reports to designate the classification level of the entire abstract. For CLASSIFIED abstracts, each paragraph must be preceded by its security classification code in parentheses.

Block 22a,b,c. Name, Telephone and Office Symbol of Responsible Individual: Give name, telephone number, and office symbol of DoD person responsible for the accuracy of the completion of this form.

ACKNOWLEDGEMENTS

The primary authors of the VIC Input Preprocessor (VIP) software package were TRAC-White Sands personnel, most notably, Jim Lankford and Linda Stead. The Technology Applications Branch graphics team of TRAC-Fort Leavenworth provided debugging and enhancement support.

The version of VIP described in this document differs significantly from the TRAC-White Sands version. The technology Applications Branch graphics team consisting of Mr. R. Pete Kaeding, Mr. Tim Daniels, and SP4 Mike Chenault have made numerous enhancements to the package with several more planned for later incorporation. Some of the documentation was extracted from the TRAC-White Sands-produced menu help text with elaboration where necessary. However, most of the context came from lessons learned during execution of the software.

CONTENTS

TITLE PAGE	1
ACKNOWLEDGEMENTS	iii
CONTENTS	v
ABSTRACT	vii
VIP REFERENCE MANUAL	
1. Purpose	1
2. Scope	1
3. Menu reference	
a. Main menu	1
b. Keyword	3
c. Unit menu	7
d. Path point menu	9
e. Tactical menu	11
f. Unit ID generator	13
g. Subordinate menu	14
h. Communications menu	15
i. Route plan menu	17
j. Minefield menu	20
k. Barrier menu	22
l. Line obstacle menu	24
m. Network menu	26
n. Logistic menu	28
o. Edit menu	29
p. Parameters menu	30

CONTENTS

VIP REFERENCE MANUAL (CONTINUED)

q. Graphics menu	31
r. Input/output menu	32
APPENDIX A. Menu representations	A-1
APPENDIX B. VIP output format	B-1
APPENDIX C. Program structure reference	C-1

ABSTRACT

VIC Input Preprocessor (VIP) was conceived as a necessity to reduce the time required to develop scenarios for the combat model, Vector-In-Commander (VIC). As such, VIP works primarily with the second and third largest of the VIC input files: the global ground module (.GG), of which VIP provides all the unit data, and the ground maneuver module (.GM), of which VIP provides the tactical area data.

In addition, the following modules receive at least part of their input from a VIP-generated output file. The logistic module (.LO) receives the node network information from VIP. The minefield module (.MF) receives the minefield location and density from VIP. The terrain and barriers module (.TB) receives the barrier information from VIP.

Another major function of VIP is the ability to create and alter maps as per user specifications. Map coordinates as well as map scale are entirely user defined. There exist separate files which contain not only all major and minor roads, but also rivers, streams, and railways which are also user selectable.

VIP is a graphics-based software package which contains a wide variety of routines to create a flexible user environment. User menus can be moved, redefined, and redrawn with no loss in operating procedures. Personal color schemes can be created, changed, and saved at any point during VIP execution. The package also contains many routines for the creation of slides, either text slides or graphic slides. In many ways, VIP is a generic menu-driven graphics package which does not have to be exclusively bound to VIC.

1. Purpose. This manual provides detailed information on all options and menus pertaining to the VIP software package. It also shows the required logical assignments necessary to execute the VIP software package.

2. Scope. This manual is designed to be an aid for use in conjunction with the VIP Users Manual. This manual provides the range of valid inputs or expected character string inputs.

3. VIP menu reference.

a. Main menu. The main menu consists of a series of data menus and several user features. You must return to the main menu to end the program or to use the keyword and parameter options, as this is the only place that they appear. Additionally, the main menu allows access to the data menus (any menu in which a file is created, i.e., unit menu, minefield menu, barrier menu, or network menu.)

Data are retained until a menu of a different data type is selected, or the data are transferred to the background plane.

If there are entities (or data) currently in memory when this menu is selected, the computer prompts: "HAS DATA BEEN RECORDED?"

Answer - YES to continue (DESTROYS EXISTING DATA IN ARRAYS!)
- NO returns to data menu to record.

No other action is possible until this question has been answered.

Main menu options:

KEYWORD **See paragraph 3b for more information.**
Transfers control to CRT. The menus are cleared from the screen. Keywords are then input from the CRT until the keyword "MENU" is input. It is through this function that picture files can be created along with slides. Individual menus can be moved or redefined by using the proper keywords. The setcolors command to change colors in a plane is reached through the keyword option.

END Exit from program. All files are closed.

UNIT MENU **See paragraph 3c for more information.**
Menu for defining unit locations and unit data. Allows access to the path points menu and the tactical menu. These menus create the data file DA DATA:UNIT#.DAT which is then used in the creation of the VIC global ground module. (.GG)

UNIT ID GEN **See paragraph 3f for more information.**
Unit identification generator for name, location, hierarchy, and symbol. The data are recorded on exit from the id generator in DA DATA:UNIT#.DAT and control is returned to the unit menu.

SUBORD MENU **See paragraph 3g for more information.**
Unit subordinate structure menu for VIC ground maneuver module (.GM) Uses as input the file DA DATA:UNIT#.DAT but when recording, it saves its data to the file DA DATA:UNIT#.SUB.

COMMS MENU **See paragraph 3h for more information.**
Communications structure menu for creation and definition of networks. Uses as input the file DA DATA:UNIT#.DAT, but when recording, it is saved to DA DATA:UNIT#.NET.

RT PLAN MENU **See paragraph 3i for more information.**
Detailed route planning menu. Not designed for use in the creation of VIC data files but useful in the area of scenario generation.

MINEFLD MENU **See paragraph 3j for more information.**
Minefield emplacement menu for minefield module (.MF)

BARRIER MENU **See paragraph 3k for more information.**
Barrier menu for area obstacles for terrain and barriers module (.TB)

LINE OB MENU **See paragraph 3l for more information.**
Line obstacle menu for terrain and barriers module (.TB)

NETWORK MENU **See paragraph 3m for more information.**
General network menu for logistics module (.LO) The logistics menu is reached from this menu. It works on the same data that are created in the network menu.

PARAMETERS **See paragraph 3p for more information.**
Menu to set parameter switches. The UTM/MC coordinate option selection resides here. The major function of this menu is to allow previously defined data files to be read in when the user is in a different data menu.

CHANGE PLANE Transfer entities from foreground to background planes. Background plane in this case is defined as plane 2. The data will be visible in plane 2 but can no longer be worked on.

GRAPHICS **See paragraph 3q for more information.**
Graphics menu to load, zoom maps. Also, used for the clearing of the upper 2 planes and setting drawing color.

PLAYBACK Play back the detailed route planning data over time. For use with the route planning files.

UTILITY MENU Draw the utility menu which contains the most commonly used keywords. Unlike the keyword option, commands are selected with the cursor.

b. Keyword. It may be necessary or useful to enter the commands via the keyboard and not with the bitpad. A complete listing of keywords is given below.

Keywords:

--GRAPHICS-----TERRAIN-----MENU MENU-----MENU DEFINE---SLIDE-----OTHER--

ERASE	SETCOORD	SELECTMENU	STARTX	SELCOLOR	HELP
ERASE1	MAPSIZE	DRAWMENU	STARTY	SELPLANE	DCL CMD
ERASE2	SETFEATURE	ERASEMENU	ITXLNG	SELTEXTSIZE	DEMOLOAD
ERASE3	DRAWGRID	SAVEMENU	ITXSZ	SELTEXTDIR	UNITID
SELERASE	DRAWBORDER	LOADMENU	NUMBRX	LINEDRAW	END
MAPERASE	DRAWROADS	MSAVEMENU	NUMBRY	TEXTDRAW	
SAVEPIC	DRAWVEG	MLOADMENU	IGRPLN	RECTDRAW	
LOADPIC	DRAWCITY	DEFINEMENU	IGRCOL	REMOVE	
SP LOADPIC	DRAWFADS	SHOWMENU	ICHPLN	MOVEPIC	
MAKEPIC	WHERE	GRIDMENU	ICHCOL	EMOVEPIC	
PICTURE	WHEREMC	SIZEMENU	IHLCOL	SMOVEPIC	
SETCOLORS	MCLINE	INQUIREMENU		ESMOVEPIC	
SAVECOLORS	MCPOINT	LISTMENU		CURLOADPIC	
LOADCOLORS	MCZUTM	WHEREMENU			
CCOLOR	UTMLINE	CAP			
CZOOM	ZONCHG	CSXY			
HZOOM	ZONECHANGE	CSX			
REZOOM	MAPNAME	CSY			
UPZOOM	SELMAPS	CHANGETEXT			
ZOOM	SPDRAWROADS				
PANORG	SPDRAWVEG				
REFMAP	SPFASTVEG				
REFPIX	FASTDRAWVEG				
RECTMAP	BDRAWVEG				
SETCLIP					
SETORIGIN					
CURORIGIN					

The function of individual keywords within these groups are as follows:

Graphics:

1. ERASE Clears all three viewable planes.
2. ERASE1 Clears the bottom plane (where the map is drawn).
3. ERASE2 Clears the middle plane.
4. ERASE3 Clears the top plane (where the unit data are drawn).
5. SELERASE Selectively erases a part of any plane.
6. MAPERASE Erases a plane using a selected color.
7. RECTMAP Draws a rectangle around a defined portion of the map.
8. SAVEPIC Saves the current map to a file.
9. LOADPIC Loads a map from a file.
10. SP LOADPIC Enters a single particular .pic file.
11. SETCOLORS Can change the colors on each plane.
12. SAVECOLORS Saves the changes made with SETCOLORS in a file.
13. LOADCOLORS Loads color file previously saved.
14. CCOLOR Changes color of a plane.
15. CZOOM Zooms on cursor position. Repeating.
16. HZOOM Hardware zoom using 0,0 as x,y min.
17. REZOOM Defaults back to original screen size.
18. UPZOOM Multiple zooms around a point.
19. ZOOM Sets with cursor the software zoom window center.
20. PANORG Zooms and pans across the picture.
21. SETCLIP Sets viewable window size.
22. CURORIGIN Moves the 0,0 point to a spot picked by cursor.
23. SETORIGIN Moves the 0,0 point to a spot input by keyboard.

Terrain:

1. SETCOORD Creates own grid pattern. Will erase current map.
2. MAPSIZE Draws grid according to military coordinates (coords).
3. SETFEATURE Draws submenu to select features active.
4. DRAWGRID Draws grid according to coord system in use.
5. DRAWBORDER Draws any border previously defined in the pic file.
6. DRAWROADS Draws the roads previously defined for this pic area.
7. DRAWVEG Draws the vegetation for this pic area.
8. DRAWCITY Draws the city names defined for this pic area.
9. WHERE Gives pixel and map coords for cursor position.
10. WHEREMC Converts cursor position into military coords.
11. MCPOINT Draws a point at a given military coord.
12. MCLINE Draws a line between military coords.
13. UTMLINE Draws a line using UTM coords.
14. MC2UTM Translates military coords to UTM coords.
15. ZONCHG Changes zones using the cursor as coord input.
16. ZONECHANGE Changes from one zone to another in UTM coords.
17. SELMAPS Draws a global map showing which maps are defined.
18. MAPNAME Using cursor, displays which map(s) are being used.
19. SPDRAWROADS Displays a specific map file, entered from keyboard.
20. SPDRAWVEG Displays a specific veg file, entered from keyboard.
21. SPFASTVEG Faster version of SPDRAWVEG.
22. FASTDRAWVEG Draws vegetation maps faster than DRAWVEG.

Menu util:

1. SELECTMENU Selects menu to work with.
2. DRAWMENU Displays to screen the menu loaded.
3. ERASEMENU Erases selected menu from screen.
4. SAVEMENU Saves selected menu to local file.
5. LOADMENU Loads a menu from the .MEN file.
6. MSAVEMENU Saves a master menu to local file.
7. MLOADMENU Loads a master menu from the .MEN file.
8. DEFINEMENU Selects menu size, position and color.
9. SHOWMENU CRT displays menu attributes.
10. CHANGETEXT Alters text within a menu field.
11. WHEREMENU Using cursor, establishes menu coordinates.
12. CSXY Draws menu at cursor origin starting at upper left.
13. CSX Draws menu at cursor x origin. y unchanged.
14. CSY Draws menu at cursor y origin. x unchanged.
15. CAP Text size of capitals.
16. GRIDMENU Draws the menu boxes with no text.
17. SIZEMENU (not active)
18. INQUIREMENU Gives menu attributes for particular menu.
19. LISTMENU Lists current menus available.

Menu define:

1. STARTX Starting x position for menu draw.
2. STARTY Starting y position for menu draw.
3. ITXLNG Widens menu box for text length.
4. ITXSZ Alters text and box size to accomodate text.
5. NUMBRX Number of columns across for menu.
6. NUMBRY Number of rows down for menu.
7. IGRPLN Plane to draw grid on.
8. IGRCOL Color grid to be drawn in.
9. ICHPLN Plane to draw text on.
10. ICHCOL Color text to be drawn in.
11. IHLCOL Highlighting color.

Slide:

1. SELCOLOR Selects color for drawing.
2. SELPLANE Selects plane to draw on.
3. SELTEXTSIZE Selects text size for display.
4. SELTEXTDIR Direction of text display.
5. LINEDRAW Draws line on CRT using defined colors and plane.
6. TEXTDRAW Draws a text string using defined colors and plane.
7. RECTDRAW Draws rectangle on CRT using defined color and plane.
8. REMOVE Erases last text, line, or rectangle drawn.
9. MOVEPIC Moves part of the picture with cursor.
10. EMOVEPIC Erases and moves part of the picture.
11. SMOVEPIC Saves and moves part of the picture.
12. ESMOVEPIC Erases, saves, and moves part of the picture.
13. CURLOADPIC Loads a picture file using cursor as 0,0 reference.

Other:

- | | |
|-------------|---|
| 1. HELP | Toggles on and off the help utility. |
| 2. DCL CMD | Allows system commands from inside VIP. |
| 3. DEMOLOAD | (demo file not present) |
| 4. UNITID | Goes into unit id generator. |
| 5. END | Stop program. |

Most of these keywords are available by using the utility menus. The utility menu is reached from the main menu.

c. Unit menu. The unit menu contains the function options to deploy units to starting positions (if there are no defined locations in ID GEN). It also allows for creation of new units, copy of units, and deletion of unwanted units. Individual data entries (i.e., initial mass, prototype, radius, delta, and orientation) can be entered at this time. Units are stored in direct access file DA_DATA:UNIT#.DAT.

- MAIN MENU Return to main menu.
Asks if data has been recorded, because if a different data type is selected, all previous data are deleted. Answer YES/NO.
If answer is NO, the previous menu is displayed so that the data may be recorded.

- PATH PT MENU Path point menu to create routes for the units. The UNIT#.DAT is still the file being worked on.
See paragraph 3d for more information.

- INPUT/OUTPUT Draws the input/output menu, at the bottom of the screen to read, record, and print data.
See paragraph 3r for more information.

- GRAPHICS Draws the graphics menu at the bottom of the screen for loading and manipulation of picture files.
See paragraph 3q for more information.

- SELECT UNIT Select new unit by touching unit with the cursor.
Selected unit is highlighted.

- NEW UNIT Create a new unit. The size of the unit will be taken to be the last values of frontage and depth. Select the position of the center of the unit with the cursor.
The unit is drawn in highlight color at the cursor position.

- COPY UNIT Copy the selected unit to produce a new unit at a new location. If no unit has been selected, you are prompted to select a unit to copy. After selection, that unit will be highlighted. Select position for center of the new unit. A unit is drawn in the new location and highlighted. Subsequent pressing of the cursor in the map area produces more copies. To terminate, select from menu area.

- DEPLOY UNIT Move unit to new location. If no unit has been selected, select unit. Select new position for the center of the unit. The unit is redrawn and highlighted at the new location. If the unit has a path and the new position for the unit is not on that path, then the path point for the unit is moved.

MIL COORD Draws a triangle on the screen at selected location. Enter military coordinates and zone number of location.

UNIT ID Name of unit. Enter up to 12 alphanumeric characters. The name is checked against the unit currently held in the computer and against the unit file loaded to ensure that the name is unique. If there is already a unit in the computer by the name, it is highlighted.

SET SYMBOL Select new symbol for selected unit. Symbols are created using the symbol generator program. The first character of the unit name is combined with the symbol number to identify the symbol. Enter the number of the new symbol. The new symbol is highlighted. Symbols are displayed as Bxxx or Rxxx by side. This option allows the user to change the three-digit TOE number associated with the unit. See paragraph 3f for TOE listing.

RADIUS Draw a circle of specified radius centered on the unit location. Enter the radius of the circle.

DELETE UNIT Select unit to be deleted. Deletes data on selected unit and removes it from the screen. The unit is only deleted from local memory. The file in DA DATA: remains intact until deleted or overwritten. Further units may be deleted by selecting with the cursor. CAUTION: This function is still active until it is deselected by making another menu selection.

INIT MASS Initial mass of the unit is derived from some computation which utilizes some system of assigning a value or weight to each piece of equipment which is organic to the unit.

PROTOTYPE Unit prototype number. Identifies generic type units which have common attributes. This number must be between 1 and the total number of prototypes.

UNIT RADIUS Radius of the area occupied by the unit's systems (meters). This circle may expand or contract depending on the ground combat status mappings data in VIC.

UNIT DELTA The radius of the circle which contains one-half of the weapons for the unit. This is the basic radius which applies when the unit is considered to be in some "standard" deployment.

ORIENTATION Unit's initial orientation measured in degrees, counterclockwise from east.

d. Path point menu. This screen allows the creation of individual paths by inputting the nodes or points the unit is to follow. Multiple paths on the same route are made easier with the copy path function. The individual node data as to point type, preparedness, requirements, and wait times can be entered at this point.

UNIT MENU	Returns to unit location menu.
TACT MENU	Tactical area menu for VIC ground movement module. If no unit has been selected, select unit. Tactical areas are automatically recorded in DA DATA:TACTAREA#.DAT where # is the unit direct access file number. If no file has been assigned, prompts for the file number.
RT PLAN MENU	Detailed route planning menu. See paragraph 3i for more information.
INPUT/OUTPUT	Draws the input/output menu, at the bottom of the screen to read, record, and print data. See paragraph 3r for more information.
GRAPHICS	Draws the graphics menu at the bottom of the screen for loading and manipulation of picture files. See paragraph 3q for more information.
SELECT UNIT	Select new unit by touching unit or path with the cursor. Selected unit and path is highlighted.
CREATE PATH	Create a path for the selected unit, or add to an existing path. If a path already exists, the path is continued from the last node. The position of each node of the path is selected with the cursor. The last node entered may be deleted by selecting it with the cursor. To complete the path, press cursor in the menu area. Then the nodes of the path are joined and highlighted. If the unit is not positioned at one of the path points, the closest end of the path is joined to the unit.
COPY PATH	May only be accessed after CREATE PATH has been keyed. Select a path to copy. Select the first and last nodes to copy. The path is highlighted. Enter any new nodes after the copied path, if any. To complete the path, press cursor in the menu area. Then the nodes of the paths are joined and highlighted. If the unit is not positioned at one of the path points, the closest end of the path is joined to the unit.
EDIT PATH	Draw the edit menu at the bottom of the screen for use in modifying individual nodes within paths. See paragraph 3n for more information.

DELETE PATH Delete the path. If no unit is selected, select unit and delete its path.

SELECT NODES Select first and last path points for which data is to be entered.

POINT TYPE The path point must have a certain type associated with it:

- IMED - Immediate
- DEF - Defense
- DLAY - Delay
- RESV - Reserve
- APZ - Air pickup zone
- ALZ - Air landing zone
- HBAS - Helo base point
- HATK - Helo attack point
- EBAS - Engineer base point

NOTE: Helicopter units that fly missions must be given HBAS point types. Engineer units that carry out missions must be given EBAS point types.

PREPRD STATE Initial prepared state of the path point. This value lies between 0.0 and 1.0 to define the degree to which this path point has currently been prepared. This parameter may be omitted for input in which case the model resorts to default values as follows: 1.0 for DEF type path points, 0.0 otherwise.

ENG REQUIRED "Y" indicates that engineers are required to prepare the path point. This is a toggle selection, default is no. The DLAY and DEF are the only types of points that can be prepared so a "Y" against any other path point types will flag an error and terminate VIC on loading.

AREA TYPE The path point is defined as being located in a particular type of area:

- CFA - Covering force area
- MBA - Main battle area
- RESV - Reserve area
- 1ECH - First echelon area
- 2ECH - Second echelon area
- REAR - Rear area

As a blue unit progresses along its path, its role is reset to the value of the area type. The red units are handled in a different manner. The area type of their starting point defines their initial role, then their role changes as a result of decision table logic only. Therefore, the area type associated with a red unit's path points is irrelevant except for the starting node.

WAIT TYPE Options for control of the time element for path point events.

- SYNC - Synchronize
- DLTA - Delta wait
- STAT - Static
- RGRP - Regroup
- RMOV - Remove
- RORG - Reorganize

WAIT TIME Specifies when a unit departs from a path point when simulating without table-driven ground movements (days, hours, minutes).

e. Tactical menu. The tactical menu creates tactical areas for the unit path points. The file is opened and the tactical areas are automatically recorded in DA DATA:TACTAREA#.DAT where # is the file number inputted for the UNIT#.DAT file. The tactical area numbers are assigned to the path points. These numbers are written to the unit file and correspond directly to the tactical area file. Both these files after going to OUTPUT: are combined and used in the VIC global ground module (.GG).

PATH PT MENU Returns to the path point menu and saves all tactical areas created.

SELECT UNIT Select unit by touching with cursor. Selected unit and its path are highlighted.

DISPLAY TAC Display tactical area for path point of selected unit. Select path point with cursor. The tactical area assigned to the selected path point is highlighted and the path points contained within the tactical area are highlighted.

CLEAR TAC Clear the tactical areas from the screen for the selected unit.

NEW TAC Create a new tactical area. New tactical areas can only be created where no tactical area exists. If there are no path points in the new tactical area, it will be deleted. The position of each node of the tactical area is selected by the cursor. To complete the tactical area, press cursor in the menu area. The nodes of the tactical area are joined and highlighted.

COPY TAC Copy the selected tactical area to produce a new tactical area at a new location. Select a node to copy, select position for node. A tactical area is drawn in the new location and highlighted. Path points within the new tactical area are highlighted. If no unassigned path points lie in the new tactical area, it will be deleted.

COPY UNT TAC Copy all tactical areas from the selected unit to the current unit.

REMOVE P PT Remove path points from tactical area. Select each path point to be removed with the cursor. If there are no path points within the tactical area, it will not be deleted since it could be used by another unit.

MOVE Move tactical area to new location. Select node to reposition. Select new position for node. Tactical area is redrawn at new location and highlighted. Determine which path points are in the tactical area and highlight.

SHOW ALL TAC Display the tactical areas for all path points of all units.

EDIT TAC Draw the edit menu at the bottom of the screen for use in editing individual tactical fields. See paragraph 3o for more information.

TAC DEFAULT Construct a default tactical area for each path point of selected unit. The tactical area encompasses the path point to each side of the selected one and extends a distance of one unit radius beyond. The width of the area is one unit radius to either side.

PRINT DATAMC Prints data on all tactical areas. Coordinates are printed in military coordinates or UTM coords depending on whether the parameter PRINT UTM is switched on or off. Input the output file number: Enter # (file number) to produce a VIC file TACTAREA#.OUT. Note tactical area data cannot be printed to the CRT.

PRINT TACS Print data on the tactical areas of the units which are currently in the computer. Coordinates are printed in military coordinates or UTM coords depending on whether the parameter PRINT UTM is switched on or off. Input the output file number: Enter # (file number) to produce a VIC file TACTAREA#.OUT.

READ VIC FILE Read from a sequential VIC data file and record data in a direct access file TACTAREA#.DAT. Enter VIC file name -.OUT. Are coords in military coords? Answer YES/NO. If reading UTM, enter coords of the VIC origin.

f. Unit ID Generator. The selection of this option will go to the unit menu and ask for you to enter a file number. If a file number has been previously assigned, you will go directly to UNIT ID GENERATOR. This number becomes the # part of the file DA_DATA:UNIT#.DAT.

This menu allows creation of individual units, locations, and TOE numbers for all sides. The unit numbers are created by selection from the individual force structure menus. The selection is highlighted and the appropriate number is displayed in the force structure box. Numbers greater than 9 are referenced alphabetically (10 = A, 11 = B, etc.). Any menu not selected displays a blank in the force structure box. If a zero is required, select the appropriate empty box in the menus.

Entering the unit location is optional. Units with no defined location are displayed in the upper right corner of the screen when the unit file is read in. If the user wants to enter a location while in UNIT ID GENERATOR, all coordinates are expressed in military coordinates.

The unit TOE number is the last group of three boxes to fill in. Menu selections are the same procedure as the unit force structure. A listing of all TOE numbers with defined symbols is provided.

(THE FUNCTIONS CHANGE, DELETE, SAVE, AND LOAD ARE NOT OPERATIONAL AND DEFAULT TO THE UNIT MENU.) Upon exit of menu, you go to the unit menu.

RED FORCE	BLUE FORCE	ORANGE FORCE	GREEN FORCE
001	001	101-102	NONE DEFINED
101-124	101-104	104-115	
126-132	106-107	201-223	
140-143	109	301-304	
201-239	113-114	401-404	
241-245	116	501-502	
251-252	119-121		
301-313	201-214		
316-318	216		
320-323	218-224		
327-328	226-230		
330-331	232-233		
333	236-238		
337-338	241-243		
340	247-249		
401-404	251		
406-408	261		
410	322-324		
501-505	422-424		
601-606	522-523		
611-612			

g. Subordinate menu. This menu assigns the superior/subordinate structure. This menu uses as input the UNIT#.DAT file but the output of this menu creates the file DA_DATA:UNIT#.SUB.

MAIN MENU	Return to main menu. Asks if data has been recorded, because if a different data type is selected all previous data are deleted. Answer YES/NO. If answer is NO, the previous menu is displayed so that the data may be recorded.
INPUT/OUTPUT	Draws the input/output menu, at the bottom of the screen to read, record, and print data. See paragraph 3r for more information
GRAPHICS	Draws the graphics menu at the bottom of the screen for loading and manipulation of picture files. See paragraph 3q for more information.
SELECT UNIT	Select new unit with cursor. Selected unit is highlighted.
SUBORDINATES	Select subordinates for current (highlighted) unit. Current unit and its subordinates are highlighted. Data are displayed on the CRT.
PHASE GROUP	Select units which belong to the same phase group. Select units are assigned the same phase group number. Data are displayed on the CRT. A phase group is a set of specific ground units which will at some time need to coordinate their movement. Units will remain at a designated position until all other units in that phase group have reached their own designated wait positions. Then all units of that phase group will begin movement to the next designated positions.
LEADING ECH	Select the leading echelon for red units. Initially identifies which unit is to be followed by this unit at the start of the campaign. Data are displayed on the CRT. This pointer can be dynamically changed during the run by the decision tables.
COORD GROUP	Select units which belong to the same coordination group. Select units are assigned the same coordination group number. Data are displayed on the CRT. Units given no paths can move automatically whenever another specified unit moves along a designated path and will remain at the same offset distance from that unit. Only one member can have a path. If not, the program will flag the fact that there can only be one leader of the group and the model will abort the run.

h. Communications menu. This menu creates and defines communications networks. This menu uses as input the UNIT#.DAT file but the output of this menu creates the file DA_DATA:UNIT#.NET.

MAIN MENU	Return to main menu. Asks if data have been recorded, because if a different data type is selected, all previous data are deleted. Answer YES/NO. If answer is NO, the previous menu is displayed so the data may be recorded.
INPUT/OUTPUT	Draws the input/output menu, at the bottom of the screen, to read, record, and print data. See paragraph 3r for more information.
GRAPHICS	Draws the graphics menu at the bottom of the screen for loading and manipulation of picture files. See paragraph 3q for more information.
SELECT UNIT	Select new unit with cursor. Selected unit is highlighted.
NEXT NET	If multiple nets have already been defined, this function will display and highlight the next network. If the case of the displayed network is the last network, the first network will be displayed.
NEW NET	Used for the creation of new networks. First unit selected is highlighted. This unit now serves as the central axis for the network. Subsequent selection of units includes those units in that network. All linked units are displayed with a line showing its linkage.
ADD/DEL MEMB	Allows for the addition and/or deletion of units from a specific network by selecting that unit while the network which contains that unit is highlighted.
NET TYPE	The network type can now be entered in alphanumeric characters.
SYSTEM NAME	System name is entered using the alphanumeric submenu.
DEL SYSTEM	Delivery system name is entered using the alphanumeric submenu.
LINKS / NODE	The average number of channels per node is entered using the numeric submenu.
TYPE DATA	The type of data is entered using the numeric submenu.

ANT POLAR	Antenna polarization number is entered using the numeric submenu.
TIME SWITCH	Time switch system number is entered with the numeric submenu.
TRANSM GAIN	Transmitter gain is entered using the numeric submenu.
RECEIVER GAIN	Receiver gain is entered using the numeric submenu.
TRANSM HT	Transmitter height in meters.
RECEIVER HT	Receiver height in meters.
TRANSM POWER	Transmitter power is entered using the numeric submenu.
TRANSM FREQ	Transmitter frequency is entered using the numeric submenu.

i. Route plan menu. NOT REQUIRED FOR VIC FILES. This menu allows for travel via individual roads or cross-country. Allows for the calculation of distances and time requirements for individual units. Can go to PATH POINT MENU or back to MAIN MENU. To plan the detailed route between path points. The route for each unit is stored in a separate direct access file
DA_DATA:UNITID.ROT

MAIN MENU	Return to the main menu. Asks if data have been recorded, because if a different data type is selected, all previous data are deleted. Answer YES/NO. If the answer is NO, the previous menu is displayed so that the data may be recorded.
PATH PT MENU	Path point menu to create routes for the units.
INPUT/OUTPUT	Draws the input/output menu to read, record, and print data.
GRAPHICS	Draws the graphics menu.
X-COUNTRY	Create a new path from node. Select node. Enter nodes of the detailed path for off-road travel. ROAD TRAVEL may be access for path of the route. Access is also available to NEAREST NODE.
ROAD TRAVEL	Select a path following the roads. Select the node of the path from which road travel is required. If the road types have not been selected, select road types. Select the start and end points of the path with the cursor. If the start or end points are not at a node, select the first and last nodes which are on the road junctions. If there is more than one option for the path at any point, select from nodes displayed. When the path is complete, the nodes of the path are joined.
SELECT ROADS	Select the type of roads for ROAD TRAVEL: AUTOBAHNS MAIN ROADS SECONDARY ROADS FAIR WEATHER ROADS RAILWAYS Selected types are highlighted.
SELECT UNIT	Select unit with the cursor, highlight and draw nodes of its path. The detailed route is drawn between the nodes if it exists.
RETURN TR	Return the traffic regulator to its first path point.
SELECT NODE	Select node of path.

NEAREST NODE Find the nearest node on the road network. Select position with the cursor. The nearest node is displayed.

UPDATE TIMES If this is switched on, then when a time is changed for a node, all times for subsequent nodes are updated.

POSITION/TIM Draw all the units at their locations at a specified time. Enter time (days, hours, minutes).

DELETE ROUTE Delete whole of the detailed path for selected unit.

COPY PATH Select unit to copy. The detailed route and the nodes are copied. The unit is moved to the end of the copied path.

EDIT PATH Edit the main nodes of the path. The detailed route connected to nodes which have been edited is removed. After the path is edited, the detailed route is redrawn.

RT PLAN DATA Draw the route plan data menu.

NEW UNIT Create a new unit. Select the position of the center of the unit with the cursor. The unit is drawn in highlight color at the cursor position.

DEPLOY UNIT Move unit to new location. If no unit has been selected, select unit. Select new position for the center of the unit. Redraw and highlight unit at new location. If the unit has a path and the new position for the unit is not on that path, then the path point for the unit is moved.

CREATE PATH Create a path for the selected unit. The position of each node of the path is selected with the cursor. The last node entered may be deleted by selecting it with the cursor. To complete the path, press cursor in the menu area. Nodes of the path are joined and highlighted. Closest end of the path is joined to the unit.

To enter the data for each node of the path.

ARRIVE TIME Enter the arrival time at the node (days, hours, minutes).

DEPART TIME Enter the time to leave the node (days, hours, minutes).

END TIME Enter the time to arrive at next node (days, hours, mins).

POSTURE Posture for the node, or for traveling from the node.
ASSEM-AREA MARCH FIRING-POSITION
TAC-A-AREA MOVE-CONTACT DESTROYED
IN COLUMN ATTACK AIR-PICK-UP
TMP-POSITION DELAY AIR-LANDING
HASTY-DEF HELI-BORNE TAC-MARCH
DELIB-DEF

COL LEN NODE Column length of unit at the node (km).

COL DIA NODE Column diameter of unit at the node (km).

COL LEN PATH Column length of unit on path from the node (km).

COL DIA PATH Column diameter of unit on path from the node (km).

ALTITUDE Altitude (m).

j. Minefield menu. Menu for the creation and alteration of individual minefields. Allows data input on each. Data is stored in DA DATA: MINEFIELD#.DAT. This menu can only be reached from and return to the main menu. When sent to the directory OUTPUT: this file becomes part of the VIC module labeled minefields (.MF).

- MAIN MENU Return to main menu. Asks if data have been recorded, because if a different data type is selected, all previous data are deleted. Answer YES/NO. If answer is NO, the previous menu is displayed so that the data may be recorded.
- INPUT/OUTPUT Draws the input/output menu at the bottom of the screen to read, record, and print data. See paragraph 3r for more information.
- GRAPHICS Draws the graphics menu at the bottom of the screen for loading and manipulation of picture files.
- SELECT MNFLD Select new minefield by touching the minefield with the cursor. Selected minefield is highlighted.
- NEW MINEFLD Create a new minefield. The position of the center of the minefield is selected with the cursor. The size of the minefield will be taken to be the last values of frontage and depth. If DENSITY FACT has been set, the number of mines is calculated.
- COPY MINEFLD Copy the selected minefield to produce a new minefield at a new location. If no minefield has been selected, select a minefield to copy. The minefield is highlighted. Select position for the center of the minefield. A minefield is drawn in the new location and highlighted. CAUTION: The copy function does not turn off until another menu selection is made. Subsequent pressing of the cursor in the map area produces more copies. To terminate, select from menu.
- MOVE MINEFLD Move minefield to new location. If no minefield has been selected, select minefield to move. Select new position for the center of the minefield. The minefield is redrawn and highlighted at the new location. The old entity is erased from the screen and local memory.

DELETE MNFLD Select minefield to be deleted. Deletes data on a selected minefield and removes it from the screen. The minefield is only deleted from local memory. The file in DA DATA: remains intact until deleted or overwritten. Further minefields may be deleted by selecting with the cursor. CAUTION: This function is still active until it is deselected by making another menu selection.

DENSITY FACT Input the density factor for minefields. The number of mines = FRONTAGE * DEPTH * DENSITY FACTOR. Or can be thought of as number of mines per square meter. This function can be overridden as required by the number of mines option below.

ENG MISSION Engineer mission number. Select with the cursor from the submenu drawn at the bottom of the screen. Groups together those minefields in the same engineer mission.

MINEFLD # Enter new identification number for the selected minefield.

MINETYPE NAM Minefield type name. Enter up to 12 alphanumeric characters. The name is checked against the minefields currently held in the computer and against the catalog if a direct access file is assigned, to ensure that the name is unique. If there is already a minefield in the computer by the name, it is highlighted.

FRONTAGE Width of the area occupied by the minefield (meters). Use the cursor to enter this number from the submenu at the bottom of the screen.

DEPTH Depth of the area occupied by the minefield (meters). Use the cursor to enter this number from the submenu at the bottom of the screen.

ORIENTATION Orientation, expressed in degrees counterclockwise from east. Use the cursor to enter this number from the submenu at the bottom of the screen.

NO OF MINES Number of mines in the minefield. Input - , then the number of mines are calculated. This overrides the density factor.

START TIME Activating time (days, hours, minutes). Zero means already activated. If engineer module is played, time indicates priority.

k. Barrier menu. Menu for the creation and alteration of individual barriers. Allows for data input as to type, visibility, and trafficability. This menu can only be reached from and return to the main menu. Data created in this menu are stored in the file DA DATA:BARRIER#.DAT, where # is the file number entered by the user. This file, when sent to the OUTPUT: directory (see paragraph 3r), later combines with the line obstacle data file to form part of the VIC file labeled .TB which stands for terrain and barriers.

- MAIN MENU** Return to main menu. Asks if data have been recorded, because if a different data type is selected, all previous data are deleted. Answer YES/NO. If answer is NO, the previous menu is displayed so that the data may be recorded.
- INPUT/OUTPUT** Draws the input/output menu at the bottom of the screen to read, record, and print data. See paragraph 3r for more information.
- GRAPHICS** Draws the graphics menu at the bottom of the screen for loading and manipulation of picture files. See paragraph 3q for more information.
- SELECT BAR** Select new barrier by touching node or line segment with the cursor. Selected barrier is highlighted showing all node positions.
- NEW BARRIER** Create a new barrier. The position of each node of the barrier is selected with the cursor. To complete the barrier, press cursor in the menu area. The nodes of the barrier are joined and highlighted.
- COPY BARRIER** Copy the selected barrier to produce a new barrier at a new location of the same dimensions. If no barrier is selected, you are prompted to select a barrier to copy. The selected barrier is highlighted and shows all node positions. Select a node to copy. This becomes the reference point in placement of the new barrier. Select position for node. A barrier is drawn in the new location and highlighted. CAUTION: The copy function does not turn off until another menu selection is made. Subsequent pressing of the cursor in the map area produces more copies. To terminate, select from menu area.
- MOVE BARRIER** Used to move barrier to a new location. If no barrier has been selected, you are prompted to select barrier. Barrier becomes highlighted and shows all node positions. Select node to reposition. This node is the cursor reference point. Select new position for node. The barrier is redrawn and highlighted at the new location while the old entity is erased. The barrier can be moved until another selection is made in the menu area.

EDIT BARRIER Draw the edit menu at the bottom of the screen for use in modifying the nodes within individual barriers. See paragraph 3n for more information.

DELETE BAR Select barrier to be deleted. Deletes data on selected barrier and removes it from the screen. The barrier is deleted from the local file only. The file in DA DATA: remains intact until deleted or overwritten. Further barriers may be deleted by selecting with the cursor. **CAUTION:** This function is still active until it is deselected by making another menu selection.

BARRIER # Using the cursor, enter new identification number for the selected barrier from the submenu drawn at the bottom of screen.

VISIBILITY The following are the only valid data ranges and their meanings for this menu entry--
 Visibility: 1 = good
 2 = fair
 3 = poor

TRAFFICABLTY The following are the only valid data ranges and their meanings for this menu entry--
 Trafficability: 1 = good
 2 = fair
 3 = poor

BARRIER TYPE The following are the only valid data ranges and their meanings for this menu entry--
 Barrier type: 1 = river
 2 = passable feature
 3 = impassable feature
 4 = urban area
 5 = chemically contaminated
 6 = nuclear contaminated
 7 = biologically contaminated.

1. Line obstacle menu. Menu used for the creation and alteration of individual line obstacles. Allows for data input on each obstacle as to owner, type, delay times, and other essential data items. This menu can only be reached from, and returns to, the main menu. Data created are stored in the file DA_DATA:LINEOBSTACLE#.DAT, where # is the user supplied file number.

- MAIN MENU** Return to main menu. Asks if data have been recorded, because if a different data type is selected, all previous data are deleted. Answer YES/NO. If answer is NO, the previous menu is displayed so that the data may be recorded.
- INPUT/OUTPUT** Draws the input/output menu at the bottom of the screen to read, record, and print data. See paragraph 3r of reference manual.
- GRAPHICS** Draws the graphics menu at the bottom of the screen. This menu is used for loading and manipulating picture files. See paragraph 3q for more information.
- SELECT OBSTL** Select new line obstacle by touching node or line segment with the cursor. Selected line obstacle is highlighted showing all node positions.
- NEW OBSTACLE** Create a new line obstacle. The position of each node of the line obstacle is selected with cursor. To complete the line obstacle, press cursor in the menu area. The nodes of the line obstacle are joined and highlighted.
- COPY OBSTACLE** Copy the selected line obstacle to a new line obstacle at a new location. If no line obstacle has been selected, you are prompted to select a line obstacle to copy. The selected line obstacle is highlighted and shows all node positions. Select a node to copy. This becomes the reference point in placement of the new line obstacle. Select position for node. A line obstacle is drawn in the new location and highlighted. CAUTION: The copy function does not turn off until another menu selection is made. Subsequent pressing of the cursor in the map area produces more copies. To terminate, select from menu area.
- MOVE OBSTACLE** Move line obstacle to new location. If no line obstacle has been selected, you are prompted to select line obstacle. The line obstacle becomes highlighted and shows all node positions. Select node to reposition. This node is the cursor reference point. Select new position for node. The line obstacle is redrawn and highlighted at the new location while the old entity is erased. The line obstacle can be moved until another menu selection is made.

EDIT LINE OB Draw the edit menu at the bottom of the screen for use in modifying the nodes within individual line obstacles. See paragraph 3n for more information.

DELETE OBSTL Select line obstacle to be deleted. Deletes data on selected line obstacle and removes it from the screen. The line obstacle is deleted from local memory only. The file in DA DATA: remains intact until deleted or overwritten. Further line obstacles may be deleted by selecting with the cursor. CAUTION: This function is still active until it is deselected by making another menu selection.

FEATURE # Using the cursor, enter new identification number for the selected line obstacle from the submenu drawn at the bottom of the screen. A number identifying the line feature of this obstacle forms a part. A line feature may be composed of several obstacles, each one having a unique prototype along its length.

PROTOTYPE Line obstacle prototype name. Using the cursor, enter up to 12 alphanumeric characters.

ENG MISSION Engineer mission number. Zero indicates that the obstacle is active. All obstacles having the same engineer mission number will be constructed serially by the same engineer unit which has been given the mission.

OWNER / SIDE BLUE, RED, or -. (- means not belonging to either side). The side owning the obstacle will suffer a delay equal to the breached time.

BREACH TYPE Type of feature for breaching purposed.
 1 - bridgeable
 2 - breachable

DLAY UB BLUE The delay (in hours) suffered by a blue unit upon encountering this obstacle, given that it has not been breached.

DLAY UB RED The delay (in hours) suffered by a red unit upon encountering this obstacle, given that it has not been breached.

DLAY B BLUE The delay (in hours) suffered by a blue unit upon encountering this obstacle, given that it has been breached.

DLAY B RED The delay (in hours) suffered by a red unit upon encountering this obstacle, given that it has been breached.

SELECT NODES Select nodes to define the segments which are to be breached.

BREACHED A dashed line is placed between any two adjacent points to signify that that segment has been breached or bridged. A letter B is placed at that location point in the data file to signify a breached section.

m. Network menu. This is the menu for the creation and alteration of network links. Data are stored in DA_DATA:NETWORK#.DAT.

MAIN MENU Return to main menu. Asks if data have been recorded, because if a different data type is selected, all previous data are deleted. Answer YES/NO. If answer is NO, the previous menu is displayed so that the data may be recorded.

LOGISTIC MENU Transfers from network menu for logistics data. Data input in logistic menu goes to the same file as the network data.

INPUT/OUTPUT Draws the input/output menu at the bottom of the screen to read, record, and print data.
See paragraph 3r for more information.

GRAPHICS Draws the graphics menu at the bottom of the screen for loading and manipulating picture files.
See paragraph 3q for more information.

RENUMBER ALL Renumber the whole road network in order of increasing X-- meaning that the nodes are renumbered from west to east regardless of which link its in. All links and alternate nodes are renumbered. Enter the identification number of the first node. Nodes are redrawn with the new numbers.

RENUMBER Renumber a selected part of the network in order of increasing X. All links and alternate nodes are also renumbered. Select all nodes which are to be renumbered. Enter the identification number of the first node. Nodes are redrawn with the new numbers.

SET SYMBOL Select new symbol for all subsequent symbols drawn. If a node has been selected, its symbol will be changed. The symbols of all nodes remain unchanged.

NODE COLOUR Select new drawing color for nodes from menu. If a node has been selected, its color will be changed. The color of all other nodes remain unchanged.

LINK COLOUR Select new drawing color for links from menu. The color of all links remain unchanged.

ROAD DIST	Calculate the distance along the roads between nodes. Select the two nodes which define the link. If the road types have not been selected, select road types. Select the first and last nodes if the nodes are not on road junctions. If there is more than one option for the path at any point, select from the nodes displayed.
NODE #	Enter new identification number for the selected node.
NEW NODE	Create a new node. The position of each new node of the network is selected with the cursor. When no further nodes are required, press cursor in the menu area.
SELECT NODE	Select new node by touching node with the cursor. Selected node is highlighted.
MOVE NODE	Move node to new location. If no node has been selected, select node. Select new position for node. Recalculate distances to linked nodes. Redraw and highlight node and links at new location. The node can be moved until the cursor is returned to the menu area.
DELETE NODE	Select node to be deleted. Destroy data on selected node and remove from the screen. All links from other nodes to this node are removed. Further nodes may be deleted by selecting with the cursor.
SHOW LINKS	Highlight all the links for the currently selected node. If not selected, select node and highlight.
REMOVE LINK	Remove link between two nodes. If not selected, select node and highlight. Select node to which link is to be removed. Link is deleted from screen.
INSERT LINK	Insert link between two nodes. If not selected, select node and highlight. Select node to link. Link is drawn between the two nodes.
CREATE NET	Start by selecting an existing node or by pressing cursor at position of new node. Select subsequent nodes by pressing cursor at desired location. Each node is linked to the previous one. Nodes are given the next available identification number following that of the first node. Complete the net by pressing the cursor in the menu area. If the symbol menu has been drawn, it may be accessed and the symbol changed during CREATE NET.

n. Logistic menu. Assign logistic data to network. Data is stored in the file NETWORK#.DAT.

NETWORK MENU Returns to network menu.

INPUT/OUTPUT Draws input/output menu to read, record, and print data.

GRAPHICS Draws the graphics menu.

SELECT NODE Select new node by touching node with the cursor. Selected node is highlighted.

SELECT LINK Select connecting node for data input. Selected link is highlighted.

TYPE NODE Describes the initial status of the node:
BS = Blue supply area occupied by blue
RS = Red supply area occupied by red
B = Controlled by blue
R = Controlled by red
U = Unusable node

SUPPLY SRVCE Supply service performed:
S = Supply only to forward supply units and designated maneuver units
SR = Supply to forward supply units and designated maneuver units and receive supplies from the designated supply sources
R = Supplies designated maneuver units/receives supplies from designated supply sources.
Describes the type of service that is performed from this node if its type designation is "BS" or "RS".

ASSOC UNIT A name corresponding to a unit defined in the global ground module. This unit will be associated with the forward supply area in order that the supply area can be a target for indirect fire attack.

ALT NODE Node numbers of the backup supply points, input in order from rear area to forward area. Select nodes with cursor.

ADD ALT NODE Add alternate node by entering the number of the alternate node.

ROAD SURFACE Code for the road surface between nodes:
1 = Concrete 3 = Gravel
2 = Bituminous 4 = Dirt

ROAD WIDTH Code for the road width between nodes:
1 = roadway \geq 24 feet wide
2 = roadway $<$ 24 feet wide

ROAD TERRAIN Code for the predominate terrain characteristics between nodes:
1 = flat 3 = hills with curves
2 = rolling hills 4 = mountainous

o. Edit menu. This menu allows the editing of line segments and polygons. Upon selecting any of the editing options (i.e., EDIT LINE OB, EDIT BARRIER, etc.), this submenu will be drawn at the bottom of the screen. Using the cursor, select one of the four options. You can continue in edit mode as long as required. Select from the data menu when completed; the submenu will remain displayed until another submenu is drawn. NOTE: Once changes are made, the new entities exist only in the local memory and must be recorded to become part of the file residing in DA_DATA: See reference manual paragraph 3r on input/output.

CHANGE NODE Change the location of a node within a line segment. If no entity is selected, select entity (line segment or polygon) and it will become highlighted and show all node positions for that entity. Select node to be changed. Select new position for node and the new entity will be drawn, erasing the old entity. Other nodes may be changed until next menu item is selected.

REMOVE NODE Remove a node from the line segment. If no entity is selected, select entity and it will become highlighted and show all node positions for that entity. Select node to be removed and the new entity will be drawn, erasing the old entity. Other nodes may be removed until next menu item is selected.

INSERT NODE Insert a node in the middle of a line segment. If no entity is selected, select entity and it will become highlighted and show all node positions for that entity. Select nodes which are before and after the new node. Select the position for the new node and the new entity will be drawn erasing the old entity. Other nodes may be inserted until the next menu item is selected.

ADD NODE Add a node to either end of the line segment. If no entity is selected, select entity and it will become highlighted and show all node positions for that entity. Select the node at the end of path to add node. Select new node and the new entity will be drawn. Other nodes may be added until next menu item is selected.

p. Parameters. This command, which can only be entered from the MAIN MENU, allows the user to toggle on or off the following items:

DRAW NAMES	Switched on	- draws the names or identification numbers by each entity.
MOVE MENUS		Moves the menus to the other side of the screen.
PRINT UTM	Switched off	- the data files are printed in military coordinates.
	Switched on	- the data files are printed in UTM coordinates.
AUTO UNIT	Switched on	- the units are automatically drawn when a menu of another type is selected.
AUTO MINEFLD	Switched on	- the minefields are automatically drawn when a menu of another type is selected.
AUTO BARRIER	Switched on	- the barriers are automatically drawn when a menu of another type is selected.
AUTO LINE OB	Switched on	- the line obstacles are automatically drawn when a menu of another type is selected.

The usefulness of this menu can not be overemphasized. Though these parameters are options, this is the only way to display a data file while in a menu of a different type.

The PRINT UTM toggle is a requirement for producing VIC files. If this is not selected, the data contained within the files will be printed to the OUTPUT: directory in military coordinates. This is unsuitable for VIC input.

q. Graphics menu. The command GRAPHICS can be entered from nearly every menu. Upon the selection of this command, a submenu will be drawn at the bottom of the screen. The functions of this menu allow the input of a picture file to the screen. Until a picture has been loaded, you cannot view on the screen some of the data files you may have created due to the fact that you have no point of reference. The additional functions of this menu allow for the manipulation of this picture or the data displayed. The SET COLOUR, CLEAR FOREGD, and CLEAR BACKGD functions do not affect the picture in any way. These functions are for clearing and changing the drawing color in the upper planes, where the data are displayed.

Their functions are as follows:

- | | |
|--------------|--|
| LOADPIC | Loads and draws a map which has been saved as a picture file. Prompts for the name of the picture file. If the picture file does not exist, a default picture will be loaded. Entering the file name ALLPIC will display all the area in which data on vegetation and roads exist. |
| ZOOM | Redraws the picture on a different scale. The zoom factor is an integer between 2 and 16. Enter the scale factor and position the cursor at the new map center. |
| DRAWGRID | Draws the grid to the screen according to the size defined for the grid by using either SETCOORD or MAPSIZE (see reference manual paragraph 3b). If no grid has been defined, the default grid is drawn. |
| SET COLOUR | Select new drawing color for all new entities from the color bars drawn at the bottom of the screen. If an entity has been selected, its color will be changed when that entity is deselected or no longer highlighted. The color of all other entities created before this time remain unchanged. |
| CLEAR FOREGD | Clear foreground (top plane) is the plane in which the data menus display data. Data are not destroyed; only the display is cleared. |
| CLEAR BACKGD | Clear background (middle plane). |

r. Input/output. The menu is drawn at the bottom of the screen when this selection is made. It is used to read, record, and print data.

- SET FILE NO** Changes the direct access file number for subsequent read and record. Data are stored in files called DATANAME#.DAT. At # enter the file number for direct access input/output.
- READ DATA** Reads data from direct access file. Data are stored in files called DATANAME#.DAT. If the file number has not been set, at #, enter the number of the direct access file. Records may be referenced by the entity identification number or by characters in the entity name. It prompts for the characters to search for (enter * for any character). If no characters are input, then it prompts for the identification number of the first and last entity to be read. All entities read in are drawn on the screen. Existing entities with the same identification numbers are overwritten.
- READ VIC FILE** Read from a sequential VIC data file in OUTPUT: DATANAME#.OUT and record data in a direct access file DA DATA:DATANAME#.DAT. Enter VIC file name -.OUT Are coords in military coords? Answer YES/NO. If reading UTM, enter coords of the VIC origin.
- RECORD DATA** Writes data to direct access file. Data are stored in files called DATANAME#.DAT. If the file number has not been set, enter #, the number of the direct access file. Records may be referenced by the entity identification number, or by characters in the entity name. It prompts for the characters to search for (enter * for any character). If no characters are input, it prompts for the identification number of the first and last entity to be recorded. Data on entities which have been recorded are deleted and the entities are removed from the screen.
- PRINT DATAMC** Prints data on all entities. Entities are listed in the order in which they are read in. Therefore, if blue units are required before red units, all blue units should be read in first. Coordinates are printed in military coordinates or UTM coords depending on whether the parameter PRINT UTM is switched on or off. Input the output file number: Enter 0 to display data on CRT # (file number) to produce a VIC file DATANAME#.OUT. If printing in UTM, enter the X,Y map coords of the VIC origin to produce X,Y coords for VIC input.
- LIST FILES** Lists all direct access files from DA DATA: on the CRT, which are associated with the selected data type.

APPENDIX A
MENU REPRESENTATIONS

CONTENTS

	PAGE

1. Data menus	A-3
a. Main menu	A-3
b. Unit menu	A-4
c. Path point menu	A-5
d. Tactical menu	A-6
e. Subordinate menu	A-7
f. Communications menu	A-8
g. Route plan menu	A-9
h. Minefield menu	A-10
i. Barrier menu	A-11
j. Line obstacle menu	A-12
k. Network menu	A-13
l. Logistics menu	A-14
2. Submenus	A-15
a. Utility menu	A-15
b. Graphic menu	A-16
c. Terrain menu	A-17

	PAGE
d. Menu menu	A-18
e. Define menu	A-19
f. Slide menu	A-20
g. Alphanumeric menu	A-21
h. Route plan data posture menu	A-22
i. Input/output menu	A-23
j. Graphics menu	A-23
k. Point type menu	A-24
l. Area type menu	A-24
m. Wait type menu	A-25
n. Numeric menu	A-25
o. Road menu	A-26
p. Route plan data menu	A-26
q. Edit menu	A-27
r. Parameters menu	A-27

KEYWORD

HELP

END

UNIT ID GEN

UNIT MENU

SUBORD MENU

COMMS MENU

RT PLAN MENU

MINEFLD MENU

BARRIER MENU

LINE OB MENU

NETWORK MENU

GRAPHICS

PARAMETERS

UTILITY MENU

CHANGE PLANE

PLAYBACK

YES

NO

MAIN MENU

MAIN MENU

PATH PT MENU

INPUT/OUTPUT

GRAPHICS

SELECT UNIT

NEW UNIT

COPY UNIT

DEPLOY UNIT

MIL COORD

UNIT ID

SET SYMBOL

RADIUS

DELETE UNIT

INIT MASS

PROTOTYPE

UNIT RADIUS

UNIT DELTA

ORIENTATION

UNIT MENU

UNIT MENU

TACT MENU

RT PLAN MENU

INPUT/OUTPUT

GRAPHICS

SELECT UNIT

CREATE PATH

COPY PATH

EDIT PATH

DELETE PATH

SELECT NODES

POINT TYPE

PREPRD STATE

ENG REQUIRED

AREA TYPE

WAIT TYPE

WAIT TIME

PATH POINT MENU

PATH PT MENU

GRAPHICS

SELECT UNIT

DISPLAY TAC

CLEAR TAC

NEW TAC

COPY TAC

COPY UNT TAC

REMOVE P PT

MOVE

SHOW ALL TAC

EDIT TAC

TAC DEFAULT

PRINT DATAMC

PRINT TACS

READ VIC FIL

TACTICAL MENU

MAIN MENU

INPUT/OUTPUT

GRAPHICS

SELECT UNIT

SUBORDINATES

PHASE GROUP

LEADING ECH

COORD GROUP

SUBORDINATE MENU

MAIN MENU

INPUT/OUTPUT

GRAPHICS

SELECT UNIT

NEXT NET

NEW NET

ADD/DEL MEMB

NET TYPE

SYSTEM NAME

DEL SYSTEM

LINKS / NODE

TYPE DATA

ANT POLAR

TIME SWITCH

TRANSM GAIN

RECEIVER GAIN

TRANSM HT

RECEIVER HT

TRANSM POWER

TRANSM FREQ

COMMUNICATIONS MENU

MAIN MENU

PATH PT MENU

INPUT/OUTPUT

GRAPHICS

X-COUNTRY

ROAD TRAVEL

SELECT ROADS

SELECT UNIT

SELECT NODE

NEXT NODE

RETURN TR

NEAREST NODE

UPDATE TIMES

POSITION/TIM

COPY PATH

EDIT PATH

RT PLAN DATA

NEW UNIT

DEPLOY UNIT

CREATE PATH

ROUTE PLAN MENU

MAIN MENU
INPUT/OUTPUT
GRAPHICS
SELECT MNFLD
NEW MINEFLD
COPY MINEFLD
MOVE MINEFLD
DELETE MNFLD
DENSITY FACT
ENG MISSION
MINEFLD #
MINETYPE NAM
FRONTAGE
DEPTH
ORIENTATION
NO OF MINES
START TIME

MINEFIELD MENU

MAIN MENU
INPUT/OUTPUT
GRAPHICS
SELECT BAR
NEW BARRIER
COPY BARRIER
MOVE BARRIER
EDIT BARRIER
DELETE BAR
BARRIER #
VISIBILITY
TRAFFICABLTY
BARRIER TYPE

BARRIER MENU

MAIN MENU

INPUT/OUTPUT

GRAPHICS

SELECT OBSTL

NEW OBSTACLE

COPY OBSTCLE

MOVE OBSTCLE

EDIT LINE OB

DELETE OBSTL

FEATURE #

PROTOTYPE

ENG MISSION

OWNER / SIDE

BREACH TYPE

DLAY UB BLUE

DLAY UB RED

DLAY B BLUE

DLAY B RED

SELECT NODES

BREACHED

LINE OBSTACLE MENU

MAIN MENU

LOGISTIC MENU

INPUT/OUTPUT

GRAPHICS

RENUMBER ALL

RENUMBER

SET SYMBOL

NODE COLOUR

LINK COLOUR

SELECT ROADS

ROAD DIST

NODE #

NEW NODE

SELECT NODE

MOVE NODE

DELETE NODE

SHOW LINKS

REMOVE LINK

INSERT LINK

CREATE NET

NETWORK MENU

NETWORK MENU

INPUT/OUTPUT

GRAPHICS

SELECT NODE

SELECT LINK

TYPE NODE

SUPPLY SRVCE

ASSOC UNIT

ADD ALT NODE

ALT NODE

ROAD SURFACE

ROAD WIDTH

ROAD TERRAIN

LOGISTICS MENU

MAIN MENU

GRAPHIC MENU

TERRAIN MENU

MENU MENU

DEFINE MENU

SLIDE MENU

UTILITY MENU

UTILITY MENU

ERASE

ERASE1

ERASE2

ERASE3

SELERASE

REC TMAP

SAVEPIC

LOADPIC

SETCOLORS

SAVECOLORS

LOADCOLORS

HZOOM

ZOOM

UTILITY MENU/GRAPHIC MENU

UTILITY MENU

SETCOORD

MAPSIZE

SETFEATURE

DRAWGRID

DRAWBORDER

DRAWROADS

DRAWVEG

FASTVEG

WHEREMC

MCPOINT

MCLINE

UTMLINE

MC2UTM

ZONECHANGE

SELMAPS

MAPNAME

SPDRAWROADS

SPDRAWVEG

SPFASTVEG

UTILITY MENU/TERRAIN MENU

UTILITY MENU

SELCOLOR

SELPLANE

SELTEXTSIZE

SELTEXTDIR

LINEDRAW

TEXTDRAW

RECTDRAW

REMOVE

MOVEPIC

EMOVEPIC

ESMOVEPIC

CURLOADPIC

UTILITY MENU/SLIDE MENU

A	B
C	D
E	F
G	H
I	J
K	L
M	N
O	P
Q	R
S	T
U	V
W	X
Y	Z
1	2
3	4
5	6
7	8
9	0
+	-
*	.
ENTER	CANCEL

ALPHANUMERIC MENU

MARCH
MOVE-CONTACT
ATTACK
DELAY
HELI-BORNE
TAC-MARCH
ASSEM-AREA
TAC-A-AREA
IN COLUMN
TMP-POSITION
HASTY-DEF
DELIB-DEF
FIRING-POSTN
DESTROYED
AIR-PICK-UP
AIR-LANDING

POSTURE MENU

SET FILE NO

READ DATA

RECORD DATA

READ VIC FIL

PRINT DATAMC

LIST FILES

INPUT/OUTPUT MENU

LOADPIC

ZOOM

DRAWGRID

SET COLOUR

CLEAR FOREGD

CLEAR BACKGD

GRAPHICS MENU

IMED	DEF
DLAY	RESV
APZ	ALZ
HBAS	HATK
EBAS	

POINT TYPE MENU

CFA	MBA
RESV	1ECH
2ECH	REAR

AREA TYPE MENU

SYNC	DLTA
STAT	RGRP
RMOV	RORG

WAIT TYPE MENU

1	2
3	4
5	6
7	8
9	0
.	-
ENTER	CANCEL

NUMERIC MENU

AUTOBAHN
MAIN ROAD
SECONDARY RD
F WEATHER RD
RAILWAY
ENTER

ROAD MENU

ARRIVE TIME
DEPART TIME
END TIME
POSTURE
COL LEN NODE
COL DIA NODE
COL LEN PATH
COL DIA PATH
ALTITUDE

ROUTE PLAN DATA MENU

CHANGE NODE

REMOVE NODE

INSERT NODE

ADD NODE

EDIT MENU

DRAW NAMES

MOVE MENUS

PRINT UTM

AUTO UNIT

AUTO MINEFLD

AUTO BARRIER

AUTO LINE OB

PARAMETERS MENU

APPENDIX B
VIP OUTPUT FORMAT

CONTENTS

	PAGE
1. Format	B-2
a. Barrier file	B-2
b. Line obstacle file	B-2
c. Minefield file	B-3
d. Network file	B-3
e. Logistics file	B-3
f. Tactical area file	B-4
g. Unit file	B-4
h. Unit subordinate file	B-4
i. Communications file	B-5
2. VIP output processing	B-5
a. General	B-5
b. Tactical	B-5
c. Route planning	B-5
d. Network/logistics	B-6
e. Additional	B-6

1. Output format. The following is the header information on each of the files contained in OUTPUT:. All coordinate data must be written in x,y coordinates and not in military coordinates as VIC does not contain a translator for these computations. Also, the NETWORK#.OUT file displays node-to-node distance and the VIC software only works in node-to-node times. The necessary time calculation is performed within VIP and is displayed with the logistic data file.

a. Barrier file. From the file OUTPUT:BARRIER#.OUT

```

''
''          AREA OBSTACLE DATA

0  '' NUMBER OF BARRIERS

''BARRIER VISIBILITY TRAFFICABILITY BARRIER NO OF          COORDS
'' NO                   TYPE           POINTS

```

b. Line obstacle file. From the file OUTPUT:LINEOBSTACLE#.OUT

```

''
''          LINE OBSTACLE DATA

0  '' NUMBER OF OBSTACLE PROTOTYPES
0  '' NUMBER OF LINE OBSTACLES
0  '' NUMBER OF LINE SEGMENTS

''
''  PROTOTYPE  BREACH  UNREACHED  BREACHED
''  NAME       TYPE    BLUE  RED    BLUE  RED

''
''  FEATURE  OBSTACLE  ENGINEER  OWNER NUMBER
''  NUMBER   PROTOTYPE MISSION   SIDE POINTS

```


f. Tactical area file. From the file OUTPUT:TACTAREA#.OUT

'' TACTICAL AREA DATA

0 '' MAXIMUM TACTICAL AREA NUMBER

''NR # VERTICES X-COORD Y-COORD

g. Unit file. From the file OUTPUT:UNIT#.OUT

'' UNIT LOCATION AND PATH POINT DATA

0 '' NUMBER OF PROTOTYPES

0 '' NUMBER OF UNITS

''NR NAME	ENTRY DD:HH:MM	INIT MASS	PROTO TYPE	UNIT ORIEN	# PATH POINTS	POINT TYPE
	PREP POS	AREA TYPE	LOCATION X Y	WAIT TYPE	WAIT TIME DD :HH :MM	TAC AREA

h. Unit subordinate file. From the file OUTPUT:UNIT#.OUT

'' SUBORDINATE STRUCTURE DATA

0 '' NUMBER OF PHASE AND COORDINATION GROUPS

'' UNIT NAME #SUB PHASE GP LEADING ECH COORD GROUP

f. Communications file. From the file OUTPUT:UNIT#.OUT

0 '' NUMBER OF COMMUNICATIONS NETS

```
''
''
'' NET OWNER NET TYPE NUMBER SYSTEMS AVERAGE #
'' SYSTEMS CHANNELS TYPE POLAR
'' ON NET ON NET NODE/NET NET IZATION

TIME ANTENNA
SWITCH GAIN HEIGHT
SYSTEM TRAN REC TRAN REC TRANSMITTER
POWER FREQ

'' COMMUNICATIONS NETS
```

2. VIP output processing. Due to the fact that VIP uses the same array space when working on each of the data menus, the procedure to turn VIP data files into VIC readable files is discussed separately at this time.

a. General. The unit data files created by VIP are turned into VIC readable files by the following procedures:

(1) Entering the INPUT/OUTPUT command from either the unit menu or the path point menu.

(2) Select "PRINT DATAMC". You are prompted for a file number. The file UNIT#.OUT is in OUTPUT: awaiting processing into VIC. The same procedure is used for the following menu data files:

- (a) Subordinate menu. Creates the file OUTPUT:UNIT#.SUB
- (b) Minefield menu. Creates the file OUTPUT:MINEFIELD#.OUT
- (c) Barrier menu. Creates the file OUTPUT:BARRIER#.OUT
- (d) Line Obstacle menu. Creates the file OUTPUT:LINEOBSTACLE#.OUT

b. Tactical. This menu has no INPUT/OUTPUT selection. The file is created, opened, and closed when you enter and exit the tactical menu. To create an .OUT file, select the "PRINT DATAMC" area and enter a file number.

c. Route planning. If a route planning .OUT file is required, the following safeguards must be implemented to avoid data loss. Input/Output is still the same but it also creates a file OUTPUT:UNIT#.OUT. To avoid overwriting of the unit file, you must choose a different file number. This same provision also applies to the DA_DATA: directory when dealing with the route planning menu.

d. Network/logistics. Though the logistics menu uses the network menu data file, the output generated by these two menus are completely different. Extreme care must be taken in assigning DIFFERENT file numbers to each. Failure to do so will result in the overwriting of the previous data file.

e. Additional information. VIC cannot accept input in military coordinates though VIP can produce them. Watch the use of parameter toggle "PRINT UTM" in the main menu. Reading a VIC file back to the DA DATA: directory could create a problem if the file already exists. The file from OUTPUT: does not simply overwrite the file in DA DATA:, it "ands" the two files together with only duplicate entries being overwritten. Files (.OUT) must be run through a separate preprocessor to reduce them down to data--essentially stripping the header information off the files.

APPENDIX C
PROGRAM STRUCTURE REFERENCE

CONTENTS

	PAGE
1. General	C-2
2. Logical assignments	C-2
3. Program linking	C-3
4. VIP modules	C-4

1. General. VIP is an interactive system to facilitate the building of input files. The preprocessor is menu driven. There is a menu containing a list of keywords for each data type. Additional keywords may be input from the CRT. Files may be built for the following data:

- a. Unit locations and path points
- b. Unit subordinate structure
- c. Tactical areas
- d. Minefields
- e. Barriers (area obstacles)
- f. Line obstacles
- g. Logistics networks

The following documentation is set up for a system 11/780 with a file hierarchy that was set up by the programmer team doing the work at this time. The assigned logicals and call files are not set in stone but it is recommended that unless outside considerations override, these remain the way they are because they are time tested and proven to be accurate.

2. Logical assignments. Before the VIP package can be executed, a series of files have to be set up, assigned, or modified so the host system can initialize correctly. These statements are in a command file labeled OASG.COM. This file can be executed alone or in conjunction with the OLINK.COM or the ORUN.COM discussed in the next section.

The OASG.COM file appears as follows:

```
$ ASSIGN DATASDUA2:[VIP.KELLNER] OKGL           ! KELLNER GRAPHICS SOFTWARE
$ ASSIGN DBAO:[GRAPHICS.RAMTEK.CGIP] ORGL       ! RAMTEK GRAPHICS SOFTWARE

$ ASSIGN DATASDUA2:[VIP.DA DATA] DA DATA     ! READ/WRITE VIP RA FILES
$ ASSIGN DATASDUA2:[VIP.OUTPUT] OUTPUT        ! THE .OUT FILES FROM VIP
$ ASSIGN DATASDUA2:[VIP.ROUTE] ROUTEFILE      ! THE .ROT FILES FROM VIP
$ ASSIGN DATASDUA2:[VIP.SYMBOLS] SYMBOLS      ! THE SYMBOL FILE
$ ASSIGN DATASDUA2:[VIP.ROADS] ROADS          ! LINDA'S ROUTE PLANNING
                                                ! INPUT FILES
$ ASSIGN DATASDUA2:[VIP.MAPS] MAPFILE         ! MAP FILES .VEG,.NVG,.MAP
$ ASSIGN DATASDUA2:[VIP.PIC] PICFILE         ! PICTURE FILES
$ ASSIGN DATASDUA2:[VIP.COLOR] COLFILE       ! COLOR FILES .KOL (13BIT)
$ ASSIGN DATASDUA2:[VIP.MEN] MENFILE         ! THE MENU FILES .MMN,.MEN
$ ASSIGN DATASDUA2:[VIP.DOC] VIPDOC         ! LINDA'S HELP FILES .DOC
$ ASSIGN DATASDUA2:[VIP.COMMON] VIPCMN       ! THE COMMONS .CMN,.PAR,.FMT
                                                ! .CDA FILES
```

3. Program linking. The OLINK.COM file takes all the related object code files and creates the executable code file necessary for VIP to run. This allows the user to modify portions of the program and implement them without destroying the integrity of the software for another user. As stated above, the OASG.COM file can be part of the OLINK.COM file as follows.

Listing of the OLINK.COM:

```

$ @[VIP.CODE]OASG                ! PICK UP VIP LOGICALS
$ SET DEF DATA$DUA2:[VIP.CHENAULT] ! GO TO YOUR LOCAL DIRECTORY
$ !!!!
$ LIB/EXTR=*/OUTP=FLVN.OBJ [VIP.FLVN]A ! FLVN VIP CHANGES
$ LIB/EXTR=*/OUTP=MIKES.OBJ A      ! INDIVIDUALS VIP CHANGES
$ !!!!
$ LINK [VIP.CHENAULT]ADRIVE_VIP,- ! LINK MAIN DRIVER
FLVN.OBJ,MIKES.OBJ,-              ! WITH ANY CHANGED ROUTINES
$ !!!!
[VIP.CODE]A/LIB,-                 ! AND ALL UNCHANGED CODE
$ !!!!
OKGL:CGF/OPT                       ! TO PROPER GRAPHIC PACKAGE
$ EXIT

```

As stated before, any modifications in execution (in this case, any FLVN modifications existing in [VIP.FLVN] are picked up and linked before getting the rest of the code (FLVN/MSMR approved) from the object library in [VIP.CODE]. This link creates the VIP executable file ADRIVE_VIP.EXE. This can now be run directly or as part of a ORUN.COM file. If it is run directly, the proper assign statements must be done first. These statements are part of the ORUN.COM file but do change from system to system. See VIP support for further information.

The format of the "ORUN.COM" is as follows:

```

$ SET MESSAGE/NOFAC/NOIDENT/NOTEXT/NOSEV ! SO SUPERCEDE MSGS DONT APPEAR
$ @[VIP.CODE]OASG                          ! PICK UP VIP LOGICALS
$ SET MESSAGE/FAC/IDENT/TEXT/SEV
$ RUN [VIP.CHENAULT]ADRIVE_VIP              ! EXECUTE LO RES VIP
$ EXIT

```

As with the OLINK file, the OASG.COM is included in the ORUN.COM file. This eliminates the necessity of doing a OASG or a OLINK each terminal session, provided you use the same executable file.

4. VIP modules. The VIP software package is broken down into several different modules. These modules being:

a. ADRIVE VIP Main driver. Driven by variable KEY (12-character text variable) which is input from the menu or the CRT depending on whether the variable SELECT = MENU or KEYWORD.

b. ADRIVE KEYWORDS Determine the action resulting from the selection of KEY. Each menu has a subroutine associated with it which lists its keywords. Keywords input from the CRT are dealt with in ADRIVE_KEYWORDS_CRT and in MDRIVE.

c. ENTITY General routines which deal with operations on all types of entities. An entity may be:

- (1) Tactical area
- (2) Unit initial location + path points
- (3) Minefield
- (4) Barrier
- (5) Line obstacle

d. IO Input/output routines for direct access files, sequential files, and for printing information to the CRT or the RAMTEK.

e. NET Network routines for logistics.

f. ROAD_NET Accesses the link node data base for road networks.

g. ROAD_PATH Use the link node data base to construct paths along the roads.

h. SUBMENU Draw and select from the submenus.

i. TAC Tactical area routines.

j. UNIT_ROUTE Constructs detailed paths between VIC path points.

k. UNIT_SUBORD Constructs the unit subordinate structure.

l. UTLY Utility routines.

END

11-87

DTIC