

UNCLASSIFIED

AD

402 465

*Reproduced
by the*

DEFENSE DOCUMENTATION CENTER

FOR

SCIENTIFIC AND TECHNICAL INFORMATION

CAMERON STATION, ALEXANDRIA, VIRGINIA



UNCLASSIFIED

NOTICE: When government or other drawings, specifications or other data are used for any purpose other than in connection with a definitely related government procurement operation, the U. S. Government thereby incurs no responsibility, nor any obligation whatsoever; and the fact that the Government may have formulated, furnished, or in any way supplied the said drawings, specifications, or other data is not to be regarded by implication or otherwise as in any manner licensing the holder or any other person or corporation, or conveying any rights or permission to manufacture, use or sell any patented invention that may in any way be related thereto.

FTD-TT- 63-12

6332

TRANSLATION

MEASURING THE PARAMETERS OF ANTENNA-FEEDER
DEVICES (SELECTED PARTS)

By


A. Z. Fradin and Ye. V. Ryzhkov

FOREIGN TECHNOLOGY DIVISION

AIR FORCE SYSTEMS COMMAND

WRIGHT-PATTERSON AIR FORCE BASE

OHIO



402465

CATALOGUED BY ASTIA
AS AD No.

402465



**Best
Available
Copy**

UNEDITED ROUGH DRAFT TRANSLATION

MEASURING THE PARAMETERS OF ANTENNA-FEEDER
DEVICES (SELECTED PARTS)

BY: A. Z. Fradin and Ye. V. Ryzhkov

English Pages: 13

SOURCE: Russian Book, Izmereniye Parametrov
Antenno-Fidernykh Ustroystv, Moskva,
1962, pp 266-272, 314-316

THIS TRANSLATION IS A RENDITION OF THE ORIGINAL FOREIGN TEXT WITHOUT ANY ANALYTICAL OR EDITORIAL COMMENT. STATEMENTS OR THEORIES ADVOCATED OR IMPLIED ARE THOSE OF THE SOURCE AND DO NOT NECESSARILY REFLECT THE POSITION OR OPINION OF THE FOREIGN TECHNOLOGY DIVISION.

PREPARED BY:

TRANSLATION SERVICES BRANCH
FOREIGN TECHNOLOGY DIVISION
WP-AFB, OHIO.

Table of Contents

	Pages
Plotting the Diagram of the Directivity of Antennas with the Aid of Airplanes and Helicopters.....	1
Table of Contents (of the Foreign Document).....	8

Plotting the Diagram of the Directivity of
Antennas with the Aid of Airplanes
and Helicopters

General Information

The plotting of diagrams of the directivity of stationary antennas with ranges of short and ultrashort waves, as was shown above, is done mainly from airplanes and helicopters¹. This makes it possible to take measurements in any plane, obtain data for the making of cartographic diagrams of the directivity, and besides it makes it possible to record automatically the directivity diagram, which excludes individual errors of observation and assures complete objectivity and documentation of the results. The first automatic recording of a diagram of directivity with the aid of an airplane was done in 1934 by V. V. Tatarinov [12].

The equipment for plotting diagrams of directivity from airplanes should consist of a transmitting device, an auxiliary antenna, and instruments for tracking a flying apparatus.

There are two variants possible in the arrangement of the apparatus--directly on the aircraft or on a craft in tow.

¹The plotting of a directivity diagram is best done from a helicopter, since in the first place from an airplane it is difficult to correlate the notation of the indices of the instruments with its position, and in the second place the measurements from an aircraft have to be done over great distances, and for antennas with raised main lobe, besides at great altitude, which requires a complicated system of radar observation.

Transmitting Device

For plotting the directivity of antennas of active transmitting radio centers it is expedient to use the investigated antenna as a transmitting antenna, and as a generator, an operating transmitter in the role of carrier.

For investigating antennas of receiving radio centers or transmitting radio centers under construction it is necessary to have special measuring generators which one can place both on the flying craft and the craft in tow. In the first case as a measuring generator one can use the GSS, but generally the GSS use current of a frequency of 50 cps, and the airborne circuit has a higher frequency. Therefore one has to use a frequency converter or storage batteries and change DC into AC.

Generators set up on towed craft should have little weight and be compact and hermetically sealed. It is convenient to supply them with electricity from batteries. The power of the generators is not great--from a fraction of a watt to a watt. They should be designed for a series of fixed frequencies. The setting up for the required frequency is done before the flight. In special generators, airborne and on towed craft, there should be quartz stabilization of the frequency.

It is expedient to use the investigated antenna as a receiving one.

Receiving Device

For plotting the diagram of directivity of antennas of active transmitting radio centers as a receiving apparatus one can use commercial receivers, devices for measuring the intensity of the field, disturbance meters, etc. Automatic volume control should be connected in and the receivers calibrated.

The arrangement of the receiver on the flying craft requires that one assure its stability against disturbance and that it be well buffered.

and this applies also to the recording devices.

The problem of assuring stability against disturbance is made easier through the use of the operating transmitter of the radio center, which as a rule has great power and can create considerable fields at the place of the reception. One can improve the stability against disturbance by shielding off the receiver well blocking it on the power supply circuits.

In using the investigated antenna as a receiving one it is most expedient to use commercial receivers which have high sensitivity, since on a flying craft it is necessary, as was pointed out above, to install low-power generators.

Auxiliary Antennas

On airplanes and helicopters which are devoted specially to antenna measurements the auxiliary antennas can be installed in the best way.

At the present time in using ordinary cruising flying craft one may propose the following variations in the arrangement of the auxiliary antennas.




Fig. 9.10. Disposition of the wire horizontal symmetrical vibratory on the aircraft: a) above its fuselage; b) between the wing and the tail part.

In the case of horizontal polarization of the field of radiation, as auxiliary antennas one uses symmetrical vibrators. In Fig. 9.10 there are shown two variations of the arrangement of a short-wave vibrator made of thin copper wire or antenna stranded wire--above the fuselage of the airplane

and between the wing and the tail part. The arrangement of an analogous antenna on a helicopter is shown in Fig. 9.11. Along with the wire antennas one uses also antennas of copper tubes fastened to a wooden rod (Fig. 9.12).



Fig. 9.11. Arrangement of wire symmetrical horizontal vibrator on a helicopter

Fig. 9.12. Arrangement of antennas of Copper tube on an airplane above the fuselage.





Fig. 9.13. Arrangement of antennas of copper tubes: a) under airplane; b) under helicopter.

removing the antenna, etc. In practice this question is solved in the following fashion. The vibrator is mounted on telephone supports fastened to a wooden beam. The beam is fastened ordinarily with rubber packing materials reaching around the fuselage of the craft (Fig. 9.14). The vibrators preferably are arranged in such a way that their axis coincides with the direction of motion of the flying craft.

Along with the antenna of vertical polarization (Fig. 9.12), one also




Fig. 11

On this same drawing there is shown the arrangement of the antenna intended for vertical polarization.

For arranging the antenna under the fuselage of a flying craft (9.13) it is necessary to set up auxiliary construction: pylons, mechanisms for

uses a flexible stick (Kulikov's antenna).




Fig. 9.14. Fastening of the asymmetrical vibrator to the tail part of a helicopter

Key: (1) feeder; (2) fastening; (3) base; (4) insulators; (5) antenna.

The arrangement of the antenna in the case of locating the measuring apparatus on the towed craft is shown in Fig. 9.15. In this case the antenna finds itself at a considerable distance from the flying craft, and its diagram of directivity is not distorted by it, as in the case of the methods of placing described above. In the case of towed craft one end is fastened to a conical parachute of nylon and the other by a caprone ^{rope to} the flying craft.

The dimensions of the vibrator are selected in accordance with the length of the wave on which the testing is done from the computation $2l \approx \frac{\lambda}{2}$, where l is the length of the arm of the vibrator. If $2l \ll \frac{\lambda}{2}$ then for the increase in the operating height of the vibrator onto its ends there are placed hollow metallic spheres.

In the case of a towed antenna of vertical polarization (Fig. 9.15) there should be suspended on the lower end a weight for giving it a vertical position.




Fig. 9.15. Arrangement of antenna towed by helicopter
Key: (1) caprone cord; (2) caprone cord; (3) parachute; (4) transmitter; (5) antenna; (6) antenna, transmitter, antenna, load.

Instruments for Tracking the Flying Craft

The system of tracking the flying craft and the correlation of the indications of the instruments, which record the intensity of the field with the coordinates of the flying craft present a complicated problem which has not yet received a final solution. Let us consider some of them which are being used in practice.

As instruments which note the coordinate of the flying craft one uses a theodolite set up near the antenna being investigated and serving for determining the azimuthal angle and the angle of the place, and an altimeter of the flying apparatus for determining the altitude of the flight. It is convenient to use these instruments when the antenna being investigated is a receiving antenna. The instrument which shows the intensity at the output of the receiver can be located close to the theodolite, so that there is possible simultaneous recording of the angles, of the setting of the theodolite and the intensity on the output of the receiver. The airplane or helicopter should fly in a circle with the center in the intermediate point of the antenna and at a constant height controlled by the altimeter. Besides, it should remain all the time in the field of vision of the theodolite.

In making measurements from an airplane flying at great speed, and with sharp directivity of the investigated antenna the observations should be made by three operators. One follows the airplane through the telescope of the theodolite holding it constantly on the cross hairs of the or the objective, the second observes the angular scales of the theodolite, and the third is behind the instrument which shows the intensity at the altitude of the receiver or behind the airplane. On a signal from the operator recording the angle the third records the intensity on the instrument or makes marks on the type of the self-recorder.

With a comparatively broad lobe of the directivity pattern of the antenna and not very great speed of flight, two or even one operator can make the observation. In the case of helicopter measurements the recording of the angles and the intensity at moments of brief hovering of the helicopter. the observation can be done by one operator.

If one replaces the theodolite by an automatic radar station with great resolving capacity and synchronizes its working with the work of the automatic recorder, then the plotting of the pattern of directivity can be done automatically.

If the antenna being investigated works on radiation and the receiving apparatus is located on the flying craft, as an instrument for tracking one can also use the theodolite. But since the operator who records the intensity at the output of the receiver finds himself in this case on the flying craft, the connection between the ground and the flying craft should be very good. The measurements are made in the following fashion.

On the route of the flight one notes ground orienting point the angular coordinates of which are known in flying over these orienting points the operator records at the altitude of the receiver. If one uses an automatic recorder then two orienting points are sufficient--the initial one at which the automatic recorder cuts in, and the final one at which it cuts out. The speed of the flight of the airplane during the period of the recording should meanwhile be strictly constant.

In researching transmitting antennas it is also possible to use radar stations which track the flight of the aircraft, in accordance with the signals of which one records the intensity and cuts in or cuts out the automatic recorder. Instead of an automatic recorder one can use a loop oscillograph.

In order for the measurements with the aid of a flying craft to be suc-

cessful they must be carefully prepared, and in this preparation there should be preliminary checking measurements.

Table of Contents

Preface	3
1. <u>Parameters of antenna-feeder devices</u>	
Basic determinations	
Classification of the parameters of antennas	5
Primary experimental parameters of antennas	6
Feeder lines, their parameters and characteristics	8
Rectangular diagram of resistances	12
Polar diagram of resistances	15
Secondary parameters of the first group: frequency characteristic, resonance frequencies, band of emission	19
Graphic portrayal of the directivity pattern	20
Secondary parameters of antennas connected with the directivity pattern: relative level of lateral maxima, width of main lobe, coefficient of directed action	28
Secondary parameters of antennas connected with the amplification factor: efficiency, effective area, active height	31
Investigating antennas on models	36
Brief information on the theory of the reception of radio waves	32
2. <u>Resonance methods of measuring input resistances</u>	
General propositions	39
Method of additional resistance	39
Method of voltmeter and ammeter	43
Method of Q-meter	45
Method of Subjection	49

Antenna and feeder ohmmeters	52
Method of splitting currents	58
Method of automatic measurement of input resistance	61
3. <u>Measurement of the input resistance of antennas by bridge methods</u>	
Introduction	64
Symmetrical bridge for long, medium and short waves	64
Nonsymmetrical bridge	67
Measurement of the coefficient of the traveling wave on the feeder with the aid of a bridge	68
Coaxial and waveguide bridges	69
Notions about the matrix of dispersion	74
Analysis of the working of coaxial and waveguide bridges	76
Two-wire bridges	78
4. Measurement of the input resistance of antennas with the aid of Lecher lines	
Introduction	80
Distribution of voltages and currents on the feeder line	80
Circuit of the measuring line	85
Device of the measuring lines	85
Procedure for determining the input resistance with the aid of measuring lines	104
Unit for automatic recording of the curve of the distribution of intensity	109
Errors in measurements in using measuring lines	111
5. <u>Reflectometers</u>	
Block circuit of the reflectometer	120
Basic characteristics of directional couplers	121

Two-wire directional coupler	122
Coaxial directional couplers	129
Strip directional couplers	137
Waveguide directional couplers	140
6. <u>Mixed methods of determining input resistance</u>	
Introduction	146
Method of three probes	146
Partzer's impedometer	151
Revolving directional coupler	153
T measuring coupler	157
7. <u>Measurement of parameters of feeder lines</u>	
Measuring coefficient of shortening of coaxial cable	163
Measuring wave resistance	165
Measuring feeder attenuation factor	167
Measurement of $\sqrt{\frac{\text{asymmetry}}{i}}$ factor and wave slope on open feeder lines	172
Measurement of $\sqrt{\frac{\text{asymmetry}}{i}}$ of receiver input	177
8. <u>Measurement of intensity of field</u>	
Introduction	182
Direction of arrival of radio waves	184
Measurements of Ratio of Amplitude of Wave	189
Measurement of absolute amplitude of wave	191
Apparatus for measuring absolute amplitude of wave	204
Measurement of wave phase	211
Statistical methods of processing data of measurements of field intensity in the presence of fluctuations (fading)	217

Equipment of automatic processing of data of measurements of intensity of field in the presence of fluctuations	226
Method of current of short circuiting of antenna	232
"Calibrodyne" method of measuring intensity of field	237
Measurement of polarization of field of radio waves	240
9. <u>Plotting pattern of directivity of antennas</u>	
Determination of minimum distance between the investigated and auxiliary antennas	247
Procedure for plotting pattern of directivity	256
Using lens in plotting directivity pattern	258
Investigation of parabolic mirror antennas at reduced distances	260
Device for automatic plotting of directivity patterns	264
Plotting directivity patterns of antennas with the aid of airplanes and helicopters	266
About the use of cosmic sources of radiation for plotting directivity patterns of antennas	272
Plotting directivity pattern of ferrite antennas in a uniform magnetic field	273
10. <u>Measuring the amplification factor of antennas</u>	
Measuring the amplification factor of stationary antennas	276
Measuring the amplification factor of portable antennas by the method of comparison (substitution)	277
Measuring the amplification factor by the method of two identical antennas. Generalization of the method onto two unidentical antennas	280
Measurement of the amplification factor of antennas by the method of a flat screen	282

About the effect of the ground on the the results of the

measurements of the amplification factor of antennas

286

Supplement

287

References

312

DISTRIBUTION LIST

DEPARTMENT OF DEFENSE	Nr. Copies	MAJOR AIR COMMANDS	Nr. Copies
		AFSC	
		SCFDD	1
		ASTIA	25
HEADQUARTERS USAF		TDBTL	5
		TDBDP	7
AFCIN-3D2	1	SSD (SSP)	2
ARL (ARB)	1	APGC (PGF)	1
		ESD (ESY)	1
		RADC (RAY)	1
OTHER AGENCIES		AFSWC (SWP)	1
		AFJTC (MTW)	1
		ASD (ASYIA)	1
CIA	1		
NSA	6		
DIA	9		
AID	2		
OTS	2		
ABC	2		
PWS	1		
NASA	1		
ARMY	3		
NAVY	3		
NAFEC	1		
RAND	1		