



AD A 040796

*2*  
*NW*

**RCA**

**Language Manual For Use With  
Ideographic Composing Machines  
Models AR816 and AR3L**

**Volume VII. Supplemental List of Characters  
Japanese and Korean Pronunciations**

*9 Feb. 1970*

Prepared under  
Contract DAAG17-68-C-0064  
for  
Headquarters, Natick Laboratories  
U.S. Army  
Natick, Massachusetts

DDC  
RECEIVED  
JUN 1 1977  
*John A.*

AD No. \_\_\_\_\_  
DDC FILE COPY

Prepared by  
Advanced Technology Laboratories  
Defense Electronic Products  
Camden, New Jersey

DISTRIBUTION FOR	
DTIC	White Section <input checked="" type="checkbox"/>
NSC	Buff Section <input type="checkbox"/>
CHARACTERIZATION	
Justification <i>Letter on file</i>	
BY	
DISTRIBUTION AVAILABILITY CODES	
Dist.	AVAIL. AND SPECIAL
A	

# RCA

6

## Language Manual For Use With Ideographic Composing Machines Models AR813 and AR3L

Volume VII. Supplemental List of Characters  
Japanese and Korean Pronunciations .

Prepared under  
Contract DAAG17-68-C-0064 ✓  
for 15 ✓  
Headquarters, Natick Laboratories  
U.S. Army  
Natick, Massachusetts

Prepared by ✓  
Advanced Technology Laboratories  
Defense Electronic Products  
Camden, New Jersey

11 9 Feb 70

12 203 P.

405 561

cut

**JAPANESE PRONUNCIATION**

JAPANESE PRONUNCIATION IS A

782	1861	2986	3605	4115	5234	5334	5952	6680	9506
亞	亞	鴉	啞	蛙	痾	痾	窪	丫	阿
9713	10396								
闕	婀								

JAPANESE PRONUNCIATION IS AI

773	1075	2056	2075	2936	3732	4346	5020	7253	8398
埃	藹	霰	靄	挨	曖	曖	哀	穢	愛
9551									
隘									

JAPANESE PRONUNCIATION IS AKU

783	784	1865	2908	3178	4606	6479
堊	惡	惡	握	齧	幄	渥

JAPANESE PRONUNCIATION IS AN

909	953	2733	3692	3699	4481	4531	4854	5165	5997
鞍	菴	按	暗	晏	奄	黯	諳	庵	安
5998	8515	8517	9712						
案	餡	餡	闇						

JAPANESE PRONUNCIATION IS ATSU

JAPANESE PRONUNCIATION IS ATSU

1311 1839 2118 3755  
 幹 軋 庄 遏

JAPANESE PRONUNCIATION IS BA

52 1014 1347 3073 4129 4462 4483 6447  
 馬 墓 芭 馬 蟆 罵 罵 婆

JAPANESE PRONUNCIATION IS BAI

595 608 671 1031 1176 1177 1645 1646 1647 3512  
 賣 培 壳 邁 莓 莓 梅 梅 梅 賠  
 4043 4487 6697 7832 8635 8978 9540 10271  
 貝 買 煤 倍 徽 狽 陪 媒

JAPANESE PRONUNCIATION IS BAKU

116 273 1009 1010 1012 1015 2365 3123 3426 5852  
 駁 麥 莫 蕎 蕎 幕 麥 駁 暴 寞  
 6061 6182 6719 7440 8416 10027 10031  
 漠 瀑 爆 箔 獮 縛 縛

JAPANESE PRONUNCIATION IS BAN

1215 1714 1820 1821 2829 3741 4977 5384 7861 8537  
 蕃 礬石 輓 輓 挽 晚 蠻 蠻 伴 番  
 8720 8721 8756 8757  
 般石 盤 磐 盤

JAPANESE PRONUNCIATION IS BATSU

2591	2592	4490	4491	7453	7698	9723
拔	拔	罰	罰	筏	伐	闕

JAPANESE PRONUNCIATION IS BEI

4459	6571	6991
皿	米	袂

JAPANESE PRONUNCIATION IS BEN

911	2681	3380	3740	5045	5048	5050	5053	7648	8842
鞭	抔	晒	晃	辯	辨	辦	辦	便	勉
9959	10384								
弁	媿								

JAPANESE PRONUNCIATION IS BETSU

1054	3300	3301	4381	8380	8381	8382	8386
蔑	鼈	鼈	別	瞥	鼈	鼈	魚

JAPANESE PRONUNCIATION IS BI

153	1220	1507	1513	1747	5151	5158	5892	6490	6527
珽	微	枇	枇	梶	糜	糜	寐	瀾	美
7634	7980	8636	8637	9817	9857	9873	9893	10418	
備	鼻	微	微	尾	彌	弥	眉	媚	

JAPANESE PRONUNCIATION IS BUTSU

7535 8063 8109  
物 佛 仏

JAPANESE PRONUNCIATION IS BYO/

1035 1737 2547 3556 5141 5235 6188 7324 8145 8959  
苗 杪 描 眇 廟 病 渺 秒 鎬 猫  
9653  
水 水

JAPANESE PRONUNCIATION IS BYU/

4972 10215  
謬 繆

JAPANESE PRONUNCIATION IS CHA

1270  
茶

JAPANESE PRONUNCIATION IS CHAKU

6537 10331  
着 嫡

JAPANESE PRONUNCIATION IS CHI

124 390 402 767 792 808 1791 3009 3129 3915  
馳 耻 恥 地 耻 恥 輕 致 馬 躑

JAPANESE PRONUNCIATION IS CHI

4209	4476	4477	5290	5350	6496	6500	6927	7146	7148
蚰	置	置	痴	癡	池	治	禱	知	智
7155	7297	7325	7326	7327	7504	7638	7639	9783	9787
雉	稚	穉	穉	穉	咎	值	值	遲	遲
9810	10049	10050							
遲	緻	緻							

JAPANESE PRONUNCIATION IS CHIKU

1106	2444	2445	5521	7227	7228	7342	7361	7362
蓄	逐	逐	畜	竹	竹	竺	筑	築

JAPANESE PRONUNCIATION IS CHIN

303	1389	1628	2188	2225	5407	5423	6322	7885	8150
珍	椿	枕	礎	砧	塵	塵	沈	賃	鎮
8151	9178	9179	9503	9674	9696				
鎮	朕	朕	陳	闖	闖				

JAPANESE PRONUNCIATION IS CHITSU

642	4596	5943	7294	9169
蟄	帙	窒	秩	臍

JAPANESE PRONUNCIATION IS CHO

865	866	1115	1419	1726	3515	3829	7359	7826	7850
著	著	苧	楮	杼	貯	躅	箸	儲	佇

JAPANESE PRONUNCIATION IS CHO

8956 8957  
猪 猪

JAPANESE PRONUNCIATION IS CHOKU

1301 1315 1874 1877 3869 8496  
矗 直 敕 勅 躅 飭

JAPANESE PRONUNCIATION IS CHO/

8	386	389	533	662	790	1192	1308	1639	2493
長	聽	聽	超	塚	聽	蔦	朝	梃	頂
2808	2858	2967	3032	3503	3538	3549	3636	3637	3807
挑	挑	肇	長	貼	眺	眺	嘲	暢	町
3914	3928	3957	3968	4099	4128	4567	4571	4577	4579
跳	跳	疊	疊	吊	蝶	帳	帳	帳	帖
4790	4939	4940	5127	5166	5598	5606	5662	5896	5897
謀	調	調	廳	庁	悵	悵	悵	寵	寵
5970	5976	6067	6448	6487	6488	6491	6831	7021	7086
兆	窕	潮	澄	漲	漲	漲	冢	肇	凋
7715	7917	7947	8000	8170	8292	8305	8311	8430	8581
牒	佻	佻	鳥	釘	鈔	鈞	鈔	貂	兆
8631	8632	8633	8634	8784	8823	8824	9072	9080	9114
徵	懲	徵	懲	鰈	鰾	鰾	脹	脹	脹

JAPANESE PRONUNCIATION IS CHQ/

9122 9129 9246 9319 9849 9851 9858 9860 9930  
 雕 腸 彫 兆 張 張 吊 張 糶

JAPANESE PRONUNCIATION IS CHU

4208 5887  
 蛛 宙

JAPANESE PRONUNCIATION IS CHUTSU

4533  
 黜

JAPANESE PRONUNCIATION IS CHU/

93	1506	1879	2134	2651	3102	3792	3799	3801	3821
駐	柱	衷	厨	抽	駐	中	疇	疇	躊
3826	3827	3977	4035	4105	4170	4850	4894	5006	5128
躊	躊	胄	忠	虫	蟲	註	誅	衷	厨
5162	6202	6237	7064	7312	7355	7363	7596	7626	7785
厨	冲	注	冲	稠	籌	籌	儔	儔	仲
8120	8127	8137	8337	9110	9659	9832	9884	10075	10212
鑄	鑄	鑄	鈕	肘	晝	昼	丑	紬	紐

JAPANESE PRONUNCIATION IS DA

79	82	97	1486	1612	1731	1732	2597	3090	3105
駸	駸	駸	楫	柁	楕	楕	打	駸	駸

JAPANESE PRONUNCIATION IS DA

4307	5642	5644	6123	6582	6686	8439	8710	8746	9387
唾	懦	情	汰	糯	兑	妥	舵	舵	拿
9509	9514	10387	10402	10421					
墮	墮	娜	孛	娜					

JAPANESE PRONUNCIATION IS DAI

1967	3415	6816	6847	7500	7693	8505	8923	9965
醜	題	弟	弟	第	代	餒	乃	台

JAPANESE PRONUNCIATION IS DAKU

4789	6216	6224
諾	濁	濁

JAPANESE PRONUNCIATION IS DAN

606	3730	3976	4056	4416	4804	4882	6634	6788	7569
壇	暖	男	團	團	譚	談	斷	煖	段
9861	9865	10234							
彈	彈	斷							

JAPANESE PRONUNCIATION IS DATSU

2357	8963	8964	9191	9192
奪	獺	獺	脱	脱

JAPANESE PRONUNCIATION IS DEI

JAPANESE PRONUNCIATION IS DEI

6483

泥

JAPANESE PRONUNCIATION IS DEKAGURAMU

2996

匙

JAPANESE PRONUNCIATION IS DEKAMETORU

6574

料

JAPANESE PRONUNCIATION IS DEKI

6492

溺

JAPANESE PRONUNCIATION IS DEN

2071

電

3654

轉

3793

田

6476

澱

7600

伝

7647

傳

8205

鈿

8792

鮎

9771

殿

9772

髻

JAPANESE PRONUNCIATION IS DESHIGURAMU

3000

醜

JAPANESE PRONUNCIATION IS DO

192

鬧

383

土

4456

叟

5140

度

9373

仝

9711

鬧

10397

奴

10398

駕

10399

駕

10401

怒

JAPANESE PRONUNCIATION IS DO

10403 10405  
奴 弩

JAPANESE PRONUNCIATION IS DOKU

310 312 313 4779 8987 8990  
毒 毒 毒 読 独 獨

JAPANESE PRONUNCIATION IS DON

559 3470 7129 7511 8309 8520 10141 10278  
曇 曇 曇 吞 鈍 鈍 緞 嫩

JAPANESE PRONUNCIATION IS DOU

1259 1409 2688 3143 3312 3432 3456 3979 4564 5059  
萄 橈 撞 鬧 堂 瞳 瞳 孺 同 童

5697 5743 6228 6651 6652 6654 7333 7891 7939 8215  
恫 慟 洞 道 道 導 動 働 働 働 銅

8706 8742 9003 9140  
腫 腫 獐 胴

JAPANESE PRONUNCIATION IS E

9390  
會

JAPANESE PRONUNCIATION IS EI

JAPANESE PRONUNCIATION IS EI

214	1050	2109	3217	3219	3507	3672	3690	3774	4302
瓔	英	翳	叡	睿	嬰	映	影	曳	咏
4889	5399	5500	5815	5817	6198	6330	6758	6759	6762
詠	裔	羸	榮	營	洩	泳	瑩	榮	營
7028	8254	8255	8675	8676	8929	9939	9945		
永	銳	銳	衛	衛	盈	穎	穎		

JAPANESE PRONUNCIATION IS EKI

91	123	2700	3100	3758	4159	4875	5322	5380	5383
驛	馭	掖	驛	易	蜴	謚	疫	亦	奕
5694	6259	6655	6656	8668	9152	10086			
懌	液	益	益	役	腋	繹			

JAPANESE PRONUNCIATION IS EN

56	477	481	509	591	592	593	679	926	1228
艷	垣	堰	焉	遠	遠	袁	塩	燕	苑
1758	1776	1898	1916	2211	2212	2215	2216	2337	2586
緣	轅	鹽	豌	厭	壓	魘	饜	奄	掩
2666	2797	2954	3067	3617	3960	4000	4191	4218	4511
捐	援	鳶	艷	燕	園	艷	蜿	蜒	圓
4566	4788	5886	5924	5926	6291	6351	6352	6380	6429
円	讌	宴	寃	宛	演	淵	涎	淵	沿

JAPANESE PRONUNCIATION IS EN

6441	6704	6706	6707	6731	6754	6756	6790	6795	6802
沿	煙	煙	煙	烟	炎	焱	焰	焰	焰
6839	7454	7473	7627	7649	7675	7709	7711	7730	8312
冤	筵	簷	延	偃	俺	鼯	鼯	延	鉛
8316	8390	8643	8866	8867	8868	8955	9086	9285	9693
鉛	爰	衍	怨	鴛	燄	猿	膳	燄	閻
9728	9732	10205	10220	10266	10317	10343	10373		
閻	閻	緣	緣	媯	娟	婉	媛		

JAPANESE PRONUNCIATION IS ETSU

521	3350	3596	4835	4836	5729	5730	8080	8171	9719
越	日	噎	謁	謁	悦	悦	粵	鉞	閱
9720									
閱									

JAPANESE PRONUNCIATION IS FIX

8845  
夕

JAPANESE PRONUNCIATION IS FU

346	522	700	1123	1666	1857	2014	2155	2304	2355
夫	赴	埠	蒲	桴	敷	敷	不	布	巫

JAPANESE PRONUNCIATION IS FU

2366	2512	2780	3244	3486	3494	4221	4828	4872	4873
𪗇	扶	拊	膚	賦	賻	蜉	訃	譜	譜
5356	5357	5652	5859	6377	6568	6570	7452	7688	7746
府	腐	怖	富	浮	普	普	符	付	仆
7840	7914	8002	8057	8125	8566	8567	8571	8771	8772
俯	俘	鳧	阜	鈇	父	釜	斧	負	負
8821	9059	9063	9156	9562	10411				
鮒	孵	孵	腑	附	婦				

JAPANESE PRONUNCIATION IS FUKU

1238	1242	1243	1783	1882	1883	1946	4140	4214	4575
服	服	蔔	輻	副	逼	覆	蝠	蝮	幅
6861	6862	6965	6967	7264	7676	8654	9141	9198	9235
福	福	複	袱	馥	伏	復	服	腹	服
9247									
匐									

JAPANESE PRONUNCIATION IS FUN

463	549	1277	1456	2095	2358	2881	3589	4384	5609
墳	賁	芬	焚	霽	奮	扮	噴	吻	憤
6597	6624	9287	9430	10197					
糞	粉	劓	忿	紛					

JAPANESE PRONUNCIATION IS FUTSU

35	2917	2932	3055	5791	6493	6868	8674	9874
鬚	拂	扌	鬚	拂	沸	袂	佛	弗

JAPANESE PRONUNCIATION IS FU/

460	1702	4950	5321	9344
封	楓	諷	瘋	風

JAPANESE PRONUNCIATION IS GA

746	872	978	1859	1860	1897	1905	2983	2985	2995
雅	芽	芽	画	画	卧	卧	牙	雅	瓦
4215	4706	4707	4819	7537	7538	7539	7896	7942	8497
蛾	峩	峨	訝	我	鵝	鶯	俄	伽	餓
8498	8614	9260	9661	9663					
餓	衙	賀	畫	畫					

JAPANESE PRONUNCIATION IS GAI

96	873	1742	1743	2120	2230	2292	3104	4028	4274
駭	蓋	概	概	厓	碍	礙	駭	骸	咳
4654	4656	4660	4865	5515	5518	5519	5738	5786	5787
剋	凱	崖	該	亥	欸	劾	愾	慨	慨
5822	5828	6115	6475	8010	8221	8603	8848	9608	
害	害	涯	溉	皚	鎧	街	外	孩	

JAPANESE PRONUNCIATION IS GAKU

1040	3170	3218	4047	4731	4841	5486	5685	5820	5930
莠	齧	壑	頤	嶽	諤	孝	愕	学	額
7594	7619	8787	8803	9137					
學	岳	鯉	鯿	脬					

JAPANESE PRONUNCIATION IS GAN

160	359	2385	2386	2387	2388	2390	3563	4658	4662
玩	頑	雁	贗	鴈	贗	願	眼	岸	岩
4688	4689	4695	5088	5265	5475	8440	9338	9385	9386
巖	巖	巖	顏	癌	顏	領	丸	龕	龕
9414	9916								
含	翫								

JAPANESE PRONUNCIATION IS GEI

868	2089	3478	3613	5416	5432	7901	8807	9013	9066
藝	霓	睨	嘔	麁	麁	倪	鯨	猊	迎
9067									
迎									

JAPANESE PRONUNCIATION IS GEKI

1306	1661	1827	1837	3228	6363	9595	9820
戟	檄	擊	擊	劇	激	隙	屐

JAPANESE PRONUNCIATION IS GEN

216	338	2389	3459	4057	4058	4757	4864	5087	5274
現	元	原	眩	嚴	嚴	言	諺	彦	痊
5806	6116	6129	7794	7795	8709	8745	9596	9864	10109
嚴	減	源	儼	儼	舷	舷	限	弦	絃
10231									
幻									

JAPANESE PRONUNCIATION IS GETSU

58	1201	9071
齧	藥	月

JAPANESE PRONUNCIATION IS GI

2555	2930	3227	3232	3236	4196	4703	4867	4871	5881
技	擬	戲	戲	戲	蟻	巍	誼	議	宜
6536	6900	7528	7529	7643	7862	7870	7913	8711	8747
義	祇	犧	犧	伎	儀	偽	偽	舩	舩
9943	10276								
疑	妓								

JAPANESE PRONUNCIATION IS GIN

3177	4403	8332
齧	吟	銀

JAPANESE PRONUNCIATION IS GO

1076	1333	1766	1880	1956	3015	3167	3450	4074	4457
護	胡	五	吾	醐	互	齧	晤	圀	吳
4458	4795	4800	4844	4845	5634	5893	7096	7644	8649
吳	護	語	誤	誤	悟	寤	午	伍	御
10319	10320								
娛	娛								

JAPANESE PRONUNCIATION IS GOKU

8992  
獄

JAPANESE PRONUNCIATION IS GON

9759  
良

JAPANESE PRONUNCIATION IS GOTSU

1502  
杓

JAPANESE PRONUNCIATION IS GO/

293	602	626	1781	2531	2532	2534	3413	3788	3789
螯	壕	螯	鞦韆	拷	拷	拷	噉	号	號

JAPANESE PRONUNCIATION IS GO/

3913 4059 4611 5013 5016 6241 7059 9380  
 啣 囁 剛 豪 毫 濠 呀 合

JAPANESE PRONUNCIATION IS GU

3245 3246 3383 3384 3682 3684 9346  
 虞 虞 具 具 遇 愚 颯

JAPANESE PRONUNCIATION IS GUN

6826 9744 9745 9746  
 軍 羣 群 郡

JAPANESE PRONUNCIATION IS GU/

48 796 3683 5885 7783 9536  
 耦 藕 遇 寓 偶 隅

JAPANESE PRONUNCIATION IS GYAKU

3225 3230 4823 4825 5249 5250 6668 6669  
 虐 虐 謔 謔 瘧 瘧 逆 逆

JAPANESE PRONUNCIATION IS GYO

119 3126 6392 8650 8777  
 馭 馭 漁 禦 魚

JAPANESE PRONUNCIATION IS GYOKU

228 4746  
 玉 嶷

JAPANESE PRONUNCIATION IS GYO/

67	439	3078	3271	3401	3405	6027	7091	7612	7938
驍	翹	驍	業	曉	曉	澆	凝	僥	仰

JAPANESE PRONUNCIATION IS GYU/

7095

牛

JAPANESE PRONUNCIATION IS HA

55	158	304	743	1133	1750	1936	2059	2285	2806
耙	琶	玻	坡	菠	杷	霸	霸	破	播
2919	3933	6387	6388	6446	7367	8680	9449	9895	
把	跛	派	派	波	簸	爬	頗	巴	

JAPANESE PRONUNCIATION IS HACHI

2667

捌

JAPANESE PRONUNCIATION IS HAI

492	1490	2006	2083	2161	2502	2607	2617	2672	3062
坏	杯	配	霈	盃	拜	排	排	擺	輩
3159	3263	3483	3526	3728	5331	5373	5374	5447	5625
背	輩	貝	敗	吠	廢	廢	廢	旆	悖

JAPANESE PRONUNCIATION IS HAI

6107	6244	6336	7135	7298	7635	7725	7739	7744	7950
沛	沛	湃	拜	稗	憊	牌	俳	俳	佩
8620	8622	9101	9104	9144					
徘	徘	肺	胚	肺					

JAPANESE PRONUNCIATION IS HAKU

255	574	1122	1124	1656	2093	2569	6359	6614	7905
珀	博	薄	薄	柏	雹	搏	泊	粕	伯
7971	8007	8016	8017	8026	8715	8751	9100	9801	9994
白	帛	迫	迫	魄	舶	舶	膊	擘	剝

JAPANESE PRONUNCIATION IS HAN

237	259	498	1131	1499	1715	2437	2737	2819	2820
斑	班	坂	藩	板	攀	反	拌	搬	搬
3497	3965	3966	4222	4599	4602	5308	5309	6111	6383
販	畔	畔	蟠	幡	帆	瘢	瘢	汎	泛
6430	6498	6524	6525	6538	6552	6553	6709	6791	7375
汎	汜	半	半	叛	判	判	煩	燔	範
7550	7553	7558	7717	8459	8460	8558	8718	8719	8754
繁	繁	繁	版	飯	飯	頒	般	般	般
8755	9042	9204	9337	9516	10123	10159			
槃	犯	幡	凡	阪	絆	緡			

JAPANESE PRONUNCIATION IS HANASHI

4256

嘶

JAPANESE PRONUNCIATION IS HATA

6726

畑

JAPANESE PRONUNCIATION IS HATAKE

8006

畠

JAPANESE PRONUNCIATION IS HATSU

17	18	2885	3039	3850	4393	6449	8044	8152	8169
髮	髮	撥	髮	跋	叭	潑	魃	鉢	鉞
9362	9458	9461							
八	発	發							

JAPANESE PRONUNCIATION IS HEI

392	488	489	755	756	798	997	1125	1210	1480
聘	坪	坪	墀	墀	聘	蔽	萍	蔽	柄
2036	2047	2048	3296	3303	4993	5081	6546	6567	6569
丙	平	平	弊	幣	并	竝	并	並	並

JAPANESE PRONUNCIATION IS HEI

6708	7463	7464	7624	7828	7863	8377	8379	8384	8472
炳	篋	篋	兵	併	併	弊	弊	幣	餅
8486	9520	9522	9695	9804	9806	9811			
餅	陛	陛	閑	嬖	屏	屏			

JAPANESE PRONUNCIATION IS HEKI

256	2100	5345	8052	9734	9792	9793	9794	9797	9802
碧	霹	癖	僻	闕	辟	璧	壁	躄	劈

JAPANESE PRONUNCIATION IS HEKUTOGURAM

2997  
𪗇

JAPANESE PRONUNCIATION IS HEKUTDMETOR

6584  
𪗈

JAPANESE PRONUNCIATION IS HEN

94	98	100	2439	2440	2964	3106	3108	3528	4206
駢	駢	騙	返	返	遍	駢	騙	貶	蝸
4982	4985	5393	5453	7013	7014	7015	7444	7699	7716
變	變	變	藩	扁	遍	翩	篇	片	偏
7875	7990	8647	9142	9177	9281	10046	10134		
偏	邊	徧	胼	胼	辺	編	編		

JAPANESE PRONUNCIATION IS HI

789	995	1840	2067	2068	2159	2219	2221	2264	2266
匪	菲	響	霏	霏	否	砒	砒	碑	碑
2598	2603	2883	2947	3059	3063	3071	3072	3260	3264
批	批	披	比	非	蜚	悲	翡	非	蜚
3266	3267	3268	3413	3482	3505	3639	3809	3810	4032
斐	悲	翡	匙	脾	鼻	鄙	毗	毘	髀
4503	4504	4822	4827	5147	5148	5167	5261	5304	5330
罷	罷	誹	誹	靡	靡	庇	痺	痺	疲
6591	6893	6894	6971	6982	7008	7009	7248	7292	7293
糝	祕	祕	裨	被	靡	靡	秕	秘	秘
8020	8040	8427	8428	8670	9115	9117	9201	9234	9448
卑	卑	貔	貔	彼	腓	腓	脾	肥	皮
9778	9798	9799	9800	9803	9875	9938	9955	9956	10054
屁	譬	避	避	臂	費	匕	飛	飛	緋
10057	10293	10296	10368	10414					
緋	妣	妣	婢	妃					

JAPANESE PRONUNCIATION IS HIN

2415	2720	3185	3186	3938	4073	5034	5038	5874	5875
殞	擯	頻	嚙	嚙	品	稟	稟	賓	賓

JAPANESE PRONUNCIATION IS HIN

6160 6294 6347 7542 10340  
 瀕 濱 浜 牝 嬪

JAPANESE PRONUNCIATION IS HITSU

2462 3425 3862 4890 4891 6332 6333 7031 7032 7491  
 匹 畢 蹕 謚 謚 泌 泌 必 必 筆  
 9443 9856  
 疋 弼

JAPANESE PRONUNCIATION IS HO

1785 2013 2015 2568 2610 3183 3184 3678 4097 6105  
 輔 甫 逋 捕 抄 步 步 哺 圃 浦  
 6924 6968 7777 7778 8114 8361 8532  
 補 祿 保 堡 舖 舖 舖

JAPANESE PRONUNCIATION IS HOKU

3157 3270  
 北 业

JAPANESE PRONUNCIATION IS HON

1382 2320 7112 7372 8540 8541 8542 8543 9963  
 本 奔 犇 笨 翻 翻 翻 翻 畚

JAPANESE PRONUNCIATION IS HOU

JAPANESE PRONUNCIATION IS HO/

23	132	140	243	461	584	638	648	1033	1099
髻	奉	邦	珙	幫	彭	報	報	萌	芳
1232	1262	1693	2278	2279	2280	2373	2504	2541	2595
蓬	苞	棚	礪	砲	砲	頰	捧	杯	拋
2854	2855	2863	3043	3647	3927	3999	4231	4386	4729
抱	抱	拋	髻	呆	跑	豐	蜂	咆	峯
4730	4732	4863	4995	5023	5076	5169	5175	5320	5371
峰	崩	訪	遊	烹	剖	褒	褒	庖	庖
5439	5459	5831	5833	6030	6036	6422	6549	6738	6796
方	放	宝	寶	澎	法	泡	迸	焙	烽
6603	6978	7158	7568	7844	8300	8307	8518	8519	8641
炮	袍	邦	俸	倣	鋒	鈔	飽	飽	彷彿
8707	8743	8825	8933	9214	9215	9220	9221	9248	9298
舫	舫	鮑	逢	朋	鵬	胞	胞	匍	包
9299	9331	10093	10094	10125	10172	10173			
包	鳳	繃	緝	緝	縫	縫			

JAPANESE PRONUNCIATION IS HYAKU

7669  
佰

JAPANESE PRONUNCIATION IS HYO/

276	1212	1477	1927	1928	1929	1930	2786	3379	4807
表	苧	標	票	剝	瓢	飄	拍	瞞	評
4808	6097	7047	7062	7089	7577	7888	8238	8431	8789
評	漂	憑	憑	冰	俵	凭	鑣	豹	鰈
9647	10029								
冰	縹								

JAPANESE PRONUNCIATION IS I

467	1169	1325	1346	1495	2106	2107	2147	2329	3537
恚	萎	頤	葦	椅	医	醫	威	欵	貽
3606	3803	3808	3953	3954	3978	4163	4554	4597	4609
圉	異	畏	遺	遺	胃	蝟	圍	帷	幃
4754	4838	5067	5243	5398	5748	6142	6820	7307	7329
以	謂	意	癢	衣	惟	澆	為	移	委
7674	7831	7841	8019	8064	8065	8406	8529	9765	9766
倚	位	依	伊	偉	偉	為	飴	尉	熨
9767	9839	9885	9889	9987	9989	9991	10128	10146	10213
慰	已	違	違	彘	彘	彘	縊	維	緯

JAPANESE PRONUNCIATION IS ICHI

1	371	656	675
一	弋	壹	壹

JAPANESE PRONUNCIATION IS IKI

480 7991 9690  
域 息 闕

JAPANESE PRONUNCIATION IS IKU

2394 5513 9867  
郁 育 粥

JAPANESE PRONUNCIATION IS IN

483	1051	1291	4044	4089	4243	4341	5066	5858	6098
堙	茵	蔭	員	咽	蚓	因	韻	寅	湮
6104	7599	8507	8508	8689	8690	9357	9539	9547	9569
湮	印	飲	飲	殷	慇	胤	隕	院	隱
9570	9742	9859	9979	10316					
隱	尹	引	允	姻					

JAPANESE PRONUNCIATION IS ITSU

1809 6309 7881 8841 9947  
軼 溢 佚 逸 乙

JAPANESE PRONUNCIATION IS JA

747 4192 5417 5433  
邪 蛇 麝 麝

JAPANESE PRONUNCIATION IS JAKU

924	947	950	5877	9644	9871	9872
鵲	若	惹	寂	雀	弱	弱

JAPANESE PRONUNCIATION IS JI

384	500	557	1004	1924	2051	2257	2305	2341	2342
耳	寺	埒	蒔	事	爾	磁	而	爾	璽
2344	2525	3288	3403	4642	5212	5607	5790	5988	6073
邇	持	兕	時	峙	痔	恃	幌	字	滋
6312	6676	7074	7218	7518	7614	7707	7808	7972	8407
滋	慈	次	辞	尔	侍	兒	似	自	辭
8449	8451	9585							
餌	餌	除							

JAPANESE PRONUNCIATION IS JIKI

1300  
直

JAPANESE PRONUNCIATION IS JIKU

1798	5792	8078
軸	扭	衄

JAPANESE PRONUNCIATION IS JIN

JAPANESE PRONUNCIATION IS JIN

917	1191	1910	2039	2040	3536	4806	4949	6809	6964
靱	荏	腎	迅	迅	贖	訊	訊	燼	衽
6970	7562	7944	8005	8830	9271	9360	9502	9660	9667
衽	仁	仞	儘	鱒	刃	人	陣	尋	盡
9834									
尽									

JAPANESE PRONUNCIATION IS JITSU

3349	3777	5826	5995
日	昵	実	實

JAPANESE PRONUNCIATION IS JO

2888	3031	3544	5375	6505	8198	8345	8347	8348	8669
扞	上	助	序	汝	鋤	敘	敘	叙	徐
10254	10301	10315	10318						
女	如	恕	絮						

JAPANESE PRONUNCIATION IS JOKU

142	823	942	2113	6912	6926	9997	10033
辱	募	募	辱	禱	禱	縳	縳

JAPANESE PRONUNCIATION IS JO/

499	562	600	614	677	856	874	1294	1370	1503
城	場	壤	壤	場	茸	茸	蒸	茹	杖

JAPANESE PRONUNCIATION IS JO/

1976	1979	2480	2583	2682	3318	3331	3822	3828	4627
釀	釀	丈	擾	攘	常	狀	躡	躡	狀
4851	4861	5985	6378	6405	6844	7106	7107	7198	7199
讓	讓	宄	淨	淨	冗	乘	剩	乘	剩
7274	7276	7685	7754	7931	8223	8245	8450	8935	9489
穰	穰	仗	條	仍	鑲	錠	饒	条	承
9602	10005	10073	10074	10326	10333	10352	10416		
丞	繞	繩	繩	孃	孃	娘	孀		

JAPANESE PRONUNCIATION IS JU

740	1415	1907	1909	2064	2065	2380	2800	4091	6113
壽	樹	豎	豎	需	顛	戍	授	呪	濡
6925	7666	8400	9607	10156					
襦	儒	受	孺	綬					

JAPANESE PRONUNCIATION IS JUKU

5026	5027	5028	9868
孰	塾	熟	鬻

JAPANESE PRONUNCIATION IS JUN

104	1670	1977	2427	3112	4852	4942	5025	6242	6357
馴	楯	醇	殉	馴	諄	詢	鶉	淳	準

JAPANESE PRONUNCIATION IS JUN

6412	6470	6645	6646	7069	7070	7480	7496	7743	8588
洵	潤	遵	遵	准	準	筍	笋	順	盾
8664	9222	9253	9676	10188	10439	10440			
循	肫	旬	閏	純	巡	巡			

JAPANESE PRONUNCIATION IS JUTSU

1613	1614	2146	5753	8612	8613
迷	迷	戍	恤	術	術

JAPANESE PRONUNCIATION IS JU/

356	380	786	2889	3937	4080	5514	5814	6023	6156
戎	十	廿	揉	蹂	獸	充	獸	汁	澁
6627	7332	7607	7827	8244	8646	9470	10000	10164	10165
糅	重	什	住	銃	從	柔	絨	縱	縱

JAPANESE PRONUNCIATION IS KA

175	218	284	306	570	586	846	912	931	1008
珂	瑕	珈	瑕	嘉	嘉	華	靴	苛	菓
1021	1179	1207	1245	1322	1372	1432	1476	1493	1694
葭	荷	花	茄	葭	下	樺	柯	榎	枷
1784	1920	1921	1923	2070	2099	2140	2183	2956	3434
軻	可	哥	歌	霞	霞	厦	夏	戈	果

JAPANESE PRONUNCIATION IS KA

3436	3438	3566	3612	3658	3673	3776	3863	4008	4009
顆	夥	遐	嘩	暇	呵	暇	踝	過	過
4146	4155	4166	4213	4242	4786	4802	4832	4914	4919
蚘	蝦	蝸	蚪	蝦	譁	訶	課	訛	譌
5002	5163	5318	5864	5870	5945	5947	6096	6212	6691
裹	廈	痂	寡	家	窠	窩	河	渦	火
6881	6882	7128	7278	7279	7414	7506	7611	7654	7655
禍	禍	罅	科	稼	箇	兮	佳	何	倆
7659	7682	7775	7793	8039	8104	8107	8209	8687	8696
價	飯	假	個	假	化	貨	鍋	瓜	舸
8732	8798	8833	9251	9254	9255	9259	9262	9762	10339
舸	鰕	鰕	加	駕	架	駕	迦	遐	嫁

JAPANESE PRONUNCIATION IS KAI

258	334	474	575	604	698	781	897	963	964
瑰	戒	壞	堺	壞	塊	丐	鞋	薤	薤
1266	1272	1276	1396	1508	1514	1707	2376	2377	2524
艾	薈	芥	械	楷	楷	檜	灰	灰	掛
2599	2604	2665	2952	3496	3514	3714	3715	3980	4174
措	措	拐	皆	賄	賅	晦	晦	界	蛔
4230	4448	4507	4509	4510	4611	4620	4652	4766	4816
懈	喙	回	迴	迴	回	迴	豈	誠	諧

JAPANESE PRONUNCIATION IS KAI

4820	4902	4903	5327	5622	5654	5705	5745	5746	5747
諧	誨	誨	疥	懷	恢	懷	悔	悔	悔
5768	5789	6205	6225	6344	6345	6346	7197	7692	7732
懈	快	潰	洄	海	海	海	乖	偕	偕
7909	7956	8048	8628	8911	8912	8913	9032	9227	9372
傀	僧	魁	徊	解	蟹	邂	獾	膾	会
9405	9423	9521	9523	9677	9770	9790	9837	9844	10004
刈	介	階	階	開	屈	届	改	改	絳
10190	10192								
絵	繪								

JAPANESE PRONUNCIATION IS KAKU

601	664	673	716	896	1165	1236	1589	1683	1685
塙	殼	殼	赫	革	獲	獲	核	桷	桷
1799	1945	2258	2635	2661	2696	2705	2779	2904	3444
較	覈	確	攫	擗	擴	抃	攪	擱	隻
3601	4033	4285	4369	5029	5184	5769	5816	5929	6649
嚇	骷	喀	咯	郭	廓	恪	覺	客	戩
6837	7236	7592	8429	8892	8936	8961	9096	9504	9505
鶴	穫	覺	貉	角	各	獲	膈	隔	隔
9662	9729								
劃	閣								

JAPANESE PRONUNCIATION IS KAMISHIMO

6931

祿

JAPANESE PRONUNCIATION IS KAN

74	147	163	222	223	333	423	470	507	787
馬	干	梨	環	環	刊	款	堪	敢	甘
826	828	895	1042	1043	1044	1045	1046	1109	1116
戡	勘	艱	觀	觀	鶴	歡	勸	莞	管
1121	1307	1309	1312	1313	1393	1410	1412	1473	1538
菅	乾	幹	翰	韓	杆	橄	橄	檻	桿
1601	1610	1901	1903	1953	2137	2508	2579	2831	2832
棺	棺	監	鑿	酣	感	扞	撼	換	換
3027	3085	3211	3359	3360	3362	3363	3712	4066	4072
函	驩	鹹	旱	盱	瞰	瞰	喊	串	患
4305	4302	4363	4478	4479	4644	4805	5217	5338	5339
啣	喚	喚	還	還	嵌	諫	疳	癩	癩
5646	5671	5843	5845	5853	5854	5860	5889	5991	6009
憾	悍	寒	完	寬	寬	宦	官	官	汗
6038	6044	6062	6063	6069	6150	6287	6368	6458	6472
泔	漢	漢	灌	瀚	涵	浣	淦	涵	澗

JAPANESE PRONUNCIATION IS KAN

6793	6824	7121	7136	7137	7138	7139	7261	7348	7390
煥	冠	罐	觀	歡	勸	看	稈	竿	柑
7435	7437	7494	7597	7798	7974	7981	8115	8116	8146
管	管	簡	盥	侃	遑	鼾	館	館	罐
8156	8212	8476	8477	8478	8479	8533	8534	8657	8695
鑑	鑲	館	館	館	館	館	館	銜	艦
8731	8805	8806	9074	9372	9574	9582	9598	9689	9698
艦	鰓	鰓	肝	陷	陷	陷	函	閑	間
9717	9731	9738	9739	9936	9942	10034	10154	10257	10427
閑	閑	關	關	貫	欸	緘	緩	奸	姦

JAPANESE PRONUNCIATION IS KARIGANE

2105

厂

JAPANESE PRONUNCIATION IS KATSU

403	809	1034	1803	1804	2172	2203	2526	2767	4064
聒	聒	葛	轄	轄	夏	夏	拮	括	喝
4157	4158	4526	5823	5824	5829	6196	6197	6213	6340
蝟	蝟	黠	割	豁	割	渴	渴	滑	活
6473	6512	6530	6943	7217	7449	8984	9716		
潤	鞞	羹	褐	刮	筈	猾	闊		

JAPANESE PRONUNCIATION IS KE

464 卦  
5783 怪  
9261 袈

JAPANESE PRONUNCIATION IS KEI

7 慧	12 髻	59 挈	162 珪	283 契	327 刑	328 型	331 形	455 圭	764 馨
766 馨	847 荊	979 莖	1223 薊	1249 敬	1253 警	1297 莖	1408 桂	1792 輕	1832 輕
1838 繫	1847 惠	1858 惠	2184 硅	2522 挂	2647 揭	2648 揭	2677 攜	2794 攜	2785 携
2945 頃	2986 啓	3017 頸	3018 剗	3019 逕	3020 勁	3034 髻	3687 景	3800 畦	3911 蹊
4390 兄	4486 罫	4530 黥	4770 計	4973 詣	5030 京	5245 瘥	5438 慶	5678 憬	6374 溪
6379 溪	6733 炯	6734 炯	6761 螢	6850 楔	7020 啓	7022 祭	7216 憇	7222 憇	7349 筭
7352 筭	7690 傾	7951 係	8106 傾	8389 鷄	8436 雞	8437 鷄	8438 谿	8619 徑	8671 徑
8780 鮭	9064 卿	9112 脛	9358 系	9680 閏	9940 頃	10053 經	10127 繼	10200 經	10224 繼

JAPANESE PRONUNCIATION IS KEKI

194 3145 6825  
 鬪 鬪 冪

JAPANESE PRONUNCIATION IS KEN

112	113	1064	1065	1113	1350	1439	1634	1705	1706
驗	驗	繭	繭	萱	献	權	權	檢	檢
1734	1771	1906	1908	2174	2179	2231	2345	2740	2871
杈	軒	堅	賢	研	研	硯	犬	捲	檢
2971	3120	3215	3226	3247	3249	3393	3394	3395	3547
肩	驗	齧	獻	虔	虔	具	縣	懸	見
3569	3570	3628	3786	3962	3963	3992	3993	4154	4277
具	懸	顛	顯	遣	遣	遣	遣	蜺	喧
4296	4379	4538	4539	4736	4837	4840	4866	4878	4879
嗛	鶻	圈	圈	嶮	譴	譴	誼	謙	謙
5474	5520	5523	5636	5726	5825	5830	5840	6219	6557
彥	玄	牽	慳	慳	憲	憲	蹇	涓	眷
6561	6562	6563	6565	6666	6667	7025	7410	7864	7878
拳	券	券	卷	兼	兼	肩	筧	倦	件
7954	7955	7976	8140	8326	8364	8367	8370	8644	8988
儉	儉	健	鉗	鏈	劍	劍	劍	愆	狷

JAPANESE PRONUNCIATION IS KEN

9232	9587	9588	9657	10085	10183	10258	10261	10346
睫	險	險	建	絹	絢	妍	妍	嫌

JAPANESE PRONUNCIATION IS KETSU

956	1385	2181	2354	2353	2909	3757	3849	4963	4965
蕨	楔	頁	厥	厥	抉	歇	蹶	譎	訣
5071	5987	6002	6014	6481	7133	7925	8066	8765	8968
竭	穴	潔	潔	決	缺	傑	血	欠	獺
9606	9718	10008							
子	闕	結							

JAPANESE PRONUNCIATION IS KI

68	80	84	351	496	537	538	544	567	581
騏	騎	驥	規	埼	起	起	卉	喜	喜
726	731	811	813	814	815	818	819	820	875
逵	耆	其	基	碁	碁	欺	菁	期	萁
1281	1326	1429	1469	1701	1748	1759	1826	1856	1933
葵	熙	棋	櫃	机	杞	機	軌	匱	羈
1934	1935	2296	2325	2327	2446	2752	2884	3079	3091
羈	羈	磯	奇	敬	豨	揮	揆	騏	騎
3093	3158	3161	3250	3290	3293	3344	3702	3805	3918
驥	冀	歧	虧	輝	輝	歸	暉	畸	跪

JAPANESE PRONUNCIATION IS KI

3952	4052	4060	4061	4063	4069	4472	4474	4648	4655
貴	器	器	器	器	喟	羈	羈	岐	覬
4666	4674	4927	4967	4969	4989	5089	5154	5408	5424
崎	巖	詭	記	諱	譏	毅	麾	麒	麒
5443	5510	5511	5742	5752	5867	5932	6337	6815	6898
旗	棄	棄	悻	愧	寄	窺	汽	歸	祈
6899	7185	7190	7319	7323	7337	7366	7701	7996	8041
祈	氣	氣	稀	季	熙	箕	毀	皈	鬼
8059	8521	8522	8531	8638	8770	8773	8775	8776	8782
歸	飢	飢	饑	徽	危	龜	龜	龜	鱈
9223	9324	9392	9393	9404	9457	9751	9752	9788	9838
肌	几	希	欵	企	癸	既	既	負	己
9843	10039	10208	10232	10233	10267	10268	10275	10283	
忌	綺	紀	幾	幾	嬉	嬉	姬	姬	

JAPANESE PRONUNCIATION IS KICHI

552	7616
吉	佶

JAPANESE PRONUNCIATION IS KIKU

918	919	1258	2370	2850
鞠	鞠	菊	鞠	揆

JAPANESE PRONUNCIATION IS KIN

157	169	725	887	889	890	1005	1062	1216	1435
琴	瑾	均	堇	勤	勲	勤	菌	芹	槿
1447	1709	1911	2874	3648	4565	4787	4791	5980	6920
禁	擒	緊	擒	噤	巾	謹	謹	窘	襟
6981	7477	7587	7630	8284	8294	8306	8452	8586	8593
衿	筋	躰	僅	錦	欽	鈞	饅	斤	近
8594	8596	9408	9413	9417	9482	9604			
近	欣	禽	今	衾	衿	毳			

JAPANESE PRONUNCIATION IS KIRDGURAMU

2999

氍

JAPANESE PRONUNCIATION IS KITSU

1728	3412	4317	4708	4775	7560
橘	喫	吃	屹	詰	迄

JAPANESE PRONUNCIATION IS KD

172	205	323	577	578	587	668	879	1295	1299
瑚	琥	覲	鼓	瞽	鼓	壺	苦	菰	古
1327	1330	1441	1942	2313	2314	2962	2968	2969	3234
辜	故	枯	賈	劓	瓠	戶	雇	顧	虎

JAPANESE PRONUNCIATION IS KO

3255	3292	3847	4005	4171	4347	4353	4796	4809	5263
虎	光	跨	固	蠱	呼	呱	詰	誇	痼
5466	6065	6072	6211	6234	6577	6928	7004	7012	7023
亢	沽	湖	涸	澣	糊	袴	戶	扈	雇
7024	7391	7637	8097	8208	8455	8547	8678	8905	9019
顧	箍	估	伺	錮	餬	乎	後	觚	狐
9224	9395	9396	9419	9610	9877	10274			
股	肴	殼	込	孤	孤	姑			

JAPANESE PRONUNCIATION IS KOGARASHI

9328  
凧

JAPANESE PRONUNCIATION IS KOKU

654	658	659	670	1335	1341	1638	1991	3407	3581
穀	穀	穀	穀	克	剋	梏	酷	黑	国
3593	4062	4065	4524	5517	7200	7205	8570	8899	
国	哭	國	黑	刻	告	鵠	谷	斛	

JAPANESE PRONUNCIATION IS KON

375	563	1426	1544	1545	1744	3558	3940	4036	5189
魂	坤	柑	棍	棍	根	昆	跟	困	袞

JAPANESE PRONUNCIATION IS KON

5206	5340	5684	5788	6189	6190	6218	6260	6318	6721
袞	痕	烟	恨	混	混	溷	滾	渾	焜
6962	6963	8118	8432	8433	9049	10016	10386		
禪	禪	金	墾	懇	昏	紺	婚		

JAPANESE PRONUNCIATION IS KOTSU

1555	2404	4016	5774	7481	7559	9288
楯	兀	骨	惚	笏	乞	忽

JAPANESE PRONUNCIATION IS KO/

41	42	185	381	400	494	504	560	612	631
耕	耕	関	工	耿	項	巧	貢	壙	坑
637	682	683	705	707	711	723	739	748	806
幸	攻	考	垢	考	孝	功	考	汞	耿
849	928	962	1055	1078	1079	1105	1110	1111	1112
黃	黃	巷	薨	蒿	藁	荒	寇	寇	寇
1246	1395	1403	1414	1468	1568	1585	1587	1675	1689
苟	構	杠	楨	梗	槁	校	杭	桁	格
1843	1849	1952	2198	2217	2244	2414	2517	2628	2704
匣	更	酵	硬	厚	礦	互	扛	扣	抗
2727	2787	2848	3136	3182	3422	3487	3577	3599	3619
控	擗	拘	関	肯	昂	購	甲	哮	哄

JAPANESE PRONUNCIATION IS KO/

3625	3642	3660	3689	3695	3747	4112	4182	4219	4234
噉	晃	哽	顛	曠	昂	虹	蛟	蝗	蛤
4270	4336	4412	4435	4582	4610	4683	4692	4765	4771
咬	喉	吼	叩	幌	岡	岬	崗	講	訶
4925	5010	5011	5012	5015	5131	5198	5199	5200	5201
詬	高	敲	藁	膏	廣	交	效	効	郊
5403	5468	5617	5628	5655	5666	5714	5751	5777	5846
康	庀	慌	恒	恆	恍	慷	惶	恰	寇
5847	5871	5958	6015	6024	6033	6050	6053	6054	6055
寇	宏	窖	溝	江	鴻	洪	港	港	港
6338	6364	6439	6529	6580	6603	6700	6783	6979	7201
浩	浩	淆	羔	粳	糠	烘	煌	裕	靠
7202	7259	7275	7368	7369	7458	7527	7580	7622	7796
靠	香	稿	簧	簧	篁	犒	興	倖	候
7839	7845	7855	7973	7994	8021	8050	8067	8187	8216
倣	仇	倥	皇	皋	皓	候	皐	鈎	鋼
8224	8232	8242	8304	8308	8369	8597	8598	8602	8655
鎬	鑛	鈇	鈎	鈎	鴿	后	逅	行	徨
8665	8693	8708	8729	8744	8786	8809	8998	9014	9078
衡	舡	航	舡	航	鯁	鮫	狡	猴	肛

JAPANESE PRONUNCIATION IS KO/

9105	9109	9125	9130	9168	9236	9308	9384	9438	9576
胯	肱	眈	胛	腔	膠	勾	盒	公	降
9578	9615	9685	9687	9699	9726	9824	9882	10003	10042
降	孔	闔	関	閘	閤	尻	弘	紅	紘
10058	10089	10096	10103	10262	10395				
紘	綱	縞	絞	媯	好				

JAPANESE PRONUNCIATION IS KU

75	83	109	1695	1886	2483	3086	3117	3173	3347
驅	驅	駒	枸	區	区	驅	駒	齒	口
4650	5161	5672	5673	7143	7145	7652	7770	8087	8626
嶮	庫	惧	懼	矩	矩	偃	俱	軀	衢
9027	9252								
狗	句								

JAPANESE PRONUNCIATION IS KUN

1171	1172	1993	4910	6779	6829	6987	7334	7338	7339
薰	薰	醺	訓	燠	鞞	裙	勳	熏	勳
9743									
君									

JAPANESE PRONUNCIATION IS KURA

JAPANESE PRONUNCIATION IS KURA

4407  
喰

JAPANESE PRONUNCIATION IS KURUMA

7646  
傳

JAPANESE PRONUNCIATION IS KUTSU

757 2912 5981 8054 9829  
堀 掘 窟 屈 屈

JAPANESE PRONUNCIATION IS KU/

5933  
空

JAPANESE PRONUNCIATION IS KYAKU

778 2109 8556 9084  
却 百 卻 脚

JAPANESE PRONUNCIATION IS KYO

541	542	770	975	1964	2602	2613	2842	2907	2973
墟	墟	去	芭	醜	拒	據	拗	据	巨
3229	3231	3235	3238	3836	3852	3942	3986	3987	4893
遽	虚	虚	歛	距	距	踞	嘘	嘘	許

JAPANESE PRONUNCIATION IS KYO

5810	6141	6702	6713	6990	6992	6993	7571	7574	7605
拳	渠	炬	炬	裾	襠	襠	舉	舉	舉
8012	8091	8333	9775						
皎	倨	鋸	居						

JAPANESE PRONUNCIATION IS KYOKU

1518	2020	3943	3996	9335	9828
極	棘	躑	曲	旭	局

JAPANESE PRONUNCIATION IS KYOK

771  
去  
刮

JAPANESE PRONUNCIATION IS KYO/

9	102	609	712	735	736	738	774	775	925
匡	驕	境	教	鞏	疋	恐	劫	劫	薑
951	959	960	1173	1250	1252	1384	1533	1636	1642
共	莢	恭	蕎	驚	驚	框	杏	棍	橋
1761	1762	2375	2544	2589	3110	3354	3578	3813	4439
協	協	夾	拱	挾	驕	眶	叶	叫	叫
4657	4668	4936	5022	5072	5078	5611	5776	6220	6545
峽	峽	誑	享	竟	競	怯	恂	況	姜

JAPANESE PRONUNCIATION IS KYO/

7065	7153	7343	7512	7633	7679	7893	7997	8168	8227
况	矯	筐	喬	供	俠	僑	梟	鈇	鏡
8951	8965	8969	9218	9219	9294	9296	9397	9436	9437
狂	狹	狹	脇	胸	脅	匈	教	凶	兇
9852	9854	9862	9883	10236	10237	10238	10239	10240	10241
疆	彊	強	強	鄉	響	嚮	饗	鄉	響
10359									
嬌									

JAPANESE PRONUNCIATION IS KYU

985	996	5888	6245
菲	菲	宮	泣

JAPANESE PRONUNCIATION IS KYU/

181	195	198	1187	1500	1517	2449	2496	2497	2499
球	龜	龜	舊	樞	朽	既	求	裘	救
3060	3146	3147	3149	3261	3287	4217	4326	4368	5313
韭	龜	龜	龜	韭	旧	蚯	嗅	吸	疚
5404	5964	5977	5982	6403	7165	7474	7608	7641	7700
廐	窮	究	穹	汲	毬	笈	丘	休	臼
7704	7949	8094	8423	8915	8917	8930	8941	8944	9325
舅	仇	躬	貅	及	急	久	灸	咎	九

JAPANESE PRONUNCIATION IS KYU/

9343 9389 9848 10055 10170 10191 10216 10218  
鳩 翕 弓 糾 級 給 糾 糾

JAPANESE PRONUNCIATION IS MA

4266 5143 5144 5145 5146 5152 5153 5155 5156 5229  
嘛 麻 麻 磨 磨 摩 摩 魔 魔 痲

JAPANESE PRONUNCIATION IS MAI

220 536 1644 3375 7551 10263  
瑁 埋 枚 昧 每 妹

JAPANESE PRONUNCIATION IS MAKU

9089  
膜

JAPANESE PRONUNCIATION IS MAN

20 1027 1028 2450 3370 3675 3830 4584 4834 5677  
曼 蔓 萬 万 瞞 曼 蹻 幔 謾 慢  
6047 6048 6049 6194 8201 8466 8801 9948  
滿 懣 滿 漫 饜 饜 鰻 𩺰

JAPANESE PRONUNCIATION IS MARD

5149 5150  
磨 磨

JAPANESE PRONUNCIATION IS MATA

7773

俣

JAPANESE PRONUNCIATION IS MATSU

336

2511

6016

7233

末 抹 沫 秣

JAPANESE PRONUNCIATION IS ME

149

瑪

JAPANESE PRONUNCIATION IS MEI

1997

3471

3705

3748

3749

4203

4330

4874

6320

6608

醜 瞑 暝 明 盟 螟 鳴 謎 溟 迷

6609

6834

8299

8850

9388

迷 冥 銘 名 命

JAPANESE PRONUNCIATION IS MEN

1660

2299

2367

2368

8008

8839

10036

10148

棉 面 麪 麵 髒 免 緬 綿

JAPANESE PRONUNCIATION IS METSU

6117

滅

JAPANESE PRONUNCIATION IS MI

337 3435 8042  
未 味 魅

JAPANESE PRONUNCIATION IS MIN

3567 4502 9835  
眠 毘 民

JAPANESE PRONUNCIATION IS MIRIME/TORU

6611  
耗

JAPANESE PRONUNCIATION IS HITSU

5907 5909 5911 5913  
蜜 密 蜜 密

JAPANESE PRONUNCIATION IS MO

1438 2546  
模 摸

JAPANESE PRONUNCIATION IS MOCHI

9286  
勿

JAPANESE PRONUNCIATION IS MOKU

JAPANESE PRONUNCIATION IS MOKU

1381 3332 3402 4528 6075  
木 目 黙 默 沐

JAPANESE PRONUNCIATION IS MOMME

9295  
叻

JAPANESE PRONUNCIATION IS MON

2902 9671 9697 9722 10105  
扨 門 問 悶 紋

JAPANESE PRONUNCIATION IS MOU

51 52 732 1144 3373 4612 6064 7163 8694 8730  
耗 耗 耄 蒙 蒙 罔 濛 毛 朦 朦  
9035 9091 9490 10090  
猛 朦 孟 網

JAPANESE PRONUNCIATION IS MU

1058 2096 7108 9469 9479 9971  
夢 霧 無 矛 務 牟

JAPANESE PRONUNCIATION IS MYAKU

9193 9206 9207  
脉 脈 脈

JAPANESE PRONUNCIATION IS MYO/

1226 10406

茗 妙

JAPANESE PRONUNCIATION IS NCEN

7320

稔

JAPANESE PRONUNCIATION IS NA

1398 2311

柰 奈

7631 9230 9919

儼 那 那

JAPANESE PRONUNCIATION IS NAGI

9333

凧

JAPANESE PRONUNCIATION IS NAI

4613

内

JAPANESE PRONUNCIATION IS NAMAZU

8829

鯨

JAPANESE PRONUNCIATION IS NAN

JAPANESE PRONUNCIATION IS NAN

893 1017 1349 1444 1819 3640  
難 難 南 楠 軟 喃

JAPANESE PRONUNCIATION IS NATSU

2584  
捺

JAPANESE PRONUNCIATION IS NE

6867  
禰

JAPANESE PRONUNCIATION IS NEI

4280 5902 5903 6296 7601  
寧 寧 寧 寧 倭

JAPANESE PRONUNCIATION IS NEN

2611 2833 2878 6594 6794 7098 7134 7305 8851 9418  
拈 撚 捻 粘 燃 年 年 黏 然 念

JAPANESE PRONUNCIATION IS NETSU

643 727 2631 2781 6181  
執 執 捏 捏 涅

JAPANESE PRONUNCIATION IS NI

二<sup>2</sup> 弍<sup>4</sup> 貳<sup>61</sup> 弍<sup>146</sup> 尼<sup>9830</sup>

JAPANESE PRONUNCIATION IS NIKU

4614

肉

JAPANESE PRONUNCIATION IS NIN

4943 7194 7883 9278 10357 10365

認 壬 任 忍 妊 妊

JAPANESE PRONUNCIATION IS NIO

9307

匂

JAPANESE PRONUNCIATION IS NO

6210

濃

JAPANESE PRONUNCIATION IS NO/

320 1868 3662 3685 3998 4001 5721 5802 6208 9134  
瑙 囊 嚙 曩 農 農 惱 惱 濃 膿

9135 9164 9243 9974 10091 10092  
膿 腦 腦 能 納 納

JAPANESE PRONUNCIATION IS NYO/

8131

饒

9827

尿

JAPANESE PRONUNCIATION IS NYU/

8413 9301  
乳 入

JAPANESE PRONUNCIATION IS O

5688 5754 6021 6022  
快 懊 汙 汚

JAPANESE PRONUNCIATION IS OKU

5710 7834 8082 9145 9780  
憶 億 奧 臆 屋

JAPANESE PRONUNCIATION IS OMOKAGE

7869  
倅

JAPANESE PRONUNCIATION IS ON

4343 5037 5260 6192 6193 6724 7300 7304 9590 10070  
恩 音 瘟 温 温 焜 穩 穩 陰 緼

JAPANESE PRONUNCIATION IS O/

148 908 1394 1433 1436 1541 1593 1890 1891 1892  
王 鞅 枉 横 横 櫻 桜 鷗 歐 毆  
2413 2489 2490 2639 2940 3361 3506 3508 3646 3668  
殃 欧 毆 押 拗 旺 嬰 鸚 鴨 嘔

JAPANESE PRONUNCIATION IS O/

4340	4348	4751	4801	5205	5360	5400	5418	5434	5529
央	鶯	凹	謳	忒	應	庚	麤	麤	雍
6010	6367	6766	6787	6972	7271	8081	8639	8979	9342
汪	澳	鶯	燠	襖	秧	奧	往	狎	凰
9441	9442	9949	9951	10307					
翁	翁	凹	凹	媪					

JAPANESE PRONUNCIATION IS RA

89	1060	3098	4164	4505	4506	6941	8214
騾	蘿	騾	螺	羅	邏	裸	鑼

JAPANESE PRONUNCIATION IS RACHI

701	709
埒	埒

JAPANESE PRONUNCIATION IS RAI

39	940	958	1870	1876	1878	2049	2072	2209	2363
耒	蕾	萊	賴	賴	賴	來	雷	磊	來
2574	5231	5232	5633	6089	6092	6093	7114	7378	7379
搗	癩	癩	懶	瀨	瀨	瀨	耒	籟	籟
7788	8615								
佃	徠								

JAPANESE PRONUNCIATION IS RAKU

107	274	1132	1999	3115	6406	6797	8018	8038	10175
駱	珞	落	酪	駱	洛	烙	樂	樂	絡

JAPANESE PRONUNCIATION IS RAN

929	1319	1320	1463	1474	1738	1739	1900	1902	2562
藍	蘭	蘭	婪	攬	欄	欄	覽	覽	攬
4735	4976	4979	6095	6471	6810	6923	6986	7225	7380
嵐	巖	巖	濫	瀾	爛	襪	襪	乱	籃
8408	9058	9062	9692	10028					
亂	卵	卵	闌	纜					

JAPANESE PRONUNCIATION IS RATSU

1871	2686	2799	5044
刺	拉	捋	辣

JAPANESE PRONUNCIATION IS RATSU/

3664  
喇

JAPANESE PRONUNCIATION IS REI

302	424	1261	1400	2027	2031	2054	2074	2094	2129
玲	隸	荔	隸	麗	麗	靈	靈	零	厲

JAPANESE PRONUNCIATION IS REI

2130	2143	2206	2756	2963	3165	3176	4142	4236	4545
勵	勵	礪	揆	戾	齡	齡	蠣	蛉	罔
4720	5223	5780	6518	6880	6908	6909	7005	7087	7316
嶺	癘	怜	羚	禮	礼	礼	戾	冷	黎
7662	7663	7681	7961	8318	8444				
儷	儷	例	伶	鈴	鴿				

JAPANESE PRONUNCIATION IS REKI

1662	1812	2066	2131	2132	2265	2382	5240	6128
櫟	輓	靈	歷	曆	礫	歷	癩	瀝

JAPANESE PRONUNCIATION IS REN

348	422	844	892	1807	1808	4978	4980	4981	5194
輦	聯	聯	蓮	連	連	鸞	戀	寧	廉
5195	5388	5389	5725	6083	6705	7426	8154	8155	8159
廉	恋	孛	憐	漣	煉	簾	鏈	鍊	鍊
8252	8293	8365	8366	10023	10030				
鎌	鎌	斂	歛	練	練				

JAPANESE PRONUNCIATION IS RETSU

2406	2407	2408	6131	7057	9646
列	裂	烈	洌	冽	劣

JAPANESE PRONUNCIATION IS RI

212	238	338	1730	1919	3399	4039	4212	4489	4492
理	璃	釐	李	吏	里	哩	蛭	罍	罹
5001	5293	5489	6180	6277	6940	7255	7256	7257	7315
裏	痢	離	涖	漓	裡	利	梨	犁	犁
7431	7771	7889	8422	8795	8976	9823			
籬	俚	俐	狸	鯉	狸	履			

JAPANESE PRONUNCIATION IS RIKI

7382	9068
籟	力

JAPANESE PRONUNCIATION IS RIKU

9499	9917
陸	戮

JAPANESE PRONUNCIATION IS RIN

1321	1445	1828	1899	2061	2173	3833	5186	5228	5415
蘭	林	輪	臨	霖	厘	躡	廩	淋	麟
5431	5478	5716	6076	6438	6619	6752	7067	7068	7957
麟	吝	恪	淋	淪	鄰	燐	凜	凜	倫
8815	9549	9550	10193						
鱗	隣	隣	綸						

JAPANESE PRONUNCIATION IS RITSU

1937 5040 5638 8672  
栗 立 慄 律

JAPANESE PRONUNCIATION IS RO

85	99	994	1152	1681	1740	1793	2073	3094	3107
驢	馬	蘆	芦	櫓	櫓	轆	露	驢	馬
3210	3239	3240	3531	3921	3922	4024	5173	6167	6168
鹵	盧	顱	賂	路	鷺	艘	廬	瀘	濾
6712	6716	8942	8179	8698	8716	8734	8752	8793	8794
炉	爐	樓	鑪	艦	艦	艦	鱸	鱸	魯

JAPANESE PRONUNCIATION IS ROKU

916	1434	1455	1800	1801	2295	5183	5406	5422	6267
勒	麓	麓	輓	輓	碌	六	鹿	鹿	漉
6904	6910	8331	8340	9213					
禄	祿	録	録	肋					

JAPANESE PRONUNCIATION IS RON

4954  
論

JAPANESE PRONUNCIATION IS RO/

JAPANESE PRONUNCIATION IS RO/

165	233	249	250	610	611	729	1150	1551	1624
弄	瓏	瑯	琅	壠	壠	老	莨	樓	楼
1630	2007	2750	3897	4204	4205	4248	5092	5093	5094
榔	醪	撈	踉	螂	娘	蠟	龍	聾	聾
5099	5100	5101	5202	5203	5819	5914	5946	6251	6253
龕	聾	聾	廊	廊	勞	牢	窶	滝	瀧
6254	6325	6477	6478	6767	6999	7000	7001	7002	7424
瀧	浪	漏	漏	勞	朗	朗	郎	郎	籠
7425	7762	8344	9010	9147	9148	9507			
籠	儂	蠟	狼	朧	朧	陋			

JAPANESE PRONUNCIATION IS RU

275	3670	5259	8200	9056	9789	9813	10069
瑠	婁	婁	婁	留	屢	屢	縷

JAPANESE PRONUNCIATION IS RUI

3956	3972	3995	4759	4895	5262	5501	6140	6178	6327
壘	壘	累	誅	誅	療	羸	淚	泪	淚
6587	6588	10081							
類	類	縲							

JAPANESE PRONUNCIATION IS RYAKU

JAPANESE PRONUNCIATION IS RYAKU

2383 2684 3974 3975  
 曆 掠 略 畧

JAPANESE PRONUNCIATION IS RYO

3242 3243 4324 5452 5455 5456 7797 9707  
 盧 虜 呂 旅 旅 膺 侶 閏

JAPANESE PRONUNCIATION IS RYOKU

10206 10221  
 綠 綠

JAPANESE PRONUNCIATION IS RYO/

37	405	452	822	870	1420	1786	1787	2024	2026
鬣	聊	鬣	聊	菱	稜	輶	輶	兩	兩
2350	2587	3057	3387	3439	3518	4252	4853	5018	5019
遼	撩	鬣	瞭	量	瞭	嘒	諒	亮	亮
5238	5868	5994	6243	6415	6596	6605	6610	6710	7003
療	寮	寥	涼	梁	糧	料	糧	燎	良
7052	7066	7235	7661	7677	8441	8967	8999	9046	9416
凌	涼	稜	倆	僚	領	獠	獵	獵	令
9487	9500	10015	10040						
了	陵	綾	繚						

JAPANESE PRONUNCIATION IS RYU/

239	1691	1692	2247	5074	5091	5098	5315	5448	5979
琉	榴	柳	硫	竜	龍	龍	瘤	旒	隆
6280	6408	6599	7422	9060	9579				
流	溜	粒	笠	劉	隆				

JAPANESE PRONUNCIATION IS SA

209	1077	1536	1756	2117	2253	2288	2890	2893	2987
瑣	蓑	查	梭	友	磋	砂	叔	叔	邪
3188	3397	3723	3892	4291	4446	4896	6078	6462	6463
些	早	嘎	蹉	嗟	唆	詐	渣	沙	裳
6534	7195	7420	7640	7667	8182	8018	9484	9623	10202
差	乍	蓑	做	佐	鎖	鮓	叉	叉	紗

JAPANESE PRONUNCIATION IS SAI

476	478	594	615	1211	2016	2220	2246	2282	2500
栽	載	哉	裁	菜	再	砌	碎	碎	才
2676	2798	2961	3162	3163	3190	3400	3424	3451	3971
摧	採	妻	歲	歲	砦	最	最	晒	顛
5115	5471	5837	5839	5895	6255	6275	6740	7576	7805
齋	齋	寨	賽	宰	濟	濟	焯	債	催
7837	8391	8392	8421	8531	8859	8953	9133	9573	9782
倅	采	彩	豺	采	祭	猜	腮	際	犀

JAPANESE PRONUNCIATION IS SAI

10076 10438

細 災

JAPANESE PRONUNCIATION IS SAKAKI

1629

神

JAPANESE PRONUNCIATION IS SAKU

1379 1561 1697 1954 1990 2728 3169 3277 3326 3709

索 柵 柵 醋 酢 搾 齧 鑿 削 昨

4576 5957 6670 6672 6777 7351 7385 7884 8144 9291

冊 窄 朔 槲 炸 簣 策 作 錯 冊

JAPANESE PRONUNCIATION IS SAN

3 225 350 352 853 969 1265 1392 1509 1676

三 珊 贊 蚕 蒜 散 苳 棧 棧 杉

1818 2009 2959 3221 3222 3870 3926 4641 4898 5085

鑿 酸 盞 祭 餐 跚 跚 山 讚 産

5472 5797 5800 6715 7209 7404 7405 7406 7407 7586

産 慘 慘 燦 贊 算 筭 筭 纂 爨

8267 9292 9424 9672 9964 9982 10167

鑽 刪 傘 閃 參 參 纜

JAPANESE PRONUNCIATION IS SASA

7371  
竹世

JAPANESE PRONUNCIATION IS SATSU

1286	1793	1754	2545	2632	2634	2726	2944	4269	5105
薩	札	紮	撒	撮	撮	擦	抄	囃	颯
5925	7406	9378	9379	9805					
察	劄	殺	殺	刷					

JAPANESE PRONUNCIATION IS SE

976  
世

JAPANESE PRONUNCIATION IS SEI

277	278	281	282	321	391	394	505	514	728
青	青	靜	靜	井	聖	聖	正	政	勢
742	760	761	762	797	800	845	977	1479	1510
壻	声	聲	聲	聖	聖	菁	貫	栖	棲
1875	1949	1969	2077	2455	2456	2692	2813	2814	3191
整	西	醒	霽	成	盛	擠	誓	逝	背
3355	3365	3366	3404	3611	3707	4110	4761	4762	4813
晴	晴	晴	眦	嘶	星	蜻	請	請	誠

JAPANESE PRONUNCIATION IS SEI

5041	5042	5111	5112	5113	5114	5449	5481	5599	5600
靖	靖	齊	齋	齋	齋	旌	齊	情	情
5736	5931	6012	6013	6572	6573	7058	7097	7101	7116
性	穽	清	清	精	精	淒	生	甥	制
7117	7118	7147	7530	7835	8605	8778	9131	9149	9645
製	掣	聾	牲	儕	征	鯖	腥	臍	省
10354	10393								
姓	媿								

JAPANESE PRONUNCIATION IS SEKI

213	714	719	795	886	1091	1668	2151	2167	2208
責	赤	螯	藉	昔	蓆	析	感	石	碩
3817	3881	3886	5136	5277	5387	5613	5647	5804	5805
蹟	蹠	跡	席	瘠	迹	惜	憾	鵲	脊
6350	6396	7232	7344	7345	7824	8202	8592	8844	9085
瀉	汐	積	籍	籍	隻	錫	斥	夕	腊
9998	10366								
績	媳								

JAPANESE PRONUNCIATION IS SEN

829	933	991	1098	1224	1703	1768	1844	1846	1855
尠	茜	苫	薦	蘚	栓	亘	專	輓	專

JAPANESE PRONUNCIATION IS SEN

1939	1940	2060	2197	2424	2425	2443	2685	2747	2915
遷	遷	霰	磚	殲	殲	燹	擅	掬	撰
2972	3014	3198	3501	3815	3851	3900	4076	4169	4224
扇	戩	占	賤	踐	踐	跣	戰	蟬	蟾
4953	5036	5037	5268	5310	5457	5460	5812	5857	5942
詮	顫	氈	疝	癬	旃	旋	戰	宣	穿
6008	6138	6146	6339	6428	6482	6531	6661	6662	6663
淺	淺	潛	洗	染	潺	羨	煎	剪	翦
6776	7026	7193	7207	7396	7442	7469	7470	7482	7485
煽	扇	千	先	箋	箭	籤	籤	筌	簽
7578	7658	7718	7729	7736	7804	7882	8033	8121	8173
倩	僊	戩	僭	川	仙	仟	泉	錢	錢
8266	8269	8278	8313	8461	8526	8717	8722	8753	8758
銑	銛	釧	銓	餞	饌	船	船	船	船
8804	8811	9202	9383	9558	9641	9705	9725	9846	9847
鱻	鮮	腺	餼	阡	尖	闡	閃	選	選
10006	10007	10150	10161	10162	10314				
織	織	線	織	織	嬋				

JAPANESE PRONUNCIATION IS SENCHIGURAMU

2998  
醜

JAPANESE PRONUNCIATION IS SENCHIMETORU

6585

糲

JAPANESE PRONUNCIATION IS SENCHIRITTOR

5054

喱

JAPANESE PRONUNCIATION IS SETSU

687	2098	2518	2519	2538	2691	2809	2924	2980	4415
截	雪	攝	撮	攝	接	折	拙	切	啜
4881	4951	4992	5940	5941	5968	6057	6058	7497	7498
說	設	藝	窈	窈	竊	泄	滌	節	節
9377	9784	10019	10072	10201					
刹	屑	紕	綫	綫					

JAPANESE PRONUNCIATION IS SHA

688	689	691	692	715	718	1092	1491	1769	2322
者	者	煮	煮	赭	赦	蔗	柘	車	奢
2867	2868	4886	4913	5138	5919	6102	6108	6109	6300
捨	捨	這	謝	遮	寫	洒	灑	灑	瀉
6466	6833	6853	6854	7099	7629	8089	8346	8853	9365
娑	写	社	社	卸	借	射	斜	灸	舍

JAPANESE PRONUNCIATION IS SHA

9368 9374 9422  
 斜 舍 舍

JAPANESE PRONUNCIATION IS SHAKU

1256 1696 2000 3175 3437 4137 4345 4432 5292 6800  
 芍 杓 酌 齧 晰 蜥 嚼 呖 癩 灼  
 8287 8395 8396 8544 8546 9272 9831 10056 10388  
 鑠 爵 爵 釋 釈 勺 尺 綽 灼

JAPANESE PRONUNCIATION IS SHI

19 38 90 92 366 382 512 641 644 676  
 髭 肆 駛 駟 示 士 址 執 執 志  
 817 1149 1156 1464 1574 1575 1673 1674 1764 1765  
 斯 芝 茨 枝 柿 梓 梔 梔 支 翅  
 2022 2182 2276 2435 2447 2675 2929 3005 3040 3058  
 刺 廁 砥 死 豕 揣 指 至 髭 肆  
 3099 3101 3160 3164 3166 3187 3189 3194 3196 3197  
 駛 駟 止 齒 齒 此 柴 雌 鬣 紫  
 3340 3602 3855 3948 3970 4098 4102 4339 4394 4441  
 师 嗜 趾 嘴 思 嗣 嗤 只 史 嗤  
 4549 4590 4763 4773 4780 4892 4957 4970 5039 5121  
 四 幟 試 詩 誌 諮 諡 詞 市 啻

JAPANESE PRONUNCIATION IS SHI

5179	5214	5248	5464	6011	6295	6675	6679	6739	6869
廁	痣	疵	施	漬	滓	茲	孳	熾	祉
6870	6876	6877	6901	6905	6907	6998	7076	7077	7078
祉	視	視	祇	祀	祠	之	瓷	咨	資
7081	7093	7140	7224	7328	7462	7609	7653	7769	7929
恣	姿	矢	舐	私	篩	仕	使	使	侈
7968	8058	8095	8111	8527	8528	8802	9015	9048	9052
仔	師	伺	俟	飼	飼	鯤	獅	氏	鴟
9095	9238	9376	9488	9609	9763	9777	9812	9833	9840
肢	脂	弒	子	孜	尸	屍	屎	咫	巳
9880	9898	9941	9958	10179	10222	10228	10229	10329	10392
弛	司	旨	厶	紙	絲	糸	絲	姉	姉
10426									
始									

JAPANESE PRONUNCIATION IS SHICHI

2975  
七

JAPANESE PRONUNCIATION IS SHIKI

305 4855 8922  
式 識 色

JAPANESE PRONUNCIATION IS SHIME

8113

夕

JAPANESE PRONUNCIATION IS SHIN

122	137	141	143	144	145	825	827	932	1082
駸	秦	辰	唇	蜃	脣	甚	斟	蕈	薪
1140	1153	1303	1304	1356	1388	1390	1451	1831	1896
晋	芯	真	真	蓼	榛	榛	林	軫	臣
2053	2063	2112	2114	2115	2116	2507	2576	2605	3013
震	震	辰	唇	蜃	脣	振	振	搢	晋
3128	3357	3374	3474	3485	3495	3579	4051	4922	4923
駸	晨	瞋	晨	賑	賑	申	呻	識	識
4959	5043	5047	5049	5328	5620	5621	5827	5861	5880
診	辛	親	新	疹	慎	慎	宸	宸	寢
5894	5921	6321	6331	6467	6474	6499	6502	6636	6878
寢	審	深	沁	津	浸	滲	滲	糝	神
6879	6953	7030	7157	7386	7398	7776	7819	7820	7825
神	襯	心	矧	箴	簪	伸	進	進	信
8015	8086	8128	8163	10020	10051	10066	10256	10288	
侵	身	針	鍼	經	縉	紳	娠	娠	

JAPANESE PRONUNCIATION IS SHITSU

155	156	1515	1641	4147	4223	4444	5289	5876	6081
瑟	瑟	桎	櫛	蛭	蟋	叱	疾	室	漆
6191	6201	7141	8545	8595	9094	9339	9953	10335	
湿	濕	失	悉	質	膝	蝨	虱	嫉	

JAPANESE PRONUNCIATION IS SHO

697	1000	1053	1074	1565	1631	2970	3252	3351	3410
翦	苴	薯	諸	櫛	杵	所	處	且	暑
3411	3674	4233	4469	4470	4709	4710	4781	4782	5137
暑	曙	蛛	署	署	嶼	嶼	諸	諸	庶
5669	5749	6032	6977	7321	8691	8948	9541	9658	10013
悄	憔	渚	初	黍	所	処	障	書	緒
10014									
緒									

JAPANESE PRONUNCIATION IS SHOKU

397	803	1442	1443	2360	2400	2401	2509	3491	4424
職	職	植	植	嗇	殖	殖	拭	贖	唧
4427	4430	4500	6732	7245	7266	8448	8471	8493	8494
囑	囑	蜀	燭	穡	稷	食	蝕	飾	飾
8032	8897	8898	9421	10097					
鯽	觸	觸	食	織					

JAPANESE PRONUNCIATION IS SHO/

138	387	388	497	957	1024	1070	1071	1186	1497
春	聶	顛	墻	蕃	菖	蔣	蔣	蕉	檣
1521	1531	1578	1655	1682	1721	2069	2227	2228	2263
椒	梢	樟	樵	椽	松	霄	硝	硝	礁
2384	2601	2847	2892	2899	2922	3307	3308	3313	3315
匠	捷	招	拯	抄	摺	尚	尚	嘗	賞
3319	3320	3322	3324	3327	3332	3333	3396	3582	3608
裳	掌	嘗	肖	道	將	獎	睫	聶	聶
3620	3652	3659	3711	3750	3751	3902	4014	4053	4292
喋	昌	晶	昇	昭	照	躑	哨	唱	咲
4420	4626	4628	4635	4637	4638	4639	4677	4774	4870
嘯	牀	牆	將	醬	獎	漿	峭	証	詳
4941	4960	4961	4962	5052	5058	5063	5109	5119	5126
詔	訟	證	誦	竦	章	彰	妾	商	庄
5142	5159	5176	5213	5270	5631	5709	5878	5879	6071
床	廂	廠	症	瘴	悚	憧	宵	宵	瀟
6158	6159	6174	6175	6411	6520	6601	6693	6694	6782
涉	涉	消	消	沼	翔	粧	燒	燒	焦
6890	6891	7212	7243	7216	7302	7445	7451	7747	7749
祥	祥	升	秤	称	稱	笙	笑	倘	償

JAPANESE PRONUNCIATION IS SHQ/

7752	7781	7816	7892	8132	8185	8226	8271	8273	8325
俏	倡	焦	傷	鉦	銷	鐘	鍬	鍾	鈔
8504	8579	8623	8653	8660	8661	8662	8663	8714	8750
餉	頌	徜	衝	從	聳	聳	慇	艘	艘
8808	8838	8904	8980	8981	9187	9188	9250	9559	9639
鱒	象	觴	猖	猩	勝	勝	召	陞	小
9643	10182	10306							
少	紹	娼							

JAPANESE PRONUNCIATION IS SHU

31	251	410	518	534	832	833	836	837	840
鬚	珠	取	趣	趨	取	聚	聚	聚	聚
841	1594	1632	1720	2419	3051	3532	4772	4785	4990
娶	棕	株	梭	殊	鬚	調	諏	諏	主
5873	6103	6349	6648	7113	7160	7295	7880	8682	9197
守	酒	洩	首	朱	手	種	侏	須	腫
9306	9354	10032							
鄒	爰	繻							

JAPANESE PRONUNCIATION IS SHU-

1995  
醜

JAPANESE PRONUNCIATION IS SHUKU

2150	3154	3876	5918	6153	6884	6885	9332	9668	9669
蹙	叔	蹴	宿	淑	祝	祝	夙	肅	肅
10118									
縮									

JAPANESE PRONUNCIATION IS SHUN

128	135	136	3133	3522	3523	4747	5108	5799	6501
駿	春	蠢	駿	瞬	瞬	峻	竣	俊	浚
7902	8112	9977							
雋	俊	浚							

JAPANESE PRONUNCIATION IS SHUTSU

4188	4189	8079	9926
蟀	蟀	卹	出

JAPANESE PRONUNCIATION IS SHU/

64	411	414	419	639	1022	1164	1198	1547	1796
驟	聚	聚	娶	執	葺	萩	菟	楫	輯
1797	1986	2869	3075	3081	3269	4541	4749	4750	5031
輯	酬	拾	驟	驟	収	囚	收	収	就
5033	5097	5793	6157	6313	6523	6540	6639	6690	6946
鷲	襲	懼	洪	洲	羞	羞	苜	州	袖

JAPANESE PRONUNCIATION IS SHU/

6995	7282	7284	7286	7309	7758	7759	7812	7815	7821
褶	秋	毘	愁	秀	修	脩	集	誰	讐
7977	7978	8072	8272	8328	8692	8728	8816	8820	8940
臭	臭	衆	鏽	鏽	舟	舟	鱈	鯨	蝨
9002	9119	9121	9200	9244	9245	9305	9741	9914	9915
狩	周	週	腴	周	週	皺	帚	習	習
10176	10204								
終	繡								

JAPANESE PRONUNCIATION IS SHI

3509

賜

JAPANESE PRONUNCIATION IS SO

316	1225	1280	1461	1588	1850	2196	2542	3168	3423
素	蘇	蔬	楚	梳	甦	礎	措	齒	噤
4037	4152	4831	4924	5253	5412	5428	6177	6311	6595
咀	蛆	詛	訴	疽	麤	麤	沮	溯	粗
6671	6673	6873	6874	6895	7260	7708	8552	8624	8974
塑	朔	祖	祖	祚	租	鼠	俎	徂	狙
9195	9420	9432	9451	9452	9573	10061	10084	10302	
胙	倉	俎	踈	疏	阻	組	纛	俎	

JAPANESE PRONUNCIATION IS SUCHI

8060  
帥

JAPANESE PRONUNCIATION IS SOKU

1869	1872	1873	2149	2395	2655	3504	3982	5674	5836
束	速	速	戚	仄	捉	則	足	惻	塞
6184	6729	6784	7774	7790	8240	9755	9756		
測	烛	熄	側	促	鏃	即	即		

JAPANESE PRONUNCIATION IS SON

1505	1625	2660	3895	4295	5658	6643	6644	7611	9612
村	樽	損	蹲	尊	忖	尊	尊	孫	遜
9845									
巽									

JAPANESE PRONUNCIATION IS SOTSU

5196	5522	5524	5525
卒	率	率	率

JAPANESE PRONUNCIATION IS SD/

118	120	134	404	408	515	810	906	966	970
騷	騷	奏	聰	聰	走	聰	鞘	葬	藏

982	999	1002	1026	1069	1128	1260	1275	1470	1537
卅	莊	草	藪	莊	藻	葱	蒼	槽	相
1540	1711	1770	1862	1863	1864	1884	2021	2025	2062
想	槍	鞦	曹	遭	遭	喪	棗	匝	霜
2482	2643	2663	2773	2782	2817	2837	2891	2905	3125
爽	搜	操	插	搜	抓	扱	搔	掃	騷
3127	3275	3329	3330	3520	3661	3665	3666	3868	3888
騷	叢	壯	裝	贈	嘈	嗽	嗽	躁	踪
3917	3932	4083	4297	4623	4625	4920	5300	5326	5731
蹤	踰	噪	噌	壯	裝	諍	瘦	瘡	憎
5781	5813	5849	5856	5935	5936	5962	5983	6005	6137
愴	巢	宗	宋	竈	竈	窗	窓	湊	漕
6091	6288	6443	6559	6560	6581	6687	6728	6808	7254
漱	淙	滄	送	送	糟	曾	燥	炒	稍
7374	7468	7472	7495	7536	7822	7866	7867	8084	8220
竹相	箏	笊	箒	惣	雙	僧	僧	惣	鏘
8290	8319	8434	8447	8679	8725	8761	8921	9290	9485
錚	鎗	爭	創	爪	艙	艙	爭	惣	蚤
9624	9632	9633	9815	9816	10111	10153	10198	10287	10362
蚤	双	桑	層	層	綜	總	總	孀	嫂

JAPANESE PRONUNCIATION IS SO/

10430 10431 10432 10433

巢 剽 勦 勦

JAPANESE PRONUNCIATION IS SU

363 7503 9497 9501  
壽 筍 陬 陬

JAPANESE PRONUNCIATION IS SUBE

2102  
之

JAPANESE PRONUNCIATION IS SUI

6	226	1095	1980	2002	2783	3473	3480	4086	4355
彗	瑞	萃	醉	醉	推	睡	睢	雖	吹
4911	5003	5712	5955	6602	6622	6658	6659	6753	6792
誰	衰	悴	邃	粹	粹	遂	遂	燧	炊
7104	7240	7242	8261	8279	9090	9552	9557	9650	9910
垂	穗	穗	錘	錐	聩	隧	陞	水	翠
9927									
崇									

JAPANESE PRONUNCIATION IS SUN

2494  
寸

JAPANESE PRONUNCIATION IS SU/

130	1472	1504	3671	4693	4696	6638	9302	9303
寿	樞	枢	數	崇	嵩	数	匆	雛

JAPANESE PRONUNCIATION IS TA

713	733	1268	4283	4868	6305	7853	7858	8099	8861
塚	塚	茶	咤	詫	沱	佻	佻	他	多
9548									
陀									

JAPANESE PRONUNCIATION IS TAI

126	139	254	349	573	588	686	861	971	992
駘	泰	玳	替	戴	臺	堆	臺	帶	帶
1355	2057	2306	2309	2346	2436	2529	2935	3131	3273
苔	隸	耐	大	太	殆	擡	抬	駘	對
4025	5476	6056	6059	6988	7318	7642	7694	7695	7697
體	对	滯	滯	褪	頽	体	貸	黛	袋
8604	9233	9239	9351	9553	9554	9749	9750	9757	9758
待	腿	胎	颯	隊	隊	逮	逮	退	退
9970	9976								
怠	態								

JAPANESE PRONUNCIATION IS TAKU

9336

夙

JAPANESE PRONUNCIATION IS TAKU

178	179	1671	2272	2582	2669	2778	2812	2913	3199
琢	琢	析	礫	拓	擇	托	拆	扱	卓
3745	4857	4858	4904	5916	6223	6484	6497	8211	
啄	謫	譚	託	宅	澤	沢	濯	鐸	

JAPANESE PRONUNCIATION IS TAN

401	553	717	721	807	894	1572	1987	2629	2754
耽	坦	赧	赧	耽	歎	檀	醜	担	探
2622	3353	3517	3615	3622	4075	4298	4669	4670	4906
擔	旦	賺	嘆	嘆	單	啖	炭	炭	誕
4909	5056	5080	5254	5286	5686	5811	6042	6045	6101
誕	站	端	疸	痰	憚	單	湛	灘	潭
6232	6314	6391	6938	7144	7168	7415	7769	8276	9128
湍	淡	澹	袒	短	毯	簞	但	鍛	胆
9208	9273	9415	9445	10112					
膽	丹	貪	蛋	綻					

JAPANESE PRONUNCIATION IS TATSU

635 636 2530  
達 達 捷

JAPANESE PRONUNCIATION IS TEI

558	1159	1626	1690	1961	2086	2154	2248	2492	2633
堤	薙	梯	柢	酏	霆	遞	碇	丁	提
2766	2843	3202	3398	3409	3431	3454	3469	3644	3768
挺	抵	貞	呈	逞	鼎	鼎	睇	嚏	叮
3879	4211	4263	4580	4814	4859	5014	5120	5242	5354
蹄	蜓	啼	幘	訂	諦	亭	帝	疔	庭
5370	5732	5851	6135	6317	6642	6817	6819	6871	6872
底	悌	定	汀	涕	鄭	剃	鷄	禎	禎
7210	7262	7534	7742	7829	7937	8585	8713	8749	9053
廷	程	抵	偵	停	低	遞	艇	艇	邸
10098	10348								
締	娣								

JAPANESE PRONUNCIATION IS TEKI

596	1235	2693	2744	2921	3759	3894	5116	5117	5118
覲	荻	摘	擲	擢	剔	躑	適	適	敵
6256	6354	7412	8029	8230	8601	9008			
滴	滌	笛	的	鐫	彳	狄			

JAPANESE PRONUNCIATION IS TEN

280	347	354	473	1305	1757	1773	1782	1835	2082
靛	天	忝	填	顛	椽	軫	轉	輓	霑
2290	3206	3207	4002	4405	4521	4529	4646	4935	4945
碾	覘	点	典	唸	點	點	巔	諂	詔
5172	5178	5227	5741	6161	6289	6343	6640	7215	7505
店	廬	癩	恬	沾	淀	添	奠	甜	篆
7514	7786	9773	10037	10102					
忝	佃	展	纏	纏					

JAPANESE PRONUNCIATION IS TETSU

1802	2708	2810	3898	6281	7150	7151	8133	8263	8642
轍	撤	哲	跌	澈	迭	迭	鐵	鉄	徹
10297									
姪									

JAPANESE PRONUNCIATION IS TU

468	690	694	695	1404	1867	3492	3580	4508	4517
堵	覩	都	都	杜	蠹	賭	吐	圖	囑
5595	6258	6433	8055	8234	8607	9079	9268	9369	9370
斗	渡	塗	兔	鍍	徒	肚	兔	途	途
9581	9769	10289							
陶	屠	妬							

JAPANESE PRONUNCIATION IS TOCHI

1489

枋

JAPANESE PRONUNCIATION IS TOKU

325	1417	3155	4026	4776	6031	7317	7346	7399	7521
匿	積	督	觸	讀	瀆	禿	篤	篤	特
7522	7714	8610	8611	8625					
擯	牘	德	德	得					

JAPANESE PRONUNCIATION IS TON

329	4389	5024	6426	8589	9107	9108	9314	9315
井	噸	敦	沌	遁	遜	豚	屯	頓

JAPANESE PRONUNCIATION IS TOTSU

2041	3216	4100	4440	4847	5938	5939
凸	凸	呐	咄	訥	突	突

JAPANESE PRONUNCIATION IS TOI

186	190	472	617	1126	1170	1209	1239	1240	1467
鬪	鬪	塔	塘	蕩	董	荊	藤	藤	棟
1522	1552	1560	1667	1700	1722	1724	1725	1752	1842
棹	榻	桐	桃	桃	橙	桶	樋	櫂	東

JAPANESE PRONUNCIATION IS TO/

1912	1915	1917	2310	2318	2334	2516	2523	2535	2550
豆	頭	逗	套	套	套	擣	撓	擣	搭
2612	2788	2852	2864	3008	3137	3141	3316	3317	3321
掉	搗	掏	投	到	鬪	鬪	當	黨	党
3328	3769	3910	3939	4034	4151	4190	4484	4712	4815
当	吋	蹈	踏	骰	螳	蚪	罩	嶋	討
4918	4926	5233	5314	5405	5664	5863	6020	6025	6185
諂	謔	痘	疼	唐	悼	宕	濤	濤	湯
6186	6376	6390	6419	6604	6711	6807	6851	6852	6857
盪	滔	盜	淘	糖	灯	燈	禱	禱	禱
6936	7054	7079	7301	7303	7310	7311	7358	7419	7476
褱	凍	盜	稻	稻	透	透	等	筒	籐
7483	7489	7735	7833	7958	7998	8030	8320	8584	8939
答	筍	倒	僮	偷	島	兜	鐙	逃	冬
9070	9180	9181	9183	9185	9186	9322	9323	9459	9651
刀	騰	騰	騰	騰	騰	逃	逃	登	沓
9691	9890	10108	10400						
鬪	韜	統	帑						

JAPANESE PRONUNCIATION IS TO/GE

4673  
峽

JAPANESE PRONUNCIATION IS TSUI

1651 1664 8061 8062 8288 9556 10152  
椎 槌 追 追 鎚 墜 繼

JAPANESE PRONUNCIATION IS TSUJI

1380  
辻

JAPANESE PRONUNCIATION IS TSU/

5332 9463 9464  
痛 通 通

JAPANESE PRONUNCIATION IS U

368 369 370 854 2017 4335 5465 5850 8034 9903  
于 孟 迂 芋 雨 鳴 於 宇 烏 羽  
9904 10001  
羽 紆

JAPANESE PRONUNCIATION IS UN

44 373 855 1358 1968 2055 3703 5676 6827 6828  
耘 云 芸 蘊 醞 雲 暈 愠 運 運

JAPANESE PRONUNCIATION IS UTSU

1633 1716 1718  
榼 榼 榼  
鬱 鬱 鬱

JAPANESE PRONUNCIATION IS WA

4899 7258 7890  
話 和 倭

JAPANESE PRONUNCIATION IS WAI

2157 6727 7152 8982 9538  
歪 煨 矮 猥 隈

JAPANESE PRONUNCIATION IS WAKU

1851 1852  
或 惑

JAPANESE PRONUNCIATION IS WAN

1607 2250 4987 5396 6236 6265 9167 10117 10119  
椀 碗 彎 弯 灣 湾 腕 縮 縮

JAPANESE PRONUNCIATION IS YA

409 831 1406 2520 2540 3419 5177 7092 8568 8569  
耶 耶 椰 挪 挪 野 夜 冶 爺 爺  
9901  
也

JAPANESE PRONUNCIATION IS YAKU

1194 1197 1789 2457 2553 2916 3941 3945 4846 4966  
藥 藥 輓 厄 扼 搨 躍 躍 譯 詁

JAPANESE PRONUNCIATION IS YAKU

8315 9382 10185  
鑰 龔 約

JAPANESE PRONUNCIATION IS YO

3024 5809 7566 7570 7573 7575 7602 7604 7606 7702  
与 誉 輿 與 譽 歟 與 譽 歟 昇

8523 9366 9467 9468 9483  
餘 余 予 預 豫

JAPANESE PRONUNCIATION IS YOKU

2844 2953 6342 6382 8553 8554 9906 9907 9908 9909  
抑 弋 沃 浴 欲 慾 翼 翼 翌 翌

JAPANESE PRONUNCIATION IS YOI

878 1534 1542 1606 1609 1620 1621 1947 2213 2637  
葉 杳 楊 榕 榕 樣 樣 要 靨 揚

2712 2796 2835 2873 3291 3294 3775 3780 3935 4160  
擁 搖 搖 揄 耀 耀 曜 曜 踊 蠅

4161 4239 4915 4917 4934 5257 5279 5282 5352 5361  
蠅 蛹 謠 謠 謠 瘍 痒 癢 癰 鷹

5362 5402 5526 5527 5922 5953 5984 6302 6306 6450  
膺 庸 雍 壅 容 窠 窈 溶 洋 涌

JAPANESE PRONUNCIATION IS YO/

6508	6532	6543	6746	6747	6814	7510	7842	7859	8013
羊	恙	養	熔	熔	燿	夭	傭	佯	邀
8246	8855	8928	9098	9113	9535	10227	10358		
鎔	遙	孕	腰	用	陽	幼	妖		

JAPANESE PRONUNCIATION IS YU

1554	1708	1829	1830	4401	4908	4955	4956	5325	5778
柚	榆	輸	輸	喻	諛	諭	諭	癒	愉
5779	6203	7705	7712	8374	9400				
愉	油	臾	鼬	覷	愈				

JAPANESE PRONUNCIATION IS YUI

4322  
唯

JAPANESE PRONUNCIATION IS YU/

1894	1950	2168	2205	2393	2438	2468	2479	3794	4162
融	酉	右	憂	有	友	尤	雄	由	蚰
4184	4433	4753	4900	5241	5461	5462	5691	5869	6270
游	邑	幽	誘	疣	遊	遊	悒	宥	游
6864	6865	6973	7105	7668	7670	7680	7757	8538	9007
祐	祐	裕	郵	佑	優	侑	悠	糶	猶

JAPANESE PRONUNCIATION IS YU/

9453 9617 9975  
勇 又 熊

JAPANESE PRONUNCIATION IS ZA

2807 5363 8550  
挫 座 坐

JAPANESE PRONUNCIATION IS ZAI

1506 2152 3500 4482 4485 5110 5482 5485  
材 在 財 罪 罪 劑 劑 劑

JAPANESE PRONUNCIATION IS ZAN

1813 1814 1816 1817 2397 2404 2982 4649 4929 4931  
斬 斬 暫 慙 殘 殘 既 嶄 讒 讒  
5629 5758 5759 5959  
慚 懺 懺 竄

JAPANESE PRONUNCIATION IS ZE

3414  
是

JAPANESE PRONUNCIATION IS ZEI

290 623 1562 4175 4201 4314 7280 7281 7388  
贅 贅 杓 蚋 蛻 啞 稅 稅 筮

JAPANESE PRONUNCIATION IS ZEN

22	1063	3042	4104	4141	6085	6515	6526	6660	6883
髯	苒	髯	喘	蠕	漸	善	善	前	禪
6889	9171	9172	9175	9363	9364	10121	10122	10124	
禪	膳	膳	膳	全	全	繕	繕	繕	

JAPANESE PRONUNCIATION IS ZETSU

7213	10171
舌	絶

JAPANESE PRONUNCIATION IS ZO

3493  
贓

JAPANESE PRONUNCIATION IS ZOKU

1943	3488	3489	3564	4271	5430	7429	7916	9781	9818
粟	賊	賊	矚	嗾	族	簇	俗	屬	属
10010	10012								
續	続								

JAPANESE PRONUNCIATION IS ZON

2166  
存

JAPANESE PRONUNCIATION IS ZO/

652	653	943	3498	3519	5197	5728	7203	7204	7456
增	增	蔵	贓	贈	雑	憎	造	造	條
7923	9087	9088	9330						
像	臍	臍	雑						

JAPANESE PRONUNCIATION IS ZUI

1154	1155	4020	4022	5271	9510	9515
蕊	蕊	髓	髓	瘁	隨	隨

**KOREAN PRONUNCIATION**



KOREAN PRONUNCIATION IS A

782	978	1175	2983	2985	2986	3605	4146	4215	4819
亞	芽	莪	牙	雅	鴉	啞	蚱	蛾	訝
6680	7537	7538	7707	7896	8497	8498	8614	9506	10361
丫	我	鵝	兒	俄	餓	餓	衙	阿	娥

KOREAN PRONUNCIATION IS AE

773	1075	1266	2056	2230	2292	2577	2936	3382	3521
埃	藹	艾	霽	碍	礙	捱	挨	睚	曖
3760	4660	5020	6115	8398	9551	9973			
呃	崖	哀	涯	愛	隘	欸			

KOREAN PRONUNCIATION IS AEK

1789	2437	2593	2700	2746	5930	6259	9152	9517
軛	厄	扼	掖	搯	額	液	腋	阨

KOREAN PRONUNCIATION IS AENG

1541	3506	3508
櫻	嬰	鸚

KOREAN PRONUNCIATION IS AK

783	784	1040	2908	3178	4047	4048	4606	4731	4841
亞	惡	萼	握	齒	齧	鶚	幄	嶽	諤

KOREAN PRONUNCIATION IS AK

5685 7619 8803

愕 岳 鰐

KOREAN PRONUNCIATION IS AL

1311 1839 2075 2203 2558 3755 4760 9713

幹 軋 靄 憂 握 遏 訐 闕

KOREAN PRONUNCIATION IS AM

953 3692 4257 4531 4662 4688 4689 4854 5165 5265

菴 暗 喑 黯 岩 巖 巖 諳 庵 癌

9712

闇

KOREAN PRONUNCIATION IS AN

909 2385 2386 2387 2723 3563 3699 4658 5475 5997

鞍 雁 贖 鴈 按 眼 晏 岸 顏 安

5998

案

KOREAN PRONUNCIATION IS ANG

908 2413 3747 4340 4344 5688 7271 7938

鞍 殃 昂 央 盎 快 秧 仰

KOREAN PRONUNCIATION IS AP

KOREAN PRONUNCIATION IS AP

2212 2639 3646 8979  
壓 押 鴨 狎

KOREAN PRONUNCIATION IS BO/

9469  
矛

KOREAN PRONUNCIATION IS CHIA

1270 1769 2253 3187 3351 3892 4291 4699 5138 5281  
茶 車 磋 此 且 蹉 嗟 嗟 遮 瘥  
6534 7074 7466 7629 9484 9623  
差 次 劄 借 叉 叉

KOREAN PRONUNCIATION IS CHIAE

1030 1211 1227 2798 7576 8321 8324 8392 10155  
薑 菜 蔡 採 債 釵 釵 彩 綵

KOREAN PRONUNCIATION IS CHIAEK

213 704 1561 1697 3406 4210 7385 9291  
責 坼 柵 柵 嘖 蚱 策 冊

KOREAN PRONUNCIATION IS CHIAK

178 2655 2728 3277 5957  
琢 捉 搾 齧 窄

KOREAN PRONUNCIATION IS CHIAL

1753 1754 2726 2944 5925 9377  
 札 紮 擦 搽 察 刹

KOREAN PRONUNCIATION IS CHIAM

129 1813 1814 1817 1818 3134 4649 4724 4818 4922  
 駮 斬 斬 慙 慙 駮 嶄 嶄 讒 讒  
 4923 4929 4931 5056 5758 5759 5800 7729 8296 8298  
 讒 讒 讒 站 讖 讖 慘 僭 鏡 鏡

KOREAN PRONUNCIATION IS CHIAN

2765 2915 3221 4898 5959 6715 7209 7406 7407 7586  
 攢 撰 欸 讚 竄 燦 贊 纂 纂 爨  
 8267 8526  
 鑽 饌

KOREAN PRONUNCIATION IS CHIANG

1024 1275 1711 2879 3310 3637 3652 3659 4053 4996  
 菖 蒼 槍 搶 擎 暢 昌 晶 唱 莛  
 5063 5326 5598 5606 5662 5668 5983 6443 6550 7564  
 彰 瘡 悵 悵 悵 愴 窓 滄 莛 俚  
 7610 7738 7781 8447 8980 9072 9080 9114 9409 9420  
 俚 俚 倡 創 猖 脹 脹 脹 鬯 倉

KOREAN PRONUNCIATION IS CHIANG

10306

娼

KOREAN PRONUNCIATION IS CHIE

349	2057	2220	4025	4859	6056	6317	6817	7118	9749
替	雲	劬	體	諦	滯	涕	剃	掣	隸

10098

締

KOREAN PRONUNCIATION IS CHII

124	402	808	1159	1673	1674	1841	3009	3010	3011
馬	恥	恥	薙	梔	梔	輜	致	鷄	致
3129	3166	4102	4476	4477	4642	5212	5290	5350	6500
馬	齒	嗤	置	置	峙	痔	痴	癡	治
6739	6927	7155	7325	7638	7639	7929	8342	8599	9052
熾	禡	雉	穉	值	值	侈	鎚	卮	氏
9932	10049	10050	10194	10226					
蚩	緻	緻	絺	縑					

KOREAN PRONUNCIATION IS CHIK

1874	1877	3504
敕	勅	則

KOREAN PRONUNCIATION IS CH'IL

2975 6081  
七 漆

KOREAN PRONUNCIATION IS CH'IM

1628 2225 5894 6322 6474 8015 8128 8163 8330 9641  
枕 砧 寢 沈 浸 侵 針 鍼 鋟 尖

KOREAN PRONUNCIATION IS CH'IN

5047  
親

KOREAN PRONUNCIATION IS CH'ING

7243 7302  
秤 稱

KOREAN PRONUNCIATION IS CH'ID

33	533	906	1002	1186	1461	1521	1655	1737	1823
髻	超	鞘	草	蕉	楚	楸	樵	杪	輶
1954	1994	2196	2227	2263	2899	3053	3323	4014	4323
醋	醮	礎	硝	礁	抄	髻	肖	哨	噍
4677	4830	4912	5669	5749	6808	6977	7254	7816	7817
峭	誚	譙	悄	憔	炒	初	稍	焦	顛

KOREAN PRONUNCIATION IS CHID

7818 7903 8271 8430 10059  
雉 焦 鋏 貂 綃

KOREAN PRONUNCIATION IS CHIDE

227 1003 1006 2676 3400 3424 4711 7805  
璀 蕞 蕞 摧 最 最 崔 催

KOREAN PRONUNCIATION IS CHIDK

1301 4026 4427 4500 6732 7790 8898  
直 直 觸 觸 觸 蜀 燭 促 觸

KOREAN PRONUNCIATION IS CHIDN

1505 2494 2685 5658  
村 寸 擅 忖

KOREAN PRONUNCIATION IS CHIONG

106 404 662 810 1260 3114 3275 5896 5897 6831  
驄 聰 塚 聰 葱 驄 叢 寵 寵 冢  
8244 9290 10153  
銃 忽 總

KOREAN PRONUNCIATION IS CHIDK

974 2961 3252 5659 7058  
萋 妻 處 悽 淒

KOREAN PRONUNCIATION IS CHIOCK

2149 2582 2744 3759 3865 3894 5277 5680 5804 5805  
 戚 拓 擲 剔 踢 躑 瘠 惕 鶻 脊

6354 7824 7941 8592 9527 9831  
 滌 隻 倜 斥 陟 尺

KOREAN PRONUNCIATION IS CHIOCKL

1802 1834 2005 2041 2708 2810 2898 3216 8133 8642  
 輓 輓 醜 凸 撤 哲 掇 凸 鐵 徹

10201  
 綴

KOREAN PRONUNCIATION IS CHIOCKH

1679 4601 4935 4945 6018 6343 7215 7469 7470 7485  
 檐 檐 諂 諂 添 添 甜 籤 籤 簽

7514 8769 9383  
 忝 詹 僉

KOREAN PRONUNCIATION IS CHIOCKN

347 933 1098 1161 1940 3501 3851 4104 5942 6138  
 天 茜 薦 芊 遷 賤 踐 喘 穿 淺

7193 7578 7736 8033 8846 9558 9705  
 千 倩 川 泉 舛 阡 闡

KOREAN PRONUNCIATION IS CHIOKNG

277	278	386	790	845	3365	4110	4761	5127	6012
青	青	聽	聽	菁	晴	蜻	請	廳	清

KOREAN PRONUNCIATION IS CHIOKP

1774	2601	3503	3620	3951	3957	4579	4790	5109	7715
輒	捷	貼	喋	咕	疊	帖	諜	妾	牒

KOREAN PRONUNCIATION IS CHIU

111	534	835	838	839	910	1472	1504	1640	1651
馬	趨	聚	聚	聚	鞦	樞	樞	楸	椎
1664	1995	2651	2783	3119	4313	4772	4785	5412	5428
槌	醜	抽	推	駒	啾	諏	諏	麕	麕
7282	7446	7448	7495	8061	8261	8279	8779	8783	8816
秋	箠	筵	筵	追	錘	錐	魚	魚	魚
9302	9303	9305	9306	9555					
匆	雛	皺	鄒	墜					

KOREAN PRONUNCIATION IS CHIUK

1106	1798	2150	2444	2709	3876	5521	6884	7342	7362
蓄	軸	蹙	逐	摺	蹴	畜	祝	竺	築
9884	10118								
丑	縮								

KOREAN PRONUNCIATION IS CHIUL

4533 5626 9926  
黜 怵 出

KOREAN PRONUNCIATION IS CHIUN

135 1389  
春 椿

KOREAN PRONUNCIATION IS CHIUNG

1879 4035 4170 5006 5514 6202 7064 8653  
衷 忠 蟲 衷 充 沖 冲 衝

KOREAN PRONUNCIATION IS CHIUK

8820  
鯪

KOREAN PRONUNCIATION IS CHIUCK

5179 5674 6184 7774  
廁 惻 測 側

KOREAN PRONUNCIATION IS CHIUKN

1576 3179 6953  
親 齷 親

KOREAN PRONUNCIATION IS CHIUKNG

KOREAN PRONUNCIATION IS CHIUNG

3896 9816  
躐 層

KOREAN PRONUNCIATION IS CHIE

2154  
唬

KOREAN PRONUNCIATION IS CHA

19	528	688	715	1092	1491	1575	2022	2257	3040
鬚	趨	者	赭	蔗	柘	梓	刺	磁	鬚
3193	3194	3196	3197	3597	3856	4886	4892	5139	5291
訾	雌	觜	紫	嗜	趾	這	諮	鷓	疥
5988	6073	6312	6676	6677	6679	7076	7077	7078	7080
字	滋	滋	慈	鷄	孳	瓷	咨	資	柒
7081	7083	7322	7968	7972	8853	9488	9609	10392	
恣	姿	秭	仔	自	炙	子	孜	姊	

KOREAN PRONUNCIATION IS CHAE

476	478	594	615	1506	2016	2152	2500	3500	5114
栽	載	哉	裁	材	再	在	才	財	齎
5115	5895	6295	10438						
齎	宰	滓	災						

KOREAN PRONUNCIATION IS CHAENG

4718 4920 7468 8290 8434  
 崢 諍 箏 錚 爭

KOREAN PRONUNCIATION IS CHAK

924 1256 1637 2000 2269 3709 6777 6800 7884 8395  
 鵲 芍 柞 酌 斫 昨 炸 灼 作 爵

9272 9644 10056  
 勺 雀 綽

KOREAN PRONUNCIATION IS CHAM

934 1816 2982 3517 4739 6042 6146 6233 7386 7398  
 蘸 暫 蟻 賺 岑 湛 潛 涔 箴 簪

KOREAN PRONUNCIATION IS CHAN

1509 2404 2959 6482 9825  
 棧 殘 盞 潺 孱

KOREAN PRONUNCIATION IS CHANG

8 497 562 957 966 970 1069 1070 1071 1497  
 長 墻 場 蓄 葬 藏 莊 蔣 蔣 檣  
 1503 1578 2384 2461 2480 3032 3320 3484 3490 3498  
 杖 樟 匠 臧 丈 長 掌 賬 賬 贓

KOREAN PRONUNCIATION IS CHANG

3502	4567	4571	4577	4623	4625	4628	4629	4635	4637
賬	帳	帳	帳	壯	裝	牆	戕	將	醬
4638	4639	5058	5126	5270	6487	6488	6491	6601	8220
獎	漿	章	庄	瘡	漲	漲	漲	粧	鏘
8993	9088	9129	9541	9849	9851				
獐	臟	腸	障	張	張				

KOREAN PRONUNCIATION IS CHAP

2025	5197
匝	雜

KOREAN PRONUNCIATION IS CHE

558	1089	1626	1967	2077	2633	2692	3415	3416	3878
堤	薺	梯	醜	霽	提	擠	題	鴿	躋
3879	4781	5110	5111	5120	6255	6816	6819	7116	7117
蹄	諸	劑	齊	帝	濟	弟	鶻	制	製
7500	7835	8859	9149	9534	9573	9585	10133	10348	
第	儕	祭	躋	隄	際	除	緜	娣	

KOREAN PRONUNCIATION IS CHI

512	641	676	731	767	884	1149	1464	1556	1764
址	贄	志	耆	地	芟	芝	枝	枳	支

KOREAN PRONUNCIATION IS CHI

1791	2276	2525	2929	3005	3160	3855	3915	4209	4780
輕	砥	持	指	至	止	趾	躋	蚰	誌
6496	6901	6998	7146	7148	7224	7400	9095	9238	9783
池	祗	之	知	智	舐	箎	肢	脂	遲
9833	9941	10179							
尺	旨	紙							

KOREAN PRONUNCIATION IS CHIK

397	803	1300	1315	7266	10097
職	職	直	直	稷	織

KOREAN PRONUNCIATION IS CHIL

1097	1515	1809	3012	3898	4147	4444	4596	5289	5943
疾	桎	軼	邛	跌	蛭	叱	帙	疾	窒
7150	7294	7881	8595	10297	10335				
迭	秩	佚	質	姪	嫉				

KOREAN PRONUNCIATION IS CHIM

827	6843	9178
斟	鳩	朕

KOREAN PRONUNCIATION IS CHIN

137	303	473	536	812	816	1140	1303	1388	1390
秦	珍	填	趁	蓁	蓁	晋	真	榛	榛

KOREAN PRONUNCIATION IS CHIN

1831	2093	2063	2112	2114	2432	2507	2576	2605	3013
軫	震	震	辰	唇	殄	振	振	摺	晉
3374	3485	3495	3635	4959	5407	5423	6467	7819	8150
瞋	賑	賑	嗔	診	塵	塵	津	進	鎮
9502	9503	9667	10051						
陣	陳	盡	縉						

KOREAN PRONUNCIATION IS CHING

5307	6448	8631	8632
癥	澄	徵	懲

KOREAN PRONUNCIATION IS CHIP

639	642	1796	1797	6023	7812
執	執	輯	輯	汁	集

KOREAN PRONUNCIATION IS CHO

524	1128	1192	1308	1470	1862	1863	1990	2021	2542
趙	澡	薦	朝	槽	曹	遭	酢	棗	措
2663	3397	3440	3538	3544	3549	3636	3661	3751	3868
操	早	罌	眺	助	眺	嘲	嘈	照	躁
3914	3928	4083	4099	4232	4831	4939	4941	5458	5935
跳	跳	噪	吊	凋	詛	調	詔	旄	竈

KOREAN PRONUNCIATION IS CHO

5936	6067	6087	6215	6581	6595	6612	6728	6873	6897
竈	潮	漕	澡	糟	粗	糙	燥	祖	祧
6902	7007	7086	7203	7260	7472	7754	7979	8000	8292
祧	肇	凋	造	租	笊	條	阜	鳥	鈹
8305	8311	8581	8679	9122	9123	9124	9138	9319	9432
鈞	鈹	兆	爪	雕	鷗	彫	燥	兆	俎
9485	9533	9624	9858	9922	9930	10061	10431		
蚤	阻	蚤	吊	刁	糴	組	剿		

KOREAN PRONUNCIATION IS CHOE

4482	4485
罪	罪

KOREAN PRONUNCIATION IS CHOK

1100	3982	4271	5450	7429	8240
簇	足	嗾	族	簇	鏃

KOREAN PRONUNCIATION IS CHOL

2924	5196	8997
拙	卒	猝

KOREAN PRONUNCIATION IS CHON

2166	6643
存	尊

KOREAN PRONUNCIATION IS CHONG

1594	1720	3902	3917	5849	7295	8226	8273	8660	8663
棕	梭	踵	蹤	宗	種	鐘	鍾	從	慙
8940	9197	10111	10165	10176					
蝨	腫	綜	縱	終					

KOREAN PRONUNCIATION IS CHOK

691	865	1115	1419	1482	1631	1690	1726	2441	2843
煮	著	苧	楮	樗	杵	柢	杼	豬	抵
3515	4037	5253	5370	6133	6177	6516	7359	7826	7850
貯	咀	疽	底	潴	沮	羝	箸	儲	佇
7937	9051	9053	10115						
低	氐	邸	紕						

KOREAN PRONUNCIATION IS CHOCK

714	795	1235	2693	3488	3489	3881	3990	4857	5116
赤	藉	荻	摘	賊	賊	蹠	迪	謫	適
5118	5292	5877	6256	7232	7344	7412	8029	9008	9912
敵	癢	寂	滴	積	藉	笛	的	狄	翟
10331									
嫡									

KOREAN PRONUNCIATION IS CHOCL

687 2809 2980 5296 5968 7497 10171  
 截 折 切 癩 竊 節 絕

KOREAN PRONUNCIATION IS CHOCH

991 2082 3198 3206 4529 5172 6085 6594 7305 7473  
 苦 霑 占 覘 點 店 漸 粘 黏 簷

8792  
 鮎

KOREAN PRONUNCIATION IS CHOCH

1305	1703	1782	1835	1844	2071	2197	2290	2300	3793
顛	栓	轉	輓	專	電	磚	碾	覷	田
3684	3973	4002	4076	4664	4953	5036	5037	5178	5227
躔	畋	典	戰	顛	詮	顛	氈	塵	癩
5342	5457	5799	6476	6513	6640	6660	6661	6662	6663
癩	旃	悛	澱	羶	奠	前	煎	剪	翦
7396	7442	7505	7647	7786	7814	8173	8313	8461	9136
箋	箭	篆	傳	佃	雋	錢	銓	錢	腆
9363	9771	9773	10102						
全	殿	展	纏						

KOREAN PRONUNCIATION IS CHO<NG

281	321	505	514	1639	1875	1961	2086	2248	2492
靜	井	正	政	挺	整	酉	霆	碇	丁
2493	2766	3202	3431	3454	3768	3807	4113	4120	4580
頂	挺	貞	鼎	鼎	叮	町	蠶	蠶	幘
4774	4814	5014	5041	5042	5242	5354	5449	5599	5600
証	訂	亭	靖	靖	疔	庭	旌	情	情
5608	5851	6135	6378	6572	6642	6871	7210	7262	7742
怔	定	汀	淨	精	鄭	禎	廷	程	偵
7829	8132	8170	8245	8605					
停	鈺	釘	錠	征					

KOREAN PRONUNCIATION IS CHO<P

2691	4128	8784
接	蝶	鰈

KOREAN PRONUNCIATION IS CHU

93	134	251	515	1566	1632	2679	3102	3168	3532
馬	奏	珠	走	柱	株	拄	駐	齒	週
3821	3826	3827	3883	3977	4179	4208	4850	4894	4990
躄	躄	躄	躄	胄	蛀	蛛	註	誅	主
5128	5410	5426	5887	6103	6237	6647	6690	7113	7312
廚	塵	塵	宙	酒	注	迺	州	朱	稠

KOREAN PRONUNCIATION IS CHU

7355	7363	7640	7827	7880	8127	8137	8692	8728	9110
壽	壽	做	住	侏	鑄	鑄	舟	舟	肘
9119	9121	9659	10043	10075	10180				
周	週	晝	紂	紂	網				

KOREAN PRONUNCIATION IS CHUK

7227	7228	9867
竹	竹	粥

KOREAN PRONUNCIATION IS CHUL

1352  
茁

KOREAN PRONUNCIATION IS CHUN

128	136	1625	1652	3133	3895	4747	5108	6164	6357
駿	春	樽	榘	駿	蹲	峻	竣	濬	準
6501	6645	7069	7132	8112	8530	9977			
浚	遵	淮	罇	俊	餛	浚			

KOREAN PRONUNCIATION IS CHUNG

3792	7332	7785	8072
中	重	仲	衆

KOREAN PRONUNCIATION IS CHUCK

KOREAN PRONUNCIATION IS CHUCK

2395 4424 8832 9755  
仄 唧 鯽 即

KOREAN PRONUNCIATION IS CHUNG

653 1294 2892 3520 4961 5213 5731 6687 6689 9603  
增 蒸 拯 贈 證 症 憎 曾 甌 丞

10132  
緜

KOREAN PRONUNCIATION IS CHUCK

10067 10068  
緝 緝

KOREAN PRONUNCIATION IS CHWIAL

2632 2634  
撮 撮

KOREAN PRONUNCIATION IS CHWIE

1095 2675  
萃 揣

KOREAN PRONUNCIATION IS CHWI

64 290 410 411 414 419 518 623 832 833  
駮 贅 取 聚 聚 娶 趣 贅 取 聚

KOREAN PRONUNCIATION IS CHWII

836	837	840	841	1980	3075	3081	3948	4355	5031
取	取	取	取	醉	駮	駮	嘴	吹	就
5033	6792	7978	9090	9209	9910				
驚	炊	臭	滕	脆	翠				

KOREAN PRONUNCIATION IS CHWA

2117	2807	5363	7667	8550
左	挫	座	佐	坐

KOREAN PRONUNCIATION IS CHUCL

1641  
櫛

KOREAN PRONUNCIATION IS GHANG

9860  
張

KOREAN PRONUNCIATION IS HA

218	306	1179	1372	2070	2099	2140	2183	3566	3781
瑕	瑕	荷	下	霞	霞	厦	夏	遐	呀
4155	6242	6096	7128	7654	9260	9762			
蝦	蝦	河	罅	何	賀	遐			

KOREAN PRONUNCIATION IS HAE

KOREAN PRONUNCIATION IS HAE

96	963	964	1508	1514	1959	3104	3514	4028	4274
駭	薤	薤	楷	楷	醞	駭	賅	骸	咳
4816	4820	4865	5273	5515	5768	5822	6344	6346	7692
諧	諧	該	咳	亥	懈	害	海	海	偕
7732	8435	8780	8911	8913	9026	9608			
偕	奚	鮭	解	懈	獬	孩			

KOREAN PRONUNCIATION IS HAEK

1589	1945	5519
核	覈	劾

KOREAN PRONUNCIATION IS HAENG

637	1523	5610	7622	8602
幸	杏	悻	倖	行

KOREAN PRONUNCIATION IS HAI

8912  
解  
虫

KOREAN PRONUNCIATION IS HAK

3225	3230	4823	4825	5249	5250	6837	7594
虐	虐	謔	謔	瘧	瘧	鶴	學

KOREAN PRONUNCIATION IS HAL

KOREAN PRONUNCIATION IS HAL

1803 5823  
轄 割

KOREAN PRONUNCIATION IS HAM

980 981 1473 2136 3027 3211 3712 6150 8440 8515  
齒 齒 檻 咸 函 鹹 喊 涵 頷 餡  
8517 8657 8695 8731 9414 9574 9582  
餡 銜 艦 艦 含 陷 陷

KOREAN PRONUNCIATION IS HAN

852 1020 1312 1313 2508 3359 5671 5788 5843 6009  
邯 菟 翰 韓 扞 旱 悍 恨 寒 汗  
6044 6068 6842 7981 9038 9596 9689 9731 10410  
漢 澣 罕 鼾 狠 限 閑 閒 嫵

KOREAN PRONUNCIATION IS HANG

494 962 1587 1675 2704 5466 5628 6055 6272 6741  
項 巷 杭 桁 抗 亢 恒 港 沆 炕  
7120 7845 8708 8744 9078 10277  
缸 伉 航 航 肛 姪

KOREAN PRONUNCIATION IS HAP

4234 4397 6037 9380 9384 9685 9726  
蛤 哈 溘 合 盒 闔 閤

KOREAN PRONUNCIATION IS HENG

6766  
鶯

KOREAN PRONUNCIATION IS HIL

4775  
詰

KOREAN PRONUNCIATION IS HO

205	602	668	880	1078	1333	2314	3015	3254	3255
琥	壕	壺	葫	蒿	胡	瓠	互	虎	虎
3365	3789	4180	4347	4795	5013	5016	5619	6072	6241
昊	號	壕	呼	護	豪	毫	怙	湖	濠
6338	6364	6577	7004	7012	7018	7527	8011	8021	8224
浩	濔	糊	戶	扈	庠	犒	皜	皓	鎬
8455	8962	9019	9877	10096	10395				
餉	猢	狐	弧	縞	好				

KOREAN PRONUNCIATION IS HOE

1272	1707	2376	3496	3714	3715	4174	4507	4510	4618
薈	檜	灰	賄	晦	晦	蛔	回	迴	回
4811	5654	5705	5745	5747	6155	6356	8372	9227	9390
誼	恢	懷	悔	悔	濊	淮	劓	膾	會

KOREAN PRONUNCIATION IS HOE

10192

繪

KOREAN PRONUNCIATION IS HOEK

1236

獲

8961

獲

9662

劃

KOREAN PRONUNCIATION IS HOENG

1433

橫

1436

橫

7590

鬻

KOREAN PRONUNCIATION IS HOK

661

殼

1851

或

1852

惑

1991

酷

KOREAN PRONUNCIATION IS HOL

4548

囫

7481

笏

9288

忽

KOREAN PRONUNCIATION IS HON

375

魂

6189

混

6190

混

6218

溷

6318

渾

6721

焜

8464

餽

8465

餽

9049

昏

9730

閻

10386

婚

KOREAN PRONUNCIATION IS HONG

748 1055 3619 4112 4771 6033 6050 9882 10003  
永 薨 哄 虹 誼 鴻 洪 弘 紅

KOREAN PRONUNCIATION IS HOK

1751 3235 3238 3987 4893  
栩 虛 歔 噓 許

KOREAN PRONUNCIATION IS HOKL

3757  
曷

KOREAN PRONUNCIATION IS HOKM

112 3120 8985 8986 9031 9587  
馬 驗 獫 獫 獫 險

KOREAN PRONUNCIATION IS HOKN

1350 1771 3226 5825  
獻 軒 獻 憲

KOREAN PRONUNCIATION IS HU

699 1517 2004 2217 4326 4336 4925 5305 6211 7796  
堍 朽 酗 厚 嗅 喉 詬 瘼 涸 候  
8050 8503 8597 8678 9014  
候 餽 后 後 猴

KOREAN PRONUNCIATION IS HUN

576 1146 1172 1993 3703 3713 4910 6779 7339 9012  
塤 葦 薰 醺 暈 曛 訓 燠 勳 獯

KOREAN PRONUNCIATION IS HUKI

567 581 1326 2446 3227 3765 4116 4117 4258 6855  
喜 喜 熙 豨 戲 晞 嬉 嬉 噫 禧  
6856 7319 7337 7528 9392 10267 10268  
禧 稀 熙 犧 希 嬉 嬉

KOREAN PRONUNCIATION IS HUCK

4524

黑

KOREAN PRONUNCIATION IS HUKL

4317 4708 4905 7560  
吃 屹 訖 迄

KOREAN PRONUNCIATION IS HUCM

5068 8294 8765  
歆 欽 欠

KOREAN PRONUNCIATION IS HUCN

2815 3736 5340 7587 8596  
掀 昕 痕 覺 欣

KOREAN PRONUNCIATION IS HUKNG

7580

興

KOREAN PRONUNCIATION IS HUKP

4368 5777 6435 9389  
吸 恰 洽 翕

KOREAN PRONUNCIATION IS HWA

846 912 1207 1432 1859 4786 4899 6691 6881 7230  
華 靴 花 樺 画 譁 話 火 禍 禾  
7258 8104 8107 9661  
和 化 貨 畫

KOREAN PRONUNCIATION IS HWAK

2258 2635 2696 3444 4132  
確 攫 擴 矍 蠖

KOREAN PRONUNCIATION IS HWAL

2767 5824 6213 6340 8984 9716  
括 豁 滑 活 猾 闊

KOREAN PRONUNCIATION IS HWAN

223 1045 1466 1768 2831 2832 4072 4362 4363 4479  
環 歡 桓 亘 換 換 患 喚 喚 還

KOREAN PRONUNCIATION IS HWAN

5860 5890 5891 5992 6395 8805 8806 8960 9338 10189  
宦 逌 寰 迨 渙 鰈 鰈 穉 丸 紉

10231  
幻

KOREAN PRONUNCIATION IS HWANG

849 1105 3642 4123 4219 5617 5666 5690 5751 6043  
黃 荒 晃 蟻 蝗 慌 恍 恍 惶 潢

6220 6783 7368 7973 7974  
況 煌 簧 皇 遑

KOREAN PRONUNCIATION IS HWE

4448 7701  
喙 毀

KOREAN PRONUNCIATION IS HWI

2752 3290 3293 4969 5154 8638 9991  
揮 輝 輝 諱 麾 徽 彙

KOREAN PRONUNCIATION IS HWO<N

680 1113 3698 4277  
堊 萱 暄 喧

KOREAN PRONUNCIATION IS HYANG

KOREAN PRONUNCIATION IS HYANG

5022 7259 8097 8504 10236 10237 10238 10239  
享 香 向 餉 鄉 鄉 鄉 鄉  
音 嚮 食

KOREAN PRONUNCIATION IS HYE

6 7 897 923 1847 3911 4138 7713  
慧 鞋 蕙 惠 蹊 蟪 鼷  
彗

KOREAN PRONUNCIATION IS HYO

67 711 1553 1952 3078 3401 3599 3625 5199 6439  
馬 孝 枵 醜 馬 曉 哮 噓 效 洵  
7997 9431  
梟 爻

KOREAN PRONUNCIATION IS HYOKK

194 716 896 3145 5383  
鬪 赫 革 鬪 奕

KOREAN PRONUNCIATION IS HYOKL

60 5987 8066 9606  
韌 糸 穴 血 子

KOREAN PRONUNCIATION IS HYOKM

10346  
嫌

KOREAN PRONUNCIATION IS HYOKN

216	1908	3394	3395	3459	3570	3786	4154	4678	5274
現	賢	縣	懸	眩	懸	顯	蜺	峴	痲
5520	6282	6742	8709	8745	9864	10109			
玄	法	炫	舷	舷	弦	絃			

KOREAN PRONUNCIATION IS HYOKNG

327	328	331	4390	4605	5021	6733	6761	6763	8665
刑	型	形	兄	迴	亨	炯	螢	熒	衡

KOREAN PRONUNCIATION IS HYOKP

959	1701	1762	2373	2375	2589	4143	4668	5604	6127
莢	協	協	頰	夾	挾	蛟	峽	愜	浹
7679	8168	8969	9294						
俠	鉞	狹	脅						

KOREAN PRONUNCIATION IS HYU

2785	3250	7641
携	虜	休

KOREAN PRONUNCIATION IS HYUL

4963	5753	9473
譎	恤	鷓

KOREAN PRONUNCIATION IS HYUNG

6420 9219 9296 9436 9437  
 洵 胸 凶 凶 兇

KOREAN PRONUNCIATION IS I

2 01 384 1130 1325 1730 2051 2305 2341 2344  
 二 貳 耳 蒞 頤 李 爾 而 爾 爾  
 2974 3537 3803 4332 4754 5798 7307 8019 8529 9839  
 夷 貽 異 咿 以 怡 移 伊 飴 巳  
 9880 9944 9989 10295  
 弛 肄 彝 姨

KOREAN PRONUNCIATION IS IK

2953 5106 6655 9906 9908  
 弋 翊 益 翼 立

KOREAN PRONUNCIATION IS IL

1 656 3349 6309 7966  
 一 壹 日 溢 侑

KOREAN PRONUNCIATION IS IM

1191 6964 7194 7883 7885 8490 10357 10365  
 莅 社 壬 任 賃 飪 妊 姪

KOREAN PRONUNCIATION IS IN

483	917	1051	4089	4341	4943	5858	6098	6104	7178
堙	鞞	茵	咽	因	認	寅	湮	湮	氤
7562	7599	8854	9271	9278	9360	9859	10316		
仁	印	夤	刃	忍	人	引	姻		

KOREAN PRONUNCIATION IS ING

7199	7931	8928
剩	仍	孕

KOREAN PRONUNCIATION IS IO

9322  
洮

KOREAN PRONUNCIATION IS IP

9361  
入

KOREAN PRONUNCIATION IS K'OE

5789  
快

KOREAN PRONUNCIATION IS KA

284	570	586	931	1021	1245	1322	1476	1493	1694
珈	嘉	嘉	苛	葭	茄	葭	柯	榎	枷

KOREAN PRONUNCIATION IS KA

1784	1920	1921	1923	3658	3673	3776	3924	4087	4382
軻	可	哥	歌	暇	呵	暇	跏	𪔐	咖
4802	5870	7279	7611	7659	7775	7942	8039	8603	9251
訶	家	稼	佳	價	假	伽	假	街	加
9254	9255	9259	9261	9262	9403	10339			
駕	架	駕	袈	迦	个	嫁			

KOREAN PRONUNCIATION IS KAE

633	781	873	1276	1743	2952	4652	4654	4656	5327
垓	丐	蓋	芥	概	皆	豈	剗	凱	疥
5700	5786	5787	6528	7414	7793	7964	8221	9423	9677
愷	慨	慨	盖	箇	個	价	鎧	介	開
9837	9844								
改	改								

KOREAN PRONUNCIATION IS KAEK

4285	5929
喀	客

KOREAN PRONUNCIATION IS KAENG

631	5401	6530	6580	8157
坑	賡	羹	粳	鏗

KOREAN PRONUNCIATION IS KAK

664	778	1683	1685	2904	4369	5517	5769	7592	8892
殼	却	桷	桷	擱	咯	刻	恪	覺	角
8936	9084	9205	9729						
各	脚	腳	閣						

KOREAN PRONUNCIATION IS KAL

1034	2233	2647	3756	4064	4157	5071	6196	6512	6943
葛	碣	揭	鷓	喝	蝎	竭	渴	羯	褐

KOREAN PRONUNCIATION IS KAM

470	507	708	787	826	828	1410	1412	1426	1901
堪	敢	坎	甘	戡	勘	橄	橄	柑	監
1903	1953	2137	2579	3215	4644	5217	5646	6116	8156
鑿	酣	感	撼	鹵	嵌	疳	憾	減	鑑
9385	9386	10016	10034						
龕	龕	紺	絨						

KOREAN PRONUNCIATION IS KAN

147	163	333	895	1307	1309	1393	1538	3360	4805
干	槩	刊	艱	乾	幹	杆	桿	盱	諫
5338	5636	6472	7139	7348	7494	7798	8329	8432	8433
癩	慳	澗	看	竿	簡	侃	鋤	墾	懇

KOREAN PRONUNCIATION IS KAN

9074 9698 9759 10257 10427  
肝 問 良 奸 姦

KOREAN PRONUNCIATION IS KANG

925 1913 2402 4197 4610 4611 4765 5403 5714 6024  
薑 豇 彊 虻 岡 剛 講 康 慷 江  
6541 6545 6603 6992 7650 8216 9168 9578 9852 9854  
羌 姜 糠 襁 僵 鋼 腔 降 疆 彊  
9862 9883 10089 10174 10209  
強 彊 綱 絳 絳

KOREAN PRONUNCIATION IS KAP

1843 3577 4683 8199 9130 9699  
匣 甲 岬 鉀 胛 聞

KOREAN PRONUNCIATION IS KI

80 167 317 537 811 813 814 815 818 819  
騎 琪 璣 起 其 基 碁 碁 欺 碁  
820 821 948 1041 1429 1748 1759 1933 1935 2296  
期 碁 夔 蘄 棋 杞 機 羈 羈 磯  
2325 2326 2328 2555 3091 3158 3161 3602 3805 4061  
奇 碁 劓 技 騎 冀 歧 嗜 畸 器

KOREAN PRONUNCIATION IS KI

4063	4246	4648	4655	4666	4967	4989	5408	5424	5443
器	蟻	岐	覬	崎	記	譏	麒	麒	旗
5510	5511	5867	6337	6898	6900	6903	7185	7366	8521
棄	棄	寄	汽	祈	祇	祁	氣	箕	飢
8531	8587	8782	9223	9404	9752	9838	9843	10039	10208
饑	頹	鱒	肌	企	既	己	忌	綺	紀
10232	10233	10276							
畿	幾	妓							

KOREAN PRONUNCIATION IS KIK

3376  
啣

KOREAN PRONUNCIATION IS KIL

552	1413	2526	7616
吉	桔	拮	佶

KOREAN PRONUNCIATION IS KIN

1911  
𦉳

KOREAN PRONUNCIATION IS KO

578	587	683	707	739	879	1079	1295	1299	1327
瞽	鼓	考	考	考	苦	藁	菰	古	辜

KOREAN PRONUNCIATION IS KO

1330	1418	1422	1441	1568	1942	2313	2531	2532	2534
故	拷	拷	枯	槁	賈	劓	拷	拷	拷
4005	4133	4171	4353	5010	5011	5015	5161	5263	6065
固	蝮	蠱	呱	高	敲	膏	庫	痼	沽
6517	6529	6695	6928	7023	7024	7200	7275	7421	7637
殺	羔	烤	袴	雇	顧	告	稿	篙	估
7988	7989	7994	8067	9105	9224	9610	9824	10274	
阜	翱	阜	鞞	胯	股	孤	尻	姑	

KOREAN PRONUNCIATION IS KOE

604	698	1663	5752	5783	7197	7909	8048
壞	塊	槐	愧	怪	乖	傀	魁

KOREAN PRONUNCIATION IS KOEK

6649  
馘

KOREAN PRONUNCIATION IS KOENG

1781 5871  
轟 宏

KOREAN PRONUNCIATION IS KOK

659	1229	1230	1638	1686	3996	4062	4165	7205	8570
穀	斛	斛	桔	榘	曲	哭	蚰	鵠	谷

KOREAN PRONUNCIATION IS KOK

8899

斛

KOREAN PRONUNCIATION IS KOL

1039

膏

4016

骨

4031

6176

汨

KOREAN PRONUNCIATION IS KON

563

坤

655

壺

1544

棍

1545

棍

1794

輓

1795

輓

3558

昆

4036

困

4679

崑

5189

袞

5684

悃

6260

滾

8797

鯤

9703

閫

10082

綑

KOREAN PRONUNCIATION IS KONG

381

工

560

貢

682

攻

723

功

735

鞏

736

鞏

737

蛩

738

恐

951

共

960

恭

1414

楨

2544

拱

2727

控

5933

空

7436

筮

7633

供

7855

控

9438

公

9615

孔

KOREAN PRONUNCIATION IS KOK

770

去

1964

醵

2602

拒

2613

據

2973

巨

3229

遽

3836

距

3852

距

3942

踞

6141

渠

6702

炬

6713

炬

7571

舉

7574

舉

7605

舉

8051

倨

8174

鉅

8333

鋸

9775

居

KOREAN PRONUNCIATION IS KOKL

1592 7559 7926 8847  
杰 乞 傑 桀

KOREAN PRONUNCIATION IS KOKM

1222 1705 2871 4532 7954 8317 8367  
茨 檢 檢 黔 儉 鈴 劍

KUREAN PRONUNCIATION IS KOKN

3247 3249 4565 5840 7878 7976 8326 8644 9232 9657  
虔 虔 巾 蹇 件 健 鍵 愆 腱 建

KOREAN PRONUNCIATION IS KOKP

775 5611  
劫 怯

KUREAN PRONUNCIATION IS KU

75 109 181 666 1187 1246 1395 1500 1650 1695  
驅 駒 球 殼 舊 苟 構 樞 柏 枸  
1886 1890 1891 1892 2496 2497 2499 2561 2628 2848  
區 鷗 歐 毆 求 裘 救 摳 扣 拘  
3060 3086 3117 3261 3347 3383 3441 3487 3634 3668  
韭 驅 駒 韭 口 具 瞿 購 咕 嘔

KOREAN PRONUNCIATION IS KU

4217	4435	4801	5313	5846	5946	5977	6015	7143	7145
蚯	叩	謳	疚	寇	窶	究	溝	矩	矩
7165	7608	7652	7700	7704	7770	7949	8087	8304	8308
毬	丘	偃	臼	舅	俱	仇	軀	鈎	鈎
8626	8930	8941	9027	9252	9266	9308	9325	9343	9346
衢	久	灸	狗	句	劬	勾	九	鳩	颯
10262	10381								
媾									

KOREAN PRONUNCIATION IS KUK

919	1258	2369	2370	3943	4065	9828
鞠	菊	麴	麴	跼	國	局

KOREAN PRONUNCIATION IS KUL

2912	4741	5981	9829
掘	崛	窟	屈

KOREAN PRONUNCIATION IS KUN

5980	6826	6987	9743	9745	9746
窟	軍	裙	君	群	郡

KOREAN PRONUNCIATION IS KUNG

1345	5888	5964	5982	8094	9848
弓	宮	窮	穹	躬	弓

KOREAN PRONUNCIATION IS KUCK

1335 1341 1518 1733 2020 3228 8555 8556 9595 9820  
克 剋 極 極 棘 劇 卻 卻 隙 屐

KOREAN PRONUNCIATION IS KUCH

157 1447 2874 3648 6920 6981 8118 8284 9408 9413  
琴 禁 擒 噤 襟 衿 金 錦 禽 今  
9417  
衾

KOREAN PRONUNCIATION IS KUCN

887 888 889 914 1216 1435 1744 3940 4787 7477  
董 覲 勤 斬 芹 槿 根 跟 謹 筋  
7630 8586 8593 9604  
僅 斤 沂 豎

KOREAN PRONUNCIATION IS KUCNG

1337 2414 3182 9482  
競 互 肯 矜

KOREAN PRONUNCIATION IS KUCP

4728 6403 8915 8917 10170 10191  
岌 汲 及 急 級 給

KOREAN PRONUNCIATION IS KWA

1008	2665	2956	3434	3436	3438	3847	3863	4007	4008
菓	拐	戈	果	顆	夥	跨	踝	剛	過
4023	4193	4213	4809	4832	5002	5864	5945	7278	8687
髀	螺	蚪	誇	課	裹	寡	窠	科	瓜

KOREAN PRONUNCIATION IS KWAE

464	1539	2522	2524	4466
卦	棵	挂	掛	罨

KOREAN PRONUNCIATION IS KWAG

2244  
礦

KOREAN PRONUNCIATION IS KWAK

941	1569	1570	5029	5184	5236
藿	椴	櫛	郭	廓	癩

KOREAN PRONUNCIATION IS KWAL

403	809	7217	7449
聒	聒	刮	筈

KOREAN PRONUNCIATION IS KWAN

423	1043	1044	1116	1121	1601	1610	4066	5794	5854
款	觀	鸛	管	管	棺	棺	串	慣	寬

KOREAN PRONUNCIATION IS KWAN

5889	5991	6063	6824	7121	7434	7435	7437	7597	8115
官	官	灌	冠	罐	筧	管	管	盥	館
8116	8146	8476	8477	8478	8479	8533	8534	9738	9936
館	罐	館	館	館	館	館	館	關	貫

KOREAN PRONUNCIATION IS KWANG

9	612	1384	1529	3292	3398	3695	4936	5131	7343
匡	壙	框	桃	光	呈	曠	誑	廣	筐
8232	8951								
鑛	狂								

KOREAN PRONUNCIATION IS KWE

1469	1701	1826	1856	3918	4927	5682	6205	7499	8468
櫃	机	軋	匱	跪	詭	憤	潰	簞	饋
9324									
几									

KOREAN PRONUNCIATION IS KWI

3743	3952	8041	8059	8775	8776
晷	貴	鬼	歸		

KOREAN PRONUNCIATION IS KWOKL

956	2355	3849	8790	9718
蕨	厥	蹶	魚厥	闕

KUREAN PRONUNCIATION IS KWON

1042	1046	1439	1734	2740	3464	4539	6557	6561	6566
觀	勸	權	杈	捲	睽	圈	眷	拳	卷
7864									
倦									

KUREAN PRONUNCIATION IS KYE

57	334	1223	1396	1408	1838	3980	4766	4770	5742
契	戒	薊	械	桂	繫	界	誠	計	悸
6379	7020	7247	7323	7784	7951	8436	8437	9358	9457
溪	啓	稽	季	偈	係	雞	鷄	系	癸
9521	9523	9770	10224						
階	階	屈	繼						

KUREAN PRONUNCIATION IS KYO

102	459	504	1096	1173	1585	1627	1642	1799	2185
驕	翹	巧	茭	蕎	校	權	橋	較	磽
2779	3110	4182	4270	4704	5198	5201	7153	7512	7893
攪	驕	蛟	咬	嶠	交	郊	矯	喬	僑
8012	8475	8809	8998	9236	9397	10103	10359		
皎	餃	鮫	狡	膠	教	絞	嬌		

KOREAN PRONUNCIATION IS KYOCK

1661 1689 1837 6363 9096 9504 9505 9724 10149  
檄 格 擊 激 隔 隔 隔 闕 繳

KOREAN PRONUNCIATION IS KYOCL

4965 6002 6481 7133 9733 10008  
訣 潔 決 缺 闕 結

KOREAN PRONUNCIATION IS KYOCH

4878 5726 6665 6666 7390 8253  
謙 慊 歉 兼 拮 鎌

KOREAN PRONUNCIATION IS KYOCH

1064 1065 1475 1906 1932 1963 2345 3547 3806 3962  
爾 爾 榑 堅 甄 甄 犬 見 畎 遄  
3992 4837 4840 5523 6657 7025 7410 8788 8988 10078  
遄 譴 譴 牽 蠟 肩 筧 鯁 狷 繒  
10080 10085  
繒 絹

KOREAN PRONUNCIATION IS KYOCHG

41 269 400 609 763 765 806 1249 1250 1251  
耕 瓊 耿 境 磬 磬 耿 敬 驚 敬

KOREAN PRONUNCIATION IS KYONG

1252	1253	1254	1468	1792	1849	2198	2945	3017	3019
敬馬	警	擎	梗	輕	更	硬	頃	頸	徑
3020	3660	3687	5030	5072	5078	5245	5400	5438	5678
勁	哽	景	京	竟	競	瘥	庚	慶	憬
6769	7690	8106	8227	8619	8786	8807	9064	9112	9940
熒	傾	傾	鏡	徑	鯁	鯨	卿	脛	頃
10053									
經									

KOREAN PRONUNCIATION IS KYU

162	351	455	540	1281	2184	2319	2884	3553	3800
珪	規	圭	赴	葵	硅	奎	揆	睽	畦
3823	4295	4439	4714	5932	9680	10215	10216		
跬	虬	叫	巋	窺	閨	繆	糾		

KOREAN PRONUNCIATION IS KYUL

1728  
橘

KOREAN PRONUNCIATION IS KYUN

725	1062	8306	9282
均	菌	鈞	勻

KOREAN PRONUNCIATION IS MA

62	149	952	954	1093	2170	3073	5143	5144	5145
馬	瑪	莽	莽	蔴	碼	馬	麻	麻	磨
5152	5155	5156	5229	10255	10298				
摩	魔	魔	痲	媽	媽				

KOREAN PRONUNCIATION IS MAE

253	556	595	1031	1176	1177	1644	1645	1647	2087
玫	埋	賣	邁	莓	莓	枚	梅	梅	霉
2088	3375	4462	4483	4487	6394	6697	7546	7554	8042
霉	昧	罵	罵	買	浼	煤	每	每	魅
10263	10271								
妹	媒								

KOREAN PRONUNCIATION IS MAEK

1010	1012	2365	8419	9207
驀	驀	麥	貉	脈

KOREAN PRONUNCIATION IS MAENG

1033	3749	3784	3785	4187	5496	5498	9035	9490
萌	盟	甍	甍	虻	盲	蝨	猛	孟

KOREAN PRONUNCIATION IS MAK

KOREAN PRONUNCIATION IS MAK

1009 1015 5852 6061 8426 9089  
 莫 幕 寞 漠 藐 膜

KOREAN PRONUNCIATION IS MAL

336 848 2511  
 末 茉 抹

KOREAN PRONUNCIATION IS MAN

20 1027 1028 1820 1821 2829 3370 3675 3741 3830  
 曼 蔓 萬 輓 輓 挽 瞞 曼 晚 蹒  
 4834 4977 4987 5677 6047 6194 6236 8466 8801 9948  
 謾 蠻 彎 慢 滿 漫 灣 饅 鰻 𩺰

KOREAN PRONUNCIATION IS MANG

1104 1129 2193 4126 4127 4612 5492 5495 5503 5505  
 芒 茫 茫 蟒 蟒 罔 望 亡 忘 望  
 5506 5508 5718 8046 8147 10090  
 望 妄 忙 魍 鎗 網

KOREAN PRONUNCIATION IS MI

337 1219 1220 1749 3435 4874 5147 5148 5151 5171  
 未 薇 薇 楣 味 謎 靡 靡 糜 鹽  
 5414 5430 6527 6571 6608 8635 8636 9040 9817 9857  
 麩 麩 美 米 迷 徽 微 獮 尾 彌

KOREAN PRONUNCIATION IS MI

9893 10418  
眉媚

KOREAN PRONUNCIATION IS MIL

5907 5909 5911 5913  
蜜密蜜密

KOREAN PRONUNCIATION IS MIN

236 3567 4742 5785 6485 7548 7556 9706 9714 9722  
玫眠岷憫泯敏敏閩閩閩

9835 10207  
民緡

KOREAN PRONUNCIATION IS MO

51 52 732 794 1013 1016 1010 1019 1282 1438  
耗耗耄某暮募募慕茅模  
2371 2546 3576 3653 4583 4783 4792 5451 6576 7163  
麤摸眸冒帽謀謨旄糶毛  
7520 7807 7899 8425 9471 9934 9937 9971 10269  
牡侮侮貌彘母母牟姥

KOREAN PRONUNCIATION IS MOK

1001 1381 3352 3367 6075 7299 7531  
苜木目睦沐穆牧

KOREAN PRONUNCIATION IS MOL

2426 2428 6421  
歿 歿 沒

KOREAN PRONUNCIATION IS MONG

1058 1144 1458 3373 6064 8694 8730 9091  
夢 蒙 夢 蒙 蒙 蒙 蒙 蒙

KOREAN PRONUNCIATION IS MU

206 357 968 1157 2096 2359 2448 2760 2925 2927  
武 无 茂 蕪 霧 巫 戊 撫 拇 拇  
4810 7108 7109 7110 9055 9476 9479 9935  
誣 無 舞 舞 負 瞽 務 毋

KOREAN PRONUNCIATION IS MUK

4525 4528  
墨 默

KOREAN PRONUNCIATION IS MUL

7535 9286  
物 勿

KOREAN PRONUNCIATION IS MUN

4185 4384 5469 5490 9287 9671 9679 9686 9697 10105  
蚊 吻 文 紊 勿 門 聞 聞 問 紋

KOREAN PRONUNCIATION IS MYE

6991

袂

KOREAN PRONUNCIATION IS MYO

1011 1035 1213 1534 2547 3556 3746 5141 6188 7324

墓 苗 藐 杳 描 眇 昴 廟 渺 秒

8145 8417 8959 9065 9653 10406

鎬 貓 猫 卵 水 水 妙

KOREAN PRONUNCIATION IS MYO<K

8394

覓

KOREAN PRONUNCIATION IS MYO<L

1054 6117

蔑 滅

KOREAN PRONUNCIATION IS MYO<N

1660 2299 2367 2368 3740 4130 7924 8008 8839 8842

棉 面 麪 麵 冕 蟻 俛 髡 免 勉

10036 10148

緬 綿

KOREAN PRONUNCIATION IS MYONG

1226 1997 3471 3748 4203 4330 6320 6834 8299 8850  
茗 酉 名 暝 明 螟 鳴 溟 冥 銘 名  
9388  
命

KOREAN PRONUNCIATION IS NA

2520 2540 2846 2923 6582 7631 9230 9387 9919  
挪 挪 挪 挪 糯 儼 那 拿 那

KOREAN PRONUNCIATION IS NAE

1398 2306 2311 4613 6996 8923  
柰 耐 奈 內 能 乃

KOREAN PRONUNCIATION IS NAK

107 3115 4789  
駱 駱 諾

KOREAN PRONUNCIATION IS NAL

2584 2631  
捺 捏

KOREAN PRONUNCIATION IS NAM

929 1349 3640 3976  
藍 南 喃 男

KOREAN PRONUNCIATION IS NAN

717 721 893 3730 5653 6788  
赧 赧 難 暖 煖 煖

KOREAN PRONUNCIATION IS NANG

1868 3685 6240  
囊 曩 讓

KOREAN PRONUNCIATION IS NAP

6951 10091  
衲 納

KOREAN PRONUNCIATION IS NI

6483 9073 9830  
泥 膩 尼

KOREAN PRONUNCIATION IS NIK

325 6492  
匿 溺

KOREAN PRONUNCIATION IS NIL

3777  
昵

KOREAN PRONUNCIATION IS NO

KOREAN PRONUNCIATION IS NO

1151	2226	4456	5801	5802	10397	10398	10399	10400	10401
芦	碯	叟	惱	惱	奴	駑	駑	帑	怒
10403	10405								
努	弩								

KOREAN PRONUNCIATION IS NOE

2652	9243
搨	腦

KOREAN PRONUNCIATION IS NONG

3998	4001	6208	6210	9134	9135
農	農	濃	濃	膿	膿

KOREAN PRONUNCIATION IS NU

40	45
耨	耨

KOREAN PRONUNCIATION IS NUL

4100	4847
呐	訥

KOREAN PRONUNCIATION IS NUN

10278
嫩

KOREAN PRONUNCIATION IS NUCK

916  
勒

KOREAN PRONUNCIATION IS NUCNG

9974  
能

KOREAN PRONUNCIATION IS NYO

192 3143 7999 9827  
鬧 鬧 袅 尿

KOREAN PRONUNCIATION IS NYOK

10254  
女

KOREAN PRONUNCIATION IS NYOKM

2611 2878 9418  
拈 捻 念

KOREAN PRONUNCIATION IS NYOKN

7098 7134  
年 年

KOREAN PRONUNCIATION IS NYOKNG

KOREAN PRONUNCIATION IS NYOENG

1602 1603 5902 7601 9003  
檸檸寧佞獍

KOREAN PRONUNCIATION IS NYU

10212  
紐

KOREAN PRONUNCIATION IS NYUK

8078  
血丑

KOREAN PRONUNCIATION IS O

291	292	293	294	295	297	626	627	628	1471
齧	齧	齧	熬	遨	齧	齧	熬	遨	梧
1766	1880	3413	4172	4335	4457	4844	5418	5434	5634
五	吾	嗷	蜈	鳴	吳	誤	麇	麇	悟
5735	5754	5893	6021	6367	6787	7096	7579	7644	8034
忤	懊	寤	汙	澳	燠	午	傲	伍	烏
8082	10319								
奧	娛								

KOREAN PRONUNCIATION IS OE

1680 2267 3808 4068 4703 6727 8848 8982  
桅 魄 畏 喂 巍 煨 外 猥

KOREAN PRONUNCIATION IS OK

228 6342 8992 9780  
玉 沃 獄 屋

KOREAN PRONUNCIATION IS OL

2464  
兀

KOREAN PRONUNCIATION IS ON

1127 1968 5260 6192 7300 8800 10070  
蒞 醞 瘟 溫 穩 鯁 緼

KOREAN PRONUNCIATION IS ONG

2712 5352 5526 5527 5529 5531 9441 10435  
擁 癰 雍 壅 雍 養 翁 雝

KOREAN PRONUNCIATION IS OK

119 3126 4800 5272 5465 6392 8649 8650 8777  
馭 馭 語 瘳 於 漁 御 禦 魚

KOREAN PRONUNCIATION IS OKK

2844 5710 7834 9145  
抑 憶 億 臆

KOREAN PRONUNCIATION IS OKL

KOREAN PRONUNCIATION IS O<L

58 1203  
齧 孽子

KOREAN PRONUNCIATION IS O<M

1960 2337 2586 4057 4058 4481 6122 7794 7795 9693  
醜 奄 掩 嚴 嚴 罨 淹 儼 儼 閼

KOREAN PRONUNCIATION IS O<N

481 509 4757 4824 4864 5474 7649  
堰 焉 言 讞 諺 彥 偃

KOREAN PRONUNCIATION IS O<P

3271  
業

KOREAN PRONUNCIATION IS P'IA

304 743 1133 1347 1750 1925 2285 2672 2806 2919  
玻 坡 菠 芭 杷 叵 破 擺 播 把  
3933 4503 5347 5750 6388 6446 6447 7367 7502 8027  
跛 罷 疤 怕 派 波 婆 簸 筈 皤  
8539 8680 9449 9895  
番 爬 頗 巴

KOREAN PRONUNCIATION IS P'IAE

KOREAN PRONUNCIATION IS P'IAE

1936	2083	3483	3526	4798	5625	6107	6244	7298	7725
霸	霈	貝	敗	諄	悖	沛	沛	稗	牌
7950	9101	9144							
佩	肺	肺							

KOREAN PRONUNCIATION IS P'IAENG

584	4118	5023	6030	9082
彭	澎	烹	澎	膨

KOREAN PRONUNCIATION IS P'IAL

9362  
八

KOREAN PRONUNCIATION IS P'IAN

498	1499	1677	3497	5051	6552	7717	7727
坂	板	板	販	辦	判	版	版

KOREAN PRONUNCIATION IS P'II

2883	5330	6982	8670	9448	9592	9799
披	疲	被	彼	皮	陂	避

KOREAN PRONUNCIATION IS P'IL

1007	2139	2462	3425	3862	7031	7032	7491	9443	9856
華	膚	匹	畢	蹕	必	必	筆	足	弼

KOREAN PRONUNCIATION IS P'IP

1883 8575  
福 乏

KOREAN PRONUNCIATION IS P'IO

1123	1244	1262	1698	2015	2279	2304	2315	2568	2595
浦	葡	苞	袍	逋	砲	布	匏	捕	拋
2854	3655	3678	4097	4386	5175	5371	5652	6105	6422
抱	曝	哺	圃	咆	褒	庖	怖	浦	泡
6803	6978	7671	8160	8307	8518	8825	9099	9203	9220
炮	袍	佈	鋪	鈔	飽	鮑	脯	脬	胞
9248	9298								
匍	包								

KOREAN PRONUNCIATION IS P'IOK

3426 4575 6719  
暴 幅 爆

KOREAN PRONUNCIATION IS P'IUM

4073 5034  
品 稟

KOREAN PRONUNCIATION IS P'UNG

KOREAN PRONUNCIATION IS PIUNG

1702 3064 4950 9344  
 楓 豐 諷 風

KOREAN PRONUNCIATION IS PAE

492 608 1190 1490 2006 2607 2617 3062 3159 3263  
 坏 培 蓓 杯 配 排 排 輩 背 輩  
 3512 4998 6738 6932 7135 7739 7744 7832 9104 9540  
 賠 裴 焙 裨 拜 俳 俳 倍 胚 陪

KOREAN PRONUNCIATION IS PAEK

1492 1696 2169 7905 7971 8007  
 栢 柏 百 伯 白 帛

KOREAN PRONUNCIATION IS PAK

116 208 598 1124 1526 1528 2093 2569 2786 3123  
 駁 璞 博 薄 樸 朴 雹 搏 拍 駁  
 8016 8715 8751 9994 10031  
 迫 舶 舶 剝 縛

KOREAN PRONUNCIATION IS PAL

18 1377 1378 2592 2885 3039 3850 6074 6449 8152  
 髮 鶻 勃 拔 撥 髮 跋 渤 潑 鉢  
 8169 9461  
 鉢 發

KOREAN PRONUNCIATION IS PAN

237	259	1714	1715	2437	2439	2819	2820	4222	6307
斑	班	攀	攀	反	返	搬	搬	蟠	泮
6524	6538	7860	8459	8460	8558	8718	8720	8721	8754
半	叛	伴	飯	飯	頒	般	磐	盤	般
8756	8757	9174	10123						
般	般	胖	鮮						

KOREAN PRONUNCIATION IS PANG

23	461	462	618	1099	1581	1586	1635	2078	2144
髻	幫	幫	坊	芳	榜	枋	柳	霽	厖
2242	2471	3043	4106	4181	4207	4860	4863	5122	5439
磅	虯	髻	蚌	螃	蚌	謗	訪	旁	方
5459	6257	7017	7158	7836	7844	8641	8810	9150	9544
放	滂	房	邦	傍	倣	彷	魴	膀	防
10104	10336								
紡	妨								

KOREAN PRONUNCIATION IS PI

153	549	789	945	995	1195	1427	1507	1513	1840
毘	賁	匪	苾	菲	萆	榧	枇	枇	纒
2067	2068	2156	2158	2219	2264	2598	2603	2947	3059
霏	霏	丕	邳	砒	碑	批	批	比	非

KOREAN PRONUNCIATION IS PI

3063	3071	3072	3260	3264	3267	3268	3482	3505	3639
非	悲	非	非	非	悲	非	脾	鼻	鄙
3809	3810	4032	4822	4827	5167	5237	5304	6332	6333
毗	毘	髀	誹	誹	庇	痞	痺	泌	泌
6591	6893	6894	6971	7248	7292	7293	7634	7635	7691
糝	祕	祕	裨	糝	秘	秘	備	備	化
7731	7980	8020	9115	9117	9201	9234	9798	9803	9875
化	鼻	卑	腓	腓	脾	肥	譬	臂	費
9938	9955	9956	10054	10057	10293	10296	10368	10414	
匕	飛	飛	緋	緋	妣	妣	婢	妃	

KOREAN PRONUNCIATION IS PIN

25	990	1457	1600	1611	2415	2720	3045	3185	3223
鬚	蘋	彬	濱	濱	殯	擯	鬚	頻	豳
3938	5875	6160	6294	8559	9427	10116	10340		
嘖	賓	瀕	濱	邠	貧	繽	嬪		

KOREAN PRONUNCIATION IS PING

392	798	7046	7047	7061	7062	7089	9647
聘	聘	馮	憑	馮	憑	冰	冰

KOREAN PRONUNCIATION IS PO

KOREAN PRONUNCIATION IS PO

638	648	700	1083	1185	1785	2013	2978	3184	3280
報	報	埠	菩	葆	輔	甫	鵠	步	黼
4873	5833	6568	6924	6968	7384	7777	7778		
譜	寶	普	補	褫	簞	保	堡		

KOREAN PRONUNCIATION IS POK

1180	1783	1946	3289	3859	4214	6861	6965	6967	7264
苻	輻	覆	卜	蹼	蝮	福	複	袱	馥
7676	7745	8654	9141	9198	9235	9247			
伏	僕	復	服	腹	服	匐			

KOREAN PRONUNCIATION IS PON

1382  
本

KOREAN PRONUNCIATION IS PONG

132	460	1232	1387	2504	4231	4730	6796	7475	7568
奉	封	蓬	棒	捧	蜂	峰	烽	篷	俸
8300	8933	9331	10172						
鋒	逢	鳳	縫						

KOREAN PRONUNCIATION IS POKL

1649	4491	7453	7698	9723
棧	罰	筏	伐	闕

KOREAN PRONUNCIATION IS POKM

1136	1459	4602	6383	6430	6498	7375	9042	9337
范	梵	帆	泛	汎	汎	範	犯	凡

KOREAN PRONUNCIATION IS POKN

1131	1215	1713	4599	5453	6381	6709	6791	7550	7558
藩	蕃	樊	幡	旛	潘	煩	燔	繁	繁
8537	8540	9204	10159						
番	翻	幡	緡						

KOREAN PRONUNCIATION IS POKP

243	6036
珐	法

KOREAN PRONUNCIATION IS PU

103	346	522	850	1212	1666	1882	2014	2155	2159
駙	夫	赴	芙	苧	桴	副	敷	不	否
2366	2512	2687	3111	3244	3486	3494	3819	3907	4111
馱	扶	陪	駙	膚	賦	賻	跣	跗	蚨
4221	4319	4480	4828	5076	5079	5356	5357	5859	6377
蜉	咐	罟	訃	剖	部	府	腐	富	浮
7119	7439	7452	7660	7688	7840	7914	8002	8057	8125
缶	簿	符	傅	付	俯	俘	鳧	阜	鈇

KOREAN PRONUNCIATION IS PU

8566 8567 8571 8771 8821 9059 9063 9562 10411  
父 釜 斧 負 鮒 孵 孵 附 婦

KOREAN PRONUNCIATION IS PUK

3157  
北

KOREAN PRONUNCIATION IS PUL

2917 3281 5791 6493 6868 8063 9874  
拂 黻 怫 沸 袂 佛 弗

KOREAN PRONUNCIATION IS PUN

463 1277 1456 1460 1712 2095 2320 2358 2881 3589  
墳 芬 焚 焚 粉 雰 奔 奮 扮 噴  
4409 5609 6597 6624 7187 7615 9425 9426 9428 9430  
吩 憤 糞 粉 氛 憤 分 盆 盆 忿  
9963 10197  
畚 紛

KOREAN PRONUNCIATION IS PUNG

1693 2278 4732 9214 9215 10093  
棚 硼 崩 朋 鵬 繃

KOREAN PRONUNCIATION IS PYIAK

KOREAN PRONUNCIATION IS PYIAK

5744

復

KOREAN PRONUNCIATION IS PYIE

1210	1332	3295	3296	3303	3309	3728	5374	8376	9520
蔽	薜	敝	弊	幣	敞	吠	廢	敝	陛
9522	9695	9804							
陛	閉	嬖							

KOREAN PRONUNCIATION IS PYIO

76	276	1477	1696	1927	1928	1929	1930	3087	5637
驃	表	標	杓	票	剽	瓢	飄	騾	慄
6097	7577	8158	8431	8789	10029				
漂	俵	鏢	豹	鰲	縹				

KOREAN PRONUNCIATION IS PYION

911  
鞭

KOREAN PRONUNCIATION IS PYIONG

488	2047
坪	平

KOREAN PRONUNCIATION IS PYIOCM

KOREAN PRONUNCIATION IS PYIOCKM

3528

貶

KOREAN PRONUNCIATION IS PYIOCKN

100	3108	4206	7013	7014	7444	7648	7699	7875	10134
馬扁	馬騙	蝙	扁	編	篇	便	片	偏	編

KOREAN PRONUNCIATION IS PYIOCKNG

938	1125	4807
苹	萍	評

KOREAN PRONUNCIATION IS PYE

997  
𨾏

KOREAN PRONUNCIATION IS PYOCK

256	2100	5345	8052	9734	9792	9793	9794	9796	9802
珀石	霹	癖	僻	闢	辟	璧玉	壁土	甃瓦	劈刀

KOREAN PRONUNCIATION IS PYOCKL

3299	3300	3301	3302	3305	4381	8381	8382	8383
𨾏	𨾏	𨾏	𨾏	𨾏	𨾏	𨾏	𨾏	𨾏

KOREAN PRONUNCIATION IS PYOCKN

94	2103	2681	4982	4985	5000	5045	5048	5050	5053
駢	𨾏	𨾏	變	變	𨾏	辯	辯	辯	辯

KOREAN PRONUNCIATION IS PYOKN

5702 7459 7990 8536 9959  
怵 邊 邊 采 弁

KOREAN PRONUNCIATION IS PYOKNG

1480 2036 4993 4994 5081 5235 6548 6567 7544 7624  
柄 丙 并 瓶 竝 病 瓶 並 秉 兵  
7828 7863 8472 9806  
併 併 餅 屏

KOREAN PRONUNCIATION IS RA

1060 1871 4094 4164 4505 4506 5231 5232 5262 5633  
蘿 刺 囉 螺 羅 邏 癩 癩 療 懶  
6941 8214  
裸 鑼

KOREAN PRONUNCIATION IS RAE

956 2363  
萊 來

KOREAN PRONUNCIATION IS RAENG

7087  
冷

KOREAN PRONUNCIATION IS RAK

KOREAN PRONUNCIATION IS RAK

1132 1999 6406 6797 8038 10175  
落 酪 洛 烙 樂 絡

KOREAN PRONUNCIATION IS RAL

3664  
喇

KOREAN PRONUNCIATION IS RAM

1474 1902 2562 4735 6095 6923 7380 10028  
攬 覽 攬 嵐 濫 襪 籃 纜

KOREAN PRONUNCIATION IS RAN

1320 1590 1739 2903 4983 4984 5219 6235 6810 6986  
蘭 欄 欄 攔 鸞 鑾 癱 灑 爛 欄  
8408 9098 9062 9692  
亂 卵 卵 闌

KOREAN PRONUNCIATION IS RANG

250 1150 1630 3897 4204 5202 5203 6325 6999 7001  
琅 莨 榔 踉 螂 廊 廊 浪 朗 郎  
7291 9010 10352  
稂 狼 娘

KOREAN PRONUNCIATION IS RAP

KOREAN PRONUNCIATION IS RAP

2686 4248 8344 9241  
拉 蠟 蠟 臘

KOREAN PRONUNCIATION IS RI

212	338	341	1163	1919	2028	2173	3399	4039	4186
理	釐	釐	莉	吏	灑	厘	里	哩	螭
4492	5001	5293	5488	5489	5501	6180	7255	7256	7431
罹	裏	痢	離	離	羸	涖	利	梨	籬
7771	8047	8422	8795	8976	9823	9992			
俚	魑	狸	鯉	狸	履	彘			

KOREAN PRONUNCIATION IS RIM

1445 1899 2061 5228 6076  
林 臨 霖 淋 淋

KOREAN PRONUNCIATION IS RIN

1321 1805 5415 5431 5478 6752 8815 9550  
藺 麟 麟 麟 吝 燐 鱗 隣

KOREAN PRONUNCIATION IS RIP

5040 6599 7422  
立 粒 笠

KOREAN PRONUNCIATION IS RO

KOREAN PRONUNCIATION IS RO

543	729	994	1681	1793	2073	2615	3210	3239	3240
壚	老	蘆	櫓	轡	露	擄	鹵	盧	顱
3241	3243	3921	3922	5287	6124	6163	6716	6767	8179
顱	虜	路	鷺	癆	潦	滷	爐	勞	鑪
8793	8794								
鱸	魯								

KOREAN PRONUNCIATION IS ROE

1876	1878	1996	1998	2072	2209	3531	5914	6092	6093
賴	賴	酌	酌	雷	磊	賂	牢	瀨	瀨

KOREAN PRONUNCIATION IS ROK

1800	1801	2295	5406	5422	6910	8340	10221
輓	輓	碌	鹿	鹿	祿	錄	綠

KOREAN PRONUNCIATION IS RON

4954  
論

KOREAN PRONUNCIATION IS RONG

165	5092	5093	5094	5099	5100	5101	5187	5188	7424
弄	龍	龍	龍	龍	龍	龍	龐	龐	籠
7425	9542	9543							
籠	隴	隴							

KOREAN PRONUNCIATION IS RU

1025	1551	1624	3670	3956	3995	4156	5259	6327	6477
婁	樓	樓	婁	壘	累	螻	瘦	淚	漏
9507	9789								
陋	屢								

KOREAN PRONUNCIATION IS RUCK

9213  
肋

KOREAN PRONUNCIATION IS RUCKM

5185	5708	7067
廩	凜	凜

KOREAN PRONUNCIATION IS RUCNG

870	1420	1558	4643	7052	8781	9500	10015
菱	稜	楞	嶺	凌	鯨	陵	綾

KOREAN PRONUNCIATION IS RYAK

3974  
略

KOREAN PRONUNCIATION IS RYANG

1615	1616	1786	1787	2024	2684	3439	4853	5019	6243
樑	樑	輶	輶	兩	掠	量	諒	亮	涼

KOREAN PRONUNCIATION IS RYANG

6415 6596 7003 7066  
梁 糧 良 涼

KOREAN PRONUNCIATION IS RYE

1971 6880 7681  
醴 禮 例

KOREAN PRONUNCIATION IS RYO

405 822 1351 2350 3387 5238 5868 6605 6710 7677  
聊 聊 蓼 遼 瞭 療 寮 料 燎 僚  
9487  
了

KOREAN PRONUNCIATION IS RYONG

5091 5098  
龍 龍

KOREAN PRONUNCIATION IS RYOK

77 85 1168 1261 1740 2027 2031 2129 2130 2206  
馬 驢 藜 荔 櫚 麗 麗 厲 厲 礪  
3088 3089 3094 3242 4324 5173 5223 5455 5456 7005  
馬 驢 馬 慮 呂 廬 癩 旅 脅 戾  
7257 7316 7662 7663 9116 9707  
利 黎 儷 儷 臚 閤

KOREAN PRONUNCIATION IS RYO<K

1662 1812 2066 2265 2382 2383 9068  
樂 輓 靈 礫 歷 曆 力

KOREAN PRONUNCIATION IS RYO<L

2406 2407 2408 7057 9646  
列 裂 烈 冽 劣

KOREAN PRONUNCIATION IS RYO<M

2324 5194 5195 6261 7426 8365  
奩 廉 廉 濂 簾 斂

KOREAN PRONUNCIATION IS RYO<N

348 422 844 892 1478 1807 2567 4980 4981 6083  
輦 聯 聯 蓮 棟 連 棟 戀 孿 漣  
6705 8159 8785 10030  
煉 鍊 鱧 練

KOREAN PRONUNCIATION IS RYO<NG

302 1484 2074 2094 4375 4545 4720 5780 6442 6518  
玲 檯 靈 零 另 囹 嶺 伶 冷 羚  
7961 8318 8441 8446 9416  
伶 鈴 領 翎 令

KOREAN PRONUNCIATION IS RYOKP

37 432 3057 3950 9046  
鬚 鬚 鬚 躡 獵

KOREAN PRONUNCIATION IS RYOK

6168  
濾

KOREAN PRONUNCIATION IS RYU

239 275 1037 1692 2247 3959 4972 5448 6280 6408  
琉 瑠 藁 柳 硫 纍 謬 旒 流 溜  
6588 8339 9056 9060 10081  
類 鏗 留 劉 縲

KOREAN PRONUNCIATION IS RYUK

5183 9499 9917  
六 陸 戮

KOREAN PRONUNCIATION IS RYUL

1937 7055 8672  
栗 凜 律

KOREAN PRONUNCIATION IS RYUN

1828 6438 7957 10193  
輪 淪 倫 綸

KOREAN PRONUNCIATION IS RYUNG

5336 9577  
癡 隆

KOREAN PRONUNCIATION IS SA

38	92	382	500	718	817	1134	1535	1619	1622
肆	馬四	士	寺	赦	斯	莎	查	槎	槎
1665	1756	1924	2288	2322	2435	2867	2880	2987	3058
榭	梭	事	砂	奢	死	捨	捨	邪	肆
3101	3188	3509	3970	4098	4192	4394	4446	4549	4896
馬四	些	賜	思	嗣	蛇	史	唆	四	詐
4913	4970	5417	5433	5919	6078	6227	6300	6462	6465
謝	詞	麇	麇	寫	渣	泗	瀉	沙	鯊
6466	6853	6907	7103	7195	7328	7420	7462	7503	7609
娑	社	祠	卸	乍	私	簞	篩	筍	仕
7653	7808	8058	8089	8095	8346	8407	8527	8528	8621
使	似	師	射	伺	斜	辭	飼	飼	徙
9015	9365	9368	9422	9840	9898	10202	10222	10229	
獅	舍	斜	舍	巳	司	紗	絲	絲	

KOREAN PRONUNCIATION IS SAE

2342 5836 5839 8802  
璽 塞 賽 鯁

KOREAN PRONUNCIATION IS SAEK

1379 8922  
索 色

KOREAN PRONUNCIATION IS SAENG

7097 7100 7101 7445 7530  
生 菁 甥 笙 牲

KOREAN PRONUNCIATION IS SAK

3325 6670 6672  
削 朔 朔

KOREAN PRONUNCIATION IS SAL

1286 2545 8918 9378 9379  
薩 撒 煞 殺 殺

KOREAN PRONUNCIATION IS SAM

3 1265 1356 1451 1676 6502 9982  
三 芟 蔘 森 杉 滲 參

KOREAN PRONUNCIATION IS SAN

298 893 969 2009 4641 4849 5472 6230 7404 8453  
珊 蒜 散 酸 山 訕 產 汕 算 餓

9292 9424 10018  
刪 傘 繖

KOREAN PRONUNCIATION IS SANG

1537	1540	1682	1884	2062	2421	2482	3031	3307	3313
相	想	橡	喪	霜	殤	爽	上	尚	嘗
3315	3318	3322	3725	4627	4870	5119	5142	5159	5192
賞	常	嘗	晌	狀	詳	商	床	廂	庠
6079	6520	6890	7374	7749	7892	7923	8623	8838	8904
湘	翔	祥	箱	償	傷	像	徜	象	觴
9632	9633	10022	10287	10300					
双	桑	緗	孀	嫦					

KOREAN PRONUNCIATION IS SAP

982	2076	2773	5105	6156	6418	8270	8275
卅	霎	插	颯	澁	澀	錘	錘

KOREAN PRONUNCIATION IS SE

728	976	977	3163	6339	7280	10076
勢	世	貰	歲	洗	稅	細

KOREAN PRONUNCIATION IS SHI

366	871	1574	1765	1914	2447	2539	3189	3403	3414
示	著	柿	翅	豉	豕	撕	柴	時	是
3418	3611	4763	4773	4957	5039	5464	5607	6041	6876
匙	嘶	試	詩	諡	市	施	恃	澌	視

KOREAN PRONUNCIATION IS SHI

7140	7614	8421	8796	8953	9376	9763	9777	10079	10311
矢	侍	豺	鮒	猜	弑	尸	屍	總	媿
10426									
始									

KOREAN PRONUNCIATION IS SHIK

305	1442	1443	1772	2400	2401	2509	4855	6784	7991
式	植	植	軾	殖	殖	拭	識	熄	息
8471	8493	8494	9421						
蝕	飾	飾	食						

KOREAN PRONUNCIATION IS SHIL

4223	5876	5995	7141	8545					
蟋	室	實	失	悉					

KOREAN PRONUNCIATION IS SHIM

825	1153	5921	6301	6321	6331	7030	8830	9660
甚	苾	審	瀋	深	沁	心	鱗	尋

KOREAN PRONUNCIATION IS SHIN

141	144	1082	1896	1910	2039	2115	3357	3474	3536
辰	蜃	薪	臣	腎	迅	蜃	晨	晨	贐
3579	3677	4051	4806	5043	5049	5620	5621	5827	5861
申	晒	呻	訊	辛	新	慎	慎	宸	宸

KOREAN PRONUNCIATION IS SHIN

6111 6878 7776 7825 8086 10066  
汛 神 伸 信 身 紳

KOREAN PRONUNCIATION IS SHIP

380 2869 7607  
十 拾 什

KOREAN PRONUNCIATION IS SHOK

8974  
狙

KOREAN PRONUNCIATION IS SO

118	316	1225	1280	1318	1531	1588	1850	2069	2847
騷	素	蘇	蔬	蕭	梢	梳	甦	霄	招
2891	2905	3125	3127	3327	3423	3750	4420	4924	5069
搔	掃	騷	騷	逍	嗒	昭	嘯	訴	韶
5878	6071	6174	6311	6411	6671	6673	6693	7451	7493
宵	瀟	消	溯	沼	塑	朔	燒	笑	簫
8185	8691	9250	9270	9451	9452	9639	9643	10182	10225
銷	所	召	邵	疎	疏	小	少	紹	縹

10430  
巢

KOREAN PRONUNCIATION IS SOE

209 1567 5003 6108 6109  
瑣 穰 衰 灑 灑

KOREAN PRONUNCIATION IS SOK

1869 1872 1943 3491 7916 8893 9781 10010  
束 速 粟 贖 俗 觥 屬 續

KOREAN PRONUNCIATION IS SOL

5522 5524  
率 率

KOREAN PRONUNCIATION IS SON

2431 2660 9611 9612 9845  
殮 損 孫 遜 巽

KOREAN PRONUNCIATION IS SONG

15 138 1721 3037 4960 4962 5052 5631 5856 6559  
鬆 春 松 鬆 訟 誦 竦 悚 宋 送  
8579  
頌

KOREAN PRONUNCIATION IS SOK

226 742 1053 1479 1510 1949 2813 2814 2888 3674  
瑞 壻 薯 栖 棲 西 誓 逝 抒 曙

KOREAN PRONUNCIATION IS SO<

4314	4469	5137	5375	7388	7708	8189	8198	8348	8669
啞	署	庶	序	筮	鼠	鉏	鋤	叙	徐
9446	9658	10013	10199	10315					
胥	書	緒	紓	恕					

KOREAN PRONUNCIATION IS SO<<

886	1668	1669	1672	2167	2208	4137	5136	5613	6396
昔	析	皙	皙	石	碩	蜥	席	惜	汐
7710	8202	8544	8844						
鼯	錫	釋	夕						

KOREAN PRONUNCIATION IS SO<L

59	1200	1385	2098	4880	4951	4992	6057	7213	7565
契	薛	楔	雪	說	設	藝	泄	舌	僂
9784									
屑									

KOREAN PRONUNCIATION IS SO<M

2424	2425	3530	3720	4224	4926	9513	9519	9725	10006
殲	殲	贍	暹	蟾	譖	陝	陝	閃	織

KOREAN PRONUNCIATION IS SO<N

202	235	829	1224	2060	3900	4169	5310	5460	5857
璿	璇	甚	鮮	霰	跣	蟬	癩	旋	宣

KOREAN PRONUNCIATION IS SO<N

6290	6515	6526	6531	6533	6776	6883	7026	7207	7804
渲	善	善	羨	羨	煽	禪	扇	先	仙
8241	8266	8717	8753	8804	8811	8812	8813	8814	9171
銓	銑	船	船	鮮	鮮	鱻	鱻	鱻	膳
9172	9175	9202	9846	10113	10121	10122	10124	10150	10314
膳	膳	腺	選	緇	繕	繕	繕	線	嬋

KOREAN PRONUNCIATION IS SO<NG

391	394	499	761	762	797	800	1969	2455	2456
聖	聖	城	聲	聲	聖	聖	醒	成	盛
3707	4813	5736	8981	9131	9645	10354			
星	誠	性	猩	腥	省	姓			

KOREAN PRONUNCIATION IS SO<P

388	2518	2538	2922	3582	3608	3875	4883	6159	8129
聾	攝	攝	摺	聒	聒	躐	燮	涉	鑷
8141									
鑷									

KOREAN PRONUNCIATION IS SO/

3410	8345
暑	敘

KOREAN PRONUNCIATION IS SSANG

7822  
雙  
又

KOREAN PRONUNCIATION IS SSI

9048  
氏

KOREAN PRONUNCIATION IS SU

31	363	740	1026	1158	1198	1415	1829	1907	1909
鬚	壽	壽	藪	茱	菟	樹	輸	豎	豎
1986	1992	2064	2380	2419	2782	2800	3051	3473	3480
酉	酥	需	戍	殊	搜	授	鬚	睡	眈
3665	3671	4020	4080	4541	4749	4911	5300	5873	5955
嗽	數	髓	獸	囚	收	誰	瘦	守	濠
6335	6523	6540	6602	6648	6658	6753	6946	7104	7160
洙	羞	羞	粹	首	遂	燧	袖	垂	手
7240	7309	7758	7759	7815	8060	8400	8682	9002	9354
穗	秀	修	脩	讎	帥	受	須	狩	爰
9508	9510	9552	9650	10158	10204	10362			
隋	隨	隧	水	綏	繡	嫂			

KOREAN PRONUNCIATION IS SUK

986 3194 5027 5028 5918 6153 7756 9332 9669  
叔 叔 熟 熟 宿 淑 倏 夙 肅

KOREAN PRONUNCIATION IS SUL

1613 2146 8612  
述 戌 術

KOREAN PRONUNCIATION IS SUN

104 145 285 922 1248 1670 1977 2116 2427 3112  
駟 脣 珣 蕁 荀 楮 醇 脣 殉 駟  
3523 4852 4942 5025 6242 7480 7496 7743 8399 8664  
瞬 諄 詢 鶉 淳 筍 笋 順 舜 循  
8667 9253 10188 10439  
徇 旬 純 巡

KOREAN PRONUNCIATION IS SUNG

883 4696  
松 崇

KOREAN PRONUNCIATION IS SUKL

155 156 9094 9339  
瑟 瑟 膝 蝨

KOREAN PRONUNCIATION IS SU<NG

3711	4160	4161	7198	7212	7867	9187	9489	9559	9602
昇	蠅	蠅	乘	升	僧	勝	承	陞	丞
10073	10074								
繩	繩								

KOREAN PRONUNCIATION IS SU<P

5097	5793	6191	6201	6995	9914
龔	惛	濕	濕	褶	羽
衣					白

KOREAN PRONUNCIATION IS SWAE

3452	3453	8341	9805
曬	曬	鎖	

KOREAN PRONUNCIATION IS SWOE

2246  
碎

KOREAN PRONUNCIATION IS T'IA

82	97	733	1486	1612	2597	2777	3105	4081	4082
駝	駝	塚	檣	柁	打	拖	駝	鼉	鼉
4307	5644	8092	8099	8439	9509	9548	9561		
唾	惰	躡	他	妥	墮	陀	陀		

KOREAN PRONUNCIATION IS T'IAE

126	139	1355	2346	2436	3131	6123	6686	7504	9239
駘	泰	苔	太	殆	駘	汰	兑	咎	胎
9351	9970	9976							
颯	怠	態							

KOREAN PRONUNCIATION IS T'IAEK

2669	5916	6223
擇	宅	澤

KOREAN PRONUNCIATION IS T'IAENG

2621  
撐

KOREAN PRONUNCIATION IS T'IAK

1671	2778	2921	3199	3745	6224	6497	8213
柝	托	擢	卓	啄	濁	濯	鑷

KOREAN PRONUNCIATION IS T'IAL

2357	9191
奪	脫

KOREAN PRONUNCIATION IS T'IAM

401	807	2754	9415
耽	耽	探	貪

KOREAN PRONUNCIATION IS T'IAN

894 2412 4669 4670 4909 6045 7511 9861 10112  
歎 殫 炭 炭 誕 灘 吞 彈 綻

KOREAN PRONUNCIATION IS T'ANG

5863 6185  
宕 湯

KOREAN PRONUNCIATION IS T'AP

472 1552 2550 2650  
塔 榻 搭 搨

KOREAN PRONUNCIATION IS T'IO

383 1255 3580 4815 9268  
土 菟 吐 討 兔

KOREAN PRONUNCIATION IS T'IOE

686 7318 9233 9757  
堆 頹 腿 退

KOREAN PRONUNCIATION IS T'ION

6988  
褪

KOREAN PRONUNCIATION IS T'IONG

KOREAN PRONUNCIATION IS TIONG

5332 5697 7419 7934 9463 10108  
痛 恫 筒 佟 通 統

KOREAN PRONUNCIATION IS TIOK

2614  
攄

KOREAN PRONUNCIATION IS TIU

186 2310 2318 2334 2864 3137 4034 7310 7958 10289  
鬪 套 套 套 投 鬪 骰 透 偷 妬  
10353

KOREAN PRONUNCIATION IS TIUCK

7521  
特

KOREAN PRONUNCIATION IS TIUCKH

9674  
𠵼

KOREAN PRONUNCIATION IS TIUCKN

9696  
𠵼

KOREAN PRONUNCIATION IS TA

1731 1732 8861 9514  
 橢 橢 多 墮

KOREAN PRONUNCIATION IS TAE

254 573 588 861 971 2309 2529 3273 7693 7694  
 玳 戴 臺 臺 帶 大 擡 對 代 貸  
 7697 8604 9553 9554 9965  
 袋 待 隊 隊 台

KOREAN PRONUNCIATION IS TAL

635 898 2530 8963 8964 10303  
 達 韃 撻 獺 獺 妲

KOREAN PRONUNCIATION IS TAM

1987 2822 3470 4882 5286 6101 6314 6391 7168 9208  
 醜 擔 曇 談 痰 潭 淡 澹 毯 膽

KOREAN PRONUNCIATION IS TAN

553 606 1572 3353 4056 4075 5080 5264 6780 6938  
 坦 壇 檀 旦 團 單 端 癩 煨 袒  
 7144 7415 7569 7769 8276 9273 9445 10141 10234  
 短 簞 段 但 鍛 丹 蛋 緞 斷

KOREAN PRONUNCIATION IS TANG

617	2688	2703	3312	3314	3316	3317	3432	4151	4589
塘	撞	搪	堂	棠	當	黨	瞠	螳	幢
4829	5405	6266	6604	7747	8183	8184			
讜	唐	漘	糖	倘	鎗	鎗			

KOREAN PRONUNCIATION IS TAP

1209	3939	4486	4501	7483	9651	9652
刮	踏	逌	逌	答	沓	畱

KOREAN PRONUNCIATION IS TO

468	694	1259	1268	1522	1667	1700	1752	2516	2535
堵	都	萄	荼	棹	桃	桃	櫂	擣	擣
2612	2788	2808	2852	2858	3008	3492	3910	4508	4712
掉	搗	挑	搗	挑	到	賭	蹈	圖	嶋
5140	5664	5771	6020	6035	6258	6376	6390	6419	6433
度	悼	恸	濤	濤	渡	滔	盜	淘	塗
6651	6653	6852	6857	7303	7735	7761	7998	8234	8584
道	導	禱	禱	稻	倒	條	島	鍍	逃
8607	9070	9581	9684	9769	9890				
徒	刀	陶	閣	屠	韜				

KOREAN PRONUNCIATION IS TOK

310	311	313	314	1417	3155	4527	4776	6031	7317
毒	燾	毒	燾	櫛	督	黷	讀	瀆	禿
7346	7399	7522	7714	8990					
篤	篤	犢	牘	獨					

KOREAN PRONUNCIATION IS TOL

4440	5939
咄	突

KOREAN PRONUNCIATION IS TON

603	4389	4550	5024	6737	9029	9107	9108	9315
墩	頓	囤	敦	燉	狫	遜	豚	頓

KOREAN PRONUNCIATION IS TONG

1170	1467	1560	1842	3456	4564	5059	5314	5709	6228
董	棟	桐	東	瞳	同	童	疼	懂	洞
6248	7054	7333	8215	8939	9140	9275			
潼	凍	動	銅	冬	胴	彤			

KOREAN PRONUNCIATION IS TOKK

8610
德

KOREAN PRONUNCIATION IS TU

930 1404 1912 1915 1917 2716 5233 5595 8030  
荳 杜 豆 頭 逗 抖 痘 斗 兜

KOREAN PRONUNCIATION IS TUN

5975 8309 8589 9314 9772  
窀 鈍 遁 屯 臀

KOREAN PRONUNCIATION IS TUCK

8625  
得

KOREAN PRONUNCIATION IS TUKNG

1239 1722 6807 7358 7476 8320 9180 9183 9185 9459  
藤 橙 燈 等 籐 鐙 騰 騰 騰 登  
9460  
登

KOREAN PRONUNCIATION IS U

854 2017 2058 2168 2205 2438 2468 3173 3245 3684  
芋 雨 雩 右 憂 友 尤 齒 虞 愚  
4304 5241 5421 5437 5850 5885 7095 7105 7668 7670  
咩 疣 麁 麁 宇 寓 牛 郵 佑 優

AD-A040 796

RCA ADVANCED TECHNOLOGY LABS CAMDEN N J  
LANGUAGE MANUAL FOR USE WITH IDEOGRAPHIC COMPOSING MACHINES MOD--ETC(U)  
FEB 70

DAAG17-68-C-0064  
NL

UNCLASSIFIED

3 OF 3  
ADA  
040796



END  
DATE  
FILMED  
7-77

KOREAN PRONUNCIATION IS U

7783 8049 9536 9617 9903 10001  
偶 禹 隅 又 羽 紆

KOREAN PRONUNCIATION IS UI

8966  
猗

KOREAN PRONUNCIATION IS UK

2394 3691 6725 9335  
郁 昱 煜 旭

KOREAN PRONUNCIATION IS UL

1329 1633 1716 1718 9766  
蔚 鬱 蔚 蔚 尉

KOREAN PRONUNCIATION IS UN

373 835 939 2055 2411 5066 6827 9539  
云 芸 蕓 雲 殞 韻 運 隕

KOREAN PRONUNCIATION IS UNG

2479 9975  
雄 熊

KOREAN PRONUNCIATION IS UKI

657 1084 1495 2107 2157 2329 2930 4196 4867 4871  
壹 恣 蕙 椅 醫 歪 欵 擬 蟻 誼 議

KOREAN PRONUNCIATION IS UKI

5067	5089	5398	5881	6536	7526	7674	7841	7862	8711
意	毅	衣	宜	義	猗	倚	依	儀	艤
8747	9943	10128							
艤	疑	縊							

KOREAN PRONUNCIATION IS UCL

9947

乙

KOREAN PRONUNCIATION IS UCM

1291	2084	4403	5057	5269	6373	8507	8508	9590
蔭	霽	吟	音	瘖	淫	飲	飲	陰

KOREAN PRONUNCIATION IS UKN

4343	8332	8689	9569
恩	銀	殷	隱

KOREAN PRONUNCIATION IS UKNG

5360	5361	5362	7091
應	鷹	膺	凝

KOREAN PRONUNCIATION IS UKP

2640	2641	4433	5691	6221	6245
揖	揖	邑	悒	浥	泣

KOREAN PRONUNCIATION IS WA

1038 1897 1905 2995 4115 4166 4914 5947 5952 6212  
蒿 卧 臥 瓦 蛙 蝸 訛 窩 窪 渦

KOREAN PRONUNCIATION IS WAE

7152 7890  
矮 倭

KOREAN PRONUNCIATION IS WAL

3350  
臼

KOREAN PRONUNCIATION IS WAN

160 242 359 1109 1607 1916 2250 4191 5845 5926  
玩 琬 頑 莞 惋 碗 碗 蜿 完 宛  
6287 9167 9495 10154 10343  
浣 腕 阮 緩 婉

KOREAN PRONUNCIATION IS WANG

148 1394 3361 6010 8639  
王 枉 旺 汪 往

KOREAN PRONUNCIATION IS WI

1169 1346 2147 3978 4069 4163 4554 4609 6206 7329  
萎 葦 威 胃 喟 蝟 圍 幃 渭 委

KOREAN PRONUNCIATION IS WI

7330	7331	7831	7913	8065	8406	8677	8770	9765	9767
逶	魏	位	偽	偉	爲	衛	危	尉	慰
9886	9889	10214							
韋	違	緯							

KOREAN PRONUNCIATION IS WOCL

521	9071
越	月

KOREAN PRONUNCIATION IS WOKM

8867  
鴛

KOREAN PRONUNCIATION IS WOKN

358	477	592	593	851	1119	1228	1596	1776	2389
元	垣	遠	袁	芫	苑	苑	萱	轅	原
2390	2797	3961	4044	4511	4512	5924	6129	8390	8866
願	援	園	員	圓	園	冤	源	爰	怨
8955	9547								
猿	院								

KOREAN PRONUNCIATION IS WU

368	369	370
于	孟	迂

KOREAN PRONUNCIATION IS YA

409 821 950 1406 3419 5177 7092 9901  
耶 耶 惹 椰 野 夜 冶 也

KOREAN PRONUNCIATION IS YAK

947 1197 1359 3945 8315 9871 9872 10185  
若 藥 葯 躍 鑰 弱 弱 約

KOREAN PRONUNCIATION IS YANG

600 1542 1621 1976 2637 2682 4851 5009 6306 6508  
壤 楊 樣 釀 揚 攘 讓 襄 洋 羊  
6543 6720 6886 7274 7859 9535 10326  
養 煬 襍 穰 佯 陽 孃

KOREAN PRONUNCIATION IS YE

424 868 1066 1067 1155 1400 1562 2108 2109 3217  
隸 藝 芮 芮 蕊 隸 杓 醫 醫 睿  
3219 3774 4973 5399 7253 7573 7604 8254 9405 9468  
睿 曳 詣 裔 穢 譽 譽 銳 刈 預  
9483  
豫

KOREAN PRONUNCIATION IS YD

KUREAN PRONUNCIATION IS YO

262	456	457	1409	1947	2523	2583	2835	3291	3294
瑤	堯	堯	堯	要	撓	擾	搖	耀	耀
4751	5953	5984	5994	6027	6896	7510	7612	8013	8131
凹	窰	窰	窰	澆	祆	夭	僥	邀	鏡
8450	8656	8658	8855	9098	9356	9949	9951	10005	10358
饒	邀	徭	遙	腰	么	凹	凹	繞	妖
10380	10390								
姚	姚								

KOREAN PRONUNCIATION IS YOK

142	2113	6007	6114	6382	6912	6926	8553	8554	9997
辱	辱	潯	潯	浴	禱	禱	欲	慾	縛
10033									
縛									

KOREAN PRONUNCIATION IS YONG

856	874	1724	3936	5402	5922	6302	6452	6746	6844
茸	茸	桶	踴	庸	容	溶	湧	熔	冗
7842	8246	8661	8662	9113	9466				
傭	鎔	聳	聳	用	勇				

KOREAN PRONUNCIATION IS YOK

KOREAN PRONUNCIATION IS YOK

1370 6505 7566 7570 7602 7702 8523 9366 10301  
茹 汝 輿 與 與 昇 餘 余 如

KOREAN PRONUNCIATION IS YOCK

91 3100 3758 4846 5322 5380 6668 8668  
驛 驛 易 譯 疫 亦 逆 役

KOREAN PRONUNCIATION IS YOCL

643 727 3596 5729 5730 6181 9719  
熱 熱 噎 悅 悅 涅 閱

KOREAN PRONUNCIATION IS YOCM

22 36 1063 1898 2211 2430 3042 3067 4000 4563  
髯 艷 苒 鹽 厭 殮 髯 豔 艷 冉  
5741 6428 6754 6795 6802 9728 9732  
恬 染 炎 焰 焰 閻 閻

KOREAN PRONUNCIATION IS YOCN

926 927 1757 1758 1819 2174 2179 2231 2666 2954  
燕 鸞 椽 緣 軟 研 研 硯 捐 鳶  
3617 4141 4447 4788 5886 6219 6291 6351 6429 6704  
嚙 蠕 吮 讌 宴 涓 演 淵 沿 煙  
6706 6707 6731 6794 7454 7730 8312 8643 8851 9086  
煙 煙 烟 燃 筵 延 鉛 衍 然 膳

KOREAN PRONUNCIATION IS YOCH

10220 10298 10272 10317

緣 妍 燕 娟

KOREAN PRONUNCIATION IS YOKNG

214	1050	1688	2018	3427	3507	3672	3690	4889	5256
瓔	英	楹	迓	映	嬰	映	影	詠	癭
5500	6279	6757	6758	6759	6762	6771	7028	8929	9066
羸	瀕	瑩	瑩	榮	營	縈	永	盈	迎
9945	10062								
穎	纓								

KOREAN PRONUNCIATION IS YOCP

878

葉

KOREAN PRONUNCIATION IS YU

108	1554	1691	1708	1950	2393	2889	3116	3794	3931
馱	柚	榴	榆	酉	有	揉	馱	由	踰
3937	3953	4162	4322	4534	4597	4753	4900	4908	4955
蹂	遺	蚰	唯	黝	帷	幽	誘	諛	諭
5325	5359	5461	5642	5748	5778	5779	5869	6113	6203
癒	庾	遊	濡	惟	愉	愉	宥	濡	油

KOREAN PRONUNCIATION IS YU

6270	6440	6925	6973	7666	7680	7712	7721	7753	7757
游	渝	襦	裕	儒	侑	鼯	牖	攸	悠
8413	8538	9006	9398	9470	9607	10146	10227		
乳	釉	猶	俞	柔	孺	維	幼		

KOREAN PRONUNCIATION IS YUK

4614	5513	7547	7555
肉	育	毓	毓

KOREAN PRONUNCIATION IS YUN

6470	9337	9676	9742	9979
潤	胤	閏	尹	允

KOREAN PRONUNCIATION IS YUNG

356	1894	10000
戎	融	絨