


AS A091 939

HARRY DIAMOND LABS ADELPHI MD F/G 18/3
NUDACC (NUCLEAR DAMAGE ASSESSMENT COMPUTER CODE) PROGRAMMER'S 8--ETC(U)
AUG 80 R B MOORE
MDL-SR-80-1 NL

UNCLASSIFIED

Fig 1
NO 2
10/10/80



END
DATE
FILMED
1-81
DTIC

AD A091939

THE
LIBRARY OF THE
CONGRESS
PHOTODUPLICATION SERVICE
510 MAZOUZ DRIVE
CATHAMPTON, VIRGINIA 22824

UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

REPORT DOCUMENTATION PAGE		READ INSTRUCTIONS BEFORE COMPLETING FORM
1. REPORT NUMBER HDL-SR-80-1V 2	2. GOVT ACCESSION NO. AD-A 092 939	3. RECIPIENT'S CATALOG NUMBER
4. TITLE (and Subtitle) NUDACC (Nuclear Damage Assessment Computer Code) Programmer's Guide.	5. TYPE OF REPORT & PERIOD COVERED Special Report	6. PERFORMING ORG. REPORT NUMBER
7. AUTHOR(s) Ralph G. Moore	8. CONTRACT OR GRANT NUMBER(s) (13) 34	
9. PERFORMING ORGANIZATION NAME AND ADDRESS Harry Diamond Laboratories 2800 Powder Mill Road Adelphi, MD 20783	10. PROGRAM ELEMENT, PROJECT, TASK AREA & WORK UNIT NUMBERS Program Ele: 6.57.08.A	
11. CONTROLLING OFFICE NAME AND ADDRESS Commander US Army Training & Doctrine Command Fort Monroe, VA 23651	12. REPORT DATE August 1980	
14. MONITORING AGENCY NAME & ADDRESS (if different from Controlling Office)	13. NUMBER OF PAGES 25	
	15. SECURITY CLASS. (of this report) UNCLASSIFIED	
	15a. DECLASSIFICATION/DOWNGRADING SCHEDULE	
16. DISTRIBUTION STATEMENT (of this Report) Approved for public release; distribution unlimited.		
17. DISTRIBUTION STATEMENT (of the abstract entered in Block 20, if different from Report)		Accession For NTIS GRA&I <input checked="" type="checkbox"/> DTIC TAB <input type="checkbox"/> Unannounced <input type="checkbox"/> Justification
18. SUPPLEMENTARY NOTES DRCMS Code: 6657089870000 HDL Project: 251921 PRON: YE9 47 YEA9		By Distribution/ Availability Codes Avail and/or Dist Special A
19. KEY WORDS (Continue on reverse side if necessary and identify by block number) Nuclear damage assessment Nuclear weapons effects Assessment code Computer code		
20. ABSTRACT (Continue on reverse side if necessary and identify by block number) This report serves as a user's manual primarily for the analyst or the programmer interested in installing and using the Nuclear Damage Assessment Computer Code (NUDACC). Toward this interest, detailed descriptions of file structure, mass storage requirements, and logic flow are provided. Additionally, a full description of the NUDACC methodology is presented along with an example of vulnerability array modification.		

UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

163050

CONTENTS

	<u>Page</u>
1. INTRODUCTION.....	5
2. NUDACC METHODOLOGY.....	6
2.1 Subroutine Flow Chart.....	6
2.2 Environments.....	9
2.3 Restrictions.....	10
3. INPUT FILES.....	11
3.1 General.....	11
3.2 NUDACC Input Files.....	11
3.3 NUDPRINT Input Files.....	12
4. MASS STORAGE FILES.....	12
5. JOB CONTROL LANGUAGE.....	13
6. NUDACC NAMED COMMON BLOCKS.....	15
7. NUDACC PROGRAM MODULES.....	18
7.1 Introduction.....	18
7.2 MAIN Program.....	19
7.3 Subroutine GOTONE.....	20
8. MODIFYING NUDACC VULNERABILITY ARRAYS.....	21
9. ADDING NEW EQUIPMENT ITEMS TO NUDACC VULNERABILITY ARRAYS.....	22
DISTRIBUTION.....	25

FIGURES

1. NUDACC subroutine flow chart.....	8
2. Unit within range.....	8
3. Job execution sequence.....	8

TABLES

1 NUDACC Mass Storage Files.....	12
2 Sort Routine Mass Storage Files.....	13
3 NUDPRINT Program Mass Storage Files.....	13

Listing 1. Run stream to execute NUDACC, SORT routine, and NUDPRINT program.....	13
---	----

1. INTRODUCTION

The Nuclear Damage Assessment Computer Code (NUDACC)¹ described in this report is an outgrowth of a requirement of the U.S. Army's Theater Nuclear Force Survivability Program to provide accurate assessment of the survival of blue theater nuclear forces after a USSR-Warsaw Pact (red) nuclear attack. Assessments of this nature have often been made by using a cookie-cutter methodology. A circle of appropriate radius is drawn around the actual ground zero (AGZ), and items within the circle are considered killed.

A moment's reflection on this approach will confirm that although the simplicity of method is attractive, it is certainly not realistic.

The NUDACC methodology determines a probability of survival for personnel and equipment based on a cumulative log-normal function of a particular nuclear weapons effects (NWE) environment. Many equipment items are vulnerable to several NWE environments, in which case the individual probabilities are multiplied to determine the probability of survival of the item.

To simplify further discussion, it is necessary to define the following terms:

UNIT	Any combination of personnel and equipment that constitutes a logical functional entity and can be contained in a rectangular area as small as 50 m on a side or as large as 500 m on a side (This size restriction is due to the current data dimensions of the program and can easily be modified.)
UNIT NAME	Name assigned to unit
UNIT IDENTIFICATION NUMBER	Unique seven-digit integer number assigned to each unit (This number is used to correlate corresponding data in several files.)
UNIT LENGTH, WIDTH	Geometric parameters of unit (in meters): LENGTH = distance from front to rear; WIDTH = distance across front (Each value can range from 50 to 500 m.)
RIGHT REAR CORNER	Corner to right and rear of observer located in center of unit and looking toward front (This corner is used to locate unit.)

¹J. Michalowicz, R. Moore, and K. Sweasy, NUDACC--A Nuclear Damage Assessment Computer Code (U), Harry Diamond Laboratories HDL-PR-78-3 (November 1978). (CONFIDENTIAL)

UNIT LOCATION The x-y location of unit's right rear corner (in meters)
 (Origin of coordinate system must be chosen so that all
 x-y values are positive.)

UNIT ROTATION ANGLE Angle in degrees about right rear corner measured counterclockwise from horizontal

EQUIPMENT MENU List of personnel and equipment organic to unit

EQUIPMENT CODE Unique three-digit integer number used to identify item in equipment menu

DOMINANT KILL MECHANISM Most damaging of several NWE environments affecting an item

DOMINANT KILL MECHANISM CODE	Code	Meaning
	0	No NWE vulnerability data on item (or hard)
	1	Electromagnetic pulse (EMP) only
	2	Neutron fluence only
	3	EMP and neutron fluence
	4	Peak static overpressure (ΔP) \times dynamic pressure impulse (I_q) - threshold for vehicle overturn (K) only
	5	$\Delta P I_q$ - K and EMP
	6	$\Delta P I_q$ - K and neutron fluence
	7	$\Delta P I_q$ - K and neutron fluence and EMP

2. NUDACC METHODOLOGY

2.1 Subroutine Flow Chart

The current version of NUDACC can perform a static (snapshot) evaluation of NWE equipment damage and personnel casualties after a nuclear burst on the battlefield. All units are considered stationary; the weapons are considered in the order in which their parameters are entered as input data. A narrative of the control logic written in structured form and a subroutine flow chart (fig. 1) follow.

- Read in the unit location, size, and orientation.
- Read in the weapon location and yield.
- Calculate the maximum effects radius.

- Read in the equipment for each unit.

- Select and detonate each weapon.

For each unit,

- Calculate the distance from the weapon burst point projected on the ground to the unit.
- If this distance is less than the maximum effects radius of the weapon, process the unit.
- Divide the unit into grid squares 50 m on a side, and calculate the distance from the weapon to the center of each of these grids (fig. 2).
- Calculate the various environments at the center of each grid square, and accumulate the dose.
- Calculate the probability of survival of all items for which data exist as a result of these environments.
- Calculate the attrition of the items.

The attrition of items (personnel and equipment) is calculated in the following manner:

- If the items have not been distributed over the unit, then distribute the items; otherwise, read the surviving items from a random file.
- Multiply the items in each grid square by the appropriate probability of survival to determine the number surviving at that grid.
- Sum each item over the unit to determine the number of that particular item surviving after that particular weapon, and write those items to a file for further processing; then redistribute surviving personnel and equipment according to the computed values for each grid square, and write the distributed equipment to the random file.

The output from NUDACC is passed to a SORT routine, which reorganizes the data for the NUDPRINT program. The output from NUDPRINT is a printout that has an entry for each unit and lists the personnel and the equipment surviving each critical weapon and the dominant kill mechanism for that item. The job execution sequence is illustrated in figure 3.




Figure 1. NUDACC subroutine flow chart.




Figure 2. Unit within range.




Figure 3. Job execution sequence.

2.2 Environments

Sweeney et al² comprehensively discuss the environmental equations used in NUDACC. The following environments are calculated:

Radiation (total dose)

Blast (vehicle overturn, $\Delta PI_q - K$)

Transient radiation effects on electronics (TREE) (neutron fluence)

EMP (vertical electric field)

The following damage mechanisms are considered:

a. Personnel (total dose)

(1) Postures considered

- (a) Exposed
- (b) Open vehicle
- (c) Foxhole
- (d) Armored personnel carrier
- (e) Tank

(2) Damage criteria for each posture

- (a) Immediate permanent incapacitation, undemanding tasks (18 krad [tissue])
- (b) Immediate permanent incapacitation, demanding tasks (8 krad [tissue])
- (c) Immediate transient incapacitation, undemanding tasks (3 krad [tissue])
- (d) Immediate transient incapacitation, demanding tasks (2 krad [tissue])
- (e) Latent lethality (0.65 krad [tissue])

²W. Sweeney, Jr., C. Moazed, and J. Wicklund, Nuclear Weapons Environments for Vulnerability Assessments to Support Tactical Nuclear Warfare Studies (U), Harry Diamond Laboratories HDL-TM-77-4 (June 1977). (CONFIDENTIAL)

b. Vehicles (overturn)-- ΔPI_q - K

c. Electronics

- (1) Neutron fluence (TREE)
- (2) EMP
- (3) ΔPI_q - K (mounted in vehicles)

Any items located within the circle defined by the projection of the fireball on the ground are considered destroyed without further processing.

Equipment is categorized into one of the following nine equipment codes for input:

- 100-199 Wheeled vehicles
- 200-299 Tracked vehicles
- 300-399 Radios
- 400-499 Electronic equipment
- 500-599 Radars and sensors
- 600-699 Missile systems
- 700-799 Power generation equipment
- 800-899 Weapon items
- 900-999 Aircraft

Personnel and their posture may also be specified according to the following code:

- 001 Exposed
- 002 Open vehicle
- 003 Foxhole
- 004 Armored personnel carrier
- 005 Tank

The number of personnel or items of equipment is specified by a three-digit count immediately following the category code.

2.3 Restrictions

The current data arrays and file structures for both NUDACC and NUDPRINT are limited to maxima of 600 units, 45 equipment codes per unit, and 200 weapons.

3. INPUT FILES

3.1 General

The files described below, except for the Equipment Menu file, are generated by the user. The Equipment Menu file is directly related to the vulnerability data organic to NUDACC and cannot be casually modified. All records within the files are expected to be in card image format.

3.2 NUDACC Input Files

Unit data, data set reference No. 5, File 1

Code FORMAT (I7,3X,2F10.0,3F5.0)

Card format:	<u>Column</u>	<u>Description</u>
	01-07	Unit identification number
	08-10	Unused
	11-20	Unit location (x value, meters)
	21-30	Unit location (y value, meters)
	31-35	Unit rotation angle (degrees)
	36-40	Unit length (meters)
	41-45	Unit width (meters)
	46-80	Unused (or comments)

Weapon data, data set reference No. 5, File 2

Code FORMAT (3F10.0)

Card format:	<u>Column</u>	<u>Description</u>
	01-10	Yield (kilotons)
	11-20	Weapon location (x value, meters)
	21-30	Weapon location (y value, meters)

Unit equipment file, data set reference No. 5, File 3

Code FORMAT (I7,5X,9(2I3,1X))

Card format:	<u>Column</u>	<u>Description</u>
	01-07	Unit identification number
	08-12	Unused
	13-75	9 (equipment code, count, 1 space)
	76-80	Unused

TABLE 2. SORT ROUTINE MASS STORAGE FILES

Data set reference No.	Routine	File type	File status	Record size (words)	Number of records
SORTIN	SORT	S	OTD	5	V
SORTOUT	SORT	S	NTP	5	V

TABLE 3. NUDPRINT PROGRAM MASS STORAGE FILES

Data set reference No.	Routine	File type	File status	Record size (words)	Number of records
1	MAIN	S	OTD	1200	2
2	MAIN	S	OTD	5	V
11	MAIN	R	OTD	91	600
12	MAIN	R	NTD	12	200

5. JOB CONTROL LANGUAGE

The run stream of listing 1 executes NUDACC, SORT, and NUDPRINT on the HDL IBM 370/168. The FORTRAN IV H Extended Compiler is used.

LISTING 1. RUN STREAM TO EXECUTE NUDACC, SORT ROUTINE, AND NUDPRINT PROGRAM

```
//NUDACC JOB (Installation dependent)
//COMPUTE EXEC FORTXCG,PARM.GO='NORES'
//FORT.SYSIN DD *
        NUDACC PROGRAM
/*
//GO.FT05F001 DD *
        UNIT DATA DECK
/*
//GO.FT05F002 DD *
        WEAPON DATA DECK
/*
//GO.FT05F003 DD *
```

LISTING 1. RUN STREAM TO EXECUTE NUDACC, SORT ROUTINE, AND NUDPRINT
PROGRAM (Cont'd)

UNIT EQUIPMENT DECK

```
/*
//GO.FT10F001 DD DSN=&&RDOSE,DISP=(NEW,DELETE),SPACE=(400,(600)),
//   DCB=(RECFM=F,LRECL=400),UNIT=SYSDA
//GO.FT11F001 DD DSN=&&RNCDCN,DISP=(NEW,PASS),SPACE=(364,(600)),
//   DCB=(RECFM=F,LRECL=364),UNIT=SYSDA
//GO.FT12F001 DD DSN=&&REQPT,DISP=(NEW,DELETE),SPACE=(300,(9000)),
//   DCB=(RECFM=F,LRECL=300),UNIT=SYSDA
//GO,FT16F001 DD DSN=&&SORTIN,DISP=(NEW,PASS),UNIT=SYSDA,
//   SPACE=(1084,(1000)),DCB=(RECFM=VBS,LRECL=24,BLKSIZE=1084)
//GO,F17F001 DD DSN=&&HITCNT,DISP=(NEW,PASS),UNIT=VIO,
//   SPACE=(4808,(2)),DCB=(RECFM=VS,LRECL=4804)
//SORT EXEC SORT
//SORTIN DD DSN=&&SORTIN,DISP=(OLD,DELETE)
//SORTOUT DD DSN=&&SORTOUT,DISP=(NEW,PASS),UNIT=SYSDA
//   SPACE=(1084,(1000)),DCB=(RECFM=VBS,LRECL=24,BLKSIZE=1084)
//SYSIN DD *
    SORT FIELDS=(5.0,4.0,A,13.0,4.0,A,9.0,4.0,A),FORMAT=BI,SIZE=E10000
END
/*

//PRINT EXEC FORTXCG
//FORT.SYSIN DD *
        NUDPRINT PROGRAM

/*
//GO.FT01F001 DD DSN=&&HITCNT,DISP=(OLD,DELETE)
//GO.FT02F001 DD DSN=&&SORTOUT,DISP=(OLD,DELETE)
//GO.FT03F001 DD *
        UNIT NAME DECK

/*
//GO.FT10F001 DD *
```

LISTING 1. RUN STREAM TO EXECUTE NUDACC, SORT ROUTINE, AND NUDPRINT
PROGRAM (Cont'd)

EQUIPMENT NAME DECK

```
/*  
//GO.FT11F001 DD DSN=&&RNCDCN,DISP=(OLD,DELETE)  
//GO.FT12F001 DD DSN=&&MN,DISP=(NEW,DELETE),SPACE=(48,(200)),  
// DCB=(RECFM=F,LRECL=48),UNIT=VIO  
//
```

6. NUDACC NAMED COMMON BLOCKS

ATTBLK

The ATTBLK block is used to pass the array AT(75,10,10) between subroutines ATTRIT, DSTRT, RDRER, SURVIV, and WTRER (fig. 1). AT is used as a work area to keep track of the items of personnel and equipment surviving over the grid structure of the unit. After the number of items surviving a weapon has been calculated, the personnel items are reset at their original values due to the cumulative nature of total dose.

DKM

The DKM block is used to pass the array DKM(3,75) between subroutines ATTRIT and SURVIV. DKM is a logical array used to indicate the dominant kill mechanism for each equipment item over the unit.

DPIQ, DSBLK, EMP1, and RNF

The DPIQ, DSBLK, EMP1, and RNF blocks are used to pass the arrays DPIQ(10,10), DOSE(10,10), EMP1(10,10), and RNF(10,10), respectively, between the subroutines ENVCAL and PBSURV. The arrays respectively contain the environments $\Delta P_{i,q}$, total dose, vertical electric field, and neutron fluence calculated at the center of each grid square of the unit being considered.

NUMHIT

The NUMHIT block is used to pass the arrays NH(600) and IC(600) between subroutines CKUNIT, GOTONE, and RDEQPT. NH contains the number of times that a unit has been within range of a weapon; IC contains the total number of items associated with a unit. NH reflects the fact that each personnel item generates five survival numbers. The NUMHIT block is eventually passed via temporary file to the NUDPRINT program.

OUTBLK

The OUTBLK block is used to arrange the value NEQP and the arrays ICODE(45) and ICOUNT(45) in contiguous areas of memory before writing to a random file. NEQP is the number of equipment codes associated with the unit; ICODE contains the respective equipment codes, and ICOUNT contains the number of each item of equipment represented by the code.

PSDOSE, PSDPIQ, PSEMP1, and PSNF

The PSDOSE, PSDPIQ, PSEMP1, and PSNF blocks are used to pass the arrays PSDOSE(5,4,10,10), PSDPIQ(15,10,10), PSEMP1(2,10,10), and PSNF(31,3,10,10), respectively, between subroutines ATTRIT and PBSURV. The arrays respectively contain the probabilities of survival of personnel to dose, vehicles to airblast overturn ($\Delta P I_g - K$), electronics to vertical electric field, and electronics to neutron fluence for all possible equipment items in each grid square of a unit.

UNTANG

The UNTANG block is used to pass the array THETA(600) between subroutines DISSQR and RDUNIT. THETA contains the angle of rotation of each unit about its right rear corner.

UNTDIS

The UNTDIS block is used to pass the array DS(10,10) between subroutines DISSQR and ENVCAL. DS contains the distance from the weapon AGZ to the center of each grid square of the unit.

UNTEPT

The UNTEPT block is used to pass the array IPOINT(45,600) between subroutines ATTRIT and POINT. IPOINT contains the index value of each item of nonpersonnel equipment in the unit. This index is used to locate data relevant to the item in arrays IVLARY, IDPVUL, IEPVUL, NFIVUL, and NFSVUL found in subroutine ATTRIT.

UNTFBL

The UNTFBL block is used to pass the array IFB(10,10) between subroutines ATTRIT, ENVCAL, and PBSURV. IFB is a logical array that indicates whether a grid square is within the projection of the fireball on the ground and therefore destroyed.

UNTGRD

The UNTGRD block is used to pass the arrays IL(600) and IW(600) between subroutines GOTONE and RDUNIT. The arrays respectively contain the length and the width of the units in number of grid squares.

UNTHIT

The UNTHIT block is used to pass the array IH(600) between subroutines ENVCAL, GOTONE, and RDUNIT. A nonzero entry in IH indicates that the unit has been hit previously and points to the proper random record containing accumulated dose.

UNTIDN

The UNTIDN block is used to pass the array IDEN(600) between subroutines RDEQPT and RDUNIT. IDEN contains the respective unit identification numbers. The UNTIDN block is passed via temporary file to the NUDPRINT program.

UNTLAW

The UNTLAW block is used to pass the variables ILEN and IWID between subroutines ATTRIT, DISSQR, DSTRT, ENVCAL, GOTONE, PBSURV, RDRER, SURVIV, and WTRER. These items respectively contain the length and the width of the unit under consideration in number of grid squares.

UNTLOC

The UNTLOC block is used to pass the arrays XU(600) and YU(600) between subroutines CKUNIT, DISSQR, and RDUNIT. The arrays respectively contain the x and y coordinates of the units in meters.

UNTNCT

The UNTNCT block is used to pass the array NC(600) between subroutines DSTRT, RDRER, RDUNIT, SURVIV, and WTRER. NC contains the number of counts associated with each unit. The individual entries reflect the fact that five counts are generated for each personnel item.

UNTNDX

The UNTNDX block is used to pass the variables IRAN and IREC between subroutines ATTRIT, ENVCAL, GOTONE, and RDUNIT. IRAN points to the next sequential random record to which dose data will be written for a unit exposed to nuclear radiation for the first time. IREC points to the random record containing dose information for a unit that has been exposed previously.

UNTPER

The UNTPER block is used to pass the array NPER(600) between subroutines ATTRIT and DSTRBT. NPER is the total number of items of personnel information for a particular unit.

UNTRER

The UNTRER block is used to pass the array ISTRT(600) between subroutines RDRER, RDUNIT, and WTRER. ISTRT points to the start of the random attrited equipment records for a particular unit.

WEPAGZ

The WEPAGZ block is used to pass the arrays XA(200) and YA(200) between subroutines CKUNIT and RDWEAP. XA and YA are the coordinates of the AGZ for a particular weapon.

WEPNUM

The WEPNUM block is used to pass the variable IWNM between subroutines CKUNIT, ENVCAL, and SURVIV. IWNM is the sequence number of the weapon whose effects are being considered.

WEPRAD

The WEPRAD block is used to pass the arrays RN(200), RTD(200), REMP(200), and RDPIQ(200) between subroutines LARRAD and RDWEAP. The arrays respectively contain the radius beyond which the effects of neutron fluence, total dose, EMP, and $\Delta P I_q$ are insignificant for a particular weapon.

WEPYLD

The WEPYLD block is used to pass the array YIELD(200) between subroutines CKUNIT and RDWEAP. YIELD is the yield of a particular weapon.

7. NUDACC PROGRAM MODULES

7.1 Introduction

NUDACC was designed by using the concept of functional modules. Each module resolves one of the several problems facing an analyst who wishes to know the survivability of personnel and equipment items after a weapon laydown. For example, the analyst needs to know

the location of units (personnel and equipment) and the yield and the AGZ of the various weapons, to examine the magnitude of the several NWE environments produced by each weapon at each unit location. If the magnitude of any one of the environments is sufficient to damage the unit, he calculates the probability of survival of the various items within the unit due to the environment and the number of items surviving the weapon. He also records the total dose value to which any future dose from subsequent weapon burst will be added before calculating subsequent personnel survival. The NUDACC program modules perform these functions in greater detail.

7.2 MAIN Program

The MAIN program consists of four CALL statements to subroutines RDUNIT, RDWEAP, RDEOPT, and CKUNIT. The first three of these define the problem, and the fourth performs the analysis.

RDUNIT

The RDUNIT subroutine reads the location and the size of the units considered in the analysis. The number of 50-m grid squares in each unit is calculated, and several unit related arrays are set to zero.

RDWEAP

The RDWEAP subroutine reads the location and the yield of the weapons considered. The maximum radius of effect for each environment is calculated by function RMAX and stored in arrays.

RMAX

(See RDWEAP.)

RDEOPT

The RDEOPT subroutine reads the items of personnel and equipment associated with a unit and generates a random access file of equipment codes and counts for each unit.

CKUNIT

The CKUNIT subroutine determines the largest of the several maximum radii of effects for a weapon with a call to subroutine LARRAD and examines each unit to see if it is in range. A unit in range results in a call to subroutine GOTONE.

7.3 Subroutine GOTONE

The GOTONE subroutine locates the various records required to determine the probability of survival of the unit and performs the analysis with calls to subroutines DISSQR, ENVCAL, PBSURV, and ATTRIT.

DISSQR

The DISSQR subroutine divides the unit into 50-m squares and computes the distance from the weapon AGZ to the center of each square.

ENVCAL

The ENVCAL subroutine calculates the environment at the center of each 50-m square after first determining that the square is outside the fireball radius of the weapon. If the square is inside the fireball, a status switch is set for reference during probability-of-survival calculations.

PBSURV

For the environments at the centers of each grid square in the unit, the PBSURV subroutine calculates probabilities of survival for all items in the unit that have vulnerability numbers. Function PSFUNC performs the actual calculation. These survival probabilities provide a menu from which the proper probability-of-survival numbers are chosen, depending on the unit's equipment list.

PSFUNC

(See PBSURV.)

ATTRIT

The ATTRIT subroutine calculates the number of items of personnel and equipment surviving the effects of the weapon. The items of personnel and equipment are initially evenly distributed over the unit's grid squares, that is, the first time that a unit is within range of a weapon (hit). This information is eventually written in to a random access file and read directly if the unit is subsequently hit. For items vulnerable to more than one environment, the separate probabilities of survival are multiplied, and the product is taken to be the overall probability of survival of the item.

DSTRBT

The DSTRBT subroutine distributes the original complement of the unit's personnel and equipment over the unit's grid squares. This routine is called only once: the first time a unit is hit. Subroutine POINT is called from this routine.

POINT

The POINT subroutine determines the index value of each equipment item in the unit. The index value is the relative position of the item's equipment code in the arrays LISTA and LISTB. This index value is the key to the various vulnerability arrays in subroutine ATTRIT.

RDRER

The RDRER subroutine reads the distributed items of personnel and equipment surviving before the current weapon is considered. This subroutine is called only if the unit is hit more than once.

SURVIV

The SURVIV subroutine calculates the actual number of items of personnel and equipment surviving the current weapon by taking the sum of each item over the unit's grid squares. The dominant kill mechanism also is determined.

WTRER

The WTRER subroutine writes the updated random access record containing the number of each item of personnel and equipment surviving at each grid square of the unit.

8. MODIFYING NUDACC VULNERABILITY ARRAYS

The vulnerability of an item of equipment is expressed in arrays LISTA and LISTB in subroutine POINT; arrays IVLARA and IVLARB, IDPVLA and IDPVLB, IEPVLA and IEPVLB, NFIVLA and NFIVLB, and NFSVLA and NFSVLB in subroutine ATTRIT; and arrays DSMU, DSSIG, DPMU, DPSIG, KAY, RNFMU, RNFSIG, EP1MU, and EP1SIG in subroutine PBSURV.

The arrays in subroutines POINT and ATTRIT do not contain actual data, but pointers to data. The similar geometric configuration of these arrays means that information regarding any particular equipment item will always be located in the same row and column as the item's

equipment number in array LISTA or LISTB. For example, equipment item 373 is a radio mounted in a vehicle. First, locate the value 373 in the DATA statements for array LISTA or LISTB in subroutine POINT. This gives a row-column value of C3 in LISTB. To determine the vulnerability information on this item, locate row-column C3 in IVLARB in subroutine ATTRIT and find the value 07. By the dominant kill mechanism code (sect. 1), a value of 7 indicates vulnerability numbers for $\Delta P I_q - K$, neutron fluence, and EMP. To determine the vulnerability numbers for $\Delta P I_q - K$, locate row-column C3 in the DATA statement for array IDPVLB and find the value 05. This means that the fifth elements in arrays DPMU, DPSIG, and KAY in subroutine PBSURV correspond to the mean (μ), standard deviation (σ), and K values for $\Delta P I_q - K$ for item 373. These values are 1.68, 1.96, and 8.88, respectively.

To determine the vulnerability numbers for neutron fluence, go to subroutine ATTRIT, locate row-column C3 in the DATA statement for array NFIVLB, and find the value 01. In subroutine PBSURV locate the first elements in the DATA statements for arrays RNFMU and RNFSIG that correspond to the μ and σ values for neutron fluence for item 373; these are 27.3 and 0.37, respectively. The second element in array T2 gives 0.9 as the neutron transmission factor for the vehicle. Also of interest is the C3 entry in the DATA statement for array NFSVLB, which holds the value 02. This number points to the neutron transmission factor for the vehicle.

The vulnerability numbers for EMP are located in a similar manner. Find row-column C3 in the DATA statement for array IEPVLB, which holds the value 02. The second elements in the DATA statements for arrays EP1MU and EP1SIG in subroutine PBSURV contain 14.7 and 2.94, respectively.

When vulnerability number updates are required for item 373, the new μ , σ , and K values will have replaced the original entries. Since it is possible for several items to use the same vulnerability numbers, assure that the update applies to all the items whose pointers reference the modified values.

9. ADDING NEW EQUIPMENT ITEMS TO NUDACC VULNERABILITY ARRAYS

Adding new equipment to NUDACC involves providing values to the various vulnerability arrays. The basic methodology outlined in section 8 applies also to locating the proper array elements to be changed.

Before NUDACC can be used to calculate the probability of survival of an item, it is mandatory that μ and σ be available for the log-normal distribution representing the probability of damage of the item (and for some items the overturn constant or the transmission factor).

The first step is to select an appropriate equipment code for the item. This must be one of the numbers in the DATA statements for the arrays LISTA and LISTB in subroutine POINT. Carefully note the row-column location of this number because it will be the key to locating related elements in the vulnerability arrays. Choose the proper code from the list given in section 1 to indicate the availability of vulnerability data for the item. Enter this number in the proper row-column of the DATA statement for array IVLARA or IVLARB in subroutine ATTRIT.

Turn to subroutine PBSURV and check the DATA statements for arrays DPMU, DPSIG, and KAY for vehicle overturn; RNFMU and RNFSIG for neutron fluence (TREE); and EP1MU and EP1SIG for EMP, to be certain that the vulnerability numbers for the item are not already included. The numbers can be included when items that are physically similar have different names and model numbers. If the new vulnerability numbers are unique, increase the DIMENSION statements for DPMU, DPSIG, and KAY; RNFMU and RNFSIG; and EP1MU and EP1SIG, as appropriate. Add the new vulnerability numbers to the DATA statements for these arrays and note the element numbers (index values) of the new entries. Then modify the DO loops, which use the data in these arrays by increasing the test values in the DO statements. For $\Delta P_{iq} - K$ (vehicle overturn) the statement is this:

```
DO 120 M=1,(new value)
```

For neutron fluence, the statement is this:

```
DO 210 II=1,(new value)
```

For EMP, the statement is this:

```
DO 310 II=1,(new value)
```

Return to subroutine ATTRIT and modify the DATA statements for arrays IDPVLA and IDPVLB for vehicle overturn, IEPVLA and IEPVLB for EMP, NFIVLA and NFIVLB for neutron fluence, and NFSVLA and NFSVLB for the neutron fluence transmission factor by entering the index value of the vulnerability numbers in the proper row-column locations.

Finally, add the new equipment code and equipment name to the EQUIPMENT NAME LIST file. This is an input file to the NUDPRINT program with data set reference No. 10. Be careful to keep this file in ascending numerical order.

DISTRIBUTION

ADMINISTRATOR
DEFENSE DOCUMENTATION CENTER
ATTN DDC-TCA (12 COPIES)
CAMERON STATION, BUILDING 5
ALEXANDRIA, VA 22314

COMMANDER
US ARMY RSCH & STD GP (EUR)
ATTN LTC JAMES M. KENNEDY, JR.
CHIEF, PHYSICS & MATH BRANCH
FPO NEW YORK 09510

COMMANDER
US ARMY ARMAMENT MATERIEL
READINESS COMMAND
ATTN DRSAR-LEP-L, TECHNICAL LIBRARY
ROCK ISLAND, IL 61299

COMMANDER
US ARMY MISSILE & MUNITIONS
CENTER & SCHOOL
ATTN ATSK-CTD-F
REDSTONE ARSENAL, AL 35809

DIRECTOR
US ARMY MATERIEL SYSTEMS ANALYSIS
ACTIVITY
ATTN DRXSY-MP
ATTN DRXSY-GS, Mr. KING
ABERDEEN PROVING GROUND, MD 21005

DIRECTOR
US ARMY BALLISTIC RESEARCH LABORATORY
ATTN DRDAR-TSB-S (STINFO)
ATTN DRDAR-BLV, DR. J. KLOPCIC/MR. RIGOTTI
ABERDEEN PROVING GROUND, MD 21005

TELEDYNE BROWN ENGINEERING
CUMMINGS RESEARCH PARK
ATTN DR. MELVIN L. PRICE, MS-44
HUNTSVILLE, AL 35807

COMMANDING OFFICER
NAVAL TRAINING EQUIPMENT CENTER
ATTN TECHNICAL LIBRARY
ORLANDO, FL 32813

US ARMY ELECTRONICS TECHNOLOGY
AND DEVICES LABORATORY
ATTN DELET-DD
FORT MONMOUTH, NJ 07703

DIRECTOR
TRASANA
ATTN ATAA-TDC, C. KIRBY/A. BERGLUND
WHITE SANDS MISSILE RANGE, NM 88002

COMMANDER
US ARMY LOGISTICS CENTER
ATTN ATCL-FS, MR. STEWARDSON
FT LEE, VA 23801

COMMANDER
USA MERADCOM
ATTN DRDME-RT, DR. OSCAR
FT BELVOIR, VA 22060

COMMANDER
USA ERADCOM
ELECTRONIC WARFARE LABORATORY
ATTN DELEW-V, MR. MILLER
FT MONMOUTH, NJ 07703

COMMANDER
USA ARRADCOM
ATTN DRDAR-LCN-E, MR. REINER
DOVER, NJ 07801

COMMANDER
US ARMY COMBINED ARMS COMBAT
DEVELOPMENT ACTIVITY
ATTN ATCA-CIC, DR. FOLLIS
ATTN ATZLCA-CAA-Q, H. TAYLOR
FT LEAVENWORTH, KS 66027

COMMANDER
US ARMY NUCLEAR AND CHEMICAL AGENCY
ATTN MONA-SAL, LTC BENT
7500 BACKLICK ROAD
BLDG 2073
SPRINGFIELD, VA 22150

COMMANDER
US ARMY ORDNANCE AND CHEMICAL
CENTER AND SCHOOL
ATTN ATSL-CD-CS, CPT SCHOLZ
ABERDEEN PROVING GROUND, MD 21005

US ARMY ELECTRONICS RESEARCH
& DEVELOPMENT COMMAND
ATTN TECHNICAL DIRECTOR, DRDEL-CT

HARRY DIAMOND LABORATORIES
ATTN CO/TD/TSO/DIVISION DIRECTORS
ATTN RECORD COPY, 81200
ATTN HDL LIBRARY, 81100 (3 COPIES)
ATTN HDL LIBRARY, 81100 (WOODBIDGE)
ATTN CHAIRMAN EDITORIAL COMMITTEE
ATTN TECHNICAL REPORTS BRANCH, 81300
ATTN CHIEF, 22000
ATTN CHIEF, 22100
ATTN CHIEF, 22300
ATTN CHIEF, 22800
ATTN CHIEF, 22900
ATTN CHIEF, 21000
ATTN CHIEF, 21100
ATTN CHIEF, 21200
ATTN CHIEF, 21300
ATTN CHIEF, 21400
ATTN CHIEF, 21500
ATTN SWEASY, K., 22100
ATTN DAVIS, D., 22100
ATTN MICHALOWICZ, J., 22100 (5 COPIES)

**DAT
FILM**