



Edgewood Chemical Biological Center

# Disparate Sensor Integration for CB Defense

By

William Underwood, Dr. Amnon  
Birenzvice, and David Sickenberger

# Report Documentation Page

*Form Approved*  
*OMB No. 0704-0188*

Public reporting burden for the collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden, to Washington Headquarters Services, Directorate for Information Operations and Reports, 1215 Jefferson Davis Highway, Suite 1204, Arlington VA 22202-4302. Respondents should be aware that notwithstanding any other provision of law, no person shall be subject to a penalty for failing to comply with a collection of information if it does not display a currently valid OMB control number.

1. REPORT DATE <b>01 OCT 2005</b>	2. REPORT TYPE <b>N/A</b>	3. DATES COVERED -			
4. TITLE AND SUBTITLE <b>Disparate Sensor Integration for CB Defense</b>		5a. CONTRACT NUMBER			
		5b. GRANT NUMBER			
		5c. PROGRAM ELEMENT NUMBER			
6. AUTHOR(S)		5d. PROJECT NUMBER			
		5e. TASK NUMBER			
		5f. WORK UNIT NUMBER			
7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES) <b>US Army Soldier and Biological Chemical Command</b>		8. PERFORMING ORGANIZATION REPORT NUMBER			
9. SPONSORING/MONITORING AGENCY NAME(S) AND ADDRESS(ES)		10. SPONSOR/MONITOR'S ACRONYM(S)			
		11. SPONSOR/MONITOR'S REPORT NUMBER(S)			
12. DISTRIBUTION/AVAILABILITY STATEMENT <b>Approved for public release, distribution unlimited</b>					
13. SUPPLEMENTARY NOTES <b>See also ADM001851, Proceedings of the 2003 Joint Service Scientific Conference on Chemical &amp; Biological Defense Research, 17-20 November 2003. , The original document contains color images.</b>					
14. ABSTRACT					
15. SUBJECT TERMS					
16. SECURITY CLASSIFICATION OF:			17. LIMITATION OF ABSTRACT <b>UU</b>	18. NUMBER OF PAGES <b>42</b>	19a. NAME OF RESPONSIBLE PERSON
a. REPORT <b>unclassified</b>	b. ABSTRACT <b>unclassified</b>	c. THIS PAGE <b>unclassified</b>			



# Objective

- Application of non-CB, force protection sensors in Chemical/Biological detection
- Sensors to be used in a dual use mode
- Earliest warning capability, detection made seconds after explosion



# Type of sensors used


- Acoustic
- Seismic
- Visible Cameras
- Infrared Cameras
- Existing intrusion sensors



# Field Test

- Total of 260 155 mm artillery rounds
  - Equally divided between conventional and simulated CB rounds
  - Equally divided between air burst and point detonation
- Order of fire was random
- First 160 rounds are used for algorithm development
- Last 100 rounds are blind shots used to test the reliability of the algorithms

# Sensors Layout






# Initial Analysis

- Difference in maximum intensity between the HE events and the Chemical simulated events
- A “pre-ringing” effect occurred before the HE events



## HE Seismic Signature





# Status

- Several algorithms based on single sensor signatures were developed from
  - Acoustic signature
  - Seismic signature
  - IR signature




# Seismic Analysis

- Ratio between time to seismic signal maximum (A) to total length of seismic signal (B) can differentiate between CB and HE rounds (Initial data – 90% accurate)







## Example of the Seismic Ratio





# Acoustic Analysis

- The area under the positive peak is a good discriminator





## Integrated Area Under the Positive Peak

	HE		Chemical	
	Air Burst	Point detonation	Air Burst	Point detonation
Mean	0.534	0.356	0.0385	0.00538
STD	0.0798	0.0586	0.0107	0.00687
<i>mean ± STD</i>	0.454-0.614	0.297-0.415	0.0278-0.0492	0-0.0123
<i>mean ± 2STD</i>	0.374-0.694	0.239-0.473	0.0171-0.0599	0-0.0191
<i>mean ± 3STD</i>	0.295-0.773	0.186-0.532	0.0064-0.0706	0-0.0260



# Results and Performance

- If area under positive peak  $< 0.11$  Pa then a chemical event occurred
- Further discrimination of a chemical rounds mode of detonation is possible
  - Area  $< 0.02$  Pa – chemical point detonation
  - $0.02$  Pa  $<$  Area  $< 0.11$  Pa – chemical air burst
- The algorithm was able to determine if an event was chemical or conventional with 100% accuracy
- It was correct 47 out of 48 times on the mode of detonation





# IR camera Analysis

- Discrimination characteristics include
  - Size of fireball
  - Shape of fireball (Eccentricity)
  - Duration of the fireball
  - Grey scale of the image
  - Rate of expansion



# First frame after detonation



Top: HE round      Bottom: Chemical Simulant Round





## Second frame after detonation

Top: HE round      Bottom: Chemical Simulant Round





# Observation

- Chemical simulant air bursts have a larger gray scale and shorter duration
- Fireball HE air bursts expand faster
- HE point detonation have a larger eccentricity value
- Chemical simulant point detonation has all negative values for growth




# Modeling and Simulation Effort

- Acoustic/Seismic as  $1/r^2$  function
- Decision process based on intensity only
- Support multiple sensors and sensor types
- Scableable
- Manual placement of sensors/events
- Supportable to the future
- Capture and display interactions of non-CB sensors to event
- Capture response by CB sensors



# Modeling and Simulation of HE and Chemical events on a Fixed Site



# Modeling and Simulation



Edgewood Chemical Biological Center



## Example 1

Type of Event: HE

Sensors:

ACOUSTIC


CHEMICAL - M22

# Modeling and Simulation



Edgewood Chemical Biological Center

300538N0452933E



Chemical Detector

Acoustic Sensors


Location of HE Detonation

T=0 seconds

# Modeling and Simulation



Edgewood Chemical Biological Center




T=1 seconds

# Modeling and Simulation




Edgewood Chemical Biological Center



# Modeling and Simulation




Edgewood Chemical Biological Center



# Modeling and Simulation



Edgewood Chemical Biological Center



T=3seconds



## Example 2

Type of Event: Chemical

Sensors:


**ACOUSTIC**

**CHEMICAL - M22**

# Modeling and Simulation



Edgewood Chemical Biological Center




T=0 seconds

# Modeling and Simulation



Edgewood Chemical Biological Center




T=1 seconds

# Modeling and Simulation



Edgewood Chemical Biological Center




T=2 seconds

# Modeling and Simulation



Edgewood Chemical Biological Center




T=3seconds

# Modeling and Simulation



Edgewood Chemical Biological Center





## Example 3

Type of Event: Chemical

Sensors:

ACOUSTIC


CHEMICAL - M22

IR

# Modeling and Simulation



Edgewood Chemical Biological Center




T=0 seconds

# Modeling and Simulation



Edgewood Chemical Biological Center




T=1 seconds

# Modeling and Simulation



Edgewood Chemical Biological Center




T=2 seconds

# Modeling and Simulation




Edgewood Chemical Biological Center



T=3seconds





# DSI Decision Layers




# Single Sensor Configuration


Ringing from HE




Extract unique and distinguishing features



Pass data and discrimination info to fusion node




Seismic Sensor




# Fusion of Common Sensors



Normal  
application of  
sensor



**DSI fusion node for CB:**  
Sensor position  
Event intensity  
Time of event  
Any unique discriminants




Triangulation  
programs



Single sensor  
type  
discrimination  
call

# Multi, Non-CB Sensor Fusion





# Overall

- Disparate, non-CB, intrusion sensors have information that can be used to make a determination
- Information is already in the battlefield
- Provides early warning to soldiers of CB event
- Can allow soldier to go from MOPP IV to MOPP II much more easily
- Relieve fatigue of soldier



Edgewood Chemical Biological Center

END