

AD-A079 743


NAVAL OCEAN RESEARCH AND DEVELOPMENT ACTIVITY NSTL S--ETC F/G 8/11
MARINE SEISMIC DISPLAY ENHANCEMENT PROGRAM. VOLUME II. PROCESSI--ETC(U)
DEC 77 B E ECKSTEIN


UNCLASSIFIED

NORDA-TN-14

NL

1 OF 2
ADA
079743





MICROCOPY RESOLUTION TEST CHART
 NATIONAL BUREAU OF STANDARDS-1963-A

14
TN-14

ADA 079743

6
**MARINE SEISMIC DISPLAY
ENHANCEMENT PROGRAM.**
[REDACTED]
Volume II.
PROCESSING SOFTWARE.

2

LEVEL II

9
Final rept.

10 Bruce E. Eckstein

OCEAN TECHNOLOGY DIVISION
CODE 350
NAVAL OCEANOGRAPHIC LABORATORY

DDC FILE COPY

11 Dec [REDACTED] 77

DDC
RECEIVED
JAN 23 1980
B



12 146

DISTRIBUTION STATEMENT A
Approved for public release;
Distribution Unlimited

A79753
TN-15

NAVAL OCEAN RESEARCH AND DEVELOPMENT ACTIVITY
NSTL Station, MS 39529

392 773

80 1 21 019 int

FOREWORD

This document describes the processing software programs developed under the Marine Seismic Display Enhancement Program. These programs provide the geophysicists and acousticians with software to enhance marine seismic profiling data. This report contains a general software program description, UNIVAC 1108 computer listing, and the operation procedure for each program. Software to decode the Seismic Data Acquisition System's data, to process the data, and to prepare the data for playback on the Seismic Data Display System is included. Required modifications to the UNIVAC 1108 computer listings for operation on the CDC 6600 are given. *→ (cont on p iii)*

This document is Volume II of the Marine Seismic Display Enhancement Program Final Report. Volume I presents a summary of project results with examples of processed seismic profiling data. Volume III describes the operation of the hardware acquisition and display systems developed under this program.

ACCESSION for	
NTIS	White Section <input checked="" type="checkbox"/>
DOC	Buff Section <input type="checkbox"/>
UNANNOUNCED	<input type="checkbox"/>
JUSTIFICATION	_____
BY _____	
DISTRIBUTION/AVAILABILITY CODES	
Dist.	AVAIL. and/or SPECIAL
A	

(cont. from pi)
This volume

ABSTRACT

This document explains six software programs developed to enhance display of digitally recorded seismic data. The first two programs are digital filters which remove undesired frequency content from seismic data; The third program vertically stacks several records with the same source to hydrophone array distance resulting in improved signal-to-noise. The fourth program is an optimum least squares filter commonly known as the Wiener Filter; The fifth program develops a band limited zero-phase time domain pulse with defined frequency content; The sixth program develops a spectral analysis routine for time series data by use of a fast fourier transform method. A complete listing of the program for implementation on the UNIVAC 1108 is provided and the required changes for implementation on the CDC 6600 are given.

PREFACE

**This document is the result of the Marine Seismic Enhancement Program (1977).
This document has been prepared through the efforts of:**

**Mr. Bruce Eckstein
Mr. Martin Fagot
Mr. Frank Stookesbory
Mr. Thomas Mero**

TABLE OF CONTENTS

	<u>PAGE</u>
I. Introduction	1
II. Program Description	1
A. Time Domain Filter (MAIN01)	1
B. Frequency Domain Filter (MAIN02)	2
C. Vertical Record Stacking Program (MAIN03)	2
D. Wiener Filter Program (MAIN04)	3
E. Desired Waveshape Program (MAIN07)	4
F. Spectral Analysis Program (SDADS)	4
III. Output Formats	4
A. SDAS Formatted Tapes	5
B. SDDS Formatted Tapes	5
C. Plot Tape	5
D. Data Listing	5
IV. Program Operation (UNIVAC 1108)	7
A. MAIN01	8
B. MAIN02	10
C. MAIN03	12
D. MAIN04	14
E. MAIN07	16
F. SDADS	18
V. Program Operation (CDC 6600)	20
A. Changes to MAIN01	21
B. Changes to SUB001	22
C. Changes to SUB002	24
D. Changes to SUB003	24
E. Changes to SUB044	25
F. MAIN01 Procedure	26

TABLE OF CONTENTS (Cont'd)

	<u>PAGE</u>
VI. Summary	28
VII. Glossary of Terms	28
VIII. References	33
Appendix A: Computer Listing (UNIVAC 1108)	35

LIST OF ILLUSTRATIONS

Figure 1	Seismic Data Acquisition System (SDAS) Data Tape Format	6
-----------------	--	---

MARINE SEISMIC DISPLAY ENHANCEMENT PROGRAM PROCESSING SOFTWARE

I. INTRODUCTION

This document describes the software programs developed to process seismic profiling data. These software programs were developed because seismic systems used to gather data introduce data distortions. These distortions may be frequency nulls, phase shifts, polarity reversals, secondary pulses, pulse images or multiples. Each of these distortions, when introduced into the data, reduce resolution and signal-to-noise. These programs are designed to remove these data distortions, thereby improving data quality.

This is Volume II of a three series set. Volume I presents a summary of project results with examples of processed and displayed data. Volume III explains the operation of the Seismic Data Acquisition System (SDAS) and the Seismic Data Display System (SDDS).

Six main programs have been implemented for processing seismic profiling data digitized by the SDAS (Seismic Data Acquisition System). These programs are:

	<u>TITLE</u>	<u>PROGRAM NAME</u>
1)	Time Domain Filter	MAIN01
2)	Frequency Domain Filter	MAIN02
3)	Vertical Record Stacking Program	MAIN03
4)	Wiener Filter Program	MAIN04
5)	Desired Waveshape Program	MAIN07
6)	Spectral Analysis Program	SDAS

The programs read an SDAS formatted tape having a maximum of 6000 data points per record. These programs operate on two computer systems; the UNIVAC 1108 or the CDC 6600 interfaced thru a CDC 1700 computer.

II. PROGRAM DESCRIPTION

A. TIME DOMAIN FILTER (MAIN01)

The Time Domain Filter (MAIN01) uses a zero phase Linnette Filter (Linnette, 1961). There are four filtering options:

- 1) **Lowpass Filter:** Passes all frequencies below a cut-off frequency
- 2) **Highpass Filter:** Passes all frequencies above a cut-off frequency
- 3) **Bandpass Filter:** Passes all frequencies between a high cut-off frequency and a low cut-off frequency
- 4) **No Filter:** Passes all frequencies unattenuated

This program uses three input parameters for the Highpass Filter or the Lowpass Filter. These parameters are CUT, H, and N. CUT relates to the cut-off frequency (F_0) of the filter. H is the slope of the filter. The actual cut-off frequency of the filter is $F_0 = \text{CUT} + H$. N indicates one-half of the number of filter weights used. A maximum of 300 filter weights is permissible.

Bandpass filtered data is produced by highpass filtering the data, then lowpass filtering the data. Filter parameters are entered separately for the Lowpass filter and the Highpass filter.

The option of "no filter" produces an unprocessed display of the data.

B. FREQUENCY DOMAIN FILTER (MAIN02)

This filter converts the data to the frequency domain employing a fast fourier transform. The program then multiplies this data by a tapered step function (controlled by the bandwidth). The available tapered step functions are:

- 1) rectangular (no taper)
- 2) cosine
- 3) gaussian
- 4) triangular (linear taper with frequency)

The resulting data is converted back to the time domain via an inverse fast fourier transform resulting in bandpass filtered data.

This filter is designed to bandpass filter data but it can be forced to lowpass filter data by setting the input parameter FRQLow equal to the negative of the parameter FRQHl.

At present the program will filter a maximum of 2048 data points. To filter larger data records the following changes must be made.:

- 1) dimension of "Y" in MAIN01 increased
- 2) dimension of "P" in MAIN01 increased
- 3) Do loop in SUB012 Line 9 must be increased

The number used in the dimension statements must be 2^N where N is the number used in change 3.

C. VERTICAL RECORD STACKING PROGRAM (MAIN03)

This program stacks consecutive records. It is not meant to be used for multiple channel streamer data as it makes no attempt to correct for the move-out condition present in multi-channel streamer data. This program reads consecutive records averaging point by point the corresponding time period samples.

After the number of records read equals the number of records to be stacked, output commences. Each new record read replaces the oldest record in the stacking process and the new record's "header data" is used as the "header data" for the output record.

The maximum output record length is limited by the number of arrays stacked. The maximum output record length equals 20010 data points divided by the number of arrays. If stacking 10 records, the maximum number of output data points allowed is 2001. To increase this limitation, two values must be changed in SUB029. The first is the dimension of DDATA and the second is the number 20010 in line 9. These two numbers must always be equal.

D. WIENER FILTER PROGRAM (MAIN04)

The Wiener Filter used consists of an input signal, a desired output signal, and an actual output series (Robinson, 1967). The process minimizes the power existing between the desired and actual output signals, resulting in the least squares optimum filter. This program uses two input waveshapes, the BASIC WAVESHAPE and the DESIRED WAVESHAPE, to develop a set of filter weights. The BASIC WAVESHAPE is a representation of the propagating sound source wavelet. The BASIC WAVESHAPE is stored in the array B and has LB number of data points. The DESIRED WAVESHAPE, stored in the array D, is a bandpass, zero phase, pulse. Its spectral content should approach that of the BASIC WAVESHAPE. LD is the number of points in the DESIRED WAVESHAPE.

The input data, BASIC WAVESHAPE and DESIRED WAVESHAPE, can be manipulated in the following ways before developing the filter weights:

- 1) BASIC WAVESHAPE may be read from any SDAS data tape.
 - a) Consecutive files can be stacked to develop BASIC WAVESHAPE.
 - b) The program can select the first data point of the basic from the data file.
 - c) The operator can select the first data point of the basic from the data file.
 - d) The period of the bubble pulse (air gun source) can be lengthened or shortened while maintaining the frequency content of the main pulse and the bubble pulse (total frequency spectrum will change because bubble period changes).
- 2) BASIC WAVESHAPE can be read from card images (a record or records still read from tape).
- 3) The DESIRED WAVESHAPE can be time shifted in reference to BASIC WAVESHAPE.

The plot output format has two sections. The first section contains the input parameters used in developing the wiener filter weights whereas the second section is the resulting Wiener Filter processed data.

The first section has the following information plotted:

- 1) Each record used in the stack (even if basic is read in from card images)
- 2) Results of stacking records (if stack greater than one)
- 3) DESIRED WAVESHAPE
- 4) BASIC WAVESHAPE
- 5) Convolution of BASIC WAVESHAPE with "Filter Weights"

- 6) Filter Weights
- 7) Convolution of "Filter Weights" with stacked file

The second section is a series of seismic records consisting of one record for each record processed by the filter weights, developed in the first section.

E. DESIRED WAVESHAPE PROGRAM (MAIN07)

This program develops a zero phase, band limited pulse waveform. This waveform is developed in the frequency domain and converted to the time domain. One hundred data points are generated to represent the DESIRED WAVESHAPE. This program writes the DESIRED WAVESHAPE in three locations:

- 1) Memory file 15 of computer
- 2) On computer listing
- 3) On card output (if requested)

This program also writes, on the computer listing, the spectral amplitudes (db) of the DESIRED WAVESHAPE. The bandwidth (Hz) of each Frequency bin is equal the sample Frequency divided by 2^N .

F. SPECTRAL ANALYSIS PROGRAM (SDADS)

This program reads a given data record and computes its frequency spectrum. The frequency spectrum data is plotted by CALCOMP for presentation. The data record can be data directly from an SDAS tape, computer filtered SDAS tape, or card images of data. The program will initiate the frequency analysis on either a first return (water-sediment interface) or prechosen point within the record. The program initially performs a frequency spectrum analysis on the total data record and plots (via CALCOMP) this spectrum (Shot Spectra). See Volume I of this report series for an example. A computer listing provides the maximum spectral level and the frequency at which it occurs. The second plot presented (Shot Ampli) is the time domain data record employed in generating the initial frequency spectrum. The data record is then divided into a series of small preselected time intervals of equal duration and frequency spectra for each interval is computed. The resulting plot (Interval) is a series of frequency spectra for each time interval presented in a water-fall format.

The plots length (time/frequency axis) can be varied in length from 2 inches to 28 inches. All spectral data is normalized to the peak level of the initial spectral analysis. The height and separation of the individual spectral plots may be varied. Highpass filtering parameters (Time Domain Filter), if filtering of the data record is performed by this program, are also indicated on the graph.

III. OUTPUT FORMATS

The above described programs have four possible output formats. These formats are:

- 1) Seismic Data Acquisition System (SDAS) Formatted Tape
- 2) Seismic Data Display System (SDDS) Formatted Tape

- 3) Plot Tape (CalComp Tape)
- 4) Data Listing

A. SDAS FORMATTED TAPES

This format of data output is normally used when processing the data with the following programs: MAIN01, MAIN02, MAIN03, and MAIN04. This output format is used to save the processed data in order that other programs may process the data further.

The SDAS formatted tape is both an input and output format. Tapes generated by the SDAS hardware are 7 track 556 Bits Per Inch. SDAS tapes generated by these programs are 7 track 800 BPI. The first 108 bits of information, 3-36 bit computer words, are the Header information coded in "Binary Coded Decimal". The program automatically decodes this information (see Figure 1).

B. SDDS FORMATTED TAPES

This is an output formatted tape with 36 db dynamic range. The output format, when played back on the SDDS (Seismic Data Display System), will produce a 36 db dynamic range analog representation of the digital signal.

The format of the tape starts with an EOF mark. Then the digital data is converted to a binary number. The resulting binary number is between 111 111 (all one's) and 000 000 (all zero's). There is a "Record Gap" after 1980 data samples (this is always the number of data samples per record). This format requires the number of data samples converted be limited to 1980 data points by:

- 1) Converting the first 1980 data points (even if less data points exist)
- 2) Resampling the data, reducing the information to 2000 data points, and converting the first 1980 points of the resulting data (Davis, 1970)

C. PLOT TAPE (CALCOMP TAPE)

This type of output is used to obtain a wiggle trace display of the data. The output tape is played back by a CalComp plotter.

This format has a maximum physical length of 30' for each record of data plotted, although shorter lengths may be used. The plotter's minimum step change between each data point is .005 in.

D. DATA LISTING

This format prints on a computer listing all data values for each record after processing. The data points are read sequentially from left to right.

IV. PROGRAM OPERATION (UNIVAC 1108 COMPUTER)

A. MAIN01

The following procedure is recommended for operating the Time Domain Filter. First the "General Format" is shown, then a specific sample is given. For meaning of the terms in the "General Format", check Glossary of Program Terms. All formats are free field formats, FORMAT (), except as noted.

GENERAL FORMAT	COMMENT
@ASG,T IN., 8C, Program Tape #	} NECESSARY ONLY ONCE PER DAY
@CAT, P W, F40//POS/5	
@COPY, G IN., W.	
@FREE IN.	
@ASG, T IUNIT., 8C, DATA TAPE #	INPUT DATA TAPE
@ASG, TM NUNIT., 8C, SAVE02	IF SDDS OUTPUT SELECTED
@ASG, T 9., 8C, SAVE02	IF PLOT OUTPUT SELECTED
@ASG, T (IUNIT+1)., 8C, SAVE02	IF SDAS OUTPUT SELECTED
@REWIND IUNIT.	
@ XQT W.AMAIN01	
IMOVE, INCRE, NUNIT, IPRT, NDATAP	
KPASS, KOUT, I2000, AMAX, IFILE, IPOINT	
IUNIT, NUNIT	
SCALEX, SCALEY	IF PLOT OUTPUT SELECTED
CUT (1), H(1), N(1)	IF KPASS = 2, 3
CUT (2), H(2), N(2)	IF KPASS = 1, 2
@TPNO NUNIT.	IF SDAS OUTPUT SELECTED
@TPNO 9.	IF PLOT OUTPUT SELECTED
@TPNO (IUNIT+1).	IF SDAS OUTPUT SELECTED

SPECIFIC EXAMPLE (MAIN01)

The following procedure is recommended for operating the Treasury Desktop Editor. First the "General Format" is shown, then a specific example is shown. For meaning of the terms in the "General Format", check Glossary of Program Terms. All formats are the field formats, EXCEPT as noted.

COMMENT

GENERAL FORMAT

@ASG,T IN., 8C, 36790

@CAT,P W., F40//POS 5

@COPY,G IN., 8C, SAVE02

@FREE IN.

@ASG,T 10., 8C, 3505

@ASG,T 9., 8C, SAVE02

@ASG,T 11., 8C, SAVE02

@XQT W.AMAIN01

1, 2, 1200, 100, 4020

3, 6, 2000, 2.0, 0, 1

10, 2

0.5, 14.0

4.0, 17.0, 80

40.0, 17.0, 80

@TPNO 9.

@TPNO 11.

B. MAIN02

The following procedure is recommended for operating the Frequency Domain Filter. First the "General Format" is shown, then a specific sample is shown. For meaning of the terms in the "General Format", check Glossary of Program Terms. All formats are free field formats, FORMAT (), except as noted.

GENERAL FORMAT	COMMENT
@ ASG, T IN., 8C, PROGRAM TAPE #	
@ CAT, P W., F40//POS/5	} NECESSARY ONLY ONCE PER DAY
@ COPY, G IN., W.	
@ FREE IN.	
@ ASG, T IUNIT., 8C, DATA TAPE #	INPUT DATA TAPE
@ ASG, TM NUNIT., 8C, SAVE02	IF SDDS OUTPUT SELECTED
@ ASG, T 9., 8C, SAVE02	IF PLOT OUTPUT SELECTED
@ ASG, T (IUNIT+1)., 8C, SAVE02	IF SDAS OUTPUT SELECTED
@ REWIND IUNIT.	
@ XQT W.AMAIN02	
IMOVE, INCRE, NUNIT, IPRT, NDATAP	
KPASS, KOUT, I2000, AMAX, IFILE, IPOINT	
IUNIT, NUNIT	
SCALEX, SCALEY	IF PLOT OUTPUT SELECTED
FRQLOW, FRQHI, KFIL, NZERO, PHASE, TSHIFT	IF BANDPASS FILTER SELECTED (KPASS = 1)
@ TPNO NUNIT.	IF SDDS OUTPUT SELECTED
@ TPNO 9.	IF PLOT OUTPUT SELECTED
@ TPNO (IUNIT+1).	IF SDAS OUTPUT SELECTED

SPECIFIC EXAMPLE (MAIN02)

The following procedure is recommended for operating the Record Reader Program. First the "General Format" is shown, then a specific sample is shown. For meaning of the terms in the "General Format", check Glossary of Program Terms. All formats are free field formats, FORMAT (), except as noted.

COMMENT	@ASG,T IN., 8C,36790	GENERAL FORMAT
	@CAT,P W., F40//POS/5	
NECESSARY ONLY CODE	@COPY,G IN., W.	
	@ FREE IN.	
	@ASG,T 10., 8C, 3505	
DATA TABL	@ASG,T 9., 8C,SAVE02	
OUTPUT SELECTED	@ASG,T 1., 8C,SAVE02	
OUTPUT SELECTED	@ REWIND OUT.	
OUTPUT SELECTED	@ XQT W.AMAIN01	
	1, 1, 1200, 100, 4010	
	1, 3, 2000, 2.0, 0, 1	
	10, 1	
	0.5, 14. 0	
	. 100, 270, 1, 0, 0.0, 0.0	
OUTPUT SELECTED	@ TPNO 9.	
OUTPUT SELECTED	@ TPNO 1.	
IF PLOT OUTPUT SELECTED		
IF PLOT OUTPUT SELECTED		

C. MAIN03

The following procedure is recommended for operating the Record Stacking Program. First the "General Format" is shown, then a specific sample is shown. For meaning of the terms in the "General Format", check Glossary of Program Terms. All formats are free field formats, FORMAT (), except as noted.

GENERAL FORMAT	COMMENT
@ ASG, T IN., 8C, PROGRAM TAPE #	NECESSARY ONLY ONCE
@ CAT, P W., F40//POS/5	PER DAY
@ COPY, G IN., W.	
@ FREE IN.	
@ ASG, T IUNIT., 8C, DATA TAPE #	INPUT DATA TAPE
@ ASG, TM NUNIT., 8C, SAVE02	IF SDDS OUTPUT SELECTED
@ ASG, T 9., 8C, SAVE02	IF PLOT OUTPUT SELECTED
@ ASG, T (IUNIT+1)., 8C, SAVE02	IF SDAS OUTPUT SELECTED
@ REWIND IUNIT.	
@ XQT W.AMAIN01	
IMOVE, INCRE, NUNIT, IPRT, NDATA P	
IRRAY, KOUT, I2000, AMAX, IFILE, IPOINT	
IUNIT, NUNIT	
SCALEX, SCALEY	IF PLOT OUTPUT SELECTED
@ TPNO NUNIT	IF SDDS OUTPUT SELECTED
@ TPNO 9.	IF PLOT OUTPUT SELECTED
@ TPNO (IUNIT+1).	IF SDAS OUTPUT SELECTED

SPECIFIC EXAMPLE (MAIN03)

The following procedure is recommended for operating the Water Filter Program. First the "General Format" is shown, then a specific example is shown. For meaning of terms in the "General Format", check Glossary of Program Terms. All formats are two field formats, FORMAT () except as noted.

COMMENT

GENERAL FORMAT

- @AST, T IN., 8C, 36790**
- @CAT, P W., F40/POS/5**
- @COPY, G IN., 8C, SAVE02**
- @FREE IN.**
- @ASG, T 10., 8C, 3505**
- @ASG, T 9., 8C, SAVE02**
- @ASG, T 11., 8C, SAVE02**
- @REWIND OUT.**
- @XQT W. AMAIN01**
- 1, 2, 1200, 100, 4010**
- 10, 6, 2000, 2. 0, 0, 1**
- 10.1**
- 0.5, 14. 0**
- @TPNO 9.**
- @TPNO 11.**

D. MAIN04

The following procedure is recommended for operating the Wiener Filter Program. First the "General Format" is shown, then a specific example is shown. For meaning of terms in the "General Format", check Glossary of Program Terms. All formats are free field formats, FORMAT (), except as noted.

GENERAL FORMAT	COMMENT
@ASG,T IN., 8C, PROGRAM TAPE #	
@CAT, P W., F40//POS/9	} NECESSARY ONLY ONCE PER DAY
@COPY, G IN., W.	
@FREE IN.	
@ASG, T IUNIT., 8C, DATA TAPE #1	
@ASG, T KUNIT., 8C, SOURCE SIGNATURE TAPE	IF SEPARATE TAPE FOR BASIC
@ASG, TM NUNIT., 8C, SAVE02	IF SDDS OUTPUT SELECTED
@ASG, T 9., 8C, SAVE02	IF PLOT OUTPUT SELECTED
@ASG, T (IUNIT+1)., 8C, SAVE02	IF SDAS OUTPUT SELECTED
@XQT W.AMAIN04	
IMOVE, INCRE, NFILE, IPRT, NDATA P	
IUNIT, NUNIT	
KPASS, KOUT, IEXPND, I2000, AMAX, FILE, IPOINT	
ITER, LENGTH, INCLN, LS, LF	
IAVE, KMOVE, KUNIT	
SCALEX, SCALEY	IF PLOT OUTPUT SELECTED
LA, LB, LD, IST1, KB, KE	
D(I)	FORMAT 10F 8.5
IFTD	IF KPASS=1, 2, 3
CUT(1), H(1), N(1)	IF KPASS=2, 3
CUT(2), H(2), N(2)	IF KPASS=1, 2
FRQLOW, FRQHI, KFIL, NZERO, PHASE, TSHIFT	IF KPASS=5, 6
BASIC WAVESHAP (CARD FORMAT 10F8.5)	IF IEXPND IS -1
FRQLOW, FRQHI, KFIL, NZERO, PHASE, TSHIFT	IF KPASS=6, 7

SPECIFIC EXAMPLE (MAIN04)

@ ASG, T 10., 8C, 7651

@ ASG, T 20., 8C, X0001

@ ASG, T 9., 8C, SAVE02

1, 1, 1000, 100, 4010

10, 1

4. 14, 0, 0, 2. 0, 0, 1

1, 160, 6, 102, 140

30, 130, 20

0. 5, 14. 0

240, 160, 100, 1, 400, 400

DESIRED WAVESHAP

(CARD FORMAT 10F8.5)

E. MAIN07

The following procedure is recommended for operating the Desired Waveshape Program. First the "General Format" is shown, then a specific example is shown. The meaning of the terms in the "General Format" is given in the Glossary of Program Terms. All formats are free field formats, FORMAT (), except as noted.

GENERAL FORMAT	COMMENT
@ ASG, T IN., 8C, PROGRAM TAPE #	
@ CAT, P W., F40//POS/9	
@ COPY, G IN., W.	
@ FREE IN.	
@ XQT, W. AMAIN07	
FSAMP, NP, PHASE, NZERO, FRQLOW, FRQHI, KFIL, IPUNCH	
ZERO1(I), ZERO2(I)	IF ZERO IS GREATER THAN ONE. ONE FOR EACH FREQUENCY TO BE ZEROED
@ PRT, S 15.	

SPECIFIC EXAMPLE (MAIN07)

The following procedure is recommended for conversion of the Spectrum Analysis Program. First the "General Format" is given, then a specific example. For the meaning of terms in the "General Format", refer to the Glossary of Terms. All formulas are like field FORMAT (), except as noted.

COMMENT

GENERAL FORMAT

@XQT W.AMAIN07

1.000,1024,0.0,0,.010,.170,2,0

IF DATA IS READ FROM DISK
TAP

IF DATA IS READ FROM TAPE *

IF DATA IS READ FROM TAPE *

IF DATA IS READ FROM TAPE *

IF DATA IS READ FROM TAPE *

IF DATA IS READ FROM TAPE *

IF DATA IS READ FROM TAPE *

IF DATA IS READ FROM TAPE *

IF DATA IS READ FROM TAPE *

IF DATA IS READ FROM TAPE *

IF DATA IS READ FROM TAPE *

IF TEST GREATER THAN 1

IF TEST GREATER THAN 1000.0

IF TEST GREATER THAN 1

IF TEST GREATER THAN 1000.0

F. SDADS

The following procedure is recommended for operation of the Spectrum Analysis Program. First the "General Format" is given, then a specific example. For the meaning of terms in the "General Format", refer to the Glossary of Terms. All formats are free field, FORMAT (), except as noted.

GENERAL FORMAT	COMMENT
@ ASG, T IN., 8C, PROGRAM TAPE #	
@ CAT, P W., F40//POS/9	
@ COPY, G IN., W.	
@ FREE IN.	
@ ASG, T IUNIT, 8C, DATA TAPE #	IF DATA IS READ FROM SDAS TAPE
@ ASG, T 9., 8C, SAVE02	
@ XQT W.AMAIN15	
IGO, XFAC, IFIL, ITD, ITEST, IVER	
SAMP1, SAMP2, SAMP3, TIME, ISHIFT, SHIFT	
L1, L2, IDSH, IFFT	
ROF1, IFIRST, PD, KB, KE	
CUT(1), H(1), N(1)	IF IFIL EQUAL 1 (HIGHPASS FILTER)
IMOVE, INCRE, NFILE, IPRT, SCALE, IUNIT	
SMSEC, NSAMP, ITER, SCTSTK, DELBSP, DBRANG, TAPE	
DATA POINTS (CARD FORMAT 10F8.4) FOR ANALYSIS	IF ITEST GREATER THAN 1 (ITEST DATA POINTS)

V. PROGRAM OPERATION (CDC 6600)

The seismic processing programs described in this report have been designed for use primarily on a Univac 1108 computer. To operate these programs on the CDC 6600 computer the statements controlling input/output of data must be changed to their equivalent CDC 6600 statement form. These statements are shown below.

Univac 1108 Statement Form	CDC 6600 Equivalent Statement Form
NTRAN	BUFFER
FOLD (used to unpack computer words)	UNPAKF
FOLD (used to pack computer words)	ENCODE
READ(5,190) (Unformatted READ)	READ (5,*)

The above statements are not one for one substitutions and the programs must be changed accordingly to accept them. The changes to be made to MAIN01 are presented. Similar changes must be made to the other main programs. All of the subroutines that must be changed for operation of any of the programs are also shown. The subroutines that were changed are SUB001, SUB002, SUB003, SUB044. No other subroutines need be modified for the conversion to CDC 6600. The method of operating MAIN01 on CDC 6600 is also shown. The operation of the other programs is similar.

Refer to Appendix A listing for line number reference of UNIVAC statement.

A. CHANGES TO MAIN01

<u>Line</u>	<u>Univac Statement</u>	<u>CDC Statement</u>
0		PROGRAM (INPUT, OUTPUT, TAPE5= INPUT, TAPE6=OUTPUT, TAPE1, TAPE9, TAPE10, TAPE11)
52	READ (5, 190)	READ (5, *)
53	READ (5, 190)	READ (5, *)
55	READ (5, 190)	READ (5, *)
58	CALL NTRAN (IUNIT, 8, IMOVE)	CONTINUE
91	IF (PLOT) READ (5, 190)	IF (PLOT) READ (5, *)
92	IF (LOW) READ (5, 190)	IF (LOW) READ (5, *)
93	IF (HIGH) READ (5, 190)	IF (HIGH) READ (5, *)
95	IF (SDDS) CALL NTRAN (NUNIT, 9)	IF (. NOT. SDDS) GO TO 123 BUFFER OUT (NUNIT, 1) (DATA(1), DATA(2)) IF (UNIT(NUNIT)) 122, 122, 122
		122 REWIND NUNIT END FILE NUNIT
96	IF (SDAS) CALL NTRAN (IUNIT1, 9)	123 IF (. NOT. SDAS) GO TO 125 BUFFER OUT (IUNIT1, 1) (DATA(1), DATA(2)) IF (UNIT(IUNIT1)) 124, 124, 124
		124 END FILE IUNIT1
		125 CONTINUE
100	EXIT = 0	EXIT = 0
158	IF (SDDS) CALL NTRAN (NUNIT, 9)	IF (SDDS) END FILE NUNIT
159	IF (SDAS) CALL NTRAN (IUNIT1, 9)	IF (SDAS) END FILE IUNIT1 KK = NDATAP

B. CHANGES TO SUB001

<u>Line</u>	<u>Univac Statement</u>	<u>CDC Statement</u>
14	DIMENSION INDATA (332,2), IST(2), IHEAD(3), IDATA(27)	DIMENSION INDATA(1200), IST(2), IHEAD(3), IDATA(27) EQUVALENCE (IHEAD(3), INDATA(1))
20	CALL NTRAN (NUNIT, 9)	ENDFILE NUNIT
23	CALL NTRAN (IUNIT, 2, 3, IHEAD (1), IST(K))	IF (KK.GT.6000) KK=6000 NK = KK/5+2 BUFFER IN (IUNIT, 1) (IHEAD(1), INDATA(NK))
24	IF (IST(K).EQ.-1) CALL NTRAN (IUNIT, 22)	IF (UNIT(IUNIT)) 40, 31, 32
25	IF (IST(K).GT.0) GO TO 40	CONTINUE
26	31 KK = IST(K)	KK = -2 GO TO 33
		32 KK = -3
		33 CONTINUE

REMOVE CARDS 37 THRU 55 REPLACE
THESE CARDS

CXXXX KK IS THE NUMBER OF SAMPLES
READ

KK = 0

CXXXX READ DATA RECORD

44 CALL LENGTH X(IUNIT, IR, NUBC)
IR = IR-2
NR = NUBC/12
KK = IR*5 - NR
IF (IPR.EQ.1) PRINT 862, IR, NUBC,
NR, KK

862 FORMAT (4110)
KK = 1
CALL UNPACK (IHEAD(2), 12, 5,
JDATA)
IF (JDATA(5).GE.4000B) JDATA(5)=
4000 - JDATA(5)

CDC Statement

DATA (KK) = JDATA(5)

NK = NK-2

DO 63 I = 1, NK

CALL UNPAKF (INDATA(I), 12, 5,
JDATA)

DO 64 J = 1, 5

IF (JDATA(J).GE. 4000B) JDATA(J) =
4000B - JDATA(J)

KK = KK+1

DATA (KK) = JDATA (J) x .0048852

64 CONTINUE

63 CONTINUE

C. CHANGES TO SUB002

<u>Line</u>	<u>Univac Statement</u>	<u>CDC Statement</u>
17	DIMENSION DATA(1), NOUT(330)	DIMENSION DATA(1), NOUT(208)
23	DO 20 J = 1, 330	DO 20 J = 1, 198
25	DO 10 IX = 1, 6	DO 10 IX = 1, 10
34	FLD (IF1, 6, NOUT(J)) = FLD (30, 6, NDATA)	IY = 198 + IX NOUT (IY) = NDATA
35	IF 1 = IF 1 + 6	CONTINUE CALL ENCODE (10, 1, NOUT(J)) NOUT(199)
		1 FORMAT (10R1)
47	DO 35 J = 1, 330	DO 35 J = 1, 198
49	DO 30 IX = 1, 6	DO 30 IX = 1, 10
58	FLD (IF1, 6, NOUT(J)) = FLD (30, 6, NDATA)	IY = 198 + IX NOUT(IY) = NDATA
59	IF 1 = IF 1 + 6	CONTINUE CALL ENCODE (10, 2, NOUT(J)) NOUT(199)
62	38 CALL NTRAN (NUNIT, 1, 330, NOUT(1), ISTAT, 22)	BUFFER OUT (NUNIT, 1) (NOUT(1), NOUT(198))
63	IF (ISTAT.EQ. -1) CALL NTRAN (NUNIT, 22)	ISTAT = -2 IF (UNIT(NUNIT)) 39, 40, 41
64	IF (ISTAT.LT. 1) GO TO 40	39 CONTINUE
71	RETURN	RETURN
		41 ISTAT = -3

D. CHANGES TO SUB003

<u>Line</u>	<u>Univac Statement</u>	<u>CDC Statements</u>
11	DO 41 I = 1, 3 (REMOVE 12 - 18)	CALL UNPAKF (IHEAD, 4, 27, IDATA)

E. CHANGES TO SUB044

<u>Line</u>	<u>Univac Statement</u>	<u>CDC Statement</u>
15	DIMENSION DATA(1), NOUT(332) IHEAD(3)	DIMENSION DATA(1), NOUT(1207), IHEAD(3)
16	CALL NTRAN (NUNIT, 1, 3, IHEAD (1), ISTAT, 22)	J = IHEAD(2)
17	IF (ISTAT.EQ. -1) CALL NTRAN (NUNIT, 22)	CALL ENCODE (10, 1, IHEAD(2))I, IDATA(1)
18	IF (ISTAT.LT. 1) GO TO 40	1 FORMAT (A8, R2)
19	JI = 0	JI = 2 NOUT(1) = IHEAD(1) NOUT(2) = IHEAD(2)
20	IBUF = 332	IBUF = KK/5
21	ITEST = 332	IF (KK.GT. 6000) KK = 1200
REMOVE CARDS 22 thru 25		
28	DO 20 IX = 1, 3	DO 20 IX = 1, 5
34	IF (DATA(JI).LT. 0) ISIGN = 1	IF (DATA(JI).LT. 0) NDATA = 4000B + NDATA
35	FLD (IF 1, 1, NOUT(J)) = ISIGN	IY = 1200 + IX
36	IF 1 = IF 1 + 1	NOUT(IY) = NDATA
37	FLD (IF1, 11, NOUT(J)) = FLD (25, 11, NDATA)	CONTINUE
39	20 IF 1 = IF 1 + 11	20 CONTINUE ENCODE (10, 2, NOUT(J)) NOUT (1203)
41	CALL NTRAN (NUNIT, 1, IBUF, NOUT(1), ISTAT, 22)	2 FORMAT (5R2) IBUF = IBUF + 2 BUFFER OUT (NUNIT, 1) (NOUT(1)), NOUT(IBUF)
42	IF (ISTAT.EQ. -1) CALL NTRAN (NUNIT, 22)	ISTAT = -2
43	IF (ISTAT.LT. 1) GO TO 40	IF (UNIT(NUNIT)) 39, 40, 41
45	IF (KOUNT.LT. 1) RETURN	39 RETURN
46	ITEST = ITEST + 332	41 ISTAT = -3
47	GO TO 10	CONTINUE

F. MAIN01 PROCEDURE

The following procedure is recommended for operation of the Time Domain Filter. First the "General Format" is given, then a specific example. For the meaning of terms in the "General Format", refer to the Glossary of Terms.

GENERAL FORMAT	COMMENT
X862, F4, MTa.	} a = 1 IF NO SDAS OUTPUT a = 2 IF SDAS OUTPUT
ATTACH LIBRARY, ID=NB, SN=USET1.	
UPDATE Q, P=LIBRARY.	
FTN, I, B=BEE, SL.	
REQUEST, TAPE1, *PF, SN=USET1.	IF SDDS OUTPUT SELECTED
LABEL, TAPE10, R, L=SDAS REEL #1615	INPUT DATA TAPE
LABEL, TAPE11, W, L=SDAS., RING, X=SV, T=b.	IF SDAS OUTPUT SELECTED
SKIPF TAPE10.	
ROUTE TAPE 9, DC=PU, TID=AF, DEF, EC=80COL.	IF PLOT OUTPUT SELECTED
ATTACH, PLOT, ZETAPLOT, ID=MZ, SN=USZT2, MR=1.	IF PLOT OUTPUT SELECTED
LDSET PRESET = ZERO.	
LOAD BEE.	
LOAD PLOT.	IF PLOT OUTPUT SELECTED
EXECUTE.	
CATALOG TAPE1	IF SDDS OUTPUT SELECTED
?	
*C MAIN01	
?	
IMOVE, INCRE, NUNIT, IPRT, NDATA	
KPASS, KOUT, I2000, AMAX, IFILE, IPOINT	
IUNIT, NUNIT	
SCALEX, SCALEY	IF PLOT OUTPUT SELECTED
CUT (1), H(1), N(1)	IF KPASS = 2, 3
CUT (2), H(2), N(2)	IF KPASS = 1, 2

SPECIFIC EXAMPLE (MAIN01)

x862, F4, MT2.

B. E. ECKSTEIN

ATTACH LIBRARY, ID=NB, SN=USET1.

UPDATE Q, P=LIBRARY.

FIN, I, B=BEE, SL.

LABEL, TAPE10, R, L=SDAS.

LABEL, TAPE11, W, L=SDAS., RING, X=SV, T=364.

SKIPF TAPE10.

LDSET PRESET = ZERO.

LOAD BEE.

EXECUTE.

?

*C MAIN01

?

1, 2, 1200, 100, 4000

3, 8, 2000, 2.0, 0, 1

10, 1

4.0, 17.0, 80

40.0, 17.0, 80

?

?

VI. SUMMARY

Six software programs have been developed to enhance seismic data quality. The Time Domain Filter is a zero phase Linnette Filter. The Frequency Domain Filter filters seismic data using rectangular, cosine, gaussian or triangular shading of the frequency content. The vertical record stacking program sums multiple records having the same source to hydrophone array distance, but different common depth points. The Wiener Filter program minimizes the power existing between a desired output and an actual output signal resulting in the least squares optimum filtering of the seismic data. The desired waveshape program generates a zero phase band limited pulse with predetermined spectral frequency characteristics.

The spectral analysis program analyzes the frequency content of a time series. The output formats of these programs allow either display of information or further processing of data. The SDAS Formatted tape output, a 72 dB dynamic range data representation, allows further processing of the data to occur before display. The SDDS Formatted tapes, a 36 dB dynamic range data representation, is converted to an analog signal by the SDDS. The Plot Tape contains wiggle trace display formatted data. The computer data listing may contain a list of each data point in each record.

At present, these programs can operate on the UNIVAC 1108 or the CDC 6600. Because of the amount of computer time required by operation of these programs, they should be considered for use on a high speed computer such as the TI-ASC.

VII. GLOSSARY OF PROGRAM TERMS

<u>Term</u>	<u>Meaning</u>
AMAX	Determines the normalizing value of the data for SDDS and PLOT outputs. If AMAX is less than 0, the program assumes the maximum value of the first record for the normalizing value and uses the updates given by SUB002; if AMAX equals 0, the program assumes the maximum value of the first record is the normalizing value; if AMAX is greater than 0, the program uses the value of AMAX as the normalizing value.
B(I)	Is the array in which the transmitted pulse waveform is stored for use by the Wiener Filter Program. The waveform is called the BASIC WAVESHAPE and has LB number of points. This is card input data if IEXPND is less than 0. (Card format is 10F8.5.)
CUT(I)	Is one of the input parameters for the Time Domain Filter. The value relates to the cutoff frequency but the actual cutoff frequency is CUT(I) plus H(I) (Value in HZ). I=1 for lowpass parameters, I=2 for highpass parameters.
D(I)	Is the array in which the DESIRED WAVEFORM, used by the Wiener Filter, is stored. The waveform normally is developed by MAIN07. (Card format is 10F8.5.)
DBRANGE	Determines the range in db of the graph output of the Spectral Analysis Program.

- DDATA(I)** Is the array input data stored by the Spectral Analysis Program. ITEST number of points must be supplied to the program if analysis is to be performed on other than SDAS tapes.
- DELBSP** Is used by the Spectral Analysis Program when picking the first return. It moves the first return point (chosen on peak value) DELBSP points earlier. This value should be zero if program is not choosing the first return.
- FRQHI** The highcut filter frequency used in the FREQUENCY FILTER and the DESIRED WAVESHAPE programs (Value is in KHZ).
- FRQLOW** Is the lowcut filter frequency used in the FREQUENCY FILTER and the DESIRED WAVESHAPE programs (Value is in KHZ).
- FSAMP** This is the sample rate of the DESIRED WAVEFORM (Value is in KHZ).
- H(I)** The slope parameter for the Time Domain Filter (Zero is maximum slope.) I=1 for lowpass parameters, I=2 for highpass parameters.
- IARRAY** Is the number of records to be stacked.
- IAVE** Is the number of records stacked (added together), by the Wiener Filter developing the BASIC WAVESHAPE. This does not affect the wiener filtering of data records with filter weights directly.
- IDSH** If not equal to 0, causes printout of the first IDSH values moved by the subroutine DATSHI.
- IEXPND** Causes the Wiener Filter program to change processing of the BASIC WAVESHAPE. If IEXPND is less than zero, read in the basic waveform; if IEXPND equals 0, do not expand the bubble period; if IEXPND is greater than 0, expand the bubble period according to the input parameter length.
- IFFT** If not equal to zero, causes printout of the first IFFT values of output by the subroutine FFT (the subroutine which converts data from the time domain to the frequency domain).
- IFIL** Is used by the Spectrum Analysis, if equal to 1, causes highpass filtering of the data by the Time Domain Filter. It also demands the reading of the Time Domain Filter parameters.
- IFILE** Changes the gain of the digital data for the first IFILE number of records. If IFILE is positive, it multiplies the data by 3; if IFILE is negative, it divides the data by 3.
- IFTD** Is used in MAIN04 when processing data with the Time Domain Filter. If IFTD equals 1, filters input SDAS data used before creating filter weights; if equal 2, filter all input SDAS data; if equal 3, filters input SDAS data used to convolve with filter weights.

IMOVE Is the first file processed by the program.

INCLLEN Is used in MAIN04 when repetitive expansion of the bubble pulse period is desired. The bubble pulse period is increased by INCLLEN data samples each iteration.

INCRE Indicates which records are read (every increth record). This value must be greater than zero.

IPOINT Indicates output starts at the IPOINT point in the data array.

IPRT Indicates how often Header Records and PLOT Indication is printed on listing. The first Header Record and PLOT Indicator is always printed.

IPUNCH Punch output on card.

ISHIFT Used by Spectrum Analysis Program, shifts the data in time by this number of data samples.

IST1 Shifts the desired waveshape by IST1 data points. This value must be greater than -1 but less than 30 if LD equals 100.

ITD Indicates that the interval spectral analysis will be bandpassed analyses plotted in the time domain.

ITER Indicates the building of filter weights should be repeated ITER number of times. Used for testing with bubble pulse expansion.

ITER1 Is used in the Spectrum Analysis Program. When ITD equals 1, Low passes interval analysis data rather than bandpass data.

ITEST Is a control of Spectrum Analysis Program. If ITEST equals 1, one point is entered at the 300th data point, sample rate is 1000, sample length equals 1 sec, and analysis is performed; if ITEST is greater than 1, ITEST values are read in, sample rate set to 1000 and sample length is set appropriately and analysis is performed; if ITEST equals 0, analyzed data is read from SDAS tape.

IUNIT Is the file name of the input SDAS tape unit. This is a number not a name!

IVER Indicates that the Interval Analysis by Spectral Analysis Program is plotted vertically if IVER equals 1.

I2000 If equals 1, the data is limited to 2000 data points; if I2000 is greater than 1, the data is limited to I2000 data points; if equal to 0, uses actual number of data points.

KB Is the first data point observed when determining the maximum value of the data.

KE Is the last data point observed when determining the maximum value of the data.

KFIL Is the type of taper applied by the Frequency Domain Filter.

KFIL = 0 no taper

KFIL = 1 cosine taper

KFIL = 2 Gaussian taper

KFIL = 3 Triangular taper

KMOVE Is the record used by MAIN04 containing the BASIC WAVESHAP.

KOUT Determines the output type.

KOUT=	SDAS	SDDS	PLOT	FILE1
0	NO	NO	NO	NO
1	YES	YES	YES	YES
2	YES	YES	YES	NO
3	YES	YES	NO	YES
4	YES	YES	NO	NO
5	YES	NO	YES	YES
6	YES	NO	YES	NO
7	YES	NO	NO	YES
8	YES	NO	NO	NO
9	NO	YES	YES	YES
10	NO	YES	YES	NO
11	NO	YES	NO	YES
12	NO	YES	NO	NO
13	NO	NO	YES	YES
14	NO	NO	YES	NO
15	NO	NO	NO	YES
16	NO	NO	NO	NO

KPASS Determines type of filtering

If used in Time Domain Filter

KPASS = 1 lowpass filter

KPASS = 2 highpass filter

KPASS = 3 bandpass filter

KPASS = 4 no filtering

If used in the Frequency Domain Filter

KPASS = 1 filter

KPASS = 0 no filter

If used in MAIN04

KFIL = 1 Lowpass Filter Time Domain

KFIL = 2 Highpass Filter Time Domain

KFIL = 3 **Bandpass Filter Time Domain**
KFIL = 4 **No filtering**
KFIL = 5 **Frequency Domain Filter section 1**
KFIL = 6 **Frequency Domain Filter both sections**
KFIL = 7 **Frequency Domain Filter section 2**

KUNIT **Is BASIC WAVESHAPE tape unit file number.**

LA **Is the number of wiener filter weight points.**

LB **Is the number of BASIC WAVESHAPE points (before bubble pulse expansion).**

LD **Is the number of DESIRED WAVESHAPE points (before shifting by IST1).**

LENGTH **Is the initial length of the bubble pulse period after expansion of the BASIC WAVESHAPE.**

LF **Determines the last data point of the BASIC WAVESHAPE for bubble pulse expansion (relative to first data point read from tape).**

LS **Determines the first data point of the BASIC WAVESHAPE for bubble pulse expansion (relative to first data point read from tape).**

L1 **Controls the plotting of the line on the computer listing if 0, do not list plot; if greater than 0, list L1 points in plot (this does not affect plot output).**

L2 **Controls the plotting of the first return on computer listing. If 0, do not list plot; if greater than 0, list L1 points starting at picked first return.**

N(I), NIA **These two are the same parameter. They control how many filter weights are used by Time Domain Filter for filtering. N(I) equals 1/2 filter weights. I=1 for lowpass parameters, I=2 for highpass parameters.**

NDATAP **The maximum number of data points a data tape record will have. It may be greater than the actual number of data points.**

NFILE **The last record read.**

NSAMP **The number of "interval spectral analysis" performed by the Spectral Analysis Program.**

NUNIT **This is the output unit for SDDS output tape and normally is unit 1. Tape must be assigned medium density.**

NZERO **Indicates the number of rejection filters used by the Frequency Domain Filter.**

PHASE **Shifts the phase of the data being filtered. Normally this value is zero.**

SAMP1	Determines the height of the graphs plotted for the frequency analysis of all data and the time domain plot of the data.
SAMP2	Determines the offset between successive interval analyses. If SAMP2 equals 0, then $SAMP1 = SAMP2 = 10/NSAMP$.
SAMP3	Determines the height of interval analysis.
SCALE	If analog tapes are digitized, but at a different than real time rate, this factor compensates for the change. $SCALE = \frac{\text{speed at playback}}{\text{speed at recording}}$
SCALEX	Vertical height (in.) of the plot information.
SCALEY	Horizontal length (in.) of the plot for 2000 points of information.
SCTSTK	Value determines how many records are stacked.
SHIFT	The first point plotted in the time domain spectrum.
SMSEC	"Interval Spectral Analysis" number of data points or frequencies for analysis.
TAPE	This number is written on the graph which is plotted.
TIME	The last data point, relative to time, plotted in the "time domain spectrum".
TSHIFT	Time shifts the data by TSHIFT number of points.
XFAC	Scales down the size of the plot in the Spectrum Analysis Program.

VIII. REFERENCES

- 1) Linnette, H. M., "Statistical Filters for Smoothing and Filtering Equally Spaced Data" (10 July 1961), NEL/Report 1049, San Diego, California, U. S. Navy Electronics Laboratory.
- 2) Robinson, Enders A., "Multichannel Time Series Analysis with Digital Computer Programs" (1967), San Francisco, California, Holden-Day, Inc., p. 71-77.
- 3) Davis, Thomas M., Kontis, Angelo L., "Spline Interpolation Algorithms for Track-type Survey Data with Application to the Computation of Mean Gravity Anomalies" (December 1970), Technical Report TR 226, U. S. Naval Oceanographic Office, Washington D. C.

APPENDIX A
Computer Listing (UNIVAC 1108)

MAIN01

0F05,US W.MAIN01
FOR E3AB-09/16/77-02:38:07 (5,6)

MAIN PROGRAM

STORAGE USED: CODE(1) 001031; DATA(0) 015115; BLANK COMMON(2) 000005

EXTERNAL REFERENCES (BLOCK, NAME)

- 0003 NTRAM
- 0004 SUB001
- 0005 SUB026
- 0006 SUB008
- 0007 SUB045
- 0010 SUB002
- 0011 NINTRS
- 0012 MRDUS
- 0013 MI02S
- 0014 MRDUS
- 0015 MERR2S
- 0016 MI01S
- 0017 MSTOP5

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

Block	Type	Relative Location	Name
0001	0001	000165 100L	000171 110L
0001	0001	000425 160L	001026 180L
0000	0000	015017 210F	015036 220F
0001	0000	000276 2406	000327 2536
0001	0001	000465 3246	000114 40L
0001	0001	000145 70L	000161 90L
0000 R	000000	DATA	R 014757 AMAX
0000 L	014743	HIGH	R 000000 FSAMP
0000 I	014761	IPOINT	I 000003 IMOVE
0000 I	014756	I2000	I 014762 IUNIT
0000 I	014755	KOUT	I 014774 MKTEST
0000 I	014751	MFILE	I 013610 N
0000 R	014771	SCALEY	R 014777 SCALEY
0000 R	014266	M6TL	R 000001 TIMAX
0001	0001	000175 170L	000175 170L
0001	0001	015000 190F	000110 20L
0000	0000	015050 230F	015067 240F
0001	0001	000401 2766	000112 30L
0001	0001	000114 50L	000137 60L
0000 R	014757	AMAX	R 013604 CUT
0000 R	000000	FSAMP	R 013606 M
0000 I	000003	IMOVE	I 014750 INCR
0000 I	014762	IUNIT	I 014764 IUNIT1
0000 I	014774	MKTEST	I 014765 KOUNT
0000 I	013610	N	I 014753 MUATAP
0000 R	014777	SCALEY	R 014770 SCALEX
0000 R	000001	TIMAX	R 013612 WGTN
0000 R	014776	XMAX	R 014776 XMAX

CXXXX MAIN01 PROGRAM TO READ SDAS TAPE AND WRITE SDDS TAPE.

- 00100 1* CXXXX IMOVE = NUMBER OF EOF TO MOVE INTO TAPE
- 00100 2* CXXXX IMOVE MUST BE 1 OR GREATER
- 00100 3* CXXXX INCR = INCREMENT OF FILES TO BE PROCESSED
- 00100 4* CXXXX MFILE = NUMBER OF FILES OF BE PPOCESSED
- 00100 5* CXXXX IPRT = INCREMENT OF PROCESSED FILES TO BE PRINTED
- 00100 6* CXXXX IUNIT = INPUT TAPE UNIT
- 00100 7* CXXXX NUNIT = OUTPUT TAPE UNIT
- 00100 8* CXXXX CUT=NORMALIZED FILTER CUT-OFF FREQ.
- 00100 9* CXXXX I=I. CUT -OFF FREQ./SAMPLE RATE =30 HZ/1000 SAMPLES PER SEC.
- 00100 10* CXXXX H=CONTROL SLOPE OF THE FILTER (RISE/FALL)
- 00100 11* CXXXX N=HALF LENGTH OF THE FILTER
- 00100 12*


```

00161 70*
00161 71*
00162 72*
00164 73*
00166 74*
00167 75*
00171 76*
00172 77*
00174 78*
00175 79*
00177 80*
00200 81*
00201 82*
00202 83*
00203 84*
00204 85*
00205 86*
00206 87*
00207 88*
00210 89*
00212 90*
00214 91*
00221 92*
00227 93*
00235 94*
00246 95*
00250 96*
00252 97*
00255 98*
00256 99*
00260 100*
00261 101*
00262 102*
00264 103*
00265 104*
00270 105*
00271 106*
00273 107*
00275 108*
00300 109*
00302 110*
00303 111*
00305 112*
00306 113*
00307 114*
00310 115*
00311 116*
00311 117*
00312 118*
00316 119*
00316 120*
00316 121*
00316 122*
00316 123*
00316 124*
00317 125*
00321 126*

C
50 CONTINUE
C DECISION ON REQUESTED OUTPUTS
  IF ((KOUT.LE.0).OR.(KOUT.GE.16)) GO TO 120
  IF (KOUT.GT.4) GO TO 110
  SDAS=.TRUE.
  60 IF (KOUT.GT.4) GO TO 100
  SDDS=.TRUE.
  70 IF (KOUT.GT.2) GO TO 90
  PLOT=.TRUE.
  80 IF (KOUT.EQ.1) FILE1=.TRUE.
  GO TO 120
  90 KOUT=KOUT-2
  GO TO 80
  100 KOUT=KOUT-4
  GO TO 70
  110 KOUT=KOUT-8
  GO TO 60
  120 CONTINUE
  XDIV=3.0
  IF (IFILE.LT.0) XDIV=1/XDIV
  IF (IFILE.LT.0) IFILE=-IFILE
  IF (PLOT) READ (5,19C) SCALEX,SCALEY
  IF (LOW) READ (5,190) CUT(1),M(1),N(1)
  IF (HIGH) READ (5,190) CUT(2),H(2),N(2)
  IF (HIGH.OR.LOW) WRITE (6,22C) (CUT(I),H(I)),N(I),I=1,2)
  IF (SDDS) CALL NTPAN (NUNIT,9)
  IF (SDAS) CALL NTPAN (IUNIT1,9)
  DO 170 MFILE=MOVE,NFILE,INCRF
    KOUNT=KOUNT+1
    IF (KFILE.GE.MFILE) IPR=1
    EXIT=0
    CALL SUB001 (IUNIT,IPR,DATA,KK)
    IF (KK.LT.NDATAP) GO TO 130
    NDATAP=KK
    WRITE (6,230) NDATAP
    GO TO 180
  130 IF (KK.LT.1) GO TO 180
    IF (KFILE.GT.IFILE) GO TO 150
    DO 140 I=1,KK
      DATA(I)=DATA(I)*XDIV
  140 CONTINUE
  150 IF (KFILE.GT.IMOVE) GO TO 160
    CUT(1)=CUT(1)/FSAMP
    CUT(2)=CUT(2)/FSAMP
    H(1)=H(1)/FSAMP
    H(2)=H(2)/FSAMP
  160 CONTINUE
    WRITE(6,220)(DATA(I),I=1,KK)
    IF (KKTEST.NE.KK) WRITE (6,250) KK
    KKTEST=KK

C
CXXXX DATA PROCESSING SUBROUTINES SHOULD BE INSERTED HERE.
CXXXX ANY ADDITIONAL DIMENSION STATEMENTS REQUIRED SHOULD
CXXXX ALSO BE ADDED
C
  IF (I2000.EQ.1) KK=2300
  IF ((KFILE.EQ.IMOVE).AND.FILE1) WRITE (6,240) (DATA(I),I=1,KK)

```


FOR,US M,MAIN02
FOR E3A6-09/16/77-02:38:11 (3,4)

MAIN PROGRAM

STORAGE USED: CODE(1) 000672: DATA(1) C23752: BLANK COMMON(2) 000005

EXTERNAL REFERENCES (BLOCK, NAME)

- 0003 NTRAN
- 0004 SUP001
- 0005 SUE012
- 0006 SUB018
- 0007 SUP017
- 0010 SUB047
- 0011 SUB011
- 0012 SUP008
- 0013 SUE045
- 0014 SUB002
- 0015 NINTR5
- 0016 NRDU5
- 0017 NI025
- 0020 NVDU5
- 0021 NI015
- 0022 XPII
- 0023 NSTOPS

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001	000114	10L	0001	000310	100L	0001	000407	110L	0001	000440	120L	0001	000666	140L
0000	023646	150F	0000	023647	160F	0000	023665	170F	0700	023704	180F	0000	023723	190F
0001	000122	20L	0000	023725	200F	0001	000232	206G	0001	000304	231G	0001	000350	250G
0001	000130	30L	0001	000553	321G	0001	000136	40L	0001	000142	50L	0001	000146	60L
0001	000152	70L	0001	000270	80L	0000	R 023623	AMAX	0000	R 000000	DATA	0002	R 000004	EXIT
0000	L 023613	FILE1	0002	R 000000	FSAMP	0000	I 023636	I	0000	I 023624	IFILE	0002	I 000000	IMOVE
0000	I 023614	INCR	0000	I 023625	IPPOINT	0000	I 023632	IPR	0000	I 023616	IPRT	0000	I 023626	IUNIT
0000	I 023630	IUNIT1	0000	I 023622	I2000	0000	I 023642	J	0002	I 000002	KFILE	0000	I 023635	KK
0000	I 023637	MKTEST	0000	I 023631	KOUNT	0000	I 023621	KOUT	0000	I 023620	KPASS	0000	I 023640	M
0000	I 023617	NDATAP	0000	I 023615	NFILE	0000	I 023641	NP	0000	I 023627	NUNIT	0000	R 017606	P
0000	L 023612	PLOT	0000	R 023645	SCALEY	0000	R 023633	SCALEX	0000	R 023634	SCALEY	0000	L 023610	SDAS
0000	L 023611	SDDS	0002	P 000001	TIMAX	0000	R 023643	XMAX	0000	R 023644	XMAXY	0000	P 013604	Y

00100 1* CXXXX MAIN02 PROGRAM TO READ SDAS TAPE AND WRITE SDOS TAPE.

00100 2* CXXXX IMOVE = NUMBER OF EOF TO MOVE INTO TAPE

00100 3* CXXXX IMOVE MUST BE 1 OR GREATER

00100 4* CXXXX INCR = INCREMENT OF FILES TO BE PROCESSED

00100 5* CXXXX MFILE = NUMBER OF FILES OF BE PROCESSED

00100 6* CXXXX IPRT = INCREMENT OF PROCESSED FILES TO BE PRINTED

00100 7* CXXXX IUNIT = INPUT TAPE UNIT

00100 8* CXXXX MUNIT = OUTPUT TAPE UNIT

00100 9* CXXXX MPASS 1 = BANDPASS 0 = NO FILTER

00100 10* CXXXX KOUT -- OUTPUT REQUEST VARIABLE

* POSSIBLE OUTPUTS
 SDAS - WRITE SDAS TAPE
 SDDS - WRITE SDDS TAPE
 PLOT - WRITE CALCOMP PLOT TAPE
 FILE1 - WRITE OUT FIRST INPUT FILE

CXXXX	KOUT=	SDAS	SDDS	PLOT	FILE1
C	C	NO	NO	NO	NO
C	1	YES	YES	YES	YES
C	2	YES	YES	YES	NO
C	3	YES	YES	NO	YES
C	4	YES	YES	NO	NO
C	5	YES	NO	YES	YES
C	6	YES	NO	YES	NO
C	7	YES	NO	NO	YES
C	8	YES	NO	NO	NO
C	9	NO	YES	YES	YES
C	10	NO	YES	YES	NO
C	11	NO	YES	NO	YES
C	12	NO	YES	NO	NO
C	13	NO	NO	YES	YES
C	14	NO	NO	YES	NO
C	15	NO	NO	NO	YES
C	16	NO	NO	NO	NO

CXXXX NTRAN STATUS WORDS =
 -1 = TRANSMISSION NOT COMPLETE
 -2 = END OF FILE(READ),END OF TAPE(WRITE)
 -3 = DEVICE ERROR
 -4 = TRANSMISSION ABORTED

COMMON FSAMP, IIMAX, MFILE, IMOVE, EXIT
 DIMENSION DATA(6020), Y(2050), P(2050)
 LOGICAL SDAS, SDDS, PLOT, FILE1
 READ (5,150) IMOVE, INCR, MFILE, IPRT, NDATAP
 READ (5,150) MPASS, KOUT, IZOO, AMAX, IFTLE, IPOINT
 WRITE (6,160) IMOVE, INCR, MFILE, IPRT
 READ (5,150) IUNIT, MUNIT
 IUNIT1=IUNIT+1
 WRITE (6,170) IUNIT, MUNIT, IUNIT1
 CALL NTRAN (IUNIT, 8, IMOVE)
 KOUNT=0
 IPR=1

C DECISION ON REQUESTED OUTPUTS
 IF ((KOUT.LE.C).OR.(KOUT.GE.16)) GO TO 70
 IF (KOUT.GT.8) GO TO 60
 SDAS=.TRUE.
 10 IF (KOUT.GT.4) GO TO 50
 SDDS=.TRUE.
 20 IF (KOUT.GT.2) GO TO 40
 PLOT=.TRUE.
 30 IF (KOUT.EQ.1) FILE1=.TRUE.
 40 KOUT=KOUT-2
 60 TO 30
 50 KOUT=KOUT-4
 60 TO 20
 60 KOUT=KOUT-8

11* 00100
 12* 00100
 13* 00100
 14* 00100
 15* 00100
 16* 00100
 17* 00100
 18* 00100
 19* 00100
 20* 00100
 21* 00100
 22* 00100
 23* 00100
 24* 00100
 25* 00100
 26* 00100
 27* 00100
 28* 00100
 29* 00100
 30* 00100
 31* 00100
 32* 00100
 33* 00100
 34* 00100
 35* 00100
 36* 00100
 37* 00100
 38* 00100
 39* 00100
 40* 00100
 41* 00101
 42* 00103
 43* 00104
 44* 00105
 45* 00114
 46* 00124
 47* 00132
 48* 00135
 49* 00137
 50* 00144
 51* 00145
 52* 00146
 53* 00146
 54* 00147
 55* 00151
 56* 00153
 57* 00154
 58* 00156
 59* 00157
 60* 00161
 61* 00162
 62* 00164
 63* 00165
 64* 00166
 65* 00167
 66* 00170
 67* 00171

```

680
690
700
710
720
730
740
750
760
770
780
790
800
810
820
830
840
850
860
870
880
890
900
910
920
930
940
950
960
970
980
990
1000
1010
1020
1030
1040
1050
1060
1070
1080
1090
1100
1110
1120
1130
1140
1150
1160
1170
1180
1190
1200
1210
1220
1230
1240

GO TO 10
70 CONTINUE
IF (PLOT) READ (5,150) SCALEX,SCALEY
IF (SDS) CALL NTRAM (NUNIT,9)
IF (SDAS) CALL NTRAM (IUNIT1,9)
DO 130 NFILE=IMOVE,NFILE,INCRE
  NOUNT=NOUNT+1
  IF (NFILE=6E.NFILE) IPR=1
  EXIT=0
  CALL SUBOC1 (IUNIT,IPR,DATA,MK)
  IF (MK.LT.NDATAP) GO TO 80
  NDATAP=MK
  WRITE (6,180) NDATAP
  GO TO 140
80 IF (MK.LT.1) GO TO 140
  IF (NFILE=6T.IFILE) GO TO 100
  DO 90 I=1,MK
    DATA(I)=DATA(I)*3
  90 CONTINUE
  100 WRITE(6,220)(DATA(I),I=1,MK)
  IF (MKTEST.NE.MK) WRITE (6,200) MK
  MKTEST=MK
C
CXXXX DATA PROCESSING SUBROUTINES SHOULD BE INSERTED HERE.
CXXXX ANY ADDITIONAL DIMENSION STATEMENTS REQUIRED SHOULD
CXXXX ALSO BE ADDED
C
  IF (I2000.EQ.1) MK=2500
  IF (NFILE.EQ.IMOVE).AND.(FILE1) WRITE (6,190) (DATA(I),I=1,MK)
  IF (NPASS.NE.1) GO TO 120
C
  IF (NFILE=6T.IMOVE) GO TO 110
  I=MK
  CALL SUBO12 (I,DATA,M)
  NP=2**M
  WRITE (6,170) FSAMP,TIMAX
  J=1
C
CXXXX SUBO10 TAPERS THE INPUT DATA * THE ZERO FILL(2**M)
110 CALL SUBO10 (NP,1,NP,1,DATA)
C
  CONVERT THE REAL TIME DOMAIN DATA INTO THE CARTESIAN FORM
  CALL SUBO17 (M,DATA,-1,C)
  CALL SUBO47 (DATA,Y,P,MP)
  CALL SUBO11 (Y,P,MP,M,DATA)
  120 EXIT=1
C
  IF (NFILE.EQ.IMOVE) CALL SUBOC8 (DATA,MK,XMAX)
  CALL SUBO08 (DATA,MK,XMAX)
  IF (AMAX.LT.C.AND.NFILE.EQ.IMOVE) XMAXT=XMAX
  IF (AMAX.EQ.C) XMAXT=XMAX
  IF (AMAX=6T.O.O.AND.NFILE.EQ.IMOVE) XMAXT=AMAX
  XMAX=XMAXT
  IF (I2000.EQ.1) MK=2000
  IF (I2000=6T.1) MK=I2000
  IF (SDAS) CALL SUBO01 (IUNIT,IPR,DATA(IPOINT),MK)
  IF (MK.LT.1) GO TO 140
  IF (FILE1) WRITE (6,190) (DATA(I),I=1,MK)

```

00325 125*
 00326 126*
 00330 127*
 00332 128*
 00334 129*
 00336 130*
 00340 131*
 00342 132*
 00344 133*
 00346 134*
 00347 135*
 00351 136*
 00353 137*
 00355 138*
 00355 139*
 00356 140*
 00357 141*
 00357 142*
 00360 143*
 00360 144*
 00361 145*
 00361 146*
 00362 147*
 00363 148*
 00363 149*
 00364 150*
 END FOR

```

SCALET=SCALEY*MK/2000
IF (MFILE.EQ.IMOVE) IPR=-1
IF (MFILE.EQ.NFILE) IPR=-2
IF (PLOT) CALL SURC45 (SCALEX,SCALET,IPR,XMAX,DATA,MK)
IF (SDDS) CALL SUB002 (MK,DATA,MUNIT,XMAX)
IF (MK.LI.1) GO TO 140
IF (MOUNT.EQ.IPR) IPR=1
IF (MOUNT.LT.IPR) IPR=0
CALL NTRAN (MUNIT,8,INCRE)
CONTINUE
130 IF (SDDS) CALL NTRAN (MUNIT,9)
    IF (SDAS) CALL NTRAN (MUNIT,9)
140 STOP
C
150 FORMAT (I)
160 FORMAT (//,4X,INCRE = ,I6,4X,INCRE = ,I6,4X,NFILE = ,I6,4X,
    IPR = ,I6)
170 FORMAT (//,10X,INPUT TAPE UNIT = ,I3,10X,SDDS TAPE UNIT = ,I3,10
    1X,SDAS TAPE UNIT = ,I3)
180 FORMAT (5X,10(6H*****),5X,CHANGE IN THE SIZE OF THE DATA ARRAY
    170 ,I10//5X,I10(6H*****))
190 FORMAT (5X,10F2.5)
200 FORMAT (5X,MK=,I8)
C
END
    
```

00MDG,P MAIN03

MAIN PROGRAM

STORAGE USED: CODE(1) 000622: DATA(1) 013760; PLANK COMMON(2) 000005

EXTERNAL REFERENCES (BLOCK, NAME)

0003 NTRAN
 0004 SUB001
 0005 SUB049
 0006 SUB008
 0007 SUB045
 0010 SUB002
 0011 MINTRS
 0012 MRDUS
 0013 NI02S
 0014 MRDUS
 0015 NI01S
 0016 WSTOPS

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001 000133 10L 0001 000310 100L 0001 000405 110L 0001 000555 120L 0001 000616 140L
 0000 013637 150F 0000 013640 160F 0000 013656 17CF 0000 013675 180F 0000 013714 190F
 0001 000141 20L 0000 013716 200F 0000 013721 21CF 0001 000232 216G 0001 000304 2416
 0001 000343 2566 0001 000147 30L 0001 000503 315G 0001 000155 40L 0001 000161 50L
 0001 000165 60L 0001 000171 70L 0001 000270 80L 0000 R 013610 AMAX 0000 R 000000 DATA
 0002 R 000004 EXIT 0000 L 013607 FILE1 0002 000000 FSAMP 0000 I 013633 I 0000 I 013616 IARRAY
 0000 I 013621 IFILE 0002 I 000003 IMOVE 0000 I 013612 INCRE 0000 I 013622 IPOINT 0000 I 013627 IPRR
 0000 I 013614 IPRT 0000 I 013623 IUNIT 0000 I 013625 IUNIT1 0000 I 013620 I2000 0002 I 000002 KFILE
 0000 I 013632 KK 0000 I 013634 MRTEST 0000 I 013626 KOUNT 0000 I 013617 KOUT 0000 I 013615 MDATAF
 0001 I 013613 MFILE 0000 I 013624 MUNIT 0000 R 013636 SCALET 0000 P 013630 SCALEX
 0000 R 013631 SCALEY 0000 L 013604 SDAS 0000 L 013606 PLOT 0000 R 000001 TMAX
 0000 R 013635 XMAXT 0000 L 013605 SDDS 0002 000001 TMAX

CXXX MAIN01 PROGRAM TO READ SDAS TAPE AND WRITE SDDS TAPE.

00100 1* CXXX IMOVE = NUMBER OF EOF TO MOVE INTO TAPE
 00100 2* CXXX IMOVE MUST BE 1 OR GREATER
 00100 3* CXXX INCRE = INCREMENT OF FILES TO BE PROCESSED
 00100 4* CXXX MFILE = NUMBER OF FILES OF BE PROCESSED
 00100 5* CXXX IPRT = INCREMENT OF PROCESSED FILES TO BE PRINTED
 00100 6* CXXX IUNIT = INPUT TAPE UNIT
 00100 7* CXXX MUNIT = OUTPUT TAPE UNIT
 00100 8* CXXX KOUT -- OUTPUT REQUEST VARIABLE
 00100 9* CXXX KOUT -- POSSIBLE OUTPUTS
 00100 10* CXXX SDAS - WRITE SDAS TAPE
 00100 11* CXXX SDDS - WRITE SDDS TAPE
 00100 12* CXXX PLOT - WRITE CALCOMP PLOT TAPE
 00100 13* CXXX FILE1 - WRITE OUT FIRST INPUT FILE
 00100 14* CXXX
 00100 15* C

```

00100 16*
00100 17*
00100 18*
00100 19*
00100 20*
00100 21*
00100 22*
00100 23*
00100 24*
00100 25*
00100 26*
00100 27*
00100 28*
00100 29*
00100 30*
00100 31*
00100 32*
00100 33*
00100 34*
00100 35*
00100 36*
00100 37*
00100 38*
00100 39*
00101 40*
00103 41*
00104 42*
00105 43*
00106 44*
00110 45*
00117 46*
00127 47*
00135 48*
00142 49*
00146 50*
00147 51*
00154 52*
00155 53*
00156 54*
00156 55*
00157 56*
00161 57*
00163 58*
00164 59*
00166 60*
00167 61*
00171 62*
00172 63*
00174 64*
00175 65*
00176 66*
00177 67*
00200 68*
00201 69*
00202 70*
00203 71*
00204 72*

C KOUT= SDAS SDDS PLOT FILE1
C 0 NO NO NO NO
C 1 YES YES YES YES
C 2 YES YES YES YES
C 3 YES YES YES YES
C 4 YES YES YES YES
C 5 YES YES YES YES
C 6 YES YES YES YES
C 7 YES YES YES YES
C 8 YES YES YES YES
C 9 NO YES YES YES
C 10 NO YES YES YES
C 11 NO YES YES YES
C 12 NO YES YES YES
C 13 NO YES YES YES
C 14 NO YES YES YES
C 15 NO YES YES YES
C 16 NO YES YES YES
CXXXX NTRAN STATUS WCROS =
CXXXX -1 = TRANSMISSION NOT COMPLETE
CXXXX -2 = END OF FILE(READ),END OF TAPE(WRITE)
CXXXX -3 = DEVICE ERROR
CXXXX -4 = TRANSMISSION ABORTED
C

COMMON FSAMP, TIMAX, KFILE, IMOVE, EXIT
DIMENSION DATA(6020)
LOGICAL SDAS, SDDS, PLOT, FILE1
EXIT=10.0
IF (AMAX.LT.0) XMAX=-AMAX
READ (5,150) IMOVE, INCRE, MFILE, IPRT, MNDATAP
READ (5,150) IARRAY, KOUT, I2000, AMAX, IFILE, IPOINT
WRITE (6,160) IMOVE, INCRE, MFILE, IPRT
WRITE (6,210) IARRAY, IPOINT, I2000
READ (5,150) IUNIT, NUNIT
IUNIT1=IUNIT+1
WRITE (6,170) IUNIT, NUNIT, IUNIT1
CALL NTRAN (IUNIT, B, IMOVE)
KOUNT=0
IPR=1

C DECISION ON REQUESTED OUTPUTS
IF ((KOUT.LE.0).OR.(KOUT.GE.16)) GO TO 70
IF (KOUT.GT.8) GO TO 60
SDAS=.TRUE.
10 IF (KOUT.GT.4) GO TO 50
SDDS=.TRUE.
20 IF (KOUT.GT.2) GO TO 40
PLOT=.TRUE.
30 IF (KOUT.EQ.1) FILE1=.TRUE.
40 KOUT=KOUT-2
50 KOUT=KOUT-4
60 KOUT=KOUT-8
70 CONTINUE
IF (PLOT) READ (5,150) SCALEX, SCALEY

```

MAIN03

00211 73*
 00213 74*
 00215 75*
 00220 76*
 00221 77*
 00223 78*
 00224 79*
 00225 80*
 00227 81*
 00230 82*
 00233 83*
 00234 84*
 00236 85*
 00240 86*
 00243 87*
 00245 88*
 00246 90*
 00252 91*
 00252 92*
 00252 93*
 00252 94*
 00252 95*
 00252 96*
 00253 97*
 00252 98*
 00264 99*
 00266 100*
 00270 101*
 00271 102*
 00272 103*
 00274 104*
 00275 105*
 00277 106*
 00301 107*
 00303 108*
 00305 109*
 00306 110*
 00310 111*
 00312 112*
 00321 113*
 00322 114*
 00324 115*
 00326 116*
 00330 117*
 00332 118*
 00334 119*
 00335 120*
 00337 121*
 00341 122*
 00343 123*
 00344 124*
 00346 125*
 00350 126*
 00352 127*
 00352 128*
 00353 129*

```

IF (SD05) CALL NTRAN (NUNIT,9)
IF (SDAS) CALL NTRAN (IUNIT1,9)
DO 130 KFILE=IMOVE,NFILE,INCRE
  KOUNT=KOUNT+1
  IF (KFILE.E6.NFILE) IPR=1
  EXIT=0
  CALL SUB001 (IUNIT,IPR,DATA,KK)
  IF (KK.LT.NDATAP) GO TO 80
  NDATAP=KK
  WRITE (6,180) NDATAP
  GO TO 140
80  IF (KK.LT.1) GO TO 140
  IF (KFILE.GT.IFILE) GO TO 100
  DO 90 I=1,KK
  90  DATA(I)=DATA(I)*3
  100 CONTINUE
  C  WRITE(6,220)(DATA(I),I=1,KK)
  IF (KKTEST.NE.KK) WRITE (6,200) KK
  KKTEST=KK
  C
  CXXXX DATA PROCESSING SUBROUTINES SHOULD BE INSERTED HERE.
  CXXXX ANY ADDITIONAL DIMENSION STATEMENTS REQUIRED SHOULD
  CXXXX ALSO BE ADDED
  C
  IF (KFILE.EQ.IMOVE).AND.(FILE1) WRITE (6,190) (DATA(I),I=1,KK)
  IF (I2000.GT.1) KK=I2000
  IF (I2000.EQ.1) KK=2000
  IF (IARRAY.LE.1) GO TO 110
  EXIT=XMAX
  CALL SUB049 (DATA,KK,IARRAY,IPOINT,I2000)
  IF (KFILE.LT.IMOVE+IARRAY-1) GO TO 120
  110 EXIT=1
  IF (KFILE.EQ.IMOVE) CALL SUB006 (DATA,KK,XMAX)
  IF (AMAX.LT.0.AND.KFILE.EQ.IMOVE) XMAX=XMAX
  IF (AMAX.EQ.0) XMAX=XMAX
  IF (AMAX.GT.0.AND.KFILE.EQ.IPOVF) XMAX=XMAX
  XMAX=XMAX
  IF (SDAS) CALL SUB001 (IUNIT,IPR,DATA(I),KK)
  IF (KK.LT.1) GO TO 140
  IF (FILE1) WRITE (6,190) (DATA(I),I=1,KK)
  SCALEY=SCALEY*KK/2000
  IF (KFILE.EQ.IMOVE) IPR=-1
  IF (KFILE.EQ.NFILE) IPR=-2
  IF (PLOT) CALL SUB045 (SCALEY,SCALEY,IPR,XMAX,DATA,KK)
  IF (SD05) CALL SUB002 (KK,DATA,NUNIT,XMAX)
  IF (KK.LT.1) GO TO 140
  120 CONTINUE
  IF (KOUNT.EQ.IPRT) IPR=1
  IF (KOUNT.LT.IPRT) IPR=0
  IF (KOUNT.EQ.IPRT) KOUNT=0
  CALL NTRAN (IUNIT,8,INCRE)
  130 CONTINUE
  IF (SD05) CALL NTRAN (NUNIT,9)
  IF (SDAS) CALL NTRAN (IUNIT1,9)
  140 STOP
  C  150 FORMAT (I)

```

MAIN03

00354
 00354
 00355
 00355
 00356
 00356
 00357
 00360
 00361
 00361
 00362
 1410
 END FOR

160 FORMAT (//,4X,'IMOVE = ',I6,4X,'INCRE = ',I6,4X,'NFILE = ',I6,4X,'
 11PRT = ',I6)
 170 FORMAT (//,10X,'INPUT TAPE UNIT = ',I3,10X,'SDDS TAPE UNIT = ',I3,10
 1X,'SDAS TAPE UNIT = ',I3)
 180 FORMAT (5X,10(6H*****))/,5X,'CHANGE IN THE SIZE OF THE DATA ARRAY
 110 ',I10//5X,10(6H*****))
 190 FORMAT (5X,10F8.5)
 200 FORMAT (5X,'MK=',I8)
 210 FORMAT (10X,'NUMBER OF ARRAYS= ',I3,/, 'DELAY EACH ARRAY BY',I5,'PT
 15',/,5X,'MAXIMUM NUMBER OF PTS = ',I75)

C

END

END06,P MAIN04

FOR, US W. MAIN04
FOR E345-09/16/77-02:38:20 (21.22)

MAIN PROGRAM

STORAGE USED: CODE(1) 002576; DATA(0) 050007; BLANK COMMON(2) 000005

EXTERNAL REFERENCES (BLOCK, NAME)

0003 NTRAM
 0004 SUP001
 0005 SUB026
 0006 SUB012
 0007 SUP018
 0010 SUB017
 0011 SUB047
 0012 SUB011
 0013 SUB008
 0014 SUP045
 0015 SUP024
 0016 SUB048
 0017 SUB020
 0020 SUP023
 0021 SUB002
 0022 NINTRS
 0023 NROUS
 0024 NI025
 0025 NWDUS
 0026 NERR25
 0027 NI015
 0030 XPII
 0031 NSTOPS

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001	000100	10L	000160	100L	000164	110L	000170	120L	000170	130L	
0001	000436	140L	000505	150L	000552	160L	000613	170L	000613	180L	
0001	000103	20L	000656	200L	001050	220L	001050	230L	001121	240L	
0001	000315	260L	001161	260L	001252	280L	001274	290L	001005	30L	
0001	001313	300L	001522	350L	000617	356G	001605	370L	001701	380L	
0001	000107	40L	001764	400L	000776	403G	002060	410L	001015	411G	
0001	002202	430L	001067	432G	002257	440L	002301	450L	001145	460G	
0001	002332	460L	002505	470L	002572	490L	000107	50L	0000	047565	500F
0001	001210	501G	001222	507G	047567	510F	047570	520F	0001	001267	524F
0000	047606	530F	0000	047621	540F	0001	001322	544G	0000	047633	560F
0001	001362	562G	0000	047643	570F	0001	001453	576G	0000	047654	590F
0001	000132	60L	0000	047661	600F	0000	047667	610F	0001	001512	611G
0001	001343	625G	0000	047703	630F	0001	001555	633G	0000	047675	620F
0001	001642	654G	0000	047717	660F	0000	047723	670F	0000	047712	650F
0001	000140	70L	0001	001734	705G	0001	002022	725G	0001	001722	677G
0001	000154	90L	0000	047672	A	0000	047512	AMAX	0000	002115	753G
0000	R 030042	C	0000	R 030034	CUT	0000	R 044346	D	0000	R 047562	ASE
0002	R 000004	EXIT	0000	L 047475	FILE1	0002	R 000000	FSAMP	0000	R 024114	DATAT
0000	I 047540	I	0000	I 047523	IAVE	0000	I 047510	IEXPND	0000	L 047476	HIGH
0000	I 047557	IJK	0000	I 047551	IKOUNT	0002	I 000003	IMOVE	0000	I 047513	IFILE
									0000	I 047517	INCLN
									0001	R 044550	B
									0000	R 047500	INCR

```

0000 I 047514 IPOINT
0000 I 047537 IST2
0000 I 047535 KR
0000 I 047563 KOUNT
0000 I 047554 K2
0000 I 047516 LENGTH
0000 I 047556 LST
0000 I 047545 NP
0000 R 047555 SVELB
0000 L 047474 SDDS
0000 R 047522 XDIV
0000 I 047542 IPR
0000 I 047515 ITER
0000 I 047536 KE
0000 I 047507 KOUT
0000 I 047531 LA
0000 I 047521 LF
0000 I 047544 M
0000 I 047505 MUNIT
0000 R 047550 SCALET
0000 R 045212 SPACE
0000 R 047547 XMAX
0000 I 047502 IPRT
0000 I 047504 IUNIT
0002 I 000002 KFILE
0000 I 047506 KPASS
0000 I 047532 LB
0000 I 047560 LFT
0000 I 03004C N
0000 R 020114 P
0000 R 047526 SCALEX
0002 000001 YIMAX
0000 R 047564 XMAX
0000 I 047530 IPUNIT
0000 I 047511 I20PG
0000 I 047543 KM
0000 I 047525 KUNIT
0000 I 047561 LC
0000 I 047477 LOW
0000 I 047520 LS
0000 I 047501 NFILE
0000 L 047472 PLOT
0000 L 047473 SDAS
0000 R 047162 W6TL

```

CXXXX MAIN04 PROGRAM TO READ SDAS TAPE AND WRITE SDDS TAPE.

```

1* CXXXX IMOVE = NUMBER OF EOF TO MOVE INTO TAPE
2* CXXXX IMOVE MUST BE 1 OR GREATER
3* CXXXX INCRE = INCREMENT OF FILES TO BE PROCESSED
4* CXXXX NFIL = NUMBER OF FILFS OF BE PROCESSED
5* CXXXX IPRT = INCREMENT OF PROCESSED FILES TO BE PRINTED
6* CXXXX IUNIT = INPUT TAPE UNIT
7* CXXXX MUNIT = OUTPUT TAPE UNIT
8* CXXXX MUNIT = OUTPUT TAPE UNIT
9* CXXXX MUNIT = OUTPUT TAPE UNIT
10* CXXXX MUNIT = OUTPUT TAPE UNIT
11* CXXXX MUNIT = OUTPUT TAPE UNIT
12* CXXXX MUNIT = OUTPUT TAPE UNIT
13* CXXXX MUNIT = OUTPUT TAPE UNIT
14* CXXXX MUNIT = OUTPUT TAPE UNIT
15* CXXXX MUNIT = OUTPUT TAPE UNIT
16* CXXXX MUNIT = OUTPUT TAPE UNIT
17* CXXXX MUNIT = OUTPUT TAPE UNIT
18* CXXXX MUNIT = OUTPUT TAPE UNIT
19* CXXXX MUNIT = OUTPUT TAPE UNIT
20* CXXXX MUNIT = OUTPUT TAPE UNIT
21* CXXXX MUNIT = OUTPUT TAPE UNIT
22* CXXXX MUNIT = OUTPUT TAPE UNIT
23* CXXXX MUNIT = OUTPUT TAPE UNIT
24* CXXXX MUNIT = OUTPUT TAPE UNIT
25* CXXXX MUNIT = OUTPUT TAPE UNIT
26* CXXXX MUNIT = OUTPUT TAPE UNIT
27* CXXXX MUNIT = OUTPUT TAPE UNIT
28* CXXXX MUNIT = OUTPUT TAPE UNIT
29* CXXXX MUNIT = OUTPUT TAPE UNIT
30* CXXXX MUNIT = OUTPUT TAPE UNIT
31* CXXXX MUNIT = OUTPUT TAPE UNIT
32* CXXXX MUNIT = OUTPUT TAPE UNIT
33* CXXXX MUNIT = OUTPUT TAPE UNIT
34* CXXXX MUNIT = OUTPUT TAPE UNIT
35* CXXXX MUNIT = OUTPUT TAPE UNIT
36* CXXXX MUNIT = OUTPUT TAPE UNIT
37* CXXXX MUNIT = OUTPUT TAPE UNIT
38* CXXXX MUNIT = OUTPUT TAPE UNIT
39* CXXXX MUNIT = OUTPUT TAPE UNIT
40* CXXXX MUNIT = OUTPUT TAPE UNIT
41* CXXXX MUNIT = OUTPUT TAPE UNIT
42* CXXXX MUNIT = OUTPUT TAPE UNIT

```

```

C KOUT= SDAS SDDS PLOT FILE1
C 0 NO NO NO NO
C 1 YES YES YES YES
C 2 YES YES YES YES
C 3 YES YES YES YES
C 4 YES YES YES YES
C 5 YES YES YES YES
C 6 YES YES YES YES
C 7 YES YES YES YES
C 8 YES YES YES YES
C 9 NO NO NO NO
C 10 NO YES YES YES
C 11 NO YES YES YES
C 12 NO YES YES YES
C 13 NO YES YES YES
C 14 NO YES YES YES
C 15 NO YES YES YES
C 16 NO YES YES YES
CXXXX MTRAN STATUS WORDS =
CXXXX MTRAN STATUS WORDS =
CXXXX -1 = TRANSMISSION NOT COMPLETE
CXXXX -2 = END OF FILE(PEAD),END OF TAPE(WRITE)
CXXXX -3 = DEVICE ERROR
CXXXX -4 = TRANSMISSION ABORTED
C LA=NUMBER OF FILTER WT*5
C LB=NUMBER OF POINTS IN BASIC WAVE
C LD=NUMBER OF POINTS IN DESIRED WAVE
C MB=BEGINE SEARCH FOP BASIC WAVE AT THIS POINT IN SCAN

```

C ME-END SEARCH FOR BASIC WAVE AT THIS POINT IN SCAN

CXXX DIMENSION THE ARRAYS AS FOLLOWS
CXXX CILA*NO. OF SAMPLES +100)
CXXX A(LA)
CXXX D(LD)
CXXX B(LB)
CXXX SPACE(3*LA +10)

COMMON FSAMP, TMAX, KFILE, IMOVE, EXIT
DIMENSION DATA(6020), WGT(200), Y(2048), P(2048), DATAT(2000)
DIMENSION CUT(2), N(2), N(2)
DIMENSION C(6040), A(300), D(130), B(290), SPACE(1000), WGT(200)
LOGICAL PLOT, SDAS, SDDS, FILE1, HIGH, LOW
READ (5,510) IMOVE, INCRE, NFILE, IPRT, NDATA
WRITE (6,520) IMOVE, INCRE, NFILE, IPRT
READ (5,510) IUNIT, MUNIT
READ (5,510) KPASS, KOUT, IEXPND, I2000, AMAX, IFILE, IPOINT
READ (5,510) ITER, LENGTH, INCLN, LS, LF
C DECISION ON FILTERS (LOW, HIGH, BOTH, OR NEITHER)
LOW=.FALSE.
HIGH=.FALSE.
GO TO (10,30,20,50,50,50), KPASS
GO TO 40

10 LOW=.TRUE.
GO TO 40
20 LOW=.TRUE.
30 HIGH=.TRUE.
40 CONTINUE
50 CONTINUE

C DECISION ON REQUESTED OUTPUTS
IF ((KOUT.LE.0).OR.(KOUT.GE.16)) GO TO 120
IF (KOUT.GT.8) GO TO 110
SDAS=.TRUE.
60 IF (KOUT.GT.4) GO TO 100
SDDS=.TRUE.
70 IF (KOUT.GT.2) GO TO 90
PLOT=.TRUE.
80 IF (KOUT.EQ.1) FILE1=.TRUE.
GO TO 120
90 KOUT=KOUT-2
GO TO 80
100 KOUT=KOUT-4
GO TO 70
110 KOUT=KOUT-8
GO TO 60
120 CONTINUE
XDIV=3.0

IF (IFILE.LT.0) XDIV=1/XDIV
IF (IFILE.LT.0) IFILE=-IFILE
READ (5,510) IAVE, KMOVE, KUNIT
CALL NTRAN (KUNIT, 10)
IF IPLOT) READ (5,510) SCALEX, SCALEY
WRITE (6,530) KUNIT, MUNIT, IUNIT
WRITE (6,680) ITER, LENGTH, FILE1, I2000, IAVE, KMOVE
CALL NTRAN (KUNIT, 8, KMOVE)
CALL NTRAN (KUNIT, 9)
IPUNIT=IUNIT+1
READ (5,510) LA, LB, LD, IST1, KB, KE

C

- 30100
- 30101
- 30102
- 30103
- 30104
- 30105
- 30106
- 30107
- 30108
- 30109
- 30110
- 30111
- 30112
- 30113
- 30114
- 30115
- 30116
- 30117
- 30118
- 30119
- 30120
- 30121
- 30122
- 30123
- 30124
- 30125
- 30126
- 30127
- 30128
- 30129
- 30130
- 30131
- 30132
- 30133
- 30134
- 30135
- 30136
- 30137
- 30138
- 30139
- 30140
- 30141
- 30142
- 30143
- 30144
- 30145
- 30146
- 30147
- 30148
- 30149
- 30150
- 30151
- 30152
- 30153
- 30154
- 30155
- 30156
- 30157
- 30158
- 30159
- 30160
- 30161
- 30162
- 30163
- 30164
- 30165
- 30166
- 30167
- 30168
- 30169
- 30170
- 30171
- 30172
- 30173
- 30174
- 30175
- 30176
- 30177
- 30200
- 30201
- 30202
- 30203
- 30204
- 30205
- 30206
- 30207
- 30211
- 30213
- 30221
- 30226
- 30233
- 30243
- 30243
- 30244
- 30245

```

00255 100* IST2=IST1+LD-1
00256 101* READ (5,540) (C(I),I=IST1,IST2)
00264 102* IF (LOW.OR.HIGH) READ (5,510) IFTD
00270 103* IF (LOW) READ (5,510) CUT(1),M(1),N(1)
00276 104* IF (HIGH) READ (5,510) CUT(2),M(2),N(2)
00304 105* LD=IST2
00305 106* KFILE=1
00306 107* IPR=1
00307 108* I=1
00310 109* 130 CALL SUB001 (KUNIT,IPR,DATA,KK)
00311 110* IF (KK.LT.1) GO TO 490
00313 111* IF (KK.GT.2000.AND.I2000.GE.1) KK=2000
00315 112* IF (KFILE.GT.1) GO TO 140
00317 113* CUT(1)=CUT(1)/FSAMP
00320 114* M(1)=M(1)/FSAMP
00321 115* CUT(2)=CUT(2)/FSAMP
00322 116* M(2)=M(2)/FSAMP
00323 117* IF (IFTD.LE.0) GO TO 150
00325 118* IF (IFTD.LE.2.AND.LOW) CALL SUB026 (DATA,KK,CUT(1),M(1),N(1),C,WGT
00325 119* IL)
00327 120* IF (IFTD.LE.2.AND.HIGH) CALL SUB026 (DATA,KK,CUT(2),M(2),N(2),1,WG
00327 121* ITH)
00331 122* 150 CONTINUE
00332 123* IF (KPASS.GT.6.OR.KPASS.LT.5) GO TO 170
00334 124* IF (KFILE.EQ.IMOVE) KFILE=0
00336 125* IF (KFILE.NE.1) GO TO 160
00340 126* KFILE=IMOVE
00341 127* I=KK
00342 128* CALL SUB012 (I,DATA,M)
00343 129* NP=2**M
00344 130* J=1
00344 131*
00344 132* CXXXX SUB018 TAPERS THE INPUT DATA + THE ZERO FILL(2**M)
00345 133* 160 CALL SUB018 (NP,1,NP,1,DATA)
00345 134* C CONVERT THE REAL TIME DOMAIN DATA INTO THE CARTESIAN FORM
00346 135* CALL SUB017 (M,DATA,-1.0)
00346 136* C CONVERT THE CARTESIAN COORDINATES TO POLAR FORM
00347 137* CALL SUB047 (DATA,Y,NP)
00350 138* CALL SUB011 (Y,P,NP,M,DATA)
00351 139* IF (J.EQ.1) KFILE=1
00353 140* J=J+1
00354 141* 170 CONTINUE
00355 142* DO 180 I=1,KK
00360 143* 180 DATAT(I)=DATAT(I)+DATA(I)
00362 144* IF (.NOT.PLOT) GO TO 200
00364 145* IF (KFILE.GT.1) GO TO 190
00366 146* IPR=-1
00367 147* CALL SUB008 (DATA,KK,XMAX)
00370 148* 190 CONTINUE
00371 149* SCALEY=SCALEY*KK/2000
00372 150* CALL SUB045 (SCALEX,SCALEY,IPR,XMAX,DATA,KK)
00373 151* 200 CONTINUE
00374 152* IPR=1
00375 153* CALL NTRAN (KUNIT,8,1)
00375 154* IF (FILE1) WRITE (6,480) (DATA(I),I=1,KK)
00375 155* C IF (FILE1) PUNCH 390, (DATA(I),I=1,KK)
00376 156* KFILE=KFILE+1

```

```

157* 00377
158* 00400
159* 00402
160* 00405
161* 00406
162* 00410
163* 00413
164* 00415
165* 00417
166* 00421
167* 00422
168* 00423
169* 00424
170* 00425
171* 00427
172* 00436
173* 00440
174* 00441
175* 00441
176* 00443
177* 00445
178* 00447
179* 00450
180* 00452
181* 00455
182* 00455
183* 00455
184* 00456
185* 00456
186* 00456
187* 00457
188* 00462
189* 00464
190* 00466
191* 00470
192* 00470
193* 00473
194* 00474
195* 00477
196* 00505
197* 00506
198* 00511
199* 00513
200* 00515
201* 00516
202* 00517
203* 00520
204* 00520
205* 00520
206* 00521
207* 00523
208* 00532
209* 00533
210* 00534
211* 00535
212* 00537
213* 00540

157* 152
158* IF (KFILE.LE.IAVE) GO TO 130
159* DO 420 IKOUNT=1,ITER
160* J=-1
161* IF (KUNIT.NE.IUNIT) J=-1
162* DO 210 I=1,KK
163* DATA(I)=DATAT(I)*J
164* IF (IAVE.EQ.1) GO TO 230
165* IF (.NOT.PLOT) GO TO 220
166* CALL SUB008 (DATA,KK,XMAX)
167* SCALEY=SCALEY*KK/2000
168* CALL SUB045 (SCALEY,SCALEY,IPR,XMAX,DATA,KK)
169* CONTINUE
170* IF (IKOUNT.GT.1) GO TO 300
171* IF (FILE1) PUNCH 390, (DATA(I),I=1,KK)
172* IF (FILE1) WRITE (15,500) (DATA(I),I=1,KK)
173* IF (KK.LT.NDATAP) GO TO 240
174* NDATAP=KK
175* WRITE (6,550)
176* WRITE (6,560)
177* WRITE (6,550)
178* GO TO 490
179* IF (KK.LT.1) GO TO 490
180* WRITE (6,570) KK
181* CALL SUB008 (DATA,KK,XMAX)
182* CALL SUB010 (DATA,2000,XMAX)
183* WRITE (6,9007C) (DATA(I),I=1,600)
184* PEAK1=XMAX/2.
185* C FIND FIRST PART OF RETURN SIGNAL BY COMPAIRING THE AVERAGE
186* C TO HALF XMAX (PEAK1)
187* DO 250 I=KB,KE
188* IF (KR.EQ.KE) GO TO 260
189* IF ((DATA(I)+DATA(I+1)+DATA(I+2))/3.GT.PEAK1) GO TO 260
190* CONTINUE
191* WRITE (6,580) I
192* WRITE (6,9006C) (DATA(I),I=432,432)
193* J=I
194* WRITE (6,640) LD
195* WRITE (6,590) (D(I),I=1,LD)
196* CALL SUB024 (2000,C)
197* DO 270 I=1,LD
198* C(I)=D(I)
199* IF (.NOT.PLOT) GO TO 280
200* CALL SUB008 (D,LD,XMAX)
201* SCALEY=SCALEY*LD/2000
202* CALL SUB045 (SCALEY,SCALEY,IPR,XMAX,C,LD)
203* CONTINUE
204* CALL SUB010 (D,LD,XMAX)
205* C PUT 105 POINTS OF THE FIRST RETURN IN B TO GET A
206* IF (IEXPND.GE.O) GO TO 290
207* IF (ITER.EQ.1) READ (5,540) (B(I),I=1,LB)
208* GO TO 350
209* K1=J
210* K2=K1+LB-1
211* IF (LENGTH.EQ.O) LENGTH=LB
212* SAVELB=LB
213* LENGTH=LENGTH-INCLN

```

```

00541 214* 300 CONTINUE
00542 215* I=1
00543 216* DO 310 M=M1,K2
00546 217* B(I)=DATA(M)
00547 218* I=I+1
00551 219* LB=M2-K1+1
00551 220* I=(LB/10)*10
00551 221* IF (I.LT.LB) LB=I+10
00552 222* IF (IEXPND.EQ.0) GO TO 350
00553 223* LENGTH=LENGTH+INCLN
00555 224* CALL SUB048 (LB,B,C,LENGTH)
00556 225* LB=LENGTH
00557 226* LST=LS-K1+1
00560 227* I=0
00561 228* DO 320 IJK=1,LST
00564 229* I=I+1
00565 230* J=K1+IJK-1
00566 231* B(IJK)=DATA(J)
00570 232* WRITE (6,660) I
00573 233* LST=(LS-K1+2)*(LENGTH/SAVELB)
00574 234* LFT=(LF-K1+1)*(LENGTH/SAVELB)
00575 235* DO 330 J=LST,LFT
00600 236* I=I+1
00601 237* B(I)=C(J)
00603 238* WRITE (6,660) I
00606 239* LST=LF
00607 240* LFT=SAVELB*K1-1
00610 241* DO 340 J=LST,LFT
00613 242* I=I+1
00614 243* B(I)=DATA(J)
00616 244* LB=I
00617 245* WRITE (6,660) LB
00622 246* IF (FILE1) WRITE (6,600) (B(I),I=1,LB)
00631 247* CALL SUB024 (2000,C)
00632 248* DO 360 I=1,LB
00635 249* C(I)=B(I)
00637 250* IF (.NOT.PLOT) GO TO 370
00641 251* CALL SUB008 (B,LB,XMAX)
00642 252* SCALEY=SCALEY*LB/2000
00643 253* CALL SUB045 (SCALEX,SCALEY,IPR,XMAX,C,LF)
00644 254* CONTINUE
00644 255* CALL SUB010 (B,LB,XMAX)
00644 256* C FIND FILTER WEIGHTS TO BE USED
00645 257* CALL SUB020 (LB,B,LD,D,LA,A,LC,C,ASE,SPACE)
00646 258* WRITE (6,650) LC
00651 259* IF (FILE1) WRITE (6,620) (C(I),I=1,LC)
00651 260* WRITE (6,630) ASE
00663 261* IF (.NOT.PLOT) GO TO 380
00665 262* CALL SUB008 (C,LC,XMAX)
00666 263* SCALEY=SCALEY*LC/2000
00667 264* CALL SUB045 (SCALEX,SCALEY,IPR,XMAX,C,LC)
00670 265* CONTINUE
00670 266* CALL SUB010 (C,LC,XMAX)
00670 267* C CALL SUB010 (C,LC,XMAX)
00670 268* C WRITE (6,740) SPACE
00671 269* WRITE (6,670) LA
00674 270* IF (FILE1) WRITE (6,610) (A(I),I=1,LA)

```

MAIN04

```

2710 CALL SUB024 (2000,C)
2720 00 390 I=1,LA
2730 C(I)=A(I)
2740 IF (.NOT.PLOT) GO TO 400
2750 CALL SUB008 (A,LA,XMAX)
2760 SCALEY=SCALEY*LA/2000
2770 CALL SUB045 (SCALEY,SCALEY,IPR,XMAX,C,LA)
2780 CONTINUE
2790 CALL SUB023 (LA,A,KK,DATA,LC,C)
2800 IF (LC.GT.2000.AND.I2000.6E.1) LC=2000
2810 IF (FILE.I) WRITE (6,620) (C(I),I=1,KK)
2820 IF (IKOUNT.EQ.ITER) IPR=-2
2830 IF (.NOT.PLOT) GO TO 430
2840 CALL SUB008 (C,LC,XMAX)
2850 SCALEY=SCALEY*LC/2000
2860 CALL SUB045 (SCALEY,SCALEY,IPR,XMAX,C,LC)
2870 CONTINUE
2880 420 CONTINUE
2890 LC=2000
2900 KOUNT=0
2910 IPR=1
2920 JF (NFILE.EQ.0) GO TO 490
2930 CALL NTRAN (IUNIT,10)
2940 CALL NTRAN (IUNIT,8,IMOVE)
2950 DO 480 KFILE=IMOVE,NFILE,INCRE
2960 KOUNT=KOUNT+1
2970 IF (NFILE.6E.NFILE) IPR=1
2980 CALL SUB001 (IUNIT,IPR,DATA,KK)
2990 IF (KK.LT.1) GO TO 490
3000 IF (KK.GT.2000.AND.I2000.EQ.2) KK=2000
3010 I=2
3020 IF (NFILE.GT.IMOVE) GO TO 430
3030 I=1
3040 IF (IFTD.LE.2) GO TO 430
3050 CUT(1)=CUT(1)/FSAMP
3060 H(1)=H(1)/FSAMP
3070 CUT(2)=CUT(2)/FSAMP
3080 H(2)=H(2)/FSAMP
3090 IF (IFTD.LE.1) GO TO 440
3100 IF (IFTD.6E.2.AND.LOW) CALL SUB026 (DATA,KK,CUT(1),H(1),N(1),0,W
167L)
3110 IF (IFTD.6E.2.AND.HIGH) CALL SUB026 (DATA,KK,CUT(2),H(2),N(2),1,
167H)
3120 CALL SUB008 (DATA,KK,XMAX)
3130 IF (KPASS.LT.6) GO TO 460
3140 IF (NFILE.GT.IMOVE) GO TO 450
3150 I=KK
3160 CALL SUB012 (I,DATA,M)
3170 NP=2*#M
3180
3190
3200
3210 CXXXX SUB018 TAPERS THE INPUT DATA + THE ZERO FILL(2*#M)
3220 CALL SUB018 (NP,1,NP,1,DATA)
3230 C 450 CONVERT THE REAL TIME DOMAIN DATA INTO THE CARTESIAN FORM
3240 CALL SUB017 (M,DATA,-1,0)
3250 C CONVERT THE CARTESIAN COORDINATES TO POLAR FORM
3260 CALL SUB047 (DATA,Y,P,NP)
3270 CALL SUB011 (Y,P,NP,M,DATA)
3280
3290
3300
3310
3320
3330
3340
3350
3360
3370
3380
3390
3400
3410
3420
3430
3440
3450
3460
3470
3480
3490
3500
3510
3520
3530
3540
3550
3560
3570
3580
3590
3600
3610
3620
3630
3640
3650
3660
3670
3680
3690
3700
3710
3720
3730
3740
3750
3760
3770
3780
3790
3800
3810
3820
3830
3840
3850
3860
3870
3880
3890
3900
3910
3920
3930
3940
3950
3960
3970
3980
3990
4000
4010
4020
4030
4040
4050
4060
4070
4080
4090
4100
4110
4120
4130
4140
4150
4160
4170
4180
4190
4200
4210
4220
4230
4240
4250
4260
4270
4280
4290
4300
4310
4320
4330
4340
4350
4360
4370
4380
4390
4400
4410
4420
4430
4440
4450
4460
4470
4480
4490
4500
4510
4520
4530
4540
4550
4560
4570
4580
4590
4600
4610
4620
4630
4640
4650
4660
4670
4680
4690
4700
4710
4720
4730
4740
4750
4760
4770
4780
4790
4800
4810
4820
4830
4840
4850
4860
4870
4880
4890
4900
4910
4920
4930
4940
4950
4960
4970
4980
4990
5000
5010
5020
5030
5040
5050
5060
5070
5080
5090
5100
5110
5120
5130
5140
5150
5160
5170
5180
5190
5200
5210
5220
5230
5240
5250
5260
5270
5280
5290
5300
5310
5320
5330
5340
5350
5360
5370
5380
5390
5400
5410
5420
5430
5440
5450
5460
5470
5480
5490
5500
5510
5520
5530
5540
5550
5560
5570
5580
5590
5600
5610
5620
5630
5640
5650
5660
5670
5680
5690
5700
5710
5720
5730
5740
5750
5760
5770
5780
5790
5800
5810
5820
5830
5840
5850
5860
5870
5880
5890
5900
5910
5920
5930
5940
5950
5960
5970
5980
5990
6000
6010
6020
6030
6040
6050
6060
6070
6080
6090
6100
6110
6120
6130
6140
6150
6160
6170
6180
6190
6200
6210
6220
6230
6240
6250
6260
6270
6280
6290
6300
6310
6320
6330
6340
6350
6360
6370
6380
6390
6400
6410
6420
6430
6440
6450
6460
6470
6480
6490
6500
6510
6520
6530
6540
6550
6560
6570
6580
6590
6600
6610
6620
6630
6640
6650
6660
6670
6680
6690
6700
6710
6720
6730
6740
6750
6760
6770
6780
6790
6800
6810
6820
6830
6840
6850
6860
6870
6880
6890
6900
6910
6920
6930
6940
6950
6960
6970
6980
6990
7000
7010
7020
7030
7040
7050
7060
7070
7080
7090
7100
7110
7120
7130
7140
7150
7160
7170
7180
7190
7200
7210
7220
7230
7240
7250
7260
7270
7280
7290
7300
7310
7320
7330
7340
7350
7360
7370
7380
7390
7400
7410
7420
7430
7440
7450
7460
7470
7480
7490
7500
7510
7520
7530
7540
7550
7560
7570
7580
7590
7600
7610
7620
7630
7640
7650
7660
7670
7680
7690
7700
7710
7720
7730
7740
7750
7760
7770
7780
7790
7800
7810
7820
7830
7840
7850
7860
7870
7880
7890
7900
7910
7920
7930
7940
7950
7960
7970
7980
7990
8000
8010
8020
8030
8040
8050
8060
8070
8080
8090
8100
8110
8120
8130
8140
8150
8160
8170
8180
8190
8200
8210
8220
8230
8240
8250
8260
8270
8280
8290
8300
8310
8320
8330
8340
8350
8360
8370
8380
8390
8400
8410
8420
8430
8440
8450
8460
8470
8480
8490
8500
8510
8520
8530
8540
8550
8560
8570
8580
8590
8600
8610
8620
8630
8640
8650
8660
8670
8680
8690
8700
8710
8720
8730
8740
8750
8760
8770
8780
8790
8800
8810
8820
8830
8840
8850
8860
8870
8880
8890
8900
8910
8920
8930
8940
8950
8960
8970
8980
8990
9000
9010
9020
9030
9040
9050
9060
9070
9080
9090
9100
9110
9120
9130
9140
9150
9160
9170
9180
9190
9200
9210
9220
9230
9240
9250
9260
9270
9280
9290
9300
9310
9320
9330
9340
9350
9360
9370
9380
9390
9400
9410
9420
9430
9440
9450
9460
9470
9480
9490
9500
9510
9520
9530
9540
9550
9560
9570
9580
9590
9600
9610
9620
9630
9640
9650
9660
9670
9680
9690
9700
9710
9720
9730
9740
9750
9760
9770
9780
9790
9800
9810
9820
9830
9840
9850
9860
9870
9880
9890
9900
9910
9920
9930
9940
9950
9960
9970
9980
9990

```

01021 328*
 01022 329*
 01022 330*
 01022 331*
 01022 332*
 01022 333*
 01022 334*
 01022 335*
 01023 336*
 01024 337*
 01026 338*
 01030 339*
 01032 340*
 01034 341*
 01035 342*
 01036 343*
 01040 344*
 01041 345*
 01041 346*
 01043 347*
 01046 348*
 01050 349*
 01052 350*
 01054 351*
 01055 352*
 01056 353*
 01057 354*
 01061 355*
 01063 356*
 01065 357*
 01067 358*
 01071 359*
 01073 360*
 01074 361*
 01074 362*
 01076 363*
 01077 364*
 01077 365*
 01077 366*
 01077 367*
 01077 368*
 01100 369*
 01101 370*
 01102 371*
 01102 372*
 01103 373*
 01104 374*
 01105 375*
 01106 376*
 01107 377*
 01110 378*
 01111 379*
 01112 380*
 01113 381*
 01114 382*
 01115 383*
 01116 384*

460 CONTINUE
 KK=2000
 C CXXXX DATA PROCESSING SUBROUTINES SHOULD BE INSERTED HERE.
 CXXXX ANY ADDITIONAL DIMENSION STATEMENTS REQUIRED SHOULD
 CXXXX ALSO BE ADDED
 C
 C WRITE (6,760) (DATA(I),I=1,200)
 CALL SUB023 (LA,A,KK,DATA,LC,C)
 IF (MFILE.EQ.IMOVE) CALL SUB008 (C,LC,XMAX)
 IF (AMAX.LT.O.AND.KFILE.EQ.IMOVF) XMAX=XMAX
 IF (AMAX.EQ.O) XMAX=XMAX
 IF (AMAX.GT.O.O.AND.KFILE.EQ.IMOVE) XMAX=XMAX
 XMAX=XMAX
 EXIT=XMAX
 IF (SOAS) CALL SUB001 (IUNIT,IPR,C,LC)
 EXIT=O
 IF (LC.GT.2000.AND.I2000.GE.1) LC=2000
 IF (MFILE.EQ.IMOVE) WRITE (6,260) (C(I),I=1,KK)
 WRITE (6,570) LC
 IF (.NOT.PLOT) GO TO 470
 IF (MFILE.EQ.IMOVE) IPR=-1
 IF (MFILE.FE.MFILE) IPR=-2
 SCALEY=SCALEY*LC/2000
 CALL SUB045 (SCALEY,SCALEY,IPR,XMAX,C,LC)
 470 CONTINUE
 IF (LC.GT.2000.AND.I2000.GE.1) LC=2000
 IF (SDDS) CALL SUB002 (LC,C,NUNIT,XMAX)
 IF (MK.LT.1) GO TO 490
 IF (KOUNT.EQ.IPR) IPR=1
 IF (KOUNT.LT.IPR) IPR=O
 IF (KOUNT.EQ.IPR) KOUNT=O
 CALL NTRAN (IUNIT,8,INCRE)
 480 CONTINUE
 CALL NTRAN (NUNIT,9)
 CALL NTRAN (IUNIT,10)
 490 STOP
 C
 C 600 FORMAT (//,5X,'IFIDA=',I5,'IFIDF=',I5,'IFFDA=',I5,
 C 1,'IFFDDE=',I5,'PLOT=',I5,'SOASE=',I5,'ISDSE=',I5,'IEXPD=',I5)
 C
 C 500 FORMAT (10F8.4)
 510 FORMAT ()
 520 FORMAT (//,4X,'IMOVE =',I6,4X,'INCRE =',I6,4X,'MFILE =',I6,4X,'
 IPR =',I6)
 530 FORMAT (//,10X,'INPUT TAPE UNIT =',I3,20X,'OUTPUT TAPE UNIT =',I3)
 540 FORMAT (10F8.5)
 550 FORMAT (5X,'*****CHANGE THE SIZE OF THE ARRAY DATA',//)
 560 FORMAT (5X,'CHANGE THE SIZE OF THE ARRAY DATA',//)
 570 FORMAT (' MK=',I5)
 580 FORMAT (//,40X,'FIRST RETURN =',I4)
 590 FORMAT (40X,'D=',//,10X,10F10.5)
 600 FORMAT (//,40X,'B=',//,10X,10F10.5)
 610 FORMAT (//,40X,'A =',//,10X,10F10.5)
 620 FORMAT (//,40X,'C =',//,10X,10F10.5)
 630 FORMAT (//,40X,'ASE=',F10.6)
 640 FORMAT (//,40X,'LD=',I5)

```

01117 385*
01120 386*
01121 387*
01122 388*
01122 389*
01122 390*
01123 391*
END FOR

```

```

650 FORMAT (//,40X,'LC=',I5)
660 FORMAT (//,40X,'LB=',I5)
670 FORMAT (//,40X,'LA=',I5)
680 FORMAT (//,5X,'ITER=',I5,'LENGTH=',I5,'FILE=',I5,'I2000=',I5,
1'IAVE=',I5,'MOVE=',I5,/)

```

END

C

@HDG,P MAIND6

FOR US W.MAIN06
FOR E3AB-09/16/77-02:30:27 (16,17)

MAIN PROGRAM

STORAGE USED: CODE(1) 000224; DATA(6) C30341; BLANK COMMON(2) C00005

EXTERNAL REFERENCES (BLOCK, NAME)

- 0003 NTRAN
- 0004 SUB001
- 0005 SUB026
- 0006 MINTRS
- 0007 MRDUS
- 0010 NI028
- 0011 MRDUS
- 0012 NI018
- 0013 NSTOPS

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001	000065	1436	0001	000146	1726	0001	000165	2026	0001	000136	30L
0000	030275	40F	0000	030305	50F	0001	000222	60L	0000	030243	90026F
0000	030261	90040F	0000	030262	90041F	0000	030315	90070F	0000	030325	90090F
0000	R	013604	C	0000	R	000000	DATA	EXIT	0000	I	030241
0000	I	000003	IMOVE	0000	I	030230	INCRE	IPR	0000	I	030234
0000	I	000002	MFIL	0000	I	030240	MN	KOUNT	0000	I	030231
0000	I	030235	MUNIT	0002	000001	TIMAX		M6TH	0000	I	030233

- 00101 1*
- 00101 2*
- 00101 3*
- 00101 4*
- 00101 5*
- 00101 6*
- 00101 7*
- 00101 8*
- 00101 9*
- 00101 10*
- 00101 11*
- 00101 12*
- 00101 13*
- 00101 14*
- 00101 15*
- 00101 16*
- 00103 17*
- 00104 18*
- 00105 19*
- 00114 20*
- 00115 21*
- 00123 22*
- 00123 23*

PROGRAM MAIN06

```

C
CXXXX MAIN01 PROGRAM TO READ SDAS TAPE AND WRITE SDDS TAPE.
CXXXX IMOVE = NUMBER OF EOF TO MOVE INTO TAPE
CXXXX IMOVE MUST BE 1 OR GREATER
CXXXX INCRE = INCREMENT OF FILES TO BE PROCESSED
CXXXX MFIL = NUMBER OF FILES OF BE PROCESSED
CXXXX IPRT = INCREMENT OF PROCESSED FILES TO BE PRINTED
CXXXX IUNIT = INPUT TAPE UNIT
CXXXX MUNIT = OUTPUT TAPE UNIT
CXXXX NTRAN STATUS WORDS =
CXXXX -1 = TRANSMISSION NOT COMPLETE
CXXXX -2 = END OF FILE (READ), END OF TAPE (WRITE)
CXXXX -3 = DEVICE ERROR
CXXXX -4 = TRANSMISSION ABORTED
C
COMMON FSAMP, TIMAX, MFIL, IMOVE, EXIT
DIMENSION DATA(620), C(16220), M6TH (200)
READ(5, 90020) IMOVE, INCRE, MFIL, IPRT, M0ATAP
FORMAT(1)
90020 WRITE(6, 90026) IMOVE, INCRE, MFIL, IPRT
90026 FORMAT(//, 4X, 'IMOVE = ', I6, 4X, 'INCRE = ', I6, 4X, 'MFIL = ', I6,
C 4X, 'IPRT = ', I6)

```

```

24* 00124 READ(5,90040) IUNIT,NUNIT
25* 00130 FORMAT(I)
26* 00131 WRITE(6,90041) IUNIT,NUNIT
27* 00135 FORMAT(//,10X,'INPUT TAPE UNIT =',I3,20X,'OUTPUT TAPE UNIT =',I3)
28* 00136 CALL NTRAN(IUNIT,10)
29* 00137 CALL NTRAN(IUNIT,8,IMOVE)
30* 00140 KOUNT = 0
31* 00141 IPR = 1
32* 00142 DO 20 MFILE = IMOVE,MFILE,INCRE
33* 00145 KOUNT = KOUNT + 1
34* 00146 IF(MFILE.EE.NFILE)IPR=1
35* 00150 CALL SUB001(IUNIT,IPR,DATA(100),MK)
36* 00151 MK=MK+200
37* 00152 IF(MK.LY.NDATAP)GO TO 30
38* 00154 NDATAP=MK
39* 00155 WRITE(6,40)
40* 00157 WRITE(6,50)NDATAP
41* 00162 WRITE(6,40)
42* 00164 40 FORMAT(5X,'*****')
43* 00165 50 FORMAT(5X,'*CHANGE THE SIZE OF THE ARRAY DATA',//)
44* 00166 60 TO 60
45* 00167 30 IF(MK.LY.1) GO TO 60
46* 00171 DO 100 I=1,MK
47* 00174 C(I)=C(I)+DATA(I)
48* 00176 CALL NTRAN(IUNIT,6,INCRE)
49* 00177 20 CONTINUE
50* 00201 DO 110 I=1,MK
51* 00204 DATA(I)=C(I)
52* 00206 CALL SUB026(DATA,MK,004,.017,80,1,NGTH)
53* 00207 WRITE (6,90070 )
54* 00211 WRITE (6,90090 )(DATA(I),I=1,MK)
55* 00211 PUNCH 90090,(DATA(I),I=1,MK)
56* 00211 CALL SUB008(DATA,MK,XMAX)
57* 00211 CALL SUB010(DATA,MK,XMAX)
58* 00217 90070 FORMAT(20X,'2000 POINTS FROM ONE SCAN ')
59* 00220 90080 FORMAT(10X,8F10.5)
60* 00221 90090 FORMAT(10F8.4)
61* 00222 60 END
END FOR

```

END FOR

8FOR,US M.MAIN07
FOR E3AB-C9/16/77-02:38:31 (35,36)

MAIN PROGRAM

STORAGE USED: CODE(1) 000516; DATA(0) 012041; BLANK COMMON(2) 000000

EXTERNAL REFERENCES (BLOCK, NAME)

- 0003 SUB013
- 0004 SUB018
- 0005 SUB029
- 0006 SUB017
- 0007 NIMITS
- 0010 NROUS
- 0011 NI025
- 0012 NPRINT
- 0013 NRDCS
- 0014 NI015
- 0015 COS
- 0016 SIN
- 0017 NMDUF
- 0020 NI035
- 0021 NNDCS
- 0022 NSTOPS

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0000	011727 1F	0000	011730 10F	0000	012005 100F	0000	012016 120F	0000	012020 130F
0001	000070 1436	0001	000106 1546	0001	000123 1656	0000	011750 20F	0001	000514 200L
0001	000170 2016	0000	011752 21F	0001	000311 2376	0001	000325 245G	0001	000341 255G
0001	008406 2726	0001	000456 307G	0001	000206 40L	0001	000210 41L	0000	011765 43F
0001	000262 50L	0000	R 011724 A1	0000	R 011725 A2	0000	R 011721 DELPH	0000	R 011672 DELT
0000	R 011675 FPI	0000	R 011713 FRINT	0000	R 011665 FROMI	0000	P 011664 FRQLW	0000	R 011660 FSAMP
0000	I 011700 I	0000	I 011710 IM1	0000	I 011712 IPOWER	0000	I 011667 IPUNCH	0000	I 011711 ITEST
0000	I 011723 I1	0000	I 011717 I2	0000	I 011666 KFIL	0000	I 011726 L	0000	I 011706 LOW
0000	I 011661 NP	0000	I 011701 NP2	0000	I 011702 NP21	0000	I 011663 NZERO	0000	R 011662 PHASE
0000	R 011722 PHAS1	0000	R 011673 PI	0000	P 011714 RESOL	0000	P 011715 RESO10	0000	R 011716 TAPER
0000	R 011703 TIMOUT	0000	R 011704 T1MP	0000	R 011676 TIM8K	0000	P 011671 TSAMP	0000	R 011670 TSHIFT
0000	R 011674 TMOPI	0000	R 011707 XMI	0000	R 011705 XLOW	0000	R 011677 XIIM	0000	R 011720 XIIMI
0000	R 005670 Y	0000	R 000000 Z	0000	R 011610 ZERO1	0000	R 011634 ZERO2		

- 00101 1*
- 00101 2*
- 00101 3*
- 00101 4*
- 00101 5*
- 00101 6*
- 00101 7*
- 00101 8*
- 00101 9*
- 00101 10*

CXXX PROGRAM MAIN07
C R. L. DICUS 8/15/75

C FSAMP--SAMPLING FREQUENCY AT WHICH DATA WAS DIGITIZED (KHZ).
C TIMAX--MAXIMUM LENGTH OF DATA TIME TO BE READ IN ON LWIN
C FROLOW--LOW FREQUENCY ZERO POINT ON COSINE TAPER OF FREQUE CY
C RESPONSE FUNCTION USED FOR INVERSE FOURIER TRANSFORM ONLY *KHZ).
C FROMI--CORRESPONDING HIGH FREQUENCY ZERO POINT (KHZ).

```

11* 00101 C MFIL--TYPE OF FILTERING TAPER APPLIED TO FREQUENCY RESPONSE FUNCTION
12* 00101 C FOR COMPUTATION OF IMPULSE RESPONSE
13* 00101 C =0 FOR NO TAPER
14* 00101 C =1 FOR COSINE TAPER
15* 00101 C =2 FOR GAUSSIAN TAPER
16* 00101 C =3 FOR TRIANGULAR TAPER
17* 00101 C IREC--RECORD NUMBER TO BE PROCESSED
18* 00101 C TSHIFT--TIME SHIFT
19* 00101 C NZERO--NUMBER OF FREQUENCY REJECTION BANDS
20* 00101 C ZERO(I), ZERO2(I)--BAND REJECT FREQUENCY LIMITS
21* 00103 C SUBROUTINES REQUIRED
22* 00103 C
23* 00103 C FFTREL NLOGN TAPER REJECT
24* 00103 C
25* 00103 C DATA CARDS
26* 00103 C
27* 00103 C FSAMP TIMAX TSHIFT ( FREE FIELD)
28* 00103 C FROLOW FRQMI KFIL NZERO PHASE
29* 00103 C
30* 00103 C IF(NZERO.NE.0)ZERO1, ZERO2---ETC. (5 SPACE FORMAT)
31* CXXXXX PURPOSE:GENERATE A DESIRED SHAPE FOR THE
32* CXXXXX WEINER PROGRAM(MAIN04).THE PROGRAM PRODUCES
33* CXXXXX A CARD AND HARD COPY LISTING OF WTS.(DESIRED
34* CXXXXX SHAPE /A)
35* DIMENSION Z(3000),V(2000),ZERO1(20),ZERO2(20)
36* READ(5,1)FSAMP, NP,PHASE,NZERO,FRGLOW,FRQMI,KFIL,IPUNCH
37* 1 FORMAT(I)
38* TSHIFT=50.0
39* TSAMP=1./FSAMP
40* DELT=TSAMP
41* PI=3.1415926535898
42* TWOPI=2.*PI
43* FPI=PI/180.
44* TIMON=8193/FSAMP
45* XTIM=FSAMP*TSHIFT
46* PRINT 10,FRGLOW,FRQMI,KFIL,NZERO,PHASE
47* 10 FORMAT(1X,'FRGLOW=',F7.3,'SX','FRQMI=',F5.2,'SX','KFIL=',I5,'SX',
48* 'NZERO=',I5,'SX','PHASE=',F10.3)
49* PHASE=PHASE*FPI
50* IF(NZERO.NE.0)READ 20,(ZERO1(I),ZERO2(I)),I=1,NZERO)
51* 20 FORMAT(16F5.1)
52* IF(NZERO.NE.0)PRINT 21,(ZERO1(I),ZERO2(I)),I=1,NZERO)
53* 21 FORMAT(//1X,'FREQUENCY REJECTION BAND LIMITS'/(/1X,5(SX,2F13.3)))
54* CXXXXX START MAIN LOOP
55* NP2=NP/2
56* NP2=NP/2
57* NP2=NP2 + 1
58* DO 30 I=1,NP21
59* 30 Y(I)=1.0
60* TIMOUT=NP21/FSAMP
61* TIMP=NP/FSAMP
62* XLOW=FLOAT(NP)*FRGLOW/FSAMP
63* LOW=INT(XLOW)
64* XHI=FLOAT(NP)*FRQMI/FSAMP
65* HI=INT(XHI)
66* ITEST=1
67* DO 40 I=1,14

```

```

68*      IPOVER=I
69*      ITEST=2+ITEST
70*      IF(IITEST-NP)40,41,42
71*      42 PRINT 43
72*      43 FORMAT(//IX,'ERROR--NUMBER OF FOURIER COEFFICIENTS READ IN IS NOT
73*      10F THE FORM NP21=12**IPOWER)*1')
74*      60 TO 200
75*      40 CONTINUE
76*      41 FRINT=FSAMP/NP
77*
78*      C REJECTION FILTERING
79*
80*      IF(INZERO.EQ.0)GO TO 50
81*      RESOL=1.0/FSAMP
82*      IF(RESOL.LT.FRINT)RESOL=FRINT
83*      RESO10=RESOL*10.
84*      IF(RESOL.GT.RESO10)RESOL=RESO10
85*      CXXXX IF(INZERO.GT.0)CALL SUBO13(REJECT)
86*      IF(INZERO.GT.0)CALL SUBO13(INZERO,ZERO,ZERO,ZERO,FRINT,RESOL,Y)
87*      C TAPER FREQUENCY RESPONSE FUNCTION FOR COMPUTING IMPULSE RESPONSE
88*      IF(INFIL.GT.0) CALL SUBO18(TAPER)
89*      50 IF(INFIL.GT.0) CALL SUBO18(NP21, MFIL, IMI,LOW, Y)
89*
90*      C TRANSFER CALIBRATED AND TAPERED MAGNITUDES INTO REAL
91*      C PARTS OF COMPLEX Z ARRAY
92*      Z(2)=Y(NP21)
93*      DO 60 I=1,NP2
94*      I2=2*I-1
95*      60 Z(I2)=Y(I)
96*
97*
98*      C GENERATE ANGLES FOR FOR THE SERIES
99*      DO 70 I=1, NP21
100*      70 Y(I)=0.
101*      XTIM=XTIM
102*      DELPH=PI*XTIM/MP2
103*      PHAS1=0.
104*      DO 80 I=2,MP2
105*      PHAS1=PHAS1-DELPH
106*      Y(I)=Y(I)+PHAS1*PHASE
107*      I2=2*I
108*      80 Z(I2)=(Y(I))
109*      Y(I)=Y(I)+PHASE
110*      PHAS1=PHAS1-DELPH
111*      Y(NP21)=Y(NP21)+PHAS1*PHASE
112*      Z(I)=(Z(I)+COS(Y(I)))
113*      Z(I2)=(Z(I2)+COS(Y(NP21)))
114*
115*      C CONVERT CALIBRATED AND TAPERED FREQUENCY RESPONSE FUNCTION
116*      C FROM POLAR FORM BACK TO CARTESIAN FORM.
117*      DO 90 I=2,MP2
118*      I1=2*I-1
119*      I2=I1+1
120*      A1=(Z(I1)+COS(Z(I2)))
121*      A2=(Z(I1)+SIN(Z(I2)))
122*      Z(I1)=A1
123*      90 Z(I2)=A2
124*
125*      C CALL SUBO29(FFT) PRINT POWER SPECTRUM FROM CARTESIAN INPUT

```

```

00301 125*
00301 126*
00301 127*
00301 128*
00301 129*
00301 130*
00301 131*
00301 132*
00301 133*
00301 134*
00301 135*
00301 136*
00301 137*
00301 138*
00301 139*
00301 140*
00301 141*
00301 142*
00301 143*
00301 144*
00301 145*
00301 146*
00301 147*
00301 148*
00301 149*
00301 150*
00301 151*
END FOR

C DO 140 I=3,MP2,2
C J=I+1
C J1=2*MP2-I+2
C J2=J1+1
C Z(J1)=Z(I)
C 140 Z(J2)=Z(J)
C CALL SUB029 (NP,Z,IPOWER)
C COMPUTE FILTERED OUTPUT BY TAKING INVERSE FOURIER TRANSFORM
C PRINT OUT THE RESULTS TO SEE WHAT IT LOOKS LIKE IN
C THE TIME DOMAIN.
CXXXX CALL SUB017(FFTRFL)
C CALL SUB017(IPOWER,Z,+1.0)
C WRITE (6,100) (Z(I),I=1,MP)
100 FORMAT (/,10X,'RESULTS IN 2P6F16.8',///,(2X,2P6F16.8))
C DECREASE THE VALUE BY A THIRD
DO 110 L=1,100
110 Z(L)=Z(L)/3.0
WRITE(6,120)(Z(I),I=1,100)
WRITE(15,120)(Z(I),I=1,100)
IF (IPUNCH.EQ.1) PUNCH 130, (Z(I),I=1,100)
C 120 FORMAT(/,10X,'1/3 RESULTS IN2P10F8.5',///,(2X,3P6F16.8))
C 120 FORMAT (2P10F8.5)
CXXXX THE RESULTS ARE PUNCHED SO THEY CAN BE USED AS INPUT
CXXXX TO THE MAIN04(WEINER)PROGRAM.
130 FORMAT(2P10F8.5)
200 CONTINUE
END

```

6H06,P MAIN13

MAIN PROGRAM

STORAGE USED: CODE(1) 000563; DATA(0) 016053; BLANK COMMON(2) 010021

EXTERNAL REFERENCES (BLOCK, NAME)

- 0003 PLOTS
- 0004 NTRAN
- 0005 PLOT
- 0006 SUB001
- 0007 SUP028
- 0010 SUR010
- 0011 SUP032
- 0012 SUB027
- 0013 SUP030
- 0014 SUB033
- 0015 SUB031
- 0016 SUB034
- 0017 NINTRS
- 0020 NROUS
- 0021 NI028
- 0022 NWDUS
- 0023 NI018
- 0024 XFII
- 0025 NSTOPS

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

J001	000237	2CL	0001	000225	222G	0001	000352	25L	0001	000400	276C	0001	000442	311G	
J001	000506	326G	0001	000376	4CL	0001	000413	6CL	0000	015612	90020F	0000	015613	90026F	
J000	015631	90040F	0000	015632	90041F	0000	015645	90050F	0000	015670	90060F	0000	015706	90070F	
J000	015723	90080F	0000	015731	90090F	0000	015742	90100F	0000	015765	90110F	0000	016007	90120F	
J001	000561	99999L	0000	R	000002	DATA	0002	P	010001	0BRANG	0000	I	000001	DELESP	
J002	R	010020	EXIT	0002	R	010012	FPB	0002	I	010014	FSAMP	0000	I	013606	IBUF
0000	I	015603	IO	0000	I	015610	IJ	0002	I	010017	IMOVE	0000	I	010011	IOP
0000	I	015570	IPR	0000	I	015560	IPRT	0000	I	015561	IUNIT	0000	I	015576	JSTART
J000	I	015602	JTMPRS	0000	I	015611	JX	0000	I	015565	KB	0000	I	010016	KFILE
J000	I	015571	KK	0000	I	015572	KL	0000	I	015567	KOUNT	0000	I	015607	N
0000	I	015557	NFILE	0000	I	015606	NP	0000	I	015600	NPISL	0000	I	015564	NSAMP
0000	I	015604	NSAMP1	0000	I	015562	NUNIT	0000	R	015573	PEAK1	0000	I	000000	SCTAVE
J002	R	010005	SD	0000	R	015563	SMSEC	0002	R	010000	SR	0002	R	010000	TAPE
J002	P	004000	TEMP1	0002	R	010015	TIMAX	0000	R	015577	TFRIM	0002	R	010000	TAPE
J002	R	010004	XMAX	0002	R	010002	XNSAMP	0002	R	010007	TFRIS	0002	R	010003	XIJ

00100 1* CXXXX MAIN13 IS APROGRAG TO FIND DB LEVELS IN ONE SCAN
 00100 2* CXXXX SDAAS PROGRAM TO READ SDAAS TAPE AND WRITE SDDS TAPE.
 00100 3* CXXXX IMOVE = NUMBER OF EOF TO MOVE INTO TAPE
 00100 4* CXXXX IMOVE MUST BE 1 OR GREATER
 00100 5* CXXXX INCRE = INCREMENT OF FILES TO BE PROCESSED

```

00100 6* CXXXX NFILE = NUMBER OF FILES OF BE PROCESSED
00100 7* CXXXX IPRT = INCREMENT OF PROCESSED FILES TO BE PRINTED
00100 8* CXXXX IUNIT = INPUT TAPE UNIT
00100 9* CXXXX NUNIT = OUTPUT TAPE UNIT
00100 10* CXXXX NTRAN STATUS WORDS =
00100 11* CXXXX -1 = TRANSMISSION NOT COMPLETE
00100 12* CXXXX -2 = END OF FILE(READ),END OF TAPE(WRITE)
00100 13* CXXXX -3 = DEVICE ERROR
00100 14* CXXXX -4 = TRANSMISSION ABORTED
00100 15* C
00100 16* CXXXX DELBSP =DELTA BACK SPACE SO THAT THE START OF THE
00100 17* CXXXX FIRST RETURN WILL BE INCLUDED.
00100 18* CXXXX SMSEC=SAMPLE LENGTH IN MSEC TO BE EXTRACTED FROM ONE SCAN
00100 19* CXXXX SSEC=SAMPLE LENGTH IN SEC.
00100 20* CXXXX NSAMP=NUMBER OF SAMPLE GROUPS TO BE TAKEN FROM ONE SCAN
00100 21* CXXXX SCTAVE= SCANS TO AVERAGY THIS RUN
00100 22* CXXXX KB= BEGIN SEARCH FOR PEAK
00100 23* CXXXX KE=END SEARCH FOR PEAK
00100 24* CXXXX KL=NUMBER OF POINTS IN THIS SEARCH
00100 25* CXXXX TAPE=IS THE NUMBER GIVPE TO THE SDAS TAPE
00100 26* CXXXX TFRIS=TIME TO FIRST RETURN IN SECONDS
00100 27* CXXXX -ONE WAY TRAVAL
00100 28* CXXXX TFRIM=IME TO FIRST RETURN IN MSEC.
00100 29* CXXXX -ONE WAY TRAVAL
00100 30* CXXXX NPISL=COMPUTED NUMBER OF POINTS IN SAMPLE LENGTH
00100 31* CXXXX NPLTS=COMPUTED NUMBER OF POINTS LEFT IN THIS SCAN
00100 32* CXXXX XMAX=PEAK VALUE OF ONE SCAN
00100 33* CXXXX PEAK1=XMAX/2.
00100 34* CXXXX JFIRST=LOCATION OF POINT ON FIRST RETURN
00100 35* CXXXX JSTART=IS AN ATTEMPT TO GET TO THE START
00100 36* CXXXX OF THE FIRST RETURN
00100 37* CXXXX SD=SAMPLE DELAY IN SEC.
00100 38* CXXXX ID=SAMPLE RATE AS AN INTEGER
00100 39* CXXXX SR=SAMPLE RATE IN CYCLE PER SFC.
00100 40* CXXXX JTNPRS=TOTAL NUMBER OF POINTS THAT WERE
00100 41* CXXXX REQUESTED TO BE SAMPLED FROM THIS SCAN
00100 42* CXXXX NSAMP1=REAJUSTED OR NEW NUMBER OF SAMPLES TO
00100 43* CXXXX BE TAKEN FROM THIS RUN.IF JTNPRS IS GREATER
00100 44* CXXXX THAN THE POINTS REMAINING.
00100 45* CXXXX XNSAMP=IS THE NUMBER OF SAMPLE GROUPS IN THIS
00100 46* CXXXX SCAN AND THE PLOT LENGTH IN INCH. THE ACTUAL
00100 47* CXXXX LENGTH OF GRAPH IN INCH. IS ONE INCH. LARGER
00100 48* CXXXX DBRANG=DB RANGE TO BE USED BETWEEN TIME MARKS.
00100 49* CXXXX I.E. IF DB RANGE =80 THEN THE RANGE BETWEEN
00100 50* CXXXX EACH TIME MARK IS FROM 0 TO 80 DB
00100 51* CXXXX XIJ=UNIT INCREMENT TO ADVANCE THE PLOTTER
00100 52* CXXXX ROF=RANGE OF FREQUENCY TO BE PLOTTED
00100 53* CXXXX FPB=FREQ./BIN. THE DELTA STEP FOR FREQ.
00100 54* CXXXX IOP=1.0/FPB*ROF=INDEX OF PLOTTER.
00100 55* CXXXX =THE NUMBR OF MOVES THE PLOTTER NEEDS TO MAKE.
00100 56* CXXXX INTEGER SCTAVE,DELBSP
00100 57* CXXXX DIMENSION DATA(6020),IBUF(1000)
00100 58* CXXXX COMMON DDATA(2048),TEMP1(2048),SR,DBRANG,XNSAMP,XIJ,XMAX
00100 59* CXXXX COMMON SD,TAPE,TFRIS,SSEC,IOP,FPB,ROF
00100 60* CXXXX COMMON FSAMP,TIMAX,KFILE,MOVE,EXIT
00100 61* CXXXX CALL PLOTS (IBUF,1000,10)
00100 62* CXXXX READ(5,9C020)MOVE,INCR,NFILE,IPRT

```

```

00116 63* 90020 FORMAT(I)
00117 64* WRITE(6,90026) IMOVE,INCR,NFILE,IPRT
00125 65* FORMAT(//,4X,'I MOVE = ',I6,4X,' INCR = ',I6,4X,' NFILE = ',I6,
00126 66* 4X,' IPRT = ',I6)
00132 67* READ(5,90040) IUNIT,NUNIT
00133 68* FORMAT(I)
00137 69* WRITE(6,90041)IUNIT,NUNIT
00140 70* FORMAT(//,10X,'INPUT TAPE UNIT = ',I3,20X,'OUTPUT TAPE UNIT = ',I3)
00150 71* READ(5,90040)SMSEC,NSAMP,SCTAVE,DELBSP,DBRANG,TAPE
00155 72* WRITE(6,90050) SMSEC,NSAMP,SCTAVE
00155 73* 90050 FORMAT(//,5X,'SAMPLE LENGTH IN MSEC = ',F10.4,
00155 74* 5X,'NUMBER OF SAMPLE GROUPS = ',I5,
00155 75* **SCANS TO AVERAGE THIS RUN=I6)
00156 76* WRITE(6,90060) DBRANG,DELBSP,TAPE
00163 77* *DIAGNOSTIC* B IS AN IMPROPER PUNCTUATION MARK.
00163 78* *DIAGNOSTIC* COMMA IS MISSING BEFORE E FIELD.
00163 79* *DIAGNOSTIC* COMMA IS MISSING BEFORE T FIELD.
00163 80* *DIAGNOSTIC* COMMA IS MISSING BEFORE A FIELD.
00163 81* *DIAGNOSTIC* COMMA IS MISSING BEFORE L FIELD.
00163 82* 90060 FORMAT(//,5X,'THE DB RANGE = ',F10.2,5X,
00164 79* * DELTA BACK SPACE = ',I5,5X,'TAPE NUMBER OF THIS RUN = ',F10.1)
00170 80* READ (5,90040)KB,KE
00174 81* WRITE(6,90070)KB,KE
00175 82* 90070 FORMAT(//,10X,'BEGIN SEARCH FOR PEAK AT',I5,20X,
00175 83* :END SEARCH FOR PEAK AT',I5)
00175 84* CALL NTRAN(IUNIT,8,IMOVE)
00176 85* CZCZC CALL NTRAN(NUNIT,9) NOT NEEDED FOR THIS PROGRAM
00200 86* KOUNT = 0
00201 87* IPR = 1
00201 88* KFILE=IMOVE
00201 89* IMOVE=IMOVE+1
00202 90* CXXXX ESTABLISH THE ORIGIN ON THE PLOTTER
00203 91* CALL PLOT(0.0,-11.0,-3)
00204 92* CALL PLOT (0.0,2.0,-3)
00205 93* CALL SUB001 (IUNIT,IPR,DATA,KK,KFILE)
00207 94* IF (KK.LT.1) GO TO 99999
00211 95* IF (EXIT.EQ.7777)GO TO 99999
00212 96* CALL NTRAN (IUNIT,8,1)
00212 97* KL=KE-KB+1
00213 98* CXXXX FIND SUB028 (PEAK(XMAX)) IN RANGE OF INTEREST
00213 99* CALL SUB028 (DATA(KB),KL)
00213 100* CXXXX THE HOLE LINE IS DRAWN TO HELP DETERMIN THE ACCURACY OF
00214 101* CXXXX THE PROGRAM TO PICK THE FIRST RETURN
00216 102* WRITE(6,90080)
00217 103* 90080 FORMAT(1H,30X,'THIS IS THE HOLE LINE ')
00220 104* CALL SUB010 (DATA,KK)
00221 105* PEAK1=XMAX/2.
00224 106* DO 10 I=KB,KE
00226 107* IF ((DATA(I)+DATA(I+1)+DATA(I+2))/3.C.GT.PEAK1)GO TO 20
00230 108* 10 CONTINUE
00231 109* 20 JFIRST=I
00234 110* WRITE(6,90090)JFIRST
00235 111* JSTART=JFIRST-DELBSP
00236 112* WRITE(6,90100)
00240 113* 90100 FORMAT(1H,10X,'THE PICKED FIRST RETURN IS PLOTTED SO IT CAN',
00240 114* * * BE VERIFIED WITH THE PLOT OF THE HOLE SCAN ')

```

```

1150 CALL SUB010 (DATA(JSTART),200)
1160 SD IS THE DELAY TIME IN SEC. SR IS THE SAMPLE/SEC.
1170 CXXXX 1/SR IS THE NUMBER OF SECONDS PER SAMPLE TFRIS IS THE
1180 CXXXX TOTAL TIME TO THE FIRST RETURN IN SECONDS
1190 CXXXX TFRIM IS THE TOTAL TIME TO THE FIRST RETURN IN MSEC.
1200 TFRIS=(SD* JFIRST*(1/SR))/2.
1210 TFRIM=TFRIS*1000.
1220 WRITE (6,90110)TFRIS,TFRIM
1230 90110 FORMAT(//,10X,'TIME IN SEC TO THE FIRST RETURN IS',F10.5,
1240 *20X,'TIME IN MSEC TO THE FIRST RETURN IS',F10.5,///)
1250 CXXXX NPISL IS THE NUMBER OF POINTS TO BE USED IN THE SAMPLE LENGTH
1260 CXXXX NPISL=SMSEC*SR/1000.0
1270 CXXXX SSEC IS SAMPLE LENGTH IN SEC
1280 SSEC=SMSEC*1000.0
1290 CXXXX NPLTS IS THE NUMBER OF POINTS LEFT TO SCAN
1300 NPLTS=MK-JSTART+1
1310 CXXXX JTMPRS IS THE TOTAL NUMBER OF POINTS REQUESTED TO BE SAMPLED
1320 JTMPRS=NPISL*NSAMP
1330 CXXXX ROF IS THE RANGE OF FREQ. TO BE PLOTTED
1340 ROF=SR/4.C
1350 ID=SR
1360 CXXXX CHECK TO SEE WHICH IS LARGER, THE SAMPLE
1370 CXXXX RATE OR SAMPLE LENGTH. IF SAMPLE RATE IS
1380 CXXXX LARGER GO TO 25. IF NOT CHANGE SAMPLE RATE
1390 CXXXX (ID) TO SAMPLE LENGTH.
1400 IF (ID.GE.NPISL) GO TO 25
1410 ID=NPISL
1420 CXXXX CHECK TO SEE IF THE TOTAL SAMPLE LENGTH (JTMPRS) IS LESS THAN
1430 CXXXX OR EQUAL TO THE NUMBER OF POINTS LEFT IN THE SCAN(NPLTS).
1440 25 IF (NPLTS-JTMPRS)3C,4G,40
1450 CXXXX NSAMP1 IS THE NEW NUMBER OF SAMPLE GROUPS TO TAKE FROM
1460 CXXXX THIS SCAN FOR THE INTERVAL SPECTRA.
1470 30 NSAMP1=NPLTS/NPISL
1480 WRITE(6,90120) NSAMP,NSAMP1
1490 90120 FORMAT(//,10X,'THE',I6,' SAMPLES SELECTED WAS TO LARGE SO IT'
1500 1 ' WAS REDUCED TO ',I6,///)
1510 NSAMP=NSAMP1
1520 CXXXX XNSAMP IS USED TO SET THE PLOT LENGTH IN INCH.
1530 XNSAMP=NSAMP
1540 40 00 50 M=9,12
1550 NP=2**M
1560 IF (NP-ID)5C,6G,60
1570 50 CONTINUE
1580 CXXXX NP IS 2**M, AND M=POWER OF 2 THAT EQUALS NP
1590 CXXXX FPB=FREQ./BIN=SR/NP OR 2**N
1600 60 FPB=SR/NP
1610 CXXXX IOP=INDEX OF THE PLOTTER THAT IS THE NUMBER
1620 CXXXX OF MOVES IT WILL TAKE TO MOVE FROM 0 TO
1630 CXXXX THE UPPER FREQ.(ROF) IN HZ
1640 IOP=1.0/FPB*ROF
1650 DO 70 MFILE=IMOVE,MFILE
1660 CXXXX XIJ=UNIT INCREMENT TO ADVANCE THE PLOT ON TIME AXES
1670 XIJ =0.0
1680 CALL SUB001(IUNIT,IPR,DATA,KK,MFILE)
1690 IF (KK.LT.1)GO TO 99999
1700 CALL NTRAN(IUNIT,8,IMCRE)
1710 CALL SUB032

```

MAIN13

DATE 091677

PAGE 5

```
00321 172* CALL SUB027(NP,DATA(JSTART),M)
00322 173* CALL SUB030(NP)
00323 174* CALL SUB033
00323 175* CXXXX N IS USED AS AN ODD EVER COUNTER
00323 176* CXXXX N=1 GOES TO PLOT02
00323 177* CXXXX N=2 GOES TO PLOT03
00324 178* N=1
00325 179* DO 80 IJ = 1,NSAMP
00330 180* JX=JSTART
00330 181* CXXXX CALL DATA SHIFT PROGRAM--STORE DATA IN TEMP1
00331 182* CALL SUB031(DATA(JX),NPISL)
00332 183* CALL SUB027(NP,TEMP1,M)
00333 184* JX=JX+NPISL
00334 185* XIJ=IJ
00335 186* IF (N.EQ.1) CALL SUB034
00337 187* IF (N.EQ.2) CALL SUB033
00341 188* N=N+1
00342 189* IF (N.EQ.3) N=1
00344 190* 80 CONTINUE
00346 191* 70 CONTINUE
00350 192* 99999 CONTINUE
00351 193* END
END FOR: 5 DIAGS
```

AM06,P SUB001

FOR,US W.SUB001
FOR E3AB-09/16/77-02:38:39 (17,18)

SUBROUTINE SUB001 ENTRY POINT 000221

STORAGE USED: CODE(1) 000247; DATA(0) 001331; BLANK COMMON(2) 000005

EXTERNAL REFERENCES (BLOCK, NAME)

- 0003 SUB004
- 0004 NTRAN
- 0005 SUB003
- 0006 SUB004
- 0007 NYEUS
- 0010 NI02\$
- 0011 NERR3\$

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

```

0001 000022 1L 0001 00053 31L 0001 00072 40L 0001 00012 43L 0001 00022 45L
0001 000174 60L 0001 000211 65L 0002 R 000004 EXIT 0002 R 000000 FSAMP
0000 I 001235-IDATA 0000 I 001232 IHEAD 0000 I 000003 IMOVE 0000 I 001322 INJPS
0000 I 001230 IST 0000 I 001271 K 0002 I 000002 KFILE 0000 I 001273 L 0000 I 001272 LREC
0000 I 001270 NUNIT 0002 R 000001 TMAX

```

```

00100 1*
00100 2* CXXXX SUBROUTINE SUB001(SDAS)CREATED BY T. MERC 11/74 TO
00100 3* CXXXX READ THE DATA TAPE PRODUCED BY CODE 351'S SEISMIC
00100 4* CXXXX DATA ACQUISITION SYSTEM.
00100 5* CXXXX IUNIT = INPUT TAPE DRIVE UNIT
00100 6* CXXXX IPR = 1 IF HEADER DATA IS TO BE PRINTED, 0 IF NOT
00100 7* CXXXX DATA = DECODED OUTPUT DATA ARRAY
00100 8* CXXXX NK = NUMBER OF SAMPLES IN DATA
00100 9* CXXXX IF A TAPE READ ERROR OCCURS NK BECOMES THE NTRAN STATUS WORD.
00100 10* CXXXX SUB001(SDAS) USES SUBROUTINES SUB003(HEADER)AND SUB004(DECODE)
00100 11* C
00101 12* SUBROUTINE SUB001(IUNIT,IPR,DATA,KN)
00103 13* COMMON FSAMP,TMAX,KFILE,IMOVE,EXIT
00104 14* DIMENSION INDATA(332,2),IST(2),IHEAD(3),IDATA(27)
00105 15* DIMENSION DATA(1)
00105 16* CXXXX READ HEADER FROM TAPE.
00106 17* IF(EXIT.EQ.0)GO TO 1
00110 18* NUNIT=IUNIT+1
00111 19* CALL SUB004(KN,DATA,NUNIT,IHEAD(1))
00112 20* CALL NTRAN (NUNIT,9)
00113 21* RETURN
00114 22* K = 1
00115 23* CALL NTRAN(IUNIT,2,3,IHEAD(1),IST(K))
00116 24* IF(IST(K).EQ.-1) CALL NTRAN(IUNIT,22)
00120 25* IF(IST(K).GT.0) GO TO 40

```

```

26* 31 KK=IST(K)
27* WRITE(6,90030) KFILE, KK
28* 90030 FORMAT(//, 10X, 'TAPE READ ERROR AT FILE NUMBFR', I6,
29* 1 10X, 'NTRAN STATUS WORD =', I4, //)
30* CALL NTRAN(IUNIT, 22)
31* GO TO 65
32* 40 IF(IIPR .EQ. 0) GO TO 43
33* CXXXX BREAK DOWN HEADER RECORD
34* CALL SUB003(INEAD, LREC, IDATA)
35* FSAMP=IDATA(10)
36* TIMAX=IDATA(11)*.5*1000
37* CXXXX M IS I/O BUFFER POINTER AND KK IS NUMBER OF SAMPLES READ.
38* 43 KK = 0
39* CXXXX READ DATA RECORD. USE DOUBLE BUFFERING TO SAVE I/O TIME.
40* CALL NTRAN(IUNIT, 2, 332, INDATA(1, 1), IST(1))
41* 45 IF(IISTIN).EQ.-1) CALL NTRAN(IUNIT, 22)
42* IF(IISTIN).LT.1) GO TO 31
43* CXXXX L IS BUFFER POINTER FOR PROCESSING
44* L = K
45* CXXXX CHECK FOR FULL RECORD
46* IF(IIST(K).LT.332) GO TO 60
47* CXXXX IF K=1, MAKE K=2. IF K=2, MAKE K=0
48* IF(K.GE.2) K=0
49* K = K+1
50* CXXXX READ NEXT DATA RECORD INTO SECOND PART OF APRAY INDATA.
51* CALL NTRAN(IUNIT, 2, 332, INDATA(1, K), IST(K))
52* CXXXX DECODE DATA.
53* 60 CALL SUB004(IST, L, INDATA, DATA, KK)
54* IF(IIST(L).LT.332) GO TO 65
55* 65 RETURN
56* END FOR
57*

```

SUBROUTINE SUB002 ENTRY POINT 000316

STORAGE USED: CODE(1) 000346; DATA(1) 004613; PLANK COMMON(2) 000075

EXTERNAL REFERENCES (BLOCK, NAME)

- 0003 SUB007
- 0004 NTRAN
- 0005 SUP008
- 0006 NWDUS
- 0007 NI01S
- 0010 NI02S
- 0011 NERR3S

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001	000013	1136	0001	000015	1176	0001	000122	1446	0001	000130	1546	0001	000132	1606					
0002	000105	25L	0001	000220	38L	0001	000271	40L	0000	004552	90020F	0000	004535	90050F					
0000	004472	9008GF	0000	004511	90085F	0000	004466	91001F	0000	R	000512	AY	000004	EXIT					
0002	000000	FSAMP	0000	I	004464	I	0000	I	004461	IF1	0002	000003	IMOVE	0000	004576	INJPS			
0000	I	004465	ISTAT	0000	I	004462	IX	0000	I	004460	J	0000	I	000002	KFILE	0002	I	000002	KFILE
0000	I	004456	KOUNT	0000	I	004463	NDATA	0000	I	000000	NOUT	0002	000001	TIMAX					

```

C
00100 1*
00100 2*
00100 3*
00100 4*
00100 5*
00100 6*
00100 7*
00100 8*
00100 9*
00100 10*
00100 11*
00100 12*
00100 13*
00100 14*
00100 15*
00103 16*
00104 17*
00105 18*
00106 19*
00107 20*
00107 21*
00110 22*
00112 23*
00115 24*

CXXXX SUBROUTINE SUB002(SDDS)CREATED BY T. MERO JUNE 1975 TO GENERATE
CXXXX AN OUTPUT TAPE TO OPERATE CODE 351'S SEISMIC DATA DISPLAY SYSTEM.
CXXXX THE OUTPUT DATA RECORD CONTAINS 1980-6 BIT DATA SAMPLES
CXXXX THE SDDS OUTPUT CODE IS 000000 = + FULL SCALE,
CXXXX 100000 = ZERO, 111111 = - FULL SCALE.
CXXXX DATA = A ONE DIMENSIONAL DATA ARRAY OF AT LEAST 1980 POINTS.
CXXXX KK = THE NUMBER OF DATA VALUES IN DATA
CXXXX IF A TAPE WRITE ERROR OCCURS KK BECOMES THE NTRAN STATUS WORD.
CXXXX MUNIT = THE OUTPUT TAPE UNIT NUMBER
CXXXX XMAX = THE LARGEST ABSOLUTE AMPLITUDE IN DATA
CXXXX IF THE INPUT DATA ARRAY CONTAINS MORE THAN 2020 POINTS, A SPLINE
CXXXX INTERPOLATION PROGRAM IS USED TO REDUCE THE ARRAY TO 2000 POINTS.
C
SUBROUTINE SUB002(KK,DATA,NUNIT,XMAX)
COMMON FSAMP,TIMAX,KFILE,IMOVE,EXIT
DIMENSION DATA(1),NOUT(330)
DIMENSION AY(2020)
KOUNT = 0
JI = 0
CZ0Z0 IF(KFILE.EQ.IMOVE) WRITE(6,9008C) (DATA(I),I=1,1000)
IF(KK.GT.2020) GO TO 25
DO 20 J = 1,330
IF1 = 0

```

```

25* 00116 00 10 IX = 1,6
26* 00121 JI = JI+1
27* CXXXX THE DATA IS SCALED DOWN TO THE 36 DB DYNAMIC RANGE OF THE SDDS.
28* NDATA = (DATA(JI)/XMAX) * 32 - 32
29* IF(NDATA.GT.0) KOUNT = KOUNT+1
30* 00123 IF(NDATA.LT.-63) KOUNT = KOUNT+1
31* 00125 IF (NDATA.GT.0) NDATA=0
32* 00127 IF (NDATA.LT.-63) NDATA =-63
33* 00131 CXXXX THE 6-6 BIT SAMPLES ARE PACKED INTO ONE 36 BIT COMPUTER WORD.
34* 00133 FLD(IF1,6,NOUT(J)) = FLD(30,6,NDATA)
35* 00134 10 IF1 = IF1 + 6
36* 00136 20 CONTINUE
37* 00140 60 TO 38
38* 00141 CXXXX CALL SUB007(SPLINT)
39* 00142 25 CALL SUB007(KK,DATA,AY)
40* 00144 WRITE (6,91001) (AY(I),I=1,KK)
41* 00150 91001 FORMAT (' A(Y)=',(10F10.5))
42* 00151 C2QZQ IF (KFILE.EQ.'MOVE)WRITE(6,90085)(AY(I),I=1,100)
43* 00151 90080 FORMAT(//,'20X','FIRST HUNDRED INPUT POINTS FROM FIRST SDDS
44* 00151 1 FILE READ',//,10F10.6)
45* 00152 90085 FORMAT(//,'20X','FIRST HUNDRED OUTPUT POINTS FROM FIRST SDDS
46* 00152 1 RECORD AFTER INTERPOLATION AND PROCESSING',//,10F10.6)
47* 00153 00 35 J = 1,330
48* 00156 IF1 = 0
49* 00157 00 30 IX = 1,6
50* 00162 JI = JI+1
51* CXXXX THE DATA IS SCALED DOWN TO THE 36 DB DYNAMIC RANGE OF THE SDDS.
52* NDATA = ( AY(JI)/XMAX) * 32 - 32
53* IF(NDATA.GT.0) KOUNT = KOUNT+1
54* 00164 IF(NDATA.LT.-63) KOUNT = KOUNT+1
55* 00166 IF (NDATA.GT.0) NDATA=0
56* 00170 IF (NDATA.LT.-63) NDATA =-63
57* 00172 CXXXX THE 6-6 BIT SAMPLES ARE PACKED INTO ONE 36 BIT COMPUTER WORD.
58* 00174 FLD(IF1,6,NOUT(J)) = FLD(30,6,NDATA)
59* 00175 30 IF1 = IF1 + 6
60* 00177 35 CONTINUE
61* 00177 CXXXX THE DATA RECORD IS WRITTEN ON TAPE.
62* 00201 38 CALL NTRAN(NUNIT,1,330,NOUT(1),ISTAT,22)
63* 00202 IF(ISTAT.EQ.-1) CALL NTRAN(NUNIT,22)
64* 00204 IF(ISTAT.LT. 1) 60 TO 40
65* 00206 IF(KOUNT.LT. 1) RETURN
66* 00206 CXXXX CALL SUB008(PEAK) TO GET A NEW PEAK BASED ON THIS FILE
67* 00210 CALL SUB008(DATA,KK,XMAX)
68* 00211 WRITE(6,90050) KOUNT,KFILE
69* 00215 90050 FORMAT(//,10X,'THE NUMBER OF SAMPLES CLIPPED =',I4,10X,
70* 00215 1 'DATA RECORD NUMBER',I6)
71* 00216 RETURN
72* 00217 40 WRITE(6,90020) KFILE,ISTAT
73* 00223 90020 FORMAT(//,10X,TAPE WRITE ERROR AT RECORD NUMBER',I6,
74* 00223 1 10X,'NTRAN STATUS WORD =',I4,//)
75* 00224 KK = ISTAT
76* 00225 RETURN
77* 00226 END
END FOR

```

FOR US W-SUB003
FOR E3AB-09/16/77-02:38:45 (8,9)

SUBROUTINE SUB003 ENTRY POINT 00G417

STORAGE USED: CODE(1) 000440; DATA(0) 000233; BLANK COMMON(2) 000005

EXTERNAL REFERENCES (BLOCK, NAME)

0003 NW0US
0004 NI02S
0005 NI01S
0006 XPII
0007 NERR3S

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001	000016	1136	0001	000020	1176	0001	000107	1456	0001	000204	1736	0001	000212	1776		
0000	000031	90010F	0000	000037	90020F	0000	000051	90030F	0000	000057	90040F	0000	000101	90050F		
0000	000110	90060F	0000	000121	90070F	0000	000137	90080F	0000	000150	90090F	0000	000161	90100F		
0001	000351	99999L	0000	000001	DAY	0002	R	000004	EXIT	0002	000000	FSAMP	0000	I	000002	HR
0000	I	000022	I	0000	I	000030	IAFS	0000	I	000023	IF1	0002	000203	INJPS		
0000	I	000004	ISAMPL	0000	I	000024	J	0000	I	000025	K	0002	I	000021	KK	
0000	I	000000	MIN	0000	R	000027	SD	0000	I	000003	SEC	0000	R	000001	TIMAX	

CXXXX SUBROUTINE SUB003(HEADER) TO DECODE HEADER RECORD FROM SDAS TAPE

1* 00100
2* 00101
3* 00103
4* 00104
5* 00105
6* 00106
7* 00107
8* 00107
9* 00111
10* 00111
11* 00112
12* 00115
13* 00116
14* 00121
15* 00122
16* 00123
17* 00124
18* 00126
19* 00130
20* 00130
21* 00131
22* 00132
23* 00133
24* 00133
25* 00134

INTEGER DAY,HR,MIN,SEC
COMMON FSAMP,TIMAX,KFILE,IMOVE,EXIT
DIMENSION IHEAD(3),IDATA(27)
DATA ISAMPL/200,400,500,1000,2000,2500,4000,5000,6250,10000,
C12500,20000,25000/
KK = 0
DO 41 I=1,3
IF1 = 0
DO 42 J=1,9
KK = KK+1
IDATA(KK) = FLD(IF1,4,IHEAD(I))
IF1 = IF1+4
42 CONTINUE
41 CONTINUE
CXXXX COMPUTE SAMPLE RATE, LENGTH, AND DELAY.
K = IDATA(10)
IDATA(10) = ISAMPL/K/(IDATA(13)+1)
SL = IDATA(11)*.5
SD = (IDATA(12)-1)*.5
CXXXX PRINT HEADER INFORMATION
WRITE(6,90010) KFILE

```

00137 26*
00140 27*
00142 28*
00143 29*
00151 30*
00152 31*
00157 32*
00157 33*
00160 34*
00163 35*
00164 36*
00164 37*
00165 38*
00170 39*
00171 40*
00203 41*
00203 42*
00203 43*
00204 44*
00205 45*
00206 46*
00207 47*
00210 48*
00211 49*
00213 50*
00215 51*
00217 52*
00221 53*
00223 54*
00224 55*
00225 56*
00227 57*
00231 58*
00233 59*
00235 60*
00236 61*
00237 62*
00240 63*
00241 64*
END FOR

90010 FORMAT('1',2X,'DATA FILE NUMBER',I6,/)
WRITE(6,90020)
90020 FORMAT(10X,'DAY',7X,'HOURS',3X,'MINUTES',3X,'SECONDS')
WRITE(6,90030) (IDATA(K), K=1,9)
90030 FORMAT(10X,3I1,6X,2I1,8X,2I1,6X,2I1,/)
WRITE(6,90040) IDATA(10),SL,SD
90040 FORMAT(10X,'SAMPLE RATE = ',I5,' MZ SAMPLE LENGTH = ',F3.1,
1' SEC SAMPLE DELAY = ',F3.1,' SEC',/)
WRITE(6,90050) IDATA(13)
90050 FORMAT(10X,I3,' INPUT CHANNEL SAMPLED',/)
IAFS = (IDATA(17)+(IDATA(18)*0.1)+(IDATA(19)*0.01))
1 *(10+IDATA(20))
WRITE(6,90060) IAFS
90060 FORMAT(10X,'ANTILIASING FILTER SETTING = ',I6,' MZ',/)
WRITE(6,90070)(IDATA(I),I = 14,16), (IDATA(I),I = 21,27)
90070 FORMAT(10X,'SWITCH SETTINGS 5 THRU 7',3I4,
1 10X,'SWITCH SETTINGS 12 THRU 18',7I4,/)
CXXX COMPUTE FILE LENGTH
LREC = (IDATA(10)+IDATA(11))/2+2
DAY=IDATA(1)+IDATA(2)+IDATA(3)
HR=IDATA(4)+IDATA(5)
MIN=IDATA(6)+IDATA(7)
SEC=IDATA(8)+IDATA(9)
IF (IDATA(10).LT.200.OR.IDATA(10).GT.12500)GO TO 99999
IF (DAY.GT.365.OR.HR.GT.24.OR.MIN.GT.60.OR.SEC.GT.60)GO TO 99999
IF (SL.LT.0.5.OR.SL.GT.16.C)GO TO 99999
IF (SD.GT.15.0)GO TO 99999
IF (IAFS.LT.100.OR.IAFS.GT.5000)GO TO 99999
RETURN
99999 EXIT=7777
WRITE(6,90080)
WRITE(6,90090)
WRITE(6,90100)
WRITE(6,90080)
90080 FORMAT(10X,'*****')
90090 FORMAT(10X,'**THERE IS SOMETHING WRONG WITH THE HEADER')
90100 FORMAT(10X,'**INCREASE KFILE BY 2 AND TRY AGAIN ')
RETURN
END

```

AFOR,US W.SURE04
FOR E3AB-09/16/77-02:38:46 (5,6)

SUBROUTINE SUB004 ENTRY POINT 00012C

STORAGE USED: CODE(1) 000141; DATA(0) 000030; BLANK COMMON(2) 000000

EXTERNAL REFERENCES (BLOCK, NAME)

JOC3 NERR3S

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001 000035 1106 0001 000C41 1156 0000 I 000002 I 0000 I 000004 IF3
0000 000007 INJPS 0000 I 000G01 IR 0000 I 000000 ISIGN 0000 I 000005 J

```

00100 1* C
00101 2* CXXXX SUB004(Decode) IS USED TO UNPACK DATA FROM SDAS TAPE
00102 3* CXXXX IST = NTRAN STATUS WORD
00103 4* CXXXX L = BUFFER POINTER FROM SDAS
00104 5* CXXXX INDATA = INPUT DATA FROM SDAS
00105 6* CXXXX DATA = DECODED OUTPUT DATA ARRAY
00106 7* CXXXX MK = NUMBER OF SAMPLES IN THE ARRAY DATA
00107 8* C
00108 9* SUBROUTINE SUB004(IST,L,INDATA,DATA,MK)
00109 10* DIMENSION IST(2),DATA(1),INDATA(332,2)
00110 11* IR = 332
00111 12* IF(IST(L).LT.332) IR = IST(L)
00112 13* DO 62 I=1,IR
00113 14* IF3 = 0
00114 15* IF3 = 1
00115 16* DO 63 J =1,3
00116 17* MK = MK+1
00117 18* CXXXX READ SIGN BIT
00118 19* ISIGN = FLD(IF2,1,INDATA(I,L))
00119 20* READ THE 11 BIT BCD AMPLITUDE
00120 21* DATA(MK) = FLD(IF3,11,INDATA(I,L))
00121 22* IF(ISIGN.EQ.1) DATA(MK) = -DATA(MK)
00122 23* CXXXX SCALE DATA BACK TO THE VOLTAGE OF THE INPUT SAMPLED
00123 24* DATA(MK) = DATA(MK) * 0.0048852
00124 25* IF2 = IF2+12
00125 26* IF3 = IF3+12
00126 27* 63 CONTINUE
00127 28* 62 CONTINUE
00128 29* RETURN
00129 30* END FOR

```

MDG,P SUB005

SUB005

00157 33*
 00160 34*
 00161 35*
 00162 36*
 00163 37*
 00165 38*
 END FOR

$Q=1./(6.*D(K))$
 $C(1,K)=Z(K)+Q$
 $C(2,K)=Z(K+1)*Q$
 $C(3,K)=Y(K)/C(K)-Z(K)+P(K)$
 7 $C(4,K)=Y(K+1)/D(K)-Z(K+1)+P(K)$
 END

END6,P SUB006

DATE 091677

PAGE

2

000006
 000006
 000006
 000006

FOR,US M.SUB006
FOR E3AB-09/16/77-02:38:54 (5,6)

SUBROUTINE SUB006 ENTRY POINT 000236

STORAGE USED: CODE(1) 000304; DATA(0) 000353; BLANK COMMON(2) 000000

EXTERNAL REFERENCES (BLOCK, NAME)

- 0003 SUB005
- 0004 NPRTS
- 0005 NIOZS
- 0006 NERRS

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001	000062 1L	0000	000325 101F	0001	000162 11L	0001	000145 12L	0001	000156 13L
0001	000070 2L	0001	000044 3L	0001	000105 4L	0001	000114 5L	0001	000126 6L
0001	000216 7L	0000 R	000000 C	0000	000340 INJPS	0000 I	000324 K		

```

00100 1* CXXXX SUBROUTINE SUB006(SPLINE)
00100 2* CXXXX SEE PENNINGTON REF. FOR DESCRIPTION OF THIS SUBROUTINE
00101 3* SUBROUTINE SUB006 (X,Y,M,XINT,YINT,ATER)
00103 4* DIMENSION X(1),Y(1),C(4,53)
00104 5* IFIX(1)+Y(M)+Y(M-1)+X(M-1)+Y(M-2)-ATER) 10,3,10
00104 6* CXXXX CALL SUB005(SPLICO)
00107 7* 10 CALL SUB005 (X,Y,M,C)
00110 8* ATER= X(1)+Y(M)+Y(M-1)+X(M-1)+Y(M-2)
00111 9* K=1
00112 10* 3 IF(ABS(XINT-X(1)).LT.0.00001) GO TO 1
00114 11* IF(XINT-X(1)) 70,1,2
00117 12* 70 K=1
00120 13* GO TO 7
00121 14* 1 YINT=Y(1)
00122 15* RETURN
00123 16* 2 IF(ABS(XINT-X(K+1)).LT.C.C0001) GO TO 4
00125 17* 4 YINT=Y(K+1)
00130 18* RETURN
00131 19* 5 K=K+1
00132 20* IF(M-K) 71,71,3
00133 21* 71 K=M-1
00136 22* GO TO 7
00140 24* 6 IF(ABS(XINT-X(K)).LT.0.00001) GO TO 12
00142 25* IF(XINT-X(K))13,12,11
00145 26* 12 YINT=Y(K)
00146 27* RETURN
00147 28* 13 K=K-1
00150 29* GO TO 6
00151 30* 11 YINT=(X(K+1)-XINT)*(C(1,K)*(X(K+1)-XINT)**2+C(3,K))

```

SUB006

00152
00153
00154
00157
00160
00161
END FOR

000002

YINT=YINT+(XINT-X(K))*(C(2,K)*(XINT-X(K))*2+C(4,K))

RETURN

7 PRINT 101,XINT

101 FORMAT(' CAUTION VALUE AT POSITION',F10.2,' WAS EXTRAPOLATED')

GO TO 11

END

ENDG,P SUB007

DATE 091677

PAGE

2

SUB007

FOR US W-SUB007
FOR E3AB-09/16/77-02:38:58 (6.7)

DATE 091677

PAGE

1

SUBROUTINE SUB007 ENTRY POINT 00C044

STORAGE USED: CODE(1) 000060; DATA(C) 017540; BLANK COMMON(2) 000000

EXTERNAL REFERENCES (BLOCK, NAME)

0003 SUB009
0004 MERR35

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

00C1 00C004 1066 0000 R 000000 AX 0000 P 017526 OFLX 0000 I 017527 ICT
00C0 017532 INJPS 0000 R 003720 X 0000 R 017525 XX

```

00100 1* CXXXX PROGRAM SUB007(SPLINT)REF. NAVOCEANO TR-226, DEC. 1970
00100 2* CXXXX A GENERAL 1 DIMENSIONAL SPLINE INTERPOLATION TO
00100 3* CXXXX REDUCE A DATA ARRAY OF MORE THAN 2020 SAMPLES TO
00100 4* CXXXX 2000 SAMPLES FOR DISPLAY BY SDDS
00100 5* CXXXX KK = NUMBER OF DATA VALUES IN THE INPUT ARRAY DATA
00100 6* CXXXX DATA = INPUT DATA ARRAY
00100 7* CXXXX AY = INTERPOLATED OUTPUT ARRAY CONTAINING 2000 VALUES
00100 8* CXXXX SUBROUTINE SUBCD7(SPLINT)
00101 9* SUBROUTINE SUB007(KK,DATA,AY)
00103 10* DIMENSION DATA(1),AY(1),AX(2000)
00104 11* DIMENSION X(6020)
00105 12* DO 10 I = 1, KK
00110 13* X(I) = I
00112 14* XKK=KK
00113 15* DELX =XKK/2000
00113 16* CXXXX CALL SUB009(GINT)
00114 17* CALL SUB009(DELX, KK, 1.0, XKK, ICT, X, DATA, AX, AY)
00115 18* RETURN
00116 19* END
END FOR

```

0006, P SUB006

RTMP, US W. SUFORA
 FOR 1180-09/16/77-02:39:00 (6,7)

SUBROUTINE SUB008 ENTRY POINT 000040

STORAGE USED: CODE(1) 000055; DATA(1) 000020; BLANK COMMON(2) 000000

EXTERNAL REFERENCES (BLOCK, NAME)

0003 MW008
 0004 NI028
 0005 NEPR35

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001 000006 1066 0000 000001 90010F 0000 I 000000 I 0000 000010 INJPS

```

00100 1* C
00100 2* CXXXX SUBROUTINE TO DETERMINE LARGEST VALUE IN DATA ARRAY
00100 3* CXXXX DATA = ONE-DIMENSIONAL ARRAY
00100 4* CXXXX KK = NUMBER OF POINTS IN DATA
00100 5* CXXXX XMAX = ABSOLUTE PEAK AMPLITUDE + 308
00100 6* C
00100 7* CXXXX SUBROUTINE SUB008(PEAK)
00101 8* SUBROUTINE SUB008(DATA, KK, XMAX)
00103 9* DIMENSION DATA(1)
00104 10* XMAX = 0.0
00105 11* DO 10 I = 1, KK
00110 12* IF (ABS(DATA(I)) .GT. XMAX) XMAX = ABS(DATA(I))
00112 13* 10 CONTINUE
00114 14* CXXXX INCREASE XMAX BY 3 DB
00115 15* XMAX = XMAX * 1.412538
00120 16* WRITE(6, 90010) XMAX
00121 17* 90010 FORMAT(//, 10X, 'XMAX = ', F10.4, //)
00122 18* RETURN
00122 19* END
  
```

6HD6, P SUB009

SUB010

FOR US W.SUB010
FOR E3AB-09/16/77-02:39:06 (4,5)

DATE 091677

PAGE

1

SUBROUTINE SUB010 ENTRY POINT 000121

STORAGE USED: CODE(1) 000132; DATA(1) 000133; BLANK COMMON(2) 000000

EXTERNAL REFERENCES (BLOCK, NAME)

0003 NMDUS
0004 NI03S
0005 NI02S
0006 NERR3S

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0000	00C107	102F	0000	000112	104F	0001	000005	112G	0001	000022	123G	0001	000031	131G				
0001	00C070	666L	0001	000057	7011L	0001	000064	7022L	0000	I	000000	BLANK	0000	I	000001	DOT		
0000	00C121	INJPS	0000	I	000104	J	0000	I	000106	L	0000	I	000003	LINE	0000	I	0001C5	M
0000	I	000002	X															

```

00100 1* CXXXX SUBROUTINE SUB010(LINE)
00100 2* CXXXX SUB010(LINE) CONVERTS EACH DATA POINT TO A
00100 3* CXXXX POINT ON THE HARD COPY (I.E. A GRAPH)
00101 4* SUBROUTINE SUB010(DATA, MK, XMAX)
00103 5* INTEGER BLANK, DOT, X
00104 6* DATA BLANK/1H /, DOT/'./', X/'X'/'
00110 7* DIMENSION LINE(65), DATA(1)
00111 8* DO 101 J=1,65
00114 9* LINE(J)=DOT
00116 10* WRITE(6,102) LINE
00121 11* 102 FORMAT(1H1,50X,65A1)
00122 12* DO 103 J=1,65
00125 13* LINE(J)= BLANK
00127 14* LINE(33) = DOT
00130 15* DO 999 M= 1,MK
00133 16* L=(DATA(M)/XMAX)*32 + 33.5
00134 17* IF (L.LT.1) GO TO 7011
00136 18* IF (L.GT.65) GO TO 7022
00140 19* LINE(L) = X
00141 20* GO TO 666
00142 21* 7011 L=1
00143 22* LINE(1) = DOT
00144 23* GO TO 666
00145 24* 7022 L=65
00146 25* LINE (65) = DOT
00147 26* WRITE (6,104) LINE
00152 27* 104 FORMAT (1H ,50X,65A1)
00153 28* LINE(L) = BLANK
00154 29* LINE(33) = DOT

```

SUBDIO

00155 30*
00157 31*
END FOR

999 CONTINUE
END

AM06,P SUB011

DATE 091677

PAGE

2

FOR US M-SUB011
FOR E3AB-09/16/77-02:39:09 (14,15)

SUBROUTINE SUB011 ENTRY POINT 000442

STORAGE USED: CODE(1) 000472; DATA(0) 000211; BLANK COMMON(2) 000011

EXTERNAL REFERENCES (BLOCK, NAME)

- J003 SUB013
- J004 SUB016
- J005 SUB017
- J006 WROUS
- J007 NI025
- J010 WROUS
- J011 NI015
- J012 COS
- J013 SIM
- J014 MERR35

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0000	000104	140F	0001	000061	1446	0000	000105	150F	0001	000074	154G	0001	000031	173L
0001	000255	211G	0001	000304	2226	0001	000357	2376	0000	000131	30F	0000	000133	31F
0001	000206	320L	0001	000101	33L	0000	R 000102	A1	0000	R 000103	A2	0000	R 000077	DELPH
0000	R 000055	DELT	0002	000004	EXIT	0002	000005	F	0000	P 000057	FPI	0000	R 000071	FRINT
0002	R 000010	FR0HI	0002	R 000007	FRQL0W	0002	R 000000	FSAMP	0000	I 000061	I	0000	I 000070	IMI
0002	I 000003	MOVE	0000	000156	INJPS	0000	I 000101	I1	0000	I 000075	I2	0000	I 000050	KFIL
J002	I 000002	KFILE	0000	I 000066	LOW	0000	I 000062	NP2	0000	I 000063	NP21	0000	I 000051	NZERO
J002	000006	PEAK	0000	R 000052	PHASE	0000	R 000100	PHAS1	0000	R 000056	PI	0000	R 000073	RESOL
J000	R 000074	RES010	0000	R 000072	RESTIM	0002	R 000001	TIMAX	0000	R 000064	TIMP	0000	R 000054	TSAMP
0000	R 000053	TSHIFT	0000	R 000067	XHI	0000	R 000065	XLOW	0000	R 000060	XTIM	0000	R 000076	XTIMI
0000	R 000000	ZER01	0000	R 000024	ZER02									

- 00101 1*
- 00101 2*
- 00101 3*
- 00101 4*
- 00101 5*
- 00101 6*
- 00101 7*
- 00101 8*
- 00101 9*
- 00101 10*
- 00101 11*
- 00101 12*
- 00101 13*
- 00101 14*
- 00101 15*
- 00101 16*

SUBROUTINE SUB011 (Y, P, NP, M, Z)
 CXXXX SUBROUTINE SUB011(FFTFIL)
 C R. L. DICUS 8/15/75
 C PROGRAM FFTFIL
 C FSAMP--SAMPLING FREQUENCY AT WHICH DATA WAS DIGITIZED (KHZ).
 C TIMAX--MAXIMUM LENGTH OF DATA TIME TO BE READ IN ON LWIN
 C FRQL0W--LOW FREQUENCY ZERO POINT ON COSINE TAPER OF FREQUE CY
 C FR0HI--CORRESPONDING HIGH FREQUENCY ZERO POINT (KHZ).
 C KFIL--TYPE OF FILTERING TAPER APPLIED TO FREQUENCY RESPONSE FUNCTION
 C FOR COMPUTATION OF IMPULSE RESPONSE
 C =0 FOR NO TAPER
 C =1 FOR COSINE TAPER
 C =2 FOR GAUSSIAN TAPER
 C =3 FOR TRIANGULAR TAPER

```

17* 00101 C N4 FOR RECTANGULAR TAPER
18* 00101 C TSHIFT--TIME SHIFT
19* 00101 C NZERO--NUMBER OF FREQUENCY REJECTION BANDS
20* 00101 C ZER0(I), ZER02(I)--BAND REJECT FREQUENCY LIMITS
21* 00101 C SUBROUTINES REQUIRED
22* 00101 C FFTREL NLOGN TAPER REJECT
23* 00101 C DATA CARDS
24* 00101 C TSHIFT (5 SPACE FORMAT )
25* 00101 C FROLOW FROHI KFIL NZERO PHASE
26* 00101 C IF(NZERO.NE.0)ZER01, ZER02---ETC. (5 SPACE FORMAT)
27* 00101 C P= ARRAY WITH PHASE ANGLE
28* 00103 COMMON FSAMP,TIMAX,KFILE,IMOVE,EXIT
29* 00104 COMMON F,PEAK,FROLOW,FROHI
30* 00105 DIMENSION Z(1),Y(1),P(1),ZER01(20),ZER02(20)
31* 00105 C
32* 00105 C CXXXX READ IN FREQUENCY LIMITS
33* 00105 C
34* 00106 IF (NFILE.NE.IMOVE ) GO TO 170
35* 00110 READ(15,140 )FROLOW,FROHI,KFIL,NZERO,PHASE,TSHIFT
36* 00120 140 FORMAT ( )
37* 00121 WRITE (6,150 ) FROLOW,FROHI ,KFIL , NZERO ,PHASE ,TSHIFT
38* 00131 150 FORMAT(1X,'FROLOW =',F7.3,5X,'FROHI =',F7.2,5X,'KFIL =',15,5X,
39* 00131 1 NZERO =',15,5X, 'PHASE =',F10.3,5X,'TSHIFT =',F5.2 )
40* 00131 CXXXX FSAMP=SAMPLING FREQUENCY IN KHZ.
41* 00131 CXXXX TSAMP=SAMPLE TIME IN MSEC.
42* 00132 170 TSAMP = 1./ FSAMP
43* 00133 DELT=TSAMP
44* 00134 PI=3.1415926535898
45* 00135 FPI=PI/180.
46* 00136 XTIM=FSAMP*TSHIFT
47* 00137 PHASE=PHASE*FPI
48* 00140 IF (NZERO.EQ.0 ) GO TO 33
49* 00142 READ (5,30 )ZER01(I),ZER02(I),I=1,NZERO)
50* 00151 30 FORMAT(16F5.1)
51* 00152 WRITE(6,31)(ZER01(I),ZER02(I),I=1,NZERO)
52* 00161 31 FORMAT(//1X,'FREQUENCY REJECTION BAND LIMITS'/(/1X,5(5X,2F13.3)))
53* 00162 33 NP2 = NP/2
54* 00163 NP21 = NP2 + 1
55* 00164 TIMP=NP/FSAMP
56* 00165 XL0W=FLOAT(NP)*FROLOW/FSAMP
57* 00166 L0W=INT(XLOW)
58* 00167 XHI=FLOAT(NP)*FROHI/FSAMP
59* 00170 IHI=INT(XHI)
60* 00171 FRINT=FSAMP/NP
61* 00172 IF(NZERO.EQ.0)GO TO 320
62* 00174 RESTIM = TIMAX
63* 00175 RESOL=1./RESTIM
64* 00176 IF(RESOL.LT.FRINT)RESOL=FRINT
65* 00200 RESO10=RESOL*10.
66* 00201 IF(RESOL.GT.RESO10)RESOL=RESO10
67* 00201 CALL SUB013( REJECT )
68* 00203 IF(NZERO.GT.0)CALL SUB013(NZERO,ZER01,ZER02,FRINT,RESOL,Y)
69* 00203 CXXXX CALL SUB018(TAPER)
70* 00203 CXXXX CALL SUB018(TAPER)
71* 00205 320 IF(NFIL.GT.0) CALL SUB016(NP21,KFIL,IHI,LOW,Y)
72* 00205 C TRANSFER CALIBRATED AND TAPERED MAGNITUDES INTO REAL PARTS OF COMPLEX Z ARRA
73* 00207 Z(2)=Y(NP21)

```

SUB011

```

74* DO 440 I=1,MP2
75* I2=2*I-1
76* 440 Z(I2)=Y(I)
77* CXXXX OPERATE ON ANGLES OF INPUT SERIES
78* XTIMI=XTIM
79* DELPH=PI*XTIMI/MP2
80* PHAS1=0.
81* DO 410 I=2,MP2
82* PHAS1=PHAS1-DELPH
83* P(I)=P(I)+PHAS1+PHASE
84* I2=2*I
85* 410 Z(I2) = P(I)
86* P(I) = P(I) + PHASE
87* PHAS1=PHAS1-DELPH
88* P(MP2) = P(MP2) + PHAS1 + PHASE
89* Z(1) = Z(1) * COS (P(1))
90* Z(2) = Z(2) * COS (P(MP2))
91* C CONVERT CALIBRATED AND TAPERED FREQUENCY RESPONSE FUNCTION FROM POLAR FORM
92* C BACK TO CARTESIAN FORM
93* DO 450 I=2,MP2
94* I1=2*I-1
95* I2=I1+1
96* A1=Z(I1)*COS(Z(I2))
97* A2=Z(I1)*SIN(Z(I2))
98* Z(I1)=A1
99* 450 Z(I2)=A2
100* C COMPUTE FILTERED OUTPUT BY TAKING INVERSE FOURIER TRANSFORM
101* C CALL SUB017(FFTREL)
102* CALL SUB017 (M, Z, +1.0 )
103* RETURN
104* END FOR

```

END FOR SUB012

SUBROUTINE SUB012 ENTRY POINT 000112

STORAGE USED: CODE(1) 000132; DATA(C) 000073; BLANK COMMON(2) 000000

EXTERNAL REFERENCES (BLOCK, NAME)

0003 XPII
0004 MUDUS
0005 NI02S
0006 NERR3S

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001	000002	1056	0001	000070	1356	0001	000015	20L	0000	000004	50F			
0000	000016	60F	0000	000030	70F	0000	000042	80F	0000	000054	90F			
0000	000062	INJPS	0000	I	000001	INP	0000	I	000003	J	0000	I	000002	NPP

```

00101 1* SUBROUTINE SUBG12 (NP,DATA,M)
00101 2* CXXXX SUBROUTINE SUBG12(TESTPW)
00103 3* DIMENSION DATA(1)
00103 4* C
00103 5* CXXXX M= POWER OF 2 AND I=2**M
00103 6* CXXXX RAISES NUMBER OF POINTS TO A POWER OF 2
00103 7* CXXXX TRUNKATES NUMBER OF POINTS TO 2048 IN ANY CASE
00103 8* C
00104 9* DO 10 M=9,11
00107 10* I=2**M
00110 11* IF (I-NP) 10,20,30
00113 12* 10 CONTINUE
00113 13* C
00113 14* CXXXX TRUNKATE NUMBER OF POINTS TO 2048
00113 15* C
00115 16* 20 NP=I
00116 17* WRITE (6,50)
00120 18* WRITE (6,60)
00122 19* WRITE (6,70)
00124 20* WRITE (6,80)
00126 21* WRITE (6,50)
00130 22* RETURN
00131 23* 30 IMP=I
00132 24* MPP=NP+1
00133 25* NP=I
00134 26* DO 40 J=NPP,IMP
00137 27* DATA(J)=0.0
00141 28* WRITE (6,90) NP
00144 29* RETURN
00144 30* C

```

SUB012

00145
00146
00147
00150
00151
00151
00152
END FOR

31*
32*
33*
34*
35*
36*
37*
C

50 FORMAT (10X, '*****THE OUTPUT HAS BEEN TRUNCATED TO 2048*****')
60 FORMAT (10X, '*****IF A LARGER VALUE IS DESIRED CHANGE *****')
70 FORMAT (10X, '*****THE DO LOOP TO THE LARGER VALUE *****')
80 FORMAT (10X, 'NP= ', I6)
90 FORMAT (10X, 'NP= ', I6)

END

END OF SUB013

DATE 091677

PAGE

2

SUB013

FOR BUS W-SUB013
FOR E3AB-09/16/77-02:39:16 (5.6)

DATE 091677

PAGE

1

SUBROUTINE SUB013 ENTRY POINT 000166

STORAGE USED: CODE(1) 000212; DATA(C) 000022; BLANK COMMON(2) 000000

EXTERNAL REFERENCES (BLOCK, NAME)

0003 SUB014
0004 NERR35

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001 000134 10L 0001 07C136 2110L 0001 000001 2120L 0000 R 000004 FRQ2
0002 I 000005 IPIN 0000 000007 INJPS 0000 I 000000 IZERO 0000 I 000001 IZER01 0000 I 000002 IZER02

```

00101 1*
00102 2* SUBROUTINE SUB013(ZERO,ZER01,ZER02,FRINT,RESOL,Y)
00103 3* CXXXX SUBROUTINE SUB013(REJECT)
00104 4*
00105 5* C SET SPECTRUM MAGNITUDES TO ZERO AT BAND REJECT FREQUENCIES
00106 6*
00107 7* DIMENSION ZERO(1),ZER02(1),Y(1)
00108 8* IZERO=0
00109 9* 2120 IZERO=IZERO+1
00110 10* CXXXX CALL SUB014(IZER)
00111 11* CALL SUB014(ZER01(IZER0),ZER02(IZER0),RESOL,IZER01,IZER02)
00112 12* IF(RESOL.EQ.0..OR.RESOL.LE.FRINT*60 TO 10
00113 13* FRQ1=(IZER01-1)*RESOL
00114 14* IZER01=INT(FRQ1/FRINT+.5)+1
00115 15* FRQ2=(IZER02-1)*RESOL
00116 16* IZER02=INT(FRQ2/FRINT+.5)+1
00117 17* IF(IZER01.LT.1) IZER01=1
00118 18* IF(IZER02.LT.1) IZER02=1
00119 19* IF(IZER01.GT.8193) IZER01=8193
00120 20* IF(IZER02.GT.8193) IZER02=8193
00121 21* IC CONTINUE
00122 22* 2100 IBIN=IZER01
00123 23* 2110 Y(IBIN)=C.
00124 24* IBIN=IBIN+1
00125 25* IF(IBIN.LE. IZER02) GO TO 2110
00126 26* IF( IZER0.LT. NZER0) GO TO 2120
00127 27* RETURN
00128 28* END
END FOR

```

0006,P SUB014

SUB014

FOR,US M.SUR014
FOR E3AB-09/16/77-02:39:19 (5,6)

DATE 091677

PAGE

1

SUBROUTINE SUB014 ENTRY POINT 000076

STORAGE USED: CODE(1) 000106; DATA(0) 000014; BLANK COMMON(2) 000000

EXTERNAL REFERENCES (BLOCK, NAME)

0003 MERR35

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0000 R 000000 FRINT2 0000 R 000003 FRQIB 0000 P 000006 FRQID 0000 I 000001 IA 0000 I 000002 IP
0000 T 000004 IC 0000 I 000005 ID 0000 C 000010 INJPS

```

00101 1*
00101 2*
00101 3*
00101 4*
00101 5*
00101 6*
00101 7*
00101 8*
00103 9*
00103 10*
00103 11*
00103 12*
00103 13*
00103 14*
00104 15*
00105 16*
00106 17*
00107 18*
00110 19*
00112 20*
00113 21*
00114 22*
00115 23*
00116 24*
00120 25*
00121 26*
END FOR

```

```

SUBROUTINE SUB014(ZERO1,ZERO2,FRINT,IZERO1,IZERO2)
CXXX SUBROUTINE SUBC14(IZER)
C
C FOR TWO FREQUENCY BINS LESS THAN ZERO1 AND TWO FREQUENCY BINS GREATER
C THAN ZERO2.
C
C IZERO1=INT(IZER01/FRINT)
C IZERO2=INT(IZER02/FRINT)+3
C
C FOR ONE OR TWO FREQUENCY BINS LESS THAN ZERO1, AND ONE OR TWO
C FREQUENCY BINS GREATER THAN ZERO2.
FRINT2=FRINT/4.
IA=INT(IZER01/FRINT)
IB=IA+1
FRQIB=(IB-1)*FRINT
IZERO1=IA
IF(IZER01-FRQIB.GT.FRINT2)IZERO1=IP
IC=INT(IZER02/FRINT)+3
ID=IC-1
FRQID=(ID-1)*FRINT
IZERO2=IC
IF(FRQID-ZERO2.GT.FRINT2)IZERO2=ID
RETURN
END

```

END OF P SUB015

FOR, US W. SUB015
FOR E3AB-09/16/77-02:39:22 (6,7)

SUBROUTINE SUB015 ENTRY POINT 000132

STORAGE USED: CODE(1) 000151; DATA(0) 000024; BLANK COMMON(2) 000000

EXTERNAL REFERENCES (BLOCK, NAME)

0003 SQRT
0004 ATAN
0005 NERR3S

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001	000107	10CL	0001	000C14	1066	0001	000111	110L	0001	000035	20L	000041	30L
0001	000045	40L	0001	000056	50L	0001	000061	60L	0001	000071	70L	000074	80L
0001	000076	9CL	0000	I	0000001	I	0000	000004	INJPS	0000	R	000000	PI

```

00101 1* SUBROUTINE SUB015(L, RE, XIM, AMP, PHZ)
00101 2* CXXXX SUBROUTINE SUB015(POLAR) IS A MEANS OF CONVERTING
00101 3* CXXXX RECTANGULAR COORDINATES TO POLAR COORDINATES
00103 4* DIMENSION RE(1), XIM(1), AMP(2050), PHZ(2050)
00104 5* PI = 3.14159265
00105 6* DO 110 I = 1, L
00110 7* AMP(I) = SQRT(RE(I)**2 + XIM(I)**2)
00111 8* IF (XIM(I)) 10,20,30
00114 9* 10 IF (RE(I)) 40,50,60
00117 10* 20 IF (RE(I)) 70,80,60
00122 11* 30 IF (RE(I)) 90,100,60
00125 12* 40 PHZ(I) = ATAN (XIM(I)/RE(I)) - PI
00126 13* 60 TO 110
00127 14* 50 PHZ(I) = -PI / 2.0
00130 15* 60 TO 110
00131 16* 60 PHZ(I) = ATAN(XIM(I)/RE(I))
00132 17* 60 TO 110
00133 18* 70 PHZ(I) = - PI
00134 19* 60 TO 110
00136 20* 80 PHZ(I) = 0.0
00137 21* 60 TO 110
00140 22* 90 PHZ(I) = ATAN (XIM(I)/RE (I)) + PI
00141 23* 60 TO 110
00141 24* 100 PHZ(I) = PI/ 2.0
00142 25* 110 CONTINUE
00144 26* RETURN
00145 27* END
END FOR

```

AM06,P SUB016

SUBROUTINE SUB016 ENTRY POINT C00332

STORAGE USED: CODE(1) 000352; DATA(0) 000103; BLANK COMMON(2) 000000

EXTERNAL REFERENCES (BLOCK, NAME)

0003 XPII
0004 SIN
0005 COS
0006 CDS
0007 NERR3S

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001	000030	1106	0001	000045	1156	0001	000072	1246	0001	000175	1465
0001	000230	1626	0001	000247	1726	0001	000303	2066	0001	000245	5L
0001	000263	7L	0000	R	000035	FK	0000	P	000036	FLX	
0000	I	000034	IBLOCK	0000	I	000043	II	0000	C	000021	HOLD
0000	I	000042	JH	0000	I	000033	II	0000	I	000040	I
0000	I	000025	LX	0000	I	000033	K	0000	I	000047	INJPS
0000	C	000017	WK	0000	I	000000	M	0000	I	000027	L
								0000	I	000030	NBLOCK
								0000	I	000032	LBHALF
								0000	C	000023	Q
								0000	R	000037	V

```

00101 1*
00101 2*
00101 3*
00101 4*
00101 5*
00101 6*
00101 7*
00101 8*
00101 9*
00101 10*
00101 11*
00101 12*
00101 13*
00101 14*
00101 15*
00101 16*
00101 17*
00101 18*
00101 19*
00101 20*
00101 21*
00101 22*
00101 23*
00101 24*
00101 25*

```

```

SUBROUTINE SUB016 (N,X,SIGN)
SUBROUTINE SUB016(NLOGN)
C FROM ROBINSON PAGE 63
C NMAX = LARGEST VALUE OF N TO BE PROCESSED
C NONDUMMY DIMENSION M(MAX)
C FOR EXAMPLE, IF NMAX = 15 THEN
C DIMENSION M(15)
C DIMENSION X(2**N)
C COMPLEX X,MK,HOLD,0
LX = 2**N
DO 1 I = 1,N
1 M(I) = 2**(N - I)
DO 4 L = 1,N
NBLOCK = 2**(L - 1)
LBLOCK = LX / NBLOCK
LBHALF = LBLOCK / 2
K = 0
DO 4 IBLOCK = 1,NBLOCK
FK = K
FLX = LX
V = SIGN * 6.2831853071796*FK/FLX
WK = CMPLX( COS(V), SIN(V) )
ISTART = LBLOCK * (IBLOCK - 1)
DO 2 I = 1,LBHALF

```

```

00136 26* J = ISTART + I
00137 27* JM = J + LBHALF
00140 28* Q = X(JH) * WK
00141 29* X(JH) = X(J) - Q
00142 30* X(J) = X(J) + Q
00143 31* 2 CONTINUE
00145 32* DO 3 I = 2,N
00150 33* II = I
00151 34* IF(K.LT.M(II)) GO TO 4
00153 35* 3 K = K - M(II)
00155 36* 4 K = K + M(II)
00160 37* K = 0
00161 38* DO 7 J = 1, LX
00164 39* IF (K.LT.J) GO TO 5
00166 40* HOLD = X(J)
00167 41* X(J) = X(K + 1)
00170 42* X(K + 1) = HOLD
00171 43* 5 DO 6 I = 1,N
00174 44* II = I
00175 45* IF(K.LT.M(II)) GO TO 7
00177 46* 6 K = K - M(II)
00201 47* 7 K = K + M(II)
00203 48* IF(SIGN.LT.0.0) RETURN
00205 49* DO 8 I = 1,LX
00210 50* 8 X(I) = X(I) / FLX
00212 51* RETURN
00213 52* END
END FOR

```

AM06,P SUB017

AD-A079 743

NAVAL OCEAN RESEARCH AND DEVELOPMENT ACTIVITY NSTL S--ETC F/G 8/11
MARINE SEISMIC DISPLAY ENHANCEMENT PROGRAM. VOLUME II. PROCESSI--ETC(U)
DEC 77 B E ECKSTEIN

UNCLASSIFIED

NORDA-TN-14


NL

2 OF 2

ADA
079743



END
DATE
FILMED
2-80
DDC



MICROCOPY RESOLUTION TEST CHART
NATIONAL BUREAU OF STANDARDS-1963-A

SUB017

FOR,US W.SUB017
FOR E34B-09/16/77-02:39:28 (6,7)

DATE 091677

PAGE

1

SUBROUTINE SUB017 ENTRY POINT 000411

STORAGE USED: CODE(1) 000432; DATA(C) 000065; BLANK COMMON(2) 000000

EXTERNAL REFERENCES (BLOCK, NAME)

0003 SUB016
0004 XPII
0005 SIN
0006 COS
0007 XPCI
0010 MERR35

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001	000112	1266	0001	000273	1456	0001	000236	200L	0000	C	000000	A1	0000	C	000002	A2			
0000	I	000022	I	0000	000041	INJPS	0000	I	000010	I2N	0000	I	000011	N	0000	I	000014	N1	
0000	I	000015	N11	0000	I	000012	N2	0000	I	000013	N21	0000	R	000016	PI	0000	R	000017	PI M
0000	R	000020	R1	0000	R	000021	R2	0000	C	000004	M	0000	C	000006	MI	0000	R	000023	Z1
0000	R	000024	Z2																

00101 1* SUBROUTINE SUB017(IPOWER,Z,EXPONT)
 00101 2* CXXX SUBROUTINE SUB017(FFTREL)
 00101 3* C SUBROUTINE FFTREL PERFORMS DFT AND IDFT VIA FFT ALGORITHM. FFTREL MAKES
 00101 4* C USE OF THE SYMMETRIES AVAILABLE IN CALCULATING THE FFT FOR REAL DATA SERIES.
 00101 5* C WITH EXPONT=-1.0 THE DFT IS COMPUTED UNDER THE ASSUMPTION THAT THE INPUT
 00101 6* C SERIES IS REAL. WITH EXPONT=+1.0 THE IDFT IS COMPUTED UNDER THE ASSUMPTION
 00101 7* C THAT THE INPUT SERIES IS THE DFT OF A REAL SERIES.
 00101 8* C REF.--THE FAST FOURIER TRANSFORM ALGORITHM. PROGRAMMING CONSIDERATIONS IN T
 00101 9* C CALCULATION OF SINE,COSINE,AND LAPLACE TRANSFORMS
 00101 10* C J. W. COOLEY, P. A. W. LEWIS AND P. D. WELCH
 00101 11* C J. SOUND AND VIB., VOL. 12, PP. 315-337, JULY 1970.
 00101 12* C REF.--FOR NLOGN SUBROUTINE SEE ENDERS A. ROBINSON S BOOK.
 00101 13* C
 00101 14* C
 00101 15* C
 00101 16* COMPLEX Z,A1,A2,M,WI
 00101 17* DIMENSION Z(1)
 00101 18* I2N=2*IPOWER
 00101 19* N=I2N/2
 00101 20* M2=N/2+1
 00101 21* M1=M+1
 00101 22* M1=M+2
 00101 23* PI=3.1415926536
 00101 24* W=CMPLX(COS(PIN),SIN(PIN))
 00101 25* W=(EXPONT)100,100,200
 00101 26* C

```

270 CXXXX CALL SUB016(INLOGN)
280 100 CALL SUB016(IPOWER-1,Z,-1.0)
290 C
300 C COMPUTE FOURIER TRANSFORM FOR DC AND NYQUIST FREQUENCY. THESE TWO SPECIAL
310 C CASES ARE REAL NUMBERS AND WILL BE STORED AS THE REAL AND IMAGINARY PARTS
320 C RESPECTIVELY OF THE FIRST WORD OF THE DATA ARRAY.
330 C
340 C
350 R1=REAL(Z(1))
360 R2=AIMAG(Z(1))
370 Z(1)=-5*CMPLX(R1+R2,R1-R2)
380 DO 110 I=2,N21
390 A1=5*(CONJG(Z(N11-I))+Z(I))
400 A2=CMPLX(0,.5)*(CONJG(Z(N11-I))-Z(I))
410 W1=W*(I-1)
420 Z(I)=-5*(A1+A2+W1)
430 110 Z(N11-I)=-5*CONJG(A1-A2+W1)
440 RETURN
450 C
460 C COMPUTE INVERSE FOURIER TRANSFORM
470 C THE DC AND NYQUIST FREQUENCY COEFFICIENTS ARE STORED IN Z(1)
480 C
490 C
500 Z1=REAL(Z(1))
510 Z2=AIMAG(Z(1))
520 R1=Z1+Z2
530 R2=Z1-Z2
540 Z(1)=CMPLX(R1,R2)
550 DO 210 I=2,N21
560 W1=W*(I-1)
570 A1=Z(1)+CONJG(Z(N11-I))
580 A2=(Z(1)-CONJG(Z(N11-I)))*W1
590 Z(I)=A1+CMPLX(0,.1)*A2
600 Z(N11-I)=CONJG(A1-CMPLX(0,.1)*A2)
610 CXXXX CALL SUB016(INLOGN)
620 CALL SUB016(IPOWER-1,Z,+1.0)
630 RETURN
640 END FOR

```

AM06,P SUB018

FOR,US W.SUR018
FOR E3AB-09/16/77-02:39:31 (10,11)

SUBROUTINE SUB018 ENTRY POINT 00G234

STORAGE USED: CODE(1) 000254; DATA(0) 000047; PLANK COMMON(2) 000000

EXTERNAL REFERENCES (BLOCK, NAME)

0003 NERR2S
0004 COS
0005 EXP
0006 NERR3S

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001	000212	100L	0001	000145	110L	0001	000056	1176	0001	000110	200L	0001	000077	40L		
0001	000113	60L	0001	000164	70L	0001	000203	80L	0001	000136	90L	0000	R	000003	BAND	
0000	I	000010	I	0000	I	000002	IBAND		0000	I	000001	IFO	0000	I	000006	IJ1
0000	I	000007	IJ2	0000		000021	INJPS		0000	I	000000	PI	0000	R	000011	M
0000	R	000004	XTAPER						0000	I	000005	ITAPER				

```

00101 1*
00101 2*
00101 3*
00101 4*
00103 5*
00104 6*
00106 7*
00107 8*
00110 9*
00111 10*
00112 11*
00113 12*
00114 13*
00115 14*
00116 15*
00121 16*
00123 17*
00124 18*
00125 19*
00125 20*
00125 21*
00125 22*
00126 23*
00127 24*
00130 25*
00130 26*
00130 27*
00130 28*

SUBROUTINE SUB018(MP21,KFIL,IMI,LOW,Y)
CXXX SUBROUTINE SUB018(TAPER)
C SUBROUTINE TAPER MULTIPLIES FREQUENCY RESPONSE FUNCTION BY SOME FILTERING
C CONTOUR.
DIMENSION Y(11)
IF(KFIL.LE.0)RETURN
PI=3.1415926535898
IFO=(IMI+LOW)/2
IBAND=IMI-LOW+1
BAND=FLOAT(IBAND)
XTAPER=.1*BAND
ITAPER=INT(XTAPER)
IJ1=LOW+ITAPER
IJ2=IMI-ITAPER
DO 100 I=1,MP21
IF(1.6E.LOW.AND.1.LE.IMI)60 TO 40
M=C.
60 TO 100
40 60 TO (60, 70 , 80, 200 ) , MFIL
C
C RECTANGULAR TAPER
C
200 M=1.
60 TO 100
C
C COSINE TAPER
C
60 IF(1.6E.IJ1)60 TO 90

```


SUBROUTINE SUB019 ENTRY POINT 000174

STORAGE USED: CODE(1) 000213; DATA(1) 027517; BLANK COMMON(2) 000000

EXTERNAL REFERENCES (BLOCK, NAME)

0003 SUB020
0004 NRDU5
0005 NIO2S
0006 NRDU5
0007 NIO1S
0010 NERR3S

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0000	027443	10F	0001	000031	1176	0001	000043	1256	0001	000062	136F	0001	000124	1526	
0001	000145	1656	0000	027453	20F	0000	027455	30F	0000	027462	31F	0000	027464	32F	
0000	027447	33F	0000	027444	34F	0001	000070	42L	0001	000161	43L	0000	R	007664	A
0000	R	027442	ASE	0000	R	000000	D	0000	027502	INJPS	0000	I	027440	LA	
0000	I	027441	LC	0000	I	027434	LD	0000	I	027435	LE	0000	I	027436	LF
												0000	R	013616	SPACE

```

00101 1* SUBROUTINE SUBG19(B, LB, KFILE, C)
00101 2* CXXXX SUBROUTINE SUB019( DASHAP)
00101 3* C PROGRAM TO DESIGN WAVE SHAPING FILTERS
00101 4* C B=INPUT ,D=DESIRED OUTPUT ,A=FILTER WEIGHTS ,C=ACTUAL OUTPUT
00101 5* C ASE=AVERAGE SQUARED ERROR BETWEEN D AND C
00101 6* C LB=LENGTH OF B,LD=LENGTH OF D,LA=LENGTH OF A,LC=LENGTH OF C
00101 7* C LE=LENGTH OF A AT START ,LF=LENGTH OF A AT FINISH
00101 8* C NSET = NO. OF DATA SETS THIS RUN
00101 9* C NEED SUBROUTINES SHAPE,CROSS,EUREKA,OOT,FOLD,ZERO
00103 10* DIMENSION B(1),D(4020),A(2010),C(1),SPACE(6030)
00104 11* READ(5,10) LD,LE,LF
00111 12* 10 FORMAT(1)
00112 13* WRITE(6,34)
00114 14* 34 FORMAT(' INPUT DATA ')
00115 15* WRITE(6,31)(B(J),J=1,LB)
00123 16* READ(5,20)(D(J),J=1,LD)
00131 17* WRITE(6,33)
00133 18* 33 FORMAT(' DESIRED OUTPUT ')
00134 19* WRITE(6,31)(D(J),J=1,LD)
00142 20* 20 FORMAT(20F3.1)
00143 21* LA=LE
00143 22* CXXXX CALL SUB020(SHAPE)
00144 23* 42 CALL SUB020(LB,B,LD,D,LA,A,LC,C,ASE,SPACE)
00145 24* WRITE(6,30)
00147 25* 30 FORMAT(' SHAPING FILTER WEIGHTS ')
00150 26* WRITE(6,31)(A(J),J=1,LA)

```

SUB019

00156
00157
00162
00163
00171
00174
00175
00176
00177
END FOR

27*
28*
29*
30*
31*
32*
33*
34*
35*

31 FORMAT(10F10.5)
WRITE(6,32) ASE
32 FORMAT(' ACTUAL OUTPUT
WRITE(6,31)(C(I),J=1,6LC)
IFILA-LF)41,43,43
41 LA=LA+1
42 GO TO 42
43 RETURN
END

AVERAGE SQUARED ERROR *.F.9.4)

DATE 091677

PAGE

2

2M06,P SUB020

SUB020

FOR,US W-SUB020
FOR E3AB-09/16/77-02:39:37 (6,7)

DATE 091677

PAGE

1

SUBROUTINE SUB020 ENTRY POINT 00C110

STORAGE USED: CODE(1) 000164; DATA(0) 000010; BLANK COMMON(2) 000000

EXTERNAL REFERENCES (BLOCK, NAME)

0003 SUB021
0004 SUB025
0005 SUB022
0006 SUB023
0007 MERR34

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0000 R 000001 A6 0000 R 000000 DD 0000 000002 INJPS

```

00101 1* SUBROUTINE SUB020(LB,B,LD,D,LA,A,LC,C,ASE,SPACE)
00102 2* SUBROUTINE SUB020(SHAPE)
00103 3* DIMENSION B(LB),D(LD),A(LA),C(LC),SPACE(2)
00104 4* CALL SUB021(CROSS)
00105 5* CALL SUB021(LB,B,LD,D,LA,A,LC,C,ASE,SPACE)
00106 6* CALL SUB021(LD,D,LA,A,SPACE(LA+1))
00107 7* CALL SUB025(UREKA)
00108 8* CALL SUB025(LA,SPACE,SPACE(LA+1),A,SPACE(2*LA+1))
00109 9* CALL SUB022(DD)
00110 10* CALL SUB022(LD,D,DD)
00111 11* CALL SUB022(LA,A,SPACE(LA+1),A6)
00112 12* ASE=(DD-AG)/DD
00113 13* CALL SUB023(FOLD)
00114 14* CALL SUB023(LA,A,LD,B,LC,C)
00115 15* RETURN
00116 16* END
END FOR

```

@M06,P SUB021

SUB021

DATE 091677

PAGE

1

FOR,US M-SUB021
FOR E3AB-09/16/77-02:39:40 (6,7)

SUBROUTINE SUB021 ENTRY POINT 000051

STORAGE USED: CODE(1) 000071; DATA(0) 000021; BLANK COMMON(2) 000000

EXTERNAL REFERENCES (BLOCK, NAME)

0003 SUB022
0004 NERR38

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001 000011 1C56 0000 000002 INJPS 0000 I 000000 J

```

00101 1*
00101 2*
00103 3*
00104 4*
00104 5*
00107 6*
00111 7*
00112 8*
END FOR

```

```

SUBROUTINE SUB021(LX,X,LY,Y,L6,6)
SUBROUTINE SUB021(CROSS)
DIMENSION X(LX),Y(LY),6(L6)
DO 1 J=1,L6
CXXX CALL SUB022(DOT)
1 CALL SUB022(MIN0(LY,LX-J+1),X(J),Y,6(J))
RETURN
END

```

END OF SUB022

SUB022

FOR US V-SUB022
FOR E3AB-09/16/77-02:39:43 (6,7)

DATE 091677

PAGE 1

SUBROUTINE SUB022 ENTRY POINT 000035

STORAGE USED: CODE(1) 000052; DATA(0) 000013; BLANK COMMON(2) 000000

EXTERNAL REFERENCES (BLOCK, NAME)

0003 MERR38

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001 000016 1106 0000 I 000000 I 0000 000002 INJPS

```

00101 1* SUBROUTINE SUB022(L,X,Y,P)
00101 2* CXXXX SUBROUTINE SUB022(DDT)
00103 3* DIMENSION X(L),Y(L)
00104 4* P=0.0
00105 5* IF(L.LE.0) RETURN
00107 6* DO 1 I=1,L
00112 7* 1 P=X(I)*Y(I)
00114 8* RETURN
00115 9* END
END FOR

```

END OF SUB023

SUB023

FOR US M-SUB023
FOR E3AB-09/16/77-02:39:45 (6,7)

DATE 091677

PAGE

1

SUBROUTINE SUB023 ENTRY POINT 000066

STORAGE USED: CODE(1) 000110; DATA(0) 000025; BLANK COMMON(2) 000000

EXTERNAL REFERENCES (BLOCK, NAME)

0003 SUB024
0004 NERR36

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001 000024 1076 0001 000031 1126 0000 I 000000 I 0000 I 000001 J
0000 I 000002 K

00101	1*	SUBROUTINE SUB023(LA,A,LB,B,LC,C)
00102	2*	CXXXX SUBROUTINE SUB023(FOLD)
00103	3*	DIMENSION A(LA),B(LB),C(LC)
00104	4*	LC=LA*LB-1
00105	5*	CXXXX CALL SUB024(ZERO)
00106	6*	CALL SUB024(LC,C)
00107	7*	DO 1 I=1,LA
00108	8*	DO 1 J=1,LB
00109	9*	K=I+J-1
00110	10*	1 C(K)=C(K)+A(I)*B(J)
00111	11*	RETURN
00112	12*	END
END FOR		

END FOR SUB024

SUB024

FOR US V.SUB024
FOR E3AB-09/16/77-02:39:48 (6,7)

DATE 091677

PAGE 1

SUBROUTINE SUB024 ENTRY POINT 000026

STORAGE USED: CODE(1) 000034; DATA(0) 000011; BLANK COMMON(2) 000000

EXTERNAL REFERENCES (BLOCK, NAME)

0003 MERR35

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001 000013 1076 0000 I 000000 I 0000 000002 INJPS

```

00101 1* SUBROUTINE SUBC24(LX,X)
00101 2* SUBROUTINE SUBC24(ZERO)
00103 3* DIMENSION X(LX)
00103 4* C FOR COMPLEX VERSION REMOVE THE C FROM COL 1 OF NEXT CARD
00103 5* C COMPLEX X
00104 6* IF(LX.LE.0)RETURN
00106 7* DO 1 I=1,LX
00111 8* 1 X(I)=0.0
00113 9* RETURN
00114 10* END
END FOR

```

END OF SUB025

SUB025

00156 33*
00161 34*
00162 35*
00163 36*
00166 37*
END FOR

DO * I=1,1
K=L-I+2
O=D+A(I)*R(K)
* Q=Q+F(I)*R(K)
END

ENDG.P SUB026

FOR,US W.SUB026
FOR E3AB-09/16/77-02:39:54 (6,7)

SUBROUTINE SUB026 ENTRY POINT 00C364

STORAGE USED: CODE(1) 000416; DATA(1) 000071; BLANK COMMON(2) 000000

EXTERNAL REFERENCES (BLOCK, NAME)

0003 SIN
0004 COS
0005 NERR35

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001	00C042	1136	0001	000154	1336	0001	000176	1426	0001	00223	1506		
0001	000303	1676	0001	000324	1766	0001	000337	2046	0001	000124	61L		
0001	000166	78L	0001	000202	79L	0000	R	000007	AX	0000	R		
0000	I	000011	II	0000	000026	INJPS	0000	I	000012	J	0000	I	
0000	I	000015	L	0000	I	000000	NA	0000	I	000013	J1	0000	I
0000	R	000002	PI	0000	R	000005	Q	0000	R	000016	NC	0000	R

```

00101 1*
00101 2*
00101 3*
00101 4*
00101 5*
00101 6*
00101 7*
00101 8*
00101 9*
00101 10*
00101 11*
00101 12*
00103 13*
00104 14*
00107 15*
00107 16*
00107 17*
00110 18*
00111 19*
00112 20*
00115 21*
00116 22*
00117 23*
00121 24*
00122 25*
00123 26*
00124 27*
00126 28*

SUBROUTINE SUB026(X, NP, CUT, N, N, K, WGT)
CXXXX SUBROUTINE SUB026(FILTER)
C GENERAL ROUTINE TO HIGH OR LOW PASS A SET OF EQUALLY
C SPACED DATA USING MARTIN FILTERS.
C X=INPUT DATA AND OUTPUT DATA, NP=NO. OF POINTS IN X, CUT=NORMALIZED
C CUTOFF OF FILTER IN CYCLES/DATA INTERVAL, M=SLOPE PARAMETER,
C N=HALF LENGTH OF FILTER, TOTAL LENGTH=2M+1.
C K=1=HIGH PASS, =0 FOR LOW PASS.
C IF K = 2, THE FILTER WEIGHTS ARE NOT COMPUTED. THE WEIGHTS FROM
C A PREVIOUS CALL ARE CONVOLVED WITH THE DATA.
C
C WEIGHTS STORED IN WGT
DIMENSION X(1), WGT(1)
NA=N+1
IF(K.EQ.2) GO TO 79
WGT(1)=2.0*(CUT+H)
C CENTER WEIGHT STORED IN LOCATION 1
SUM=0.0
PI=3.1415926
DO 61 I=2, NA
P=I-1
O=1.0-16.0*M**2*P**2
IF(ABS(O).GT.0.0001) GO TO 62
WGT(I)=SIN(2.*PI*P*(CUT+H))/(4.0*P)
GO TO 61
62 WGT(I)=(COS(2.*PI*P*H))/O)+((SIN(2.*PI*P*(CUT+H)))/(PI*P))
61 SUM=SUM+WGT(I)
DELTA=1.-(WGT(1))+2.*SUM)

```

```

29* 00127
30* 00130
31* 00132
32* 00135
33* 00137
34* 00140
35* 00141
36* 00144
37* 00146
38* 00146
39* 00147
40* 00152
41* 00153
42* 00154
43* 00157
44* 00160
45* 00161
46* 00163
47* 00163
48* 00165
49* 00166
50* 00171
51* 00172
52* 00173
53* 00175
54* 00200
55* 00202
56* 00203
57* 00206
58* 00210
59* 00211
END FOR

AX=2*N+1
IF(K.LI.1) 60 TO 78
DO 65 I=2,NA
65 WGT(I)=(WGT(I)+DELTA/AX)*(-1.0)
WGT(I)=1.0-(WGT(I)+DELTA/AX)
60 TO 79
78 DO 80 I=1,NA
80 WGT(I)=WGT(I)+DELTA/AX
79 NB=NP-N
C CONVOLVE WEIGHTS WITH DATA.
DO 63 I=NA,NB
II=I+1-NA
SUM=0.0
DO 64 J=1,NA
J1=I+J-1
J2=I-J+1
64 SUM=SUM+WGT(J)*(X(J1)+X(J2))
63 X(II)=SUM-WGT(II)*X(II)
C SHIFT FILTERED DATA TO CORRECT LOCATION AND ZERO ENDS.
II=NB+1-NA
DO 67 I=1,II
J=II+1-I
L=J+N
67 X(L)=X(J)
DO 68 I=1,M
68 X(I)=0.0
MC=NB+1
DO 69 I=MC,NP
69 X(II)=0.0
RETURN
END

```

FOR US W.SUB027
FOR E3AB-09/16/77-02:39:57 (7,8)

SUBROUTINE SUB027 ENTRY POINT 000220

STORAGE USED: CODE(1) 000235; DATA(0) 004001; BLANK COMMON(2) 000000

EXTERNAL REFERENCES (BLOCK, NAME)

- 0003 SUB016
- 0004 SORT
- 0005 ALOG10
- 0006 NBDUS
- 0007 NIOZ\$
- 0010 NIO3S
- 0011 NERR3S

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001	000016	1106	0001	000053	1226	0001	000131	1416	0001	000113	420L
0001	000121	430L	0001	000125	440L	0001	000145	500L	0000	003732	510F
0000	003747	540F	0000	R	003721	ANORM	0000	R	000000	DDATA	
0000	I	003725	IA	0000	003757	INJPS	0000	I	003723	J	
0000	I	003727	JX	0000	I	003731	J1		0000	I	003722
							0000	R	003720	XMAX	

```

00101 1* SUBROUTINE SUB027(MP,DATA,M)
00101 2* CXXX SUBROUTINE SUB027(FFT)
00101 3* CXXX THIS SUBROUTINE TAKES INFORMATION IN THE TIME
00101 4* CXXX DOMAIN AND CONVERTS IT TO RECTANGULAR COORDINATES
00101 5* CXXX (FREQ. DOMAIN) AND THEN FINDS THE ENERGY CONTENT
00101 6* CXXX AT EACH FREQ. BIN.
00103 7* DIMENSION DDATA(200),DATA(1)
00104 8* XMAX = 0.0
00105 9* ANORM = 1.0
00106 10* JE = NP/2
00107 11* DO 400 J = 1,MP
00112 12* I=(J+2)-1
00113 13* DDATA(I)=DATA(J)
00114 14* IA=I+1
00115 15* 400 DDATA(IA)=0.0
00115 16* CXXX CALL SUB016(MLOGN)
00117 17* CALLS SUB016(M,DDATA,-1.0)
00120 18* INX=MP + 1
00121 19* DO 420 I = 1,INX,2
00124 20* JX = (I+1)/2
00125 21* J=I+1
00126 22* DD=SQRT(DDATA(I)**2 + DDATA(J)**2)
00127 23* IF(DD)430,430,410
00132 24* 410 DDATA(JX)=20*ALOG10((DD)**ANORM)
00133 25* 420 CONTINUE

```

SUB027

```

26* 60 TO 440
27* 430 DDATA(JX)=-160.0
28* 60 TO 420
29* 440 00 500 J=1,JE
30* IF (DDATA(J)-LT.XMAX)60 TO 500
31* XMAX=DDATA(J)
32* JI=J
33* 500 CONTINUE
34* WRITE(6,510)XMAX,JI
35* 510 FORMAT(//,20X,'XMAX=',F10.4,10X,'JI=',I5)
36* 00 520 I=1,1000
37* 520 DDATA(I)=-XMAX-DDATA(I)
38* 530 WRITE(6,530)
39* 530 FORMAT(1H1,40X,'DDATA=-XMAX-DDATA(I)')
40* WRITE(6,540)DDATA(I),I=1,1000
41* 540 FORMAT(//,110X,10F10.5)
42* RETURN
43* END

```

END FOR SUB029

SUB029

FORM, US M. SUB029
FOR E3A8-09/1677-02:40:00 (3,4)

SUBROUTINE SUB029 ENTRY POINT 000203

STORAGE USED: CODE(1) 000216; DATA(0) 003777; BLANK COMMON(2) 000000

EXTERNAL REFERENCES (BLOCK, NAME)

- 0003 SORT
- 0004 ALOG10
- 0005 MWDUS
- 0006 NIO28
- 0007 NIO18
- 0010 MERR38

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001	000017	1116	0001	000102	1306	0001	000131	1466	0001	000160	1606	0001	000064	420L	
0001	000072	430L	0001	000076	440L	0001	000116	500L	0000	003731	510F	0000	003740	530F	
0000	003746	540F	0000	R	003721	ANORM	0000	R	003727	DD	0000	R	000000	DDATA	
0000	003755	INJPS	0000	I	003723	INX	0000	I	003726	J	0000	I	003722	JE	
0000	I	003725	JX	0000	R	003720	XMAX					0000	I	003730	JI

```

00101 1* SUBROUTINE SUB029(INP,DATA,M)
00101 2* CXXXX SUBROUTINE SUB029(FFFT)
00101 3* CXXXX THIS SUBROUTINE TAKES INFORMATION IN THE FREQ.
00101 4* CXXXX DOMAIN
00101 5* CXXXX AND THEN FINDS THE ENERGY CONTENT
00101 6* CXXXX AT EACH FREQ. BIN.
00103 7* DIMENSION DDATA(2000),DATA(1)
00104 8* XMAX = -160.0
00105 9* ANORM = 1.0
00106 10* JE = NP/2
00107 11* INX=NP + 1
00110 12* DO 420 I = 1,INX,2
00113 13* JX = (I+1)/2
00114 14* J=I+1
00115 15* DD=SQRT(DATA(I)**2 + DATA(J)**2)
00116 16* IF(DD)430,430,410
00121 17* 410 DDATA(JX)=20*ALOG10((DD)*ANORM)
00122 18* 42C CONTINUE
00124 19* 60 TO 440
00125 20* 430 DDATA(JX)=-160.0
00126 21* 60 TO 420
00127 22* 440 DO 500 J=1,JE
00132 23* IF (DDATA(J).LT.XMAX)60 TO 500
00134 24* XMAX=DDATA(J)
00135 25* JI=J
00136 26* 500 CONTINUE

```

SUB029

00140 27*
00141 28*
00142 29*
00143 30*
00144 31*
00145 32*
00146 33*
00147 34*
00148 35*
00149 36*
00150 37*
END FOR

WRITE(6,510)XMAX,JI
S10 FORMAT(//,20X,'XMAX=',F10.4,10X,'JI=',I5)
DO 520 I=1,1000
S20 DDATA(I)=- (XMAX-DDATA(I))
WRITE(6,530)
S30 FORMAT(1H1,4CX,'DDATA=- (XMAX-DDATA(I))'
J=NP/2
WRITE(6,540) (DDATA(I), I=1,J)
S40 FORMAT(//, (10X,10F10.5))
RETURN
END

END OF P SUB024

FOR US W.SUB004
FOR E340-09/16/77-02:40:03 (9,10)

SUBROUTINE SUB044 ENTRY POINT 000243

STORAGE USED: CODE(1) 000267; DATA(0) 000576; BLANK COMMON(2) 000005

EXTERNAL REFERENCES (BLOCK, NAME)

0003 NTRAM
0004 MNDUS
0005 NJ025
0006 NERR35

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001	000035	10L	0001	000070	1246	0001	000072	1306	0001	000216	4CL	0000	000530	50F	
0002	R	000004	EXIT	0000	R	000526	EXITT	0002	000000	FSAMP	0000	I	000524	IF1	
0002	I	000003	IMOVE	0000	I	000556	INJPS	0000	I	000000	ISIGN	0000	I	000520	ITEST
0000	I	000525	JX	0000	I	000523	J	0000	I	000516	J1	0002	I	000521	MKK
0000	I	000522	KOUNT	0000	I	000527	MDATA	0000	I	000001	NOUT	0002	I	000001	TIMAX

```

00101 1*
00101 2*
00101 3*
00101 4*
00101 5*
00101 6*
00101 7*
00101 8*
00101 9*
00101 10*
00101 11*
00101 12*
00101 13*
00103 14*
00104 15*
00105 16*
00106 17*
00110 18*
00112 19*
00113 20*
00114 21*
00115 22*
00116 23*
00120 24*
00121 25*
00123 26*
00126 27*
00127 28*

```

SUBROUTINE SUB044 (KK,DATA,MUNIT,IMEAD)

C
CXXXX SUBROUTINE SUB002 CREATED BY B. ECKSTEIN JUNE 1977
CXXXX GENERATES AN OUTPUT TAPE OF PROCESSED DATA IN THE SDAS FORMAT
CXXXX THE OUTPUT DATA RECORD CONTAINS 996-12 BIT DATA SAMPLES
CXXXX DATA = A ONE DIMENSIONAL DATA ARRAY
CXXXX KK = THE NUMBER OF DATA VALUES IN DATA
CXXXX IF A TAPE WRITE ERROR OCCURS KK BECOMES THE NTRAM STATUS WORD.
CXXXX MUNIT = THE OUTPUT TAPE UNIT NUMBER
CXXXX XMAX = THE LARGEST ABSOLUTE AMPLITUDE IN DATA
CXXXX IF THE INPUT DATA ARRAY CONTAINS MORE THAN 2020 POINTS, A SPLINE
CXXXX INTERPOLATION PROGRAM IS USED TO REDUCE THE ARRAY TO 2000 POINTS.

C
COMMON FSAMP,IMAX,MFILE,IMOVE,EXIT
DIMENSION DATA(1),NOUT(332),IMEAD(3)
CALL NTRAM (MUNIT,1,3,IMEAD(1),JSTAT,22)
IF (JSTAT.EQ.-1) CALL NTRAM (MUNIT,22)
IF (ISTAT.LT.1) GO TO 40
JI=0
IBUF=332
ITEST=332
MKN=MK/3
10 IF (ITEST.GT.MKN) IBUF=(MK/3)-ITEST+332
KOUNT=1
IF (IBUF.LT.332) KOUNT=0
DO 30 J=1,IBUF
IF1=0
DO 20 IX=1,3

SUB0044

```

29*      JE=JI+1
30*      CXXXX THE DATA IS SCALED DOWN TO THE 72 DB DYNAMIC RANGE OF THE SOAS.
31*      ISIGN=0
32*      EXIT=(EXIT+10)/10
33*      NDATA=ABS((DATA(JI)/EXITT)/.0048852)
34*      IF (DATA(JI).LT.0) ISIGN=1
35*      FLD(IF1,1,NOUT(J))=ISIGN
36*      IF1=IF1+1
37*      FLD(IF1,1,NOUT(J))=FLD(25,11,NDATA)
38*      CXXXX THE 3-12 BIT SAMPLES ARE PACKED INTO ONE 36 BIT COMPUTER WORD.
39*      20  IF1=IF1+11
40*      30  CONTINUE
41*      CALL NTRAN (NUNIT,1,IBUF,NOUT(1),JSTAT,22)
42*      IF (JSTAT.EQ.-1) CALL NTRAN (NUNIT,22)
43*      IF (JSTAT.LT.1) GO TO 40
44*      WRITE (6,90066)IBUF,ITEST
45*      IF (KOUNT.LT.1) RETURN
46*      ITEST=ITEST+332
47*      60 TO 10
48*      40 WRITE (6,50) KFILE,JSTAT
49*      KK=JSTAT
50*      RETURN
51*
52*      50 FORMAT (//,10X,'TAPE WRITE ERROR AT RECORD NUMBER',16,10X,'NTRAN S
53*      TATUS WORD =',14,/)
54*
55*      C
56*      END FOR

```

END OF SUB0045

FOR US W.SUB045
FOR E3AB-09/16/77-02:40:06 (11,12)

SUBROUTINE SUB045 ENTRY POINT 000255

STORAGE USED: CODE(1) 000303; DATA(0) 005024; BLANK COMMON(2) 000000

EXTERNAL REFERENCES (BLOCK, NAME)

0003 PLOTS
0004 PLOT
0005 AXES
0006 MNDUS
0007 NI025
0010 NERR35

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001	000105	IOL	0001	000162	1426	0001	000124	20L	0000	004730	40F	0000	004741	50F	
0000	R	004705	DELTIC	0000	I	004715	I	0000	005001	INJPS	0000	I	004713	I2	
0000	I	004714	I3	0000	I	004710	N	0000	P	000000	PLBUF	0000	R	004704	SCALE3
0000	R	004706	TIME	0000	R	004716	X	0000	R	004720	XM	0000	R	004711	XOFFS

```

SUBROUTINE SUB045 (SCALEX,SCALEY,IPR,XMAX,DATA,KK)
THIS IS A ROUTINE TO PLOT A CALCOMP TYPE OF OUTPUT TRACE
IN THE FORM OF A WIGGLE TRACE
SCALEX = THE VERTICLE AMPLITUDE OF THE TRACE
SCALEY = THE HORIZONTAL LENGTH OF THE TRACE
DATA = DATA ARRAY
KK = # OF DATA POINTS FOR THIS RECORD
XMAX = THE MAXIMUM VALUE OF THE DATA (NORMALIZING VALUE)
IPR = CONTROL CHARACTER
IF IPR = 1 THEN WRITE # OF DATA POINTS PLOTTED
IF IPR = 0 STILL PLOTS DATA BUT NO INDICATION GIVEN
IF IPR = -1 PLOT AXES
IF IPR = -2 WRITE 999 AS FILE # ON CALCOMP TAPE
DIMENSION DATA(1), PLBUF(2500)
IF (IPR.NE.-1) 60 TO 10
CALL PLOTS (PLBUF,2500,9)
CALL PLOT (0.0,-15.0,-3)
CALL PLOT (0.0,.55,-3)
SCALE3=SCALEX*10
DELTIC=SCALEX
CALL AXES (0.0,0.0,13HFILE NUMBER,-13,SCALE3,0.0,DELTIC,0.0,1.0,
1-1)
TIME=KK/1000.0
SCALE3=(SCALEY/10)*(2000/KK)
SCALE1=400.0/KK
CALL AXES (0.0,0.0,10HTIME (SEC),10,SCALEY,90.0,SCALE3,0.0,SCALE1,
13)

```

```

00120 N=1
00121 XOFFS=SCALEX
00122 10 IF (IPR.EQ.0) GO TO 20
00123 CXXXX PRINT DATA ARRAY
00124 WRITE (6,40) KK
00127 WRITE (6,50) SCALEX,SCALEY
00133 20 CONTINUE
00134 I1=2
00135 I2=KK
00136 I3=1
00137 CALL PLOT (XOFFS,0.0,-3)
00140 XOFFS=0
00141 DO 30 I=I1,I2,I3
00144 X=-(DATA(I)/XMAX)*SCALEX+XOFFS
00145 Y=(I*SCALEY/KK)
00146 CALL PLOT (X,Y,2)
00147 30 CONTINUE
00151 XOFFS=XOFFS+SCALEX
00152 N=N+1
00153 IF (IPR.GE.-1) RETURN
00155 XM=XOFFS+.15
00156 CALL AXES (XM,0.0,10*TIME (SEC),+10,06.0,270.0,1.000,4.0,2.0,-1)
00157 XM=XM+3
00160 CALL PLOT (XM,0.0,-3)
00161 CALL PLOT (0.0,0.0,999)
00161 RETURN
00162 C
00162 40 FORMAT (10X,'DIGITIZED DATA FILE ',I6,' DATA SAMPLES')
00163 50 FORMAT (10X,'X SCALE FACTOR =',F8.5X,'Y SCALE FACTOR =',F8.5,/)
00163 C
00164 END FOR
00164 58*
00164 58*

```

FOR SUB W-SUB006
FOR E3AB-09/16/77-02:40:09 (1,2)

SUBROUTINE SUB006 ENTRY POINT 000305

STORAGE USED: CODE(1) 000332; DATA(1) 000053; BLANK COMMON(2) 000000

EXTERNAL REFERENCES (BLOCK, NAME)

0003 SUB024
0004 MLOGN
0005 XPII
0006 MBDUS
0007 NI02S
0010 SORT
0011 MERR3S

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001 000025 1106 0001 000052 1206 0001 000136 1406 0001 000206 1526 0001 000243 1626
0001 000065 30L 0000 000010 70F 0000 R 000001 B 0000 I 000002 I
0000 I 0000004 L3 0000 I 000003 J 0000 I 000006 J1 0000 I 000007 K 0000 I 000005 L2

00101 1*
00101 2*
00101 3*
00101 4*
00101 5*
00101 6*
00101 7*
00101 8*
00103 9*
00104 10*
00105 11*
00106 12*
00107 13*
00112 14*
00113 15*
00114 16*
00116 17*
00117 18*
00122 19*
00123 20*
00125 21*
00127 22*
00130 23*
00131 24*
00132 25*
00132 26*

SUBROUTINE SUB006 (DATA,I,L1,K2,K3)
THIS SUBROUTINE IS TO MOVE THE BUBBLE PULSE OF THE GUN SIGNATURE
DATA = THE DATA ARRAY
T = THE DATA ARRAY OUTPUT DATA ARRAY
L1 = THE FIRST DATA POINT FOR THE START OF EXPANSION
K2 = THE LENGTH OF THE DATA TO BE EXPANDED
K3 = THE LENGTH OF THE DATA TO BE EXPANDED TO

DIMENSION DATA(I), T(I)
A=K2
B=K3
CALL SUB024 (2000,T)
DO 10 I=1,K2
J=I+L1
L3=2*I-1
T(L3)=DATA(J)
DO 20 I=1,12
J=2*I
IF (J.GE.L2) GO TO 30
20 CONTINUE
30 CONTINUE
L2=I
J1=J
WRITE (6,70) J
WRITE (6,90020) (T(I),I=1,J1)
C

FOR US M-SUB047
FOR E3AB-09/16/77-02:40:12 (1,2)

SUBROUTINE SUB047 ENTRY POINT 000141

STORAGE USED: CODE(1) 000161; DATA(0) 000035; BLANK COMMON(2) 000000

EXTERNAL REFERENCES (BLOCK, NAME)

0003 ATAN2
0004 SORT
0005 MERR3S

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001 000064 1136 0000 R 000006 DATAIM 0000 R 000005 DATAR 0000 I 000002 I 0700 000011 INJPS
0000 I 000003 I2 0000 I 000004 I3 0000 I 000000 NP2 0000 I 000001 NP21

```

00101 1* SUBROUTINE SUB047 (DATA,Y,P,NP)
00101 2* C CONVERT THE CARTESSION COORDINATES TO POLAR FORM
00101 3* C
00101 4* C Y CONTAINS AMPLITUDE OF DATA
00101 5* C P CONTAINS ANGLE OF DATA
00103 6* C DIMENSION Y(1), P(1), DATA(1)
00104 7* NP2=NP/2
00105 8* NP21=NP2+1
00106 9* Y(1)=ABS(DATA(1))
00107 10* Y(NP21)=ABS(DATA(2))
00110 11* P(1)=ATAN2(0.,DATA(1))
00111 12* P(NP21)=ATAN2(0.,DATA(2))
00112 13* DO 10 I=2,NP2
00115 14* I2=2*I-1
00116 15* I3=I2+1
DC117 16* DATAR=DATA(I2)
00120 17* DATAIM=DATA(I2+1)
00121 18* Y(I)=SQRT (DATAR**2+DATAIM**2)
00122 19* P(I)=ATAN2(DATAIM,DATAR)
00122 20* C
00124 21* END FC:

```

#M06,P SUB048

SUB048

DATE 091677

PAGE

1

FOR, US V. SUB048
FOR E3AB-09/16/77-02:40:15 (20,21)

SUBROUTINE SUB048 ENTRY POINT 000046

STORAGE USED: CODE(1) 000064; DATA(0) 017621; BLANK COMMON(2) 000000

EXTERNAL REFERENCES (BLOCK, NAME)

0003 SUP009
0004 MERR35

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001 00004 1C66 0000 R 000000 AX 0000 P 017607 DELX 0000 I 017610 ICT
0000 017612 INJPS 0000 R 004001 X 0000 R 017606 XXK 0000 I 017605 I

```

00101 1* SUBROUTINE SUB048(MK, DATA, AY, L2)
00101 2* CXXXX PROGRAM SUB048(SPLINT)REF. NAVOCEANO TR-226, DEC. 1970
00101 3* CXXXX A GENERAL 1 DIMENSIONAL SPLINE INTERPOLATION TO
00101 4* CXXXX REDUCE A DATA ARRAY TO L2 SAMPLES
00101 5* CXXXX KK = NUMBER OF DATA VALUES IN THE INPUT ARRAY DATA
00101 6* CXXXX DATA = INPUT DATA ARRAY
00101 7* CXXXX AY = INTERPOLATED OUTPUT ARRAY CONTAINING 2000 VALUES
00101 8* CXXXX SUBROUTINE SUB007(SPLINT)
00103 9* DIMENSION DATA(1),AY(1),AX(2049)
00104 10* DIMENSION X(6020)
00105 11* DO 10 I = 1, KK
00110 12* X(I) = I
00112 13* XXK=KK
00113 14* DELX =XXK/L2
00113 15* CXXXX CALL SUB009(GINT)
00114 16* CXXXX CALL SUB009(DELX, MK, 1.0, XXK, ICT, X, DATA, AX, AY)
00115 17* RETURN
00116 18* END
END FOF

```

END, P SUB049

FOR US M.SUB049
FOR E3AB-09/1677-02:40:18 (33,34)

SUBROUTINE SUB049 ENTRY POINT 00C177

STORAGE USED: CODE(1) 000233; DATA(0) 047102; BLANK COMMON(2) 000005

EXTERNAL REFERENCES (BLOCK, NAME)

0003 MERR38

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001	000116	1266	0001	000135	1356	0000	R	000000	DDATA		
0000	I	047055	I	0000	00003	IMOVE		0000	I	047052	INDEX
0000	I	047057	I12	0000	I	047060	J	0000	I	047061	JJK
0002	000002	KFILE	0002	000001	TIMAX			0002	000004	EXIT	
								0000	047062	INJPS	
								0000	I	047054	JK
								0000	I	047053	K

```

00101 1* SUBROUTINE SUB049 (DATA,KK,IARRAY,IDELAY,IMAX)
00102 2* DATA=DATA POINTS
00103 3* KK=# OF POINTS
00104 4* INDEX=MAX LENGTH OF THE OUTPUT ARRAY
00105 5* DDATA=STORAGE ARRAYS
00106 6* THIS ROUTINE AVERAGES IARRAY NUMBER OF FILES
00107 7* DIMENSION DATA(1), DDATA(20010)
00108 8* COMMON FSAMP,TIMAX,KFILE,MOVE,EXIT
00109 9* INDEX=20010/IARRAY
00110 10* IF (IDELAY.LT.0) IDELAY=C
00111 11* IF (IDELAY.GT.0) KK=KK-IDELAY
00112 12* IF (IMAX.GT.0.AND.KK.GT.IMAX) KK=IMAX
00113 13* IF (KK.GT.INDEX) KK=INDEX
00114 14* IF (KK.LT.0) KK=C
00115 15* IF (K.GT.IARRAY.OR.K.LE.0) K=1
00116 16* JK=(K-1)*INDEX
00117 17* IF (KK.EQ.0) RETURN
00118 18* DO 10 I=1,KK
00119 19* IT1=I+JK
00120 20* IT2=I+IDELAY
00121 21* DDATA(IT1)=DATA(IT2)
00122 22* DDATA(I)=0.0
00123 23* DO 20 J=1,IARRAY
00124 24* JJK=(J-1)*INDEX+I
00125 25* DATA(I)=(DDATA(JJK)/IARRAY)+DATA(I)
00126 26* 10 CONTINUE
00127 27* K=K+1
00128 28* RETURN
00129 29*
00130 30* C
END FOR

```



SUB009

BM06.P SDADS

DATE 091677

PAGE

2

STORAGE USED: CODE(1) 002201: DATA(0) 003132: BLANK COMMON(2) 040041

EXTERNAL REFERENCES (BLOCK, NAME)

0003 ZERO
0004 PLOTS
0005 PLOT
0006 FACTOR
0007 NTRAN
0010 SOAS
0011 SUBO26
0012 PEAK
0013 LINE
0014 DATSHI
0015 TAPER
0016 FFT
0017 PLOT01
0020 PLOT02
0021 FFTSHI
0022 MINTR8
0023 MRDUS
0024 NI028
0025 NMDUS
0026 NI018
0027 XPII
0030 NSTOPS

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001	000041	10L	001043	100L	0001	001231	120L	0001	001233	130L	0001	001250	150L
0001	001321	160L	001350	170L	0001	001377	180L	0001	00130	20L	0001	001300	200L
0001	002051	220L	002112	230L	0001	002165	240L	0001	002167	250L	0001	002174	260L
0000	002460	270F	000412	271G	0000	002461	280F	0000	002477	290F	0001	000232	30L
0000	002500	300F	0000	002513	310F	0001	000464	313G	0000	002534	320F	0000	002551
0000	002557	340F	0000	002574	350F	0001	000634	356G	0000	002606	360F	0000	002631
0000	002651	380F	0000	002673	390F	0001	000315	40L	0000	002705	400F	0000	002725
0000	002745	420F	0000	002763	430F	0000	002775	440F	0000	003012	450F	0000	002725
0000	003055	470F	0001	000544	50L	0001	001235	512G	0001	000627	60L	0001	003031
0001	001713	642G	0001	000657	80L	0001	000733	90L	0002	030026	AVES1	0002	001516
0000	002421	CUT1	0002	030001	DBRANG	0002	000000	DDATA	0000	000000	DELRSP	0000	002456
0002	030024	EXIT	0002	040031	FN	0002	030012	FPB	0002	030020	FSAMP	0000	002420
0000	002417	FTIME	0002	040030	H	0000	002422	HT	0000	002415	I	0000	000002
0000	002431	ID	0000	002432	IDD	0002	030014	IDSH	0000	002415	IFFY	0000	002360
0000	002370	IFIRST	0000	002356	I60	0000	002454	IJ	0002	030016	ILN	0002	030023
0000	002375	INCR	0002	030011	IOP	0000	002407	IPR	0000	002413	IPRS	0000	002377
0000	002363	ISHIFT	0000	002405	ISTART	0002	030017	ITD	0000	002403	ITEP1	0000	002361
0000	002414	ITEST1	0000	002400	IUNIT	0002	040026	IVER	0000	002424	JFIRST	0000	002457
0002	040040	JSTART	0000	002434	JMPRS	0000	002453	JX	0000	002455	JX1	0000	002372
0000	002373	KE	0002	030022	KFILE	0000	002410	KK	0000	002452	KK1	0000	002416
0000	002406	KMOVE	0000	002404	KOUNT	0000	002365	L1	0000	002366	L2	0000	002440
0000			0000			0000			0000			0000	

```

0000 I 002447 MSHFT
0000 I 002426 NPISL
0000 I 002430 NPLT2
0000 I 002402 NSAMP
0002 R 030013 ROF
0002 R 040035 SCALE
0000 R 002401 SMSEC
0002 R 030006 TAPE
0000 R 002425 TFRIM
0002 R 030004 XMAX

0000 I 002450 MTIME
0000 I 002445 NPISL2
0000 I 002451 NPTE
0000 I 002436 NSAMP1
0000 R 002367 ROF1
0000 I 000001 SCTSTK
0002 R 030000 SR
0002 R 020000 TEMP1
0002 R 030007 TFRIS
0000 R 002446 XMAX

0000 I 002442 N
0000 I 002437 NPISLS
0000 I 002435 NPTEST
0000 I 002374 N1A
0002 R 040032 SAMP1
0002 R 030005 SD
0002 R 030010 SSEC
0000 R 040036 TIM
0000 R 001752 WGTM
0002 R 030002 XNSAMP

0000 I 002376 NFILE
0000 I 002427 NPLTS
0000 I 002433 NPZ
0000 R 002371 PD
0002 R 040033 SAMP2
0000 R 002364 SHIFT
0000 R 002411 S2
0000 R 030021 T1MAX
0000 R 002362 XFAC
0002 R 030003 XTJ

```

```

CXXXX SDAS PROGRAM TO READ SDAS TAPE AND WRITE SDAS TAPE.

```

```

CXXXX IMOVE = NUMBER OF EOF TO MOVE INTO TAPE
CXXXX IMOVE MUST BE 1 OR GREATER
CXXXX INCRE = INCREMENT OF FILES TO BE PROCESSED
CXXXX MFILE = NUMBER OF FILES OF BE PROCESSED
CXXXX IPRT = INCREMENT OF PROCESSED FILES TO BE POINTED
CXXXX IUNIT = INPUT TAPE UNIT
CXXXX MUNIT = OUTPUT TAPE UNIT
CXXXX MTRAN STATUS WORDS =
CXXXX -1 = TRANSMISSION NOT COMPLETE
CXXXX -2 = END OF FILE(READ).END OF TAPE(MWRITE)
CXXXX -3 = DEVICE ERROR
CXXXX -4 = TRANSMISSION ABORTED

```

```

CXXXX DELBSP =DELTA BACK SPACE SO THAT THE START OF THE
CXXXX FIRST RETURN WILL BE INCLUDED.
CXXXX SMSEC=SAMPLE LENGTH IN MSEC TO BE EXTRACTED FROM ONE SCAN
CXXXX SSEC=SAMPLE LENGTH IN SEC.
CXXXX NSAMP=NUMBER OF SAMPLE GROUPS TO BE TAKEN FROM ONE SCAN
CXXXX KB= BEGIN SEARCH FOR PEAK
CXXXX KE=END SEARCH FOR PEAK
CXXXX KL=NUMBER OF POINTS IN THIS SEARCH
CXXXX TAPE=IS THE NUMBER GIVER TO THE SDAS TAPE
CXXXX TFRIS=TIME TO FIRST RETURN IN SECONDS
CXXXX -ONE WAY TRAVEL
CXXXX TFRIM=TIME TO FIRST RETURN IN MSEC.
CXXXX -ONE WAY TRAVEL

```

```

CXXXX NPISL=COMPUTED NUMBER OF POINTS IN SAMPLE LENGTH
CXXXX NPLTS=COMPUTED NUMBER OF POINTS LEFT IN THIS SCAN
CXXXX XMAX=PEAK VALUE OF ONE SCAN
CXXXX PEAK1=XMAX/2.
CXXXX JFIRST=LOCATION OF POINT ON FIRST RETURN
CXXXX JSTART=IS AN ATTEMPT TO GET TO THE START
CXXXX OF THE FIRST RETURN
CXXXX SD=SAMPLE DELAY IN SEC.
CXXXX ID=SAMPLE RATE AS AN INTEGER
CXXXX SR=SAMPLE RATE IN CYCLE PER SEC.
CXXXX JTNPRS=TOTAL NUMBER OF POINTS THAT WERE
CXXXX REQUESTED TO BE SAMPLED FROM THIS SCAN
CXXXX NSAMP1=REAJUSTED OR NEW NUMBER OF SAMPLES TO
CXXXX BE TAKEN FROM THIS RUN. IF JTNPRS IS GREATER
CXXXX THAN THE POINTS REMAINING.
CXXXX XNSAMP=IS THE NUMBER OF SAMPLE GROUPS IN THIS

```

```

00100 1*
00100 2*
00100 3*
00100 4*
00100 5*
00100 6*
00100 7*
00100 8*
00100 9*
00100 10*
00100 11*
00100 12*
00100 13*
00100 14*
00100 15*
00100 16*
00100 17*
00100 18*
00100 19*
00100 20*
00100 21*
00100 22*
00100 23*
00100 24*
00100 25*
00100 26*
00100 27*
00100 28*
00100 29*
00100 30*
00100 31*
00100 32*
00100 33*
00100 34*
00100 35*
00100 36*
00100 37*
00100 38*
00100 39*
00100 40*
00100 41*
00100 42*
00100 43*

```

```

44* 00100 CXXXX SCAN AND THE PLOT LENGTH IN INCH. THE ACTUAL
45* 00100 CXXXX LENGTH OF GRAPH IN INCH. IS ONE INCH. LARGE P
46* 00100 CXXXX DBRANG=08 RANGE TO BE USED BETWEEN TIME MARKS.
47* 00100 CXXXX I.E. IF 08 RANGE =80 THEN THE RANGE BETWEEN
48* 00100 CXXXX EACH TIME MARK IS FROM 0 TO 80 DB
49* 00100 CXXXX XIJ=UNIT INCREMENT TO ADVANCE THE PLOTTER
50* 00100 CXXXX ROF=RANGE OF FREQUENCY TO BE PLOTTED
51* 00100 CXXXX FPB=FREQ./BIN. THE DELTA STEP FOR FREQ.
52* 00100 CXXXX IOP=1.0/FPB*ROF=INDEX OF PLOTTER.
53* 00100 CXXXX =THE NUMBER OF MOVES THE PLOTTER NEEDS TO MAKE.
54* 00100 CXXXX SCALE=THE SPEED UP FACTOR ADJUSTMENT BETWEEN ANALOG
55* 00100 CXXXX AND DIGITAL RECORDINGS
56* 00100 CXXXX EXIT=IS USED FOR Y AXES SCALE EXPANSION
57* 00100 CXXXX IN THE PLOT SUB-PROGRAMS
58* 00100 CXXXX EXIT- ALSO USED TO TERMINATE THE JOB IF
59* 00100 CXXXX THE HEADER RECORD IS BAD.
60* 00101 CXXXX INTEGER DELBSP, SCTSTK
61* 00103 REAL ILN
62* 00104 DIMENSION IBUF(1000), M6TH(260)
63* 00105 COMMON DDATA(8192), TEMPI(4096), SR, DBRANG, XNSAMP, XIJ, XMAX
64* 00106 COMMON SD, TAPE, TIFRIS, SSEC, IOP, FPR, ROF, IOSM, IFFT, ILN, ITD
65* 00107 COMMON FSAMP, TMAX, KFILE, IMOVE, EXIT, SL, AVES(4096), IVER
66* 00110 COMMON CUT, H, FM, SAMP1, SAMP2, SAMP3, SCALE, TIM, XTIME, JSTART
67* 00111 CALL ZERO (4096, TEMPI(1))
68* 00112 CALL ZERO (8192, DDATA(1))
69* 00113 CALL ZERO (4096, AVES(1))
70* 00114 CALL ZERO (1000, IBUF(1))
71* 00115 CALL PLOTS (IBUF, 1000, 9)
72* 00116 CALL PLOT (0.0, -11.0, -3)
73* 00117 CALL PLOT (0.0, 2.0, -3)
74* 00120 READ (5, 270) I60, XFAC, IFIL, ITD, ITEST, IVER
75* 00130 READ (5, 270) SAMP1, SAMP2, SAMP3, TIME, ISHIFT, SHIFT
76* 00140 READ (5, 270) L1, L2, IOSM, IFFT
77* 00146 READ (5, 270) ROF1, IFIRST, PD, KB, KE
78* 00155 CUT=0
79* 00156 H=0
80* 00157 NIA=0
81* 00160 IF (IFIL.NE.1) GO TO 20
82* 00162 READ (5, 270) CUT, H, NIA
83* 00167 SAMP1=SAMP1/2
84* 00170 SAMP2=SAMP2/2
85* 00171 SAMP3=SAMP3/2
86* 00172 ROF=ROF1
87* 00173 XTIME=TIME
88* 00174 IF (ISHIFT.LE.0) ISHIFT=1
89* 00176 IF (XFAC.LT.0.1.OR.XFAC.GT.1.1) XFAC=1.0
90* 00200 CALL FACTOR (XFAC)
91* 00201 READ (5, 270) IMOVE, INCRE, NFILE, IPRI, SCALE, IUNIT
92* 00211 WRITE (6, 280) IMOVE, INCRE, NFILE, IPRI
93* 00217 IF (ITEST.EQ.1) GO TO 30
94* 00221 IF (ITEST.EQ.0) CALL NTRAN (IUNIT, ID)
95* 00223 WRITE (6, 300) IUNIT
96* 00226 READ (5, 290) SMSEC, NSAMP, ITER1, SCTSTK, DELBSP, DBRANG, TAPE
97* 00237 WRITE (6, 460) SMSEC, NSAMP, SCTSTK
98* 00244 WRITE (6, 310) DBRANG, DELBSP, TAPE
99* 00251 WRITE (6, 320) KB, KE
100* 00255 IF (ITEST.EQ.1) GO TO 40

```

SDADS

```

101* IF (ITEST.EQ.0) CALL NTRAN (IUNIT,8,IMOVE)
102* 40 KOUNT=0
103* ISTART=1
104* KMOVE=1
105* IPR=0
106* KK=1000
107* S2=D.0
108* S1=0.0
109* DO 240 NFILE=IMOVE,NFILE,INCRE
110*   IPRS=0
111*   IPR=IPR+1
112*   IF (IPR.GE.IPRT) IPRS=1
113*   IF (IPR.GE.IPRT) IPR=1
114*   IF (NFILE.EQ.NFILE) IPRS=1
115*   IF (NFILE.EQ.IMOVE) IPRS=1
116*   DDATA(300)=1
117*   SD=0.0
118*   ITEST=ITEST+299
119*   IF (ITEST.GE.1) READ (5,470) (DDATA(I),I=300,ITEST1)
120*   SL=(ITEST+1300)/1000
121*   SR=1000
122*   KK=SL*SR
123*   IF (ITEST.GE.1) GO TO 50
124*   CALL SDAS (IUNIT,IPRS,DDATA(ISHIFT),KK,KFILE)
125*   IF (KK.LT.1) GO TO 260
126*   IF (EXIT.EQ.7777.0) GO TO 260
127*   IF (ITEST.EQ.0) CALL NTRAN (IUNIT,8,INCRE)
128*   ML=NE-NB+1
129*   FTIME=TIME*SR
130*   FSHIFT=SHIFT*SR
131*   IF (FTIME.EQ.0) XTIME=SL
132*   CUTT=CUT/SR
133*   HT=N/SR
134*   FNM=1A
135*   IF (IFIL.EQ.1) CALL SUB026 (DDATA(1),KK,CUTT,MT,NIA,1,WGTH)
136*   IF (ITD.EQ.0) CALL PEAK (DDATA(KB),ML)
137*   IF (L1.EQ.0) GO TO 60
138*   WRITE (6,330)
139*   CALL LINE (DDATA(L1),L1)
140*   PEAK1=XMAX/2.
141*   DO 70 I=MB,KE
142*     IF (IFIRST.NE.0) GO TO 80
143*     IF (ABS(DDATA(I)+DDATA(I+1)+DDATA(I+2))/PD.GT.PEAK1) GO TO 80
144*     CONTINUE
145*     WRITE (6,340)
146*     GO TO 260
147*   JFIRST=I
148*   IF (IFIRST.NE.0) JFIRST=IFIRST
149*   WRITE (6,350) JFIRST
150*   JSTART=JFIRST-DELBSP
151*   IF (S1.GT.0.5.OR.S2.GT.0.5) GO TO 230
152*   IF (NFILE.EQ.IMOVE) ISTART=JSTART
153*   IF (L2.EQ.0) GO TO 90
154*   WRITE (6,360)
155*   CALL LINE (DDATA(JSTART),L2)
156*   IF (SCALE.EQ.0) WRITE (6,370)
157*   IF (SCALE.LT.1) GO TO 250

```

50

60

70

80

90

```

00416 158* TFRIS=(SD*JFIRST*(1/SR))
00417 159* TFRIM=TFRIS*1000.
00420 160* WRITE (6,300) TFRIS,TFRIM
00424 161* IF (ITD.EQ.1.AND.SMSEC.EQ.0) SMSEC=ROF/NSAMP
00426 162* NPISL=SMSEC*SR/1000.0
00427 163* SSEC=SMSEC/2000.0
00430 164* NPLTS=KK-JSTART*1
00431 165* NPLTZ=NPLTS
00432 166* IF (NPLTZ.LE.4096) GO TO 100
00434 167* NPLTS=4096
00435 168* WRITE (6,390) NPLTZ,NPLTS
00441 169* IF (ROF1.EQ.0) ROF=SR/4.0
00443 170* ID=SR
00444 171* IDD=ID
00445 172* IF (IDD.GT.NPLTS) WRITE (6,400) IDD,IO
00452 173* NPZ=NPISL
00453 174* IF (NPZ.GT.NPLTS) NPISL=NPLTS
00455 175* IF (NPZ.GT.NPLTS) WRITE (6,410) NPZ,NPISL
00462 176* JTNPRS=NPISL*NSAMP
00463 177* IF (FSHIFT.GT.JSTART) FSHIFT=JSTART
00465 178* NPTEST=FTIME-JSTART*2-FSHIFT
00470 180* IF (ITD.EQ.1) NPTEST=ROF
00473 181* IF (NPTEST-JTNPRS) 110,120,120
00474 182* NSAMP1=NPTEST/NPISL
00475 183* NPISL2=NPISL/2
00476 184* JTNPRS=NPTEST-(NSAMP1*NPISL)
00500 185* IF (JTNPRS.GT.NPISL2.AND.ITD.EQ.0) NSAMP1=NSAMP1*1
00501 186* JTNPRS=NPISL*NSAMP1
00505 187* WRITE (6,420) NSAMP,NSAMP1
00506 188* NSAMP=NSAMP1
00507 189* CONTINUE
00511 190* IF (ITD.EQ.0) GO TO 130
00514 191* DO 140 M=8,12
00520 193* NP=2**M
00522 194* IF (NP-NPTEST) 140,150,150
00523 195* CONTINUE
00524 196* FPB=SR/NP
00531 197* IOP=(1.0/FPB)*ROF
00531 197* WRITE (6,430) IOP,FPB,ROF
00531 197* WRITE (6,440) SD,SR,JFIRST,NPISL
00537 199* N=0
00540 200* IF (SAMP2.NE.0) GO TO 160
00542 201* SAMP2=10.0/NSAMP
00543 202* SAMP3=SAMP2
00544 203* XNSAMP=NSAMP
00545 204* XIJ=-1
00546 205* TIMAX=SD*SL
00547 206* NP1=2*NP
00550 207* WRITE (6,450) NP,M,NPLTS,NSAMP,KK,JTNPRS
00560 208* GO TO 230
00561 209* TIM--(SCISTN)*KFILE+1
00562 210* NPLTS2=NPLTS*2
00563 211* NPISL2=NPISL*2
00564 212* IF (ITD.EQ.0) GO TO 180
00566 213* NPISL=SMSEC/FPB
00567 214* FSAMP=NPISL*1000/SR

```

100

110

120

130

140

150

160

170

180

```

00570 2150 ILLN=-1
00571 2160 CALL ZERO (NPI,DDATA(1))
00572 2170 CALL DATSHI (TEMP1(1),NP,DDATA(1),1)
00573 2180 CALL TAPER (NPLTS,1,NPLTS,1)
00574 2190 CALL FFT (NP,M,N)
00575 2200 CALL PLOT01
00576 2210 CALL PLOT02
00577 2220 XIJ=0.0
00600 2230 IOP=SR*XTIME
00601 2240 XMAXT=XMAX
00602 2250 ILLN=+1.00
00603 2260 CALL ZERO (NP,DDATA(1))
00604 2270 CALL PEAK (TEMP1(KB),KL)
00605 2280 MSHIFT=FSHIFT
00606 2290 MTIME=FTIME
00607 2300 DO 190 I=MSHIFT,MTIME
00612 2310 DDATA(I)=((TEMP1(I))/(2*XMAX))-0.5)*DBRANG
00614 2320 NPTE=KK-FSHIFT-IOP
00615 2330 KK1=KK-FSHIFT+1
00616 2340 IF (IOP.GT.KK1) CALL ZERO (NPTE,DDATA(KK1))
00620 2350 CALL PLOT02
00621 2360 IF (ITD.EQ.0) XMAX=XMAXT
00623 2370 IF (ITD.GE.1) GO TO 200
00625 2380 IF (NPISL.LE.1024.AND.NP.GT.1024) FPB=SR/1024
00627 2390 IF (NPISL.LE.1024.AND.NP.GT.1024) NP=1024
00631 2400 IOP=ROF/FPB
00632 2410 ILLN=-1.0
00633 2420 N=1
00634 2430 JX=JSTART
00635 2440 IF (ITD.EQ.1) JX=1
00637 2450 IF (NSAMP.EQ.0) GO TO 220
00641 2460 DO 210 IJ=1,NSAMP
00644 2470 CALL ZERO (NPI,DDATA(1))
00645 2480 XIJ=IJ
00646 2490 JX1=JSTART+NPISL*(IJ-1)
00647 2500 IF (ITER1.EQ.1) JX1=1
00651 2510 JX=JX+NPISL
00652 2520 IF (ITER1.EQ.0) JX=NPISL
00654 2530 IF (ITD.EQ.0) CALL DATSHI (TEMP1(IJ),NPISL,DDATA(1),1)
00656 2540 IF (ITD.EQ.1) CALL DATSHI (AVES1(I),NP,DDATA(1),2)
00660 2550 IF (ITD.EQ.1) CALL TAPER (NP,1,JX,JX1)
00662 2560 IF (ITD.EQ.1) CALL DATSHI (DDATA(1),NP,DDATA(1),-3)
00664 2570 IF (ITD.EQ.0) CALL TAPER (NPISL,1,NPISL,1)
00666 2580 CALL FFT (NP,M,N)
00667 2590 KK1=KK-FSHIFT+1
00670 2600 IF (IOP.GT.KK1) CALL ZERO (NPTE,DDATA(KK1))
00672 2610 CALL PLOT02
00673 2620 CONTINUE
00675 2630 CALL ZERO (4096,TEMP1(1))
00676 2640 CALL ZERO (8192,DDATA(1))
00677 2650 CALL ZERO (4096,AVES1(1))
00700 2660 I=KFILE+SCTSTK-1
00702 2670 DS=XNSAMP*SAMP2+SAMP1+2+3.6
00703 2680 CALL PLOT (DS,0.0,-3)
00705 2690 IF (I.GT.NFILE) GO TO 250
00706 2700 GO TO 240
00706 2710 S1=S1+1.0
    
```

190

200

210

220

230

00707 272*
 00710 273*
 00712 274*
 00714 275*
 00715 276*
 00716 277*
 00717 278*
 00721 279*
 00723 280*
 00725 281*
 00726 282*
 00727 283*
 00727 284*
 00731 285*
 00732 286*
 00732 287*
 00733 288*
 00734 289*
 00735 290*
 00735 291*
 00736 292*
 00736 293*
 00737 294*
 00740 295*
 00740 296*
 00741 297*
 00742 298*
 00742 299*
 00743 300*
 00743 301*
 00744 302*
 00744 303*
 00745 304*
 00746 305*
 00746 306*
 00747 307*
 00747 308*
 00750 309*
 00750 310*
 00751 311*
 00752 312*
 00752 313*
 00753 314*
 00753 315*
 00754 316*
 00754 317*
 00755 318*
 00755 319*
 00756 320*
 END FOR

JMOVE=JSTART-ISTART+1
 IF (JMOVE.LT.0) KMOVE=-JMOVE
 IF (JMOVE.LE.0) JMOVE=1
 EXIT=SCYSTM
 CALL FFTSHI (DDATA(JMOVE),KK,TEMP1(KMOVE))
 KMOVE=1
 IF (S1.6E-SCTSK) S1=0.0
 IF (S1.LT.0.05) GO TO 170
 240 CONTINUE
 250 CONTINUE
 CALL PLOT (0.0,0.0,999)
 260 IF (I160.EQ.1) GO TO 10
 C
 270 FORMAT (I)
 280 FORMAT (I1,4X,'KMOVE =',I6,4X,'INCR =',I6,4X,'MFILE =',I6,4X,
 'IPRT =',I6)
 290 FORMAT (I)
 300 FORMAT (//,10X,'INPUT TAPE UNIT =',I3,20X,'OUTPUT TAPE UNIT = 9')
 310 FORMAT (//,5X,'THE DB RANGE =',F10.2,5X,'DELTA BACK SPACE =',I5,5X,
 'TAPE NUMBER OF THIS RUN =',F10.1)
 320 FORMAT (//,10X,'BEGIN SEARCH FOR PEAK AT',I5,20X,'END SEARCH FOR
 IPEAK AT',I5)
 330 FORMAT (I1,30X,'THIS IS THE HOLE LINE')
 340 FORMAT (//,20X,'DID NOT FIND THE FIRST RETURN','ANALYSIS WILL ST
 OP',//,50(IH*))
 350 FORMAT (//,20X,'FIRST RETURN ACCURED AT THE',I4,'POINT')
 360 FORMAT (I1,10X,'THE PICKED FIRST RETURN IS PLOTTED SO IT CAN',
 'BE VERIFIED WITH THE PLOT OF THE HOLE SCAN')
 370 FORMAT (//,2X,(50(IH*)),//,10X,'ENTER A SCALE VALUE IN LINE ONE 0
 IF DATA1 ELEMENT',//,2X,(50(IH*)))
 380 FORMAT (//,10X,'TIME IN SEC TO THE FIRST RETURN IS',F10.5,20X,'TI
 ME IN MSEC TO THE FIRST RETURN IS',F10.5,//)
 390 FORMAT (//,5X,'THE OLD NPLTS =',I6,2X,'THE NEW NPLTS =',I6,//)
 400 FORMAT (//,5X,'THE OLD # OF SAMPLE TO TAKE WAS',I6,3X,'THE NEW # 0
 IF SAMPLE TO TAKE IS',I6,//)
 410 FORMAT (//,3X,(30(IH*)),//,5X,'THE OLD VALUE FOR NPISL IS',I6,3X,'THE
 NEW VALUE FOR NPISL IS',I6,//)
 420 FORMAT (//,10X,'THE',I6,'SAMPLES SELECTED WAS TO LARGE SO IT WAS
 1 REDUCED TO',I6,//)
 430 FORMAT (//,5X,'IOP =',I5,5X,'FPB =',F10.4,5X,'PROF =',F10.1,//)
 440 FORMAT (//,5X,'SD =',F10.1,5X,'SR =',F10.1,5X,'JFIRST =',I5,5X,'NPISL
 1 =',I5,//)
 450 FORMAT (5X,'NP =',I5,'M =',I3,'NPLTS =',I5,//,5X,'NSAMP =',I4,'KK
 1 =',I5,'JTNSP =',I5)
 460 FORMAT (//,5X,'SAMPLE LENGTH IN MSEC =',F10.4,5X,'NUMBER OF SAMPL
 1E GROUPS =',I5,5X,'SCANC TO AVERAGE THIS STACK =',I6)
 470 FORMAT (10F8.5)
 C
 END

MDG, P AXES

FOR US W.AXES
FOR E3AB-09/16/77-02:40:30 (7,8)

SUBROUTINE AXES ENTRY POINT 000311

STORAGE USED: CODE(1) 000350; DATA(0) 000071; BLANK COMMON(2) 000000

EXTERNAL REFERENCES (BLOCK, NAME)

- 0003 NUMBER
- 0004 SYMBOL
- 0005 PLOT
- 0006 COS
- 0007 SIN
- 0010 NERR3S

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001	000110	1266	0001	000237	1566	0001	000010	20L	0001	000172	40L	0000	R	000000	A	
0000	R	000004	CTH	0000	R	000005	DXB		0000	I	000013	I	0000	R	000034	INJPS
0000	I	000001	KM	0000	I	000017	NT		0000	R	000003	STH	0000	R	000007	XN
0000	R	000015	XT	0000	R	000002	XVAL		0000	P	000010	YN	0000	R	000014	Z

00101	1*	C	SUBROUTINE AXES (X,Y,IBCD,MC,AXLEN,ANG,DEL TIC,FIRSTV,DELVAL,NDEC)
00101	2*	C	MODIFIED CALCOMP AXIS SUBROUTINE ---RANKIN,NOV.1971
00101	3*	C	X,Y COORDINATES OF STARTING POINT OF AXIS IN INCHES
00101	4*	C	IBCD AXIS TITLE
00101	5*	C	MC NUMBER OF CHARACTERS IN TITLE
00101	6*	C	AXLEN FLOATING POINT AXIS LENGTH IN INCHES
00101	7*	C	ANG ANGLE OF AXIS FROM HORIZONTAL IN INCHES
00101	8*	C	DEL TIC DISTANCE BETWEEN TIC MARKS IN INCHES
00101	9*	C	FIRSTV SCALE VALUE AT FIRST TIC MARK
00101	10*	C	DELVAL SCALE INCREMENT
00101	11*	C	NDEC NUMBER OF DECIMAL PLACES OF TIC ANNOTATION PLOTTED(PUNCH
00101	12*	C	-1 IF ONLY INTEGER(MO DECIMAL POINT)IS DESIRED)
00103	13*	C	DIMENSION IBCD(10)
00104	14*	C	A=1.0
00105	15*	C	KN=MC
00106	16*	C	IF (MC) 10,20,20
00111	17*	C	10 A=-A
00112	18*	C	KN=-MC
00113	19*	C	20 XVAL=FIRSTV
00114	20*	C	STH=ANG*0.0174533
00115	21*	C	CTH=COS(STH)
00116	22*	C	STH=SIN(STH)
00117	23*	C	DXB=-0.1
00120	24*	C	DYB=0.15*A-0.05
00121	25*	C	XN=X+DXB*CTH-DYB*STH
00122	26*	C	YN=Y+DYB*CTH+DXB*STH
00123	27*	C	NTIC=AXLEN/DEL TIC+1.0

```

00124 28* NT=NTIC/2
00125 29* DO 40 I=1,NTIC
00130 30* CALL NUMBER (XN,YN,0.105,XVAL,ANG,NOEC)
00131 31* XVAL=XVAL*DELVAL
00132 32* XN=XN+CTH*DELTAIC
00133 33* YN=YN+STH*DELTAIC
00134 34* IF (MT) 40,30,40
00137 35* Z=ZN
00140 36* DXB=-0.07*Z+AXLEN*0.5
00141 37* DYB=0.325*A-0.075
00142 38* XT=X+DXB*CTH-DYB*STH
00143 39* YT=Y+DYB*CTH+DXB*STH
00144 40* CALL SYMBOL (XT,YT,0.14,IBCD(1),ANG,KN)
00145 41* NT=NT-1
00147 42* CALL PLOT (X+AXLEN*CTH,Y+AXLEN*STH,3)
00150 43* DXB=-0.07*A*STH
00151 44* DYB=0.07*A*CTH
00152 45* A=NTIC-1
00153 46* VNY=A*STH*DELTAIC
00154 47* XN=X+A*CTH*DELTAIC
00155 48* DO 50 I=1,NTIC
00160 49* CALL PLOT (XN,YN,2)
00161 50* CALL PLOT (XN+DXB,YN+DYE,2)
00162 51* CALL PLOT (XN,YN,2)
00163 52* XN=XN-CTH*DELTAIC
00164 53* YN=YN-STH*DELTAIC
00165 54* CONTINUE
00167 55* RETURN
00167 56* C
00170 57* END
END FOR

```

8HD6,P DATSHI

3FOR,US W-DATSHI
FOR E3AB-09/16/77-02:40:33 (5,6)

SUBROUTINE DATSHI ENTRY POINT 00G163

STORAGE USED: CODE(1) 000210; DATA(0) 000046; BLANK COMMON(2) 0400041

EXTERNAL REFERENCES (BLOCK, NAME)

0003 NWDUS
0004 NI01S
0005 NI02S
0006 NERR3S

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001	00C026	1136	0001	00C071	1256	0001	000132	1416	0001	000045	20L	000117	40L	
0001	000136	SOL	0001	000141	60L	0000	000004	70F	0002	030026	AVES1	040027	CUT	
0002	030001	DBRANG	0002	000000	DDATA	0002	030024	EXIT	0002	040031	FN	030012	FP8	
0002	030020	FSAMP	0002	040030	H	0000	I	000000	0002	I	030014	IDSH	030015	IFFT
0002	030016	ILN	0002	030023	IMOVE	0000	000017	INJPS	0002	030011	IOP	030017	ITD	
0002	040026	IVER	0000	I	000001	J	0002	040040	JSTART	0000	I	000003	J2	
0002	030022	KFILE	0002	030013	ROF	0002	040032	SAMP1	0002	040033	SAMP2	040034	SAMP3	
0002	040035	SCALE	0002	030005	SD	0002	030025	SL	0002	030000	SR	030010	SSEC	
0002	030006	TAPE	0002	020000	TEMP1	0002	040036	TIM	0002	030021	TIMAX	030010	SSEC	
0002	030003	XIJ	0002	030004	XMAX	0002	030002	XNSAMP	0002	040037	XTIME	030007	TIFRIS	

```

00101 1*
00103 2*
00104 3*
00105 4*
00106 5*
00107 6*
00110 7*
00112 8*
00115 9*
00116 10*
00120 11*
00122 12*
00124 13*
00127 14*
00130 15*
00131 16*
00132 17*
00133 18*
00135 19*
00137 20*
00145 21*
00146 22*
00147 23*

SUBROUTINE DATSHI (DD1,NMP,DD2,MP)
DIMENSION DD1(1), DD2(1)
COMMON DDATA(8192),TEMP1(4096),SR,DBRANG,XNSAMP,XIJ,XMAX
COMMON SD,TAPE,TIFRIS,SSEC,IOP,FP8,ROF,IDSH,IFFT,ILN,ITD
COMMON FSAMP,TIMAX,KFILE,IMOVE,EXIT,SL,AVES1(4096),IVER
COMMON CUT,H,FN,SAMP1,SAMP2,SAMP3,SCALE,TIM,XTIME,JSTART
IF (MP.EQ.-3) GO TO 60
DO 10 I=1,NMP
  J=1
  IF (MP.EQ.1) J=2+I-1
  DD2(J)=DD1(I)
10 DD2(J)=DD1(I)
20 IF (MP.NE.-2) GO TO 40
DO 30 I=3,NMP,2
  J=I+1
  J1=2*NMP-I+2
  J2=J1+1
  DD2(J1)=DD1(I)
  DD2(J2)=DD1(J)
30 DD2(J2)=DD1(J)
40 IF (IDSH.EQ.0) GO TO 50
WRITE (6,70) (DD2(I),I=1,IDSH)
50 CONTINUE
60 RETURN
60 MP=-2

```

DATSMI

DATE 091677

PAGE

2

00150 24*
00150 25*
00151 26*
00151 27*
00152 28*
END FOR

GO TO 20

C

C

70 FORMAT (///,SOX,"DATA FROM DATSMI",//,(1CX,10F10.6))

END

2HD6,P DECODE

DOWN

FOR,US M.DOWN
FOR 1348-09/16/77-02:40:39 (5,6)

DATE 091677

PAGE

1

SUBROUTINE DOWN ENTRY POINT 000034

STORAGE USED: CODE(1) 000044; DATA(0) 000012; BLANK COMMON(2) 000000

EXTERNAL REFERENCES (BLOCK, NAME)

0003 XPII
0004 MEARR3S

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001	000002	1046	0001	000015	20L	0001	000020	30L	0000	000023	40L	0000	000003	INJPS
0000	1	000000	L	0000	1	000000	1	NPX						

```

00101 1* SUBROUTINE DOWN (KI)
00103 2* DO 10 L=4,12
00106 3* NPX=2**L
00107 4* IF (NPX-KI) 10,20,30
00112 5* 10 CONTINUE
00114 6* 20 KI=NPX
00115 7* GO TO 40
00116 8* 30 KI=NPX/2
00117 9* 40 RETURN
00117 10* C
00120 11* END
END FOR

```

END OF P FFT

FFT
 FOR US M.FFT
 FOR E3AB-09/16/77-02:40:41 (5,6)

SUBROUTINE FFT ENTRY POINT 000227

STORAGE USED: CODE(1) 000245; DATA(10) 000057; BLANK COMMON(2) 040041

EXTERNAL REFERENCES (BLOCK, NAME)

- 0003 MLOGN
- 0004 FFTSHI
- 0005 VOLT
- 0006 DATSHI
- 0007 MUDUS
- 0010 MI02S
- 0011 MI01S
- 0012 MERR3S

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

Block	Type	Relative Location	Name
0001	0000	000026	100F
0001	0001	000172	50L
0001	0000	000172	50L
0002	0000	000223	90F
0002	0002	030001	DBRANG
0002	0002	030020	FSAMP
0002	0002	030015	IFFY
0002	0002	030016	ILN
0002	0002	040026	IVER
0002	0002	030022	KFILE
0002	0002	040035	SCALE
0002	0002	030006	TAPE
0002	0002	030003	XIJ
0001	0000	000050	127G
0001	0001	000172	50L
0002	0000	030001	ANORM
0002	0002	030000	DDATA
0002	0002	040030	M
0002	0002	030023	IMOVE
0002	0002	030003	J
0002	0002	030017	ROF
0002	0002	030005	SD
0002	0002	020000	TEMP1
0002	0002	030004	XMAX
0001	0001	000121	147G
0001	0002	0506	6CL
0002	0002	030026	AVES1
0002	0002	030024	EXIT
0002	0002	000005	I
0002	0002	000037	INJPS
0002	0002	030011	IOP
0002	0002	000002	JE
0002	0002	040032	SAMP1
0002	0002	030025	SL
0002	0002	040036	TIM
0002	0002	030002	XNSAMP
0001	0001	000162	163G
0000	0000	000006	70F
0000	0000	000000	AXMAX
0002	0002	040031	FN
0002	0002	030014	IDSH
0002	0002	030011	IOP
0002	0002	000004	JI
0002	0002	040033	SAMP2
0002	0002	030000	SR
0002	0002	030021	TIMAX
0002	0002	040037	XTIME

00101 1* SUBROUTINE FFT (NP,M,N)
 00101 2* SUBROUTINE SUB027(FFT)
 00103 3* REAL ILM
 00103 4* CXXXX THIS SUBROUTINE TAKES INFORMATION IN THE TIME
 00103 5* CXXXX DOMAIN AND CONVERTS IT TO RECTANGULAR COORDINATES
 00103 6* CXXXX (FREQ. DOMAIN) AND THEN FINDS THE ENERGY CONTENT
 00103 7* CXXXX AT EACH FREQ. BIN.
 00104 8* COMMON DDATA(8192),TEMP1(4096),SR,DRRANG,XNSAMP,XIJ,XMAX
 00105 9* COMMON SD,TAPE,TFRIS,SSEC,IOP,FPB,ROF,IDSH,IFFY,ILN,ITD
 00106 10* COMMON FSAMP,TIMAX,KFILE,IMOVE,EXIT,SL,AVES1(4096),IVER
 00107 11* COMMON CUT,H,FN,SAMP1,SAMP2,SAMP3,SCALE,TIM,XTIME,JSTART
 00110 12* AXMAX=-160.C
 00111 13* ANORM=1.0
 00112 14* JE=IOP
 00112 15* CXXXX CALL SUB016(MLOGN)
 00113 16* CALL MLOGN (M,DDATA,ILM)
 00114 17* IF (XIJ.GE.0.0) GO TO 10
 00116 18* CALL FFTSHI (DDATA(1),NP,AVES1(1))

```

00117 19*
00120 20*
00121 21*
00122 22*
00123 23*
00124 24*
00126 25*
00131 26*
00133 27*
00135 28*
00136 29*
00137 30*
00140 31*
00142 32*
00146 33*
00151 34*
00153 35*
00155 36*
00157 37*
00161 38*
00167 39*
00170 40*
00172 41*
00173 42*
00174 43*
00175 44*
00176 45*
00202 46*
00202 47*
00203 48*
00204 49*
00205 50*
00206 51*
00206 52*
00207
END FOR

10 CONTINUE
CALL VOLT (NP)
IF (XIJ.EQ.0) CALL DATSHI (DDATA(I),NP,TEMP(1),2)
DDATA(I)=DDATA(2)
IF (M.GT.0) GO TO 30
00 20 J=1,JE
IF (ILN.EQ.-1) GO TO 50
IF (ABS(DDATA(J)).LT.AXMAX) GO TO 20
XMAX=ABS(DDATA(J))
AXMAX=XMAX
JI=J
20 CONTINUE
WRITE (6,70) XMAX,JI
30 00 40 I=1,JE
IF (ILN.EQ.1) DDATA(I)=(DDATA(I))/(2*XMAX)-0.5)*DBRANG+XMAX
40 DDATA(I)=-XMAX-DDATA(I)
IF (IFFT.EQ.0) GO TO 60
WRITE (6,80)
WRITE (6,90) (DDATA(I),I=1,IFFT)
60 TO 60
50 IF (DDATA(J).LE.-AXMAX) GO TO 20
XMAX=DDATA(J)
AXMAX=DDATA(J)
JI=J
60 TO 20
60 WRITE (6,100) XIJ,ILN
RETURN
C
70 FORMAT (//,20X,'XMAX=',F10.4,10X,'JI=',I5)
80 FORMAT (40X,'DDATA=-XMAX-DDATA(I)')
90 FORMAT (//,(10X,10F10.5))
100 FORMAT (5X,F4.1,5X,F9.1)
C
END

```

FFTSHI

BFOR,US W,FFTSHI
FOR 33AB-09/16/77-02:40:44 (5,6)

DATE 091677

PAGE

1

SUBROUTINE FFTSHI ENTRY POINT 000027

STORAGE USED: CODE(1) 000040; DATA(10) 000014; BLANK COMMON(2) 040041

EXTERNAL REFERENCES (BLOCK, NAME)

0003 MERR3S

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001	000010	1116	0002	030026	AVES1	0002	040027	CUT	0002	030001	DBRANG	000000	DDATA	
0002	P	030024	EXIT	0002	040031	FN	0002	030012	FPB	0002	030020	FSAMP	040030	H
0000	I	000000	I	0002	030014	IDSH	0002	030015	IFFT	0002	030016	ILN	030023	IMOVE
0000		000002	INJPS	0002	030011	IOP	0002	030017	ITD	0002	040026	IVER	040040	JSTART
0002		030022	KFILE	0002	030013	ROF	0002	040032	SAMP1	0002	040033	SAMP2	040034	SAMP3
0002		040035	SCALE	0002	030005	SD	0002	030025	SL	0002	030000	SP	030010	SSEC
0002		030006	TAPE	0002	020000	TEMP1	0002	040036	TIM	0002	030021	TIMAX	030010	SSEC
0002		030003	XIJ	0002	030004	XMAX	0002	030002	XNSAMP	0002	040037	XTIME	030007	TIFRIS

00101 1*
00103 2*
00104 3*
00105 4*
00106 5*
00107 6*
00110 7*
00113 8*
00114 9*
00116 10*
00116 11*
00117 12*
END FOR

SUBROUTINE FFTSHI (DD1,NPS,DD2)
COMMON DDATA(8192),TEMP1(4096),SR,DBRANG,XNSAMP,XIJ,XMAX
COMMON SD,TAPE,TIFRIS,SSEC,IOP,FPB,ROF,IDSH,IFFT,ILN,ITD
COMMON FSAMP,TIMAX,KFILE,IMOVE,EXIT,SL,AVES1(4096),IVER
COMMON CUT,H,FN,SAMP1,SAMP2,SAMP3,SCALE,TIM,XTIME,JSTART
DIMENSION DD1(1), DD2(1)
DO 10 I=1,NPS
DD2(I)=DD1(I)/EXIT+DD2(I)
10 CONTINUE
RETURN
C
END

END OF P. HEADER

8FOR,US M.HEADER
FOR E3AB-09/16/77-02:40:47 (5,6)

SUBROUTINE HEADER ENTRY POINT 000420

STORAGE USED: CODE(1) 000441: DATA(0) 000231: BLANK COMMON(2) 040041

EXTERNAL REFERENCES (BLOCK, NAME)

- 0003 NVOUS
- 0004 WIOZS
- 0005 WIOIS
- 0006 XPII
- 0007 WERR3S

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0000	000106	100F	0000	000117	110F	0001	000016	1166	0000	000135	120F	0001	000020	1226
0000	000146	130F	0001	000157	140F	0001	000112	1476	0001	000207	1716	0001	000215	1756
0001	000352	30L	0001	000400	40L	0000	000027	50F	0000	000035	60F	0000	000047	70F
0000	000055	80F	0000	000077	90F	0002	030026	AVES1	0002	040027	CUT	0000	000001	DAY
0002	030001	DBRANG	0002	000000	DDATA	0002	R 030024	EXIT	0002	040031	FN	0002	030012	FPB
0002	030020	FSAMP	0002	040030	H	0000	I 000002	HP	0000	I 000022	I	0000	I 000026	IAFS
0002	030014	IDSH	0002	030015	IFFT	0000	I 000023	IF1	0002	030016	ILN	0002	030023	IMOVE
0000	000021	INJPS	0002	030011	IOP	0000	I 000004	ISAMPL	0002	030017	ITD	0002	040026	IVER
0000	I 000024	J	0002	040040	JSTART	0000	I 000025	K	0002	I 030022	KFILE	0000	I 000021	KK
0000	I 000000	MIN	0002	030013	ROF	0002	040032	SAMP1	0002	040033	SAMP2	0002	040034	SAMP3
0002	040035	SCALE	0002	R 030005	SD	0000	I 000003	SEC	0002	R 030025	SL	0002	R 030000	SR
0002	030010	SSEC	0002	030006	TAPE	0002	020000	TEMP1	0002	040036	TIM	0002	030021	TIMAX
0002	030007	TFRIS	0002	030003	XIJ	0002	030004	XMAX	0002	030002	XNSAMP	0002	040037	XTIME

CXXXX SUBROUTINE SUB003(HEADER) TO DECODE HEADER RECORD FROM SDAS TAPE

00100
00101
00102
00103
00104
00105
00106
00107
00108
00109
00110
00111
00112
00113
00114
00115
00116
00117
00118
00119
00120
00121
00122
00123

1* SUBROUTINE HEADER (IHEAD,LREC,IDATA)
 2* INTEGER DAY,HR,MIN,SEC
 3* COMMON DDATA(8192),TEMP1(4096),SR,DBRANG,XNSAMP,XIJ,XMAX
 4* COMMON SD,TAPE,TFRIS,SSEC,IOP,FPB,ROF,IDSH,IFFT,ILN,ITD
 5* COMMON FSAMP,TIMAX,KFILE,IMOVE,EXIT,SL,AVES1(4096),IVFR
 6* COMMON CUT,H,FN,SAMP1,SAMP2,SAMP3,SCALE,TIM,XTIME,JSTART
 7* DIMENSION IHEAD(3),IDATA(27)
 8* DIMENSION ISAMPL(13)
 9* DATA ISAMPL/200,400,500,1000,2000,2500,4000,5000,6250,10000,12500
 10* 1,20000,25000/
 11* KK=0
 12* CXXXX DECODE THE 27-4 BIT BCD NUMBERS
 13* DO 20 I=1,3
 14* IF I=0
 15* DO 10 J=1,9
 16* KK=KK+1
 17* IDATA(KK)=FLO(IF1,4,IMEAD(I))
 18*
 19*

HEADER

```

00126 20* IF1=IF1+4
00127 10 CONTINUE
00131 20 COMPUTE SAMPLE RATE, LENGTH, AND DELAY.
00133 CXXXX K=IDATA(10)
00134 K=IDATA(10)
00135 SR=IDATA(10)
00136 SL=IDATA(11)*.5
00137 SD=(IDATA(12)-1)*.5
00137 20* PRINT HEADER INFORMATION
00140 30* WRITE (6,50) MFILE
00143 31* WRITE (6,60)
00145 32* WRITE (6,70) (IDATA(K),K=1,9)
00153 33* WRITE (6,80) IDATA(10),SL,SD
00160 34* WRITE (6,90) IDATA(13)
00163 35* IAFS=(IDATA(17)+IDATA(18)+.1)+(IDATA(19)*.01)*(10**IDATA(20))
00164 36* WRITE (6,100) IAFS
00167 37* WRITE (6,110) (IDATA(1),I=14,16),(IDATA(1),I=21,27)
00167 38* CXXXX COMPUTE FILE LENGTH
00201 39* LREC=(IDATA(10)+IDATA(11))/2+2
00202 40* DAY=IDATA(1)+IDATA(2)+IDATA(3)
00203 41* HR=IDATA(4)+IDATA(5)
00204 42* MIN=IDATA(6)+IDATA(7)
00205 43* SEC=IDATA(8)+IDATA(9)
00206 44* IF (IDATA(10).LT.200.OR.IDATA(10).GT.12500) GO TO 30
00210 45* IF (DAY.GT.365.OR.HR.GT.24.OR.MIN.GT.60.OR.SEC.GT.60) GO TO 30
00212 46* IF (SL.LT.0.5.OR.SL.GT.16.0) GO TO 30
00214 47* IF (SD.GT.15.0) GO TO 30
00216 48* IF (IAFS.LT.100.OR.IAFS.GT.5000) GO TO 30
00220 49* GO TO 40
00221 50* EXIT=7777.0
00222 51* WRITE (6,120)
00224 52* WRITE (6,130)
00226 53* WRITE (6,140)
00230 54* WRITE (6,120)
00232 55*
00232 56*
00233 57*
00234 58*
00235 59*
00236 60*
00236 61*
00237 62*
00240 63*
00241 64*
00241 65*
00242 66*
00243 67*
00244 68*
00244 69*
00245 70*
END FOR

C
50 FORMAT ('1',2X,'DATA FILE NUMBER',I6,/)
60 FORMAT (10X,'DAY',7X,'HOURS',3X,'MINUTES',3X,'SECONDS',)
70 FORMAT (10X,3I1,8X,2I1,8X,2I1,8X,2I1,/)
80 FORMAT (10X,'SAMPLE RATE =',I5,' HZ SAMPLE LENGTH =',F3.1,' SE
1C SAMPLE DELAY =',F3.1,' SEC,/)
90 FORMAT (10X,I3,' INPUT CHANNEL SAMPLED',/)
100 FORMAT (10X,'ANTILIASING FILTER SETTING =',I6,' HZ,/)
110 FORMAT (10X,'SWITCH SETTINGS 5 THRU 7',3I4,10X,'SWITCH SETTINGS 12
1 THRU 18',7I4,/)
120 FORMAT (10X,'*****')
130 FORMAT (10X,'**THERE IS SOMETHING WRONG WITH THE HEADER')
140 FORMAT (10X,'**INCREASE MFILE BY 2 AND TRY AGAIN ')

C
END

```

8406,P LINE

SUBROUTINE LINE ENTRY POINT 000121

STORAGE USED: CODE(1) 000130; DATA(0) 000130; BLANK COMMON(2) 040041

EXTERNAL REFERENCES (BLOCK, NAME)

0003 NWDUS
0004 NIO3S
0005 NIO2S
0006 NERR3S

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001	000005	1166	0001	00022	1266	0001	00031	1346	0001	00057	3CL	00064	40L
0001	000070	SOL	0000	000107	70F	0000	000111	80F	0000	030026	AVES1	00000	BLANK
0002	040027	CUT	0002	030001	DBRANG	0002	000000	DDATA	0000	000001	DOT	030024	EXIT
0002	040031	FN	0002	030012	FPB	0002	030020	FSAMP	0002	040030	M	030014	IDSH
0002	030015	IFFT	0002	030016	ILN	0002	030023	IMOVE	0000	000117	INJPS	030011	IOP
0002	030017	ITO	0002	040026	IVER	0000	000104	J	0002	040340	JSTART	030022	KFILE
0000	I	000106	L	0000	I	000003	LINE	0000	I	000105	M	040032	SAMP1
0002	040033	SAMP2	0002	040034	SAMP3	0002	040035	SCALE	0002	030005	SD	030025	SL
0002	030000	SR	0002	030010	SSEC	0002	030006	TAPE	0002	020000	TEMP1	040036	TIM
0002	030021	TIMAX	0002	030007	TYFRIS	0000	I	000002	X	030003	XTJ	030004	XMAX
0002	030002	XNSAMP	0002	040037	XTIME								

```

00100 1* CXXX SUBROUTINE SUB010(LINE)
00100 2* CXXX SUB010(LINE) CONVERTS EACH DATA POINT TO A
00100 3* CXXX POINT ON THE HARD COPY (I.E. A GRAPH)
00100 4* C
00101 5* SUBROUTINE LINE (DATA, KK)
00103 6* COMMON DDATA(8192), TEMP1(4096), SR, DBRANG, XNSAMP, XIJ, XMAX
00104 7* COMMON SD, TAPE, TYFRIS, SSEC, IOP, FPR, PROF, IDSH, IFFT, ILN, ITO
00105 8* COMMON FSAMP, TIMAX, KFILE, IMOVE, EXIT, SL, AVES1(4096), IVER
00106 9* COMMON CUT, H, FN, SAMP1, SAMP2, SAMP3, SCALE, TIM, XTIME, JSTART
00107 10* INTEGER BLANK, DOT, X
00110 11* DATA BLANK / 1H / , DOT / . . . / , X / 'X' /
00114 12* DIMENSION LINE(65), DATA(1)
00115 13* DO 10 J=1,65
00120 14* 10 LINE(J)=DOT
00122 15* WRITE (6,70) LINE
00125 16* DO 20 J=1,65
00130 17* 20 LINE(J)=BLANK
00132 18* LINE(33)=DOT
00133 19* DO 60 M=1, KK
00136 20* L=(DATA(M)/XMAX)*32+33.5
00137 21* IF (L.LT.1) 60 TO 30
00141 22* IF (L.GT.65) 60 TO 40

```

```

LINE      230
00143    LINE(L)=X
00144    60 TO 50
00145    L=1
30      LINE(1)=DOT
00146    60 TO 50
00147    L=65
00150    LINE(65)=DOT
00151    WRITE (6,80) LINE
50      LINE(L)=BLANK
00155    LINE(33)=DOT
00156    L=33
60      CONTINUE
00157    C
00161    70 FORMAT (5X,65A1)
00162    80 FORMAT (5X,65A1)
00163    C
END FOR  END

```

MDG.P MLOGN

FOR US M.NLOGM
FOR E3AR-09/1677-02:40:53 (5,6)

SUBROUTINE MLOGM ENTRY POINT 000332

STORAGE USED: CODE(1) 000352: DATA(0) 000103: BLANK COMMON(2) 000000

EXTERNAL REFERENCES (BLOCK, NAME)

0003 XPII
0004 SIN
0005 COS
0006 CDVS
0007 MERR3S

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001	000030	1106	0001	000045	1156	0001	000072	1246	0001	000175	1466
0001	000230	1626	0001	000247	1726	0001	000303	2066	0001	000245	50L
0001	000263	70L	0000	R	000035	FK	0000	R	0000	I	000026
0000	I	000034	IBLOCK	0000	I	000043	II	0000	I	000040	ISTART
0000	I	000042	JM	0000	I	000033	K	0000	I	000032	LRHALF
0000	I	000025	LX	0000	I	000000	M	0000	I	000030	NBLOCK
0000	C	000017	WK					0000	C	000023	Q

```

00101 1* SUBROUTINE MLOGM (N,X,SIGN)
00101 2* SUBROUTINE SUB016(MLOGM)
00101 3* FROM ROBINSON PAGE 63
00101 4* C NMAX = LARGEST VALUE OF N TO BE PROCESSED
00101 5* C NONDUMMY DIMENSION M(NMAX)
00101 6* C FOR EXAMPLE, IF MMAX = 15 THEN
00101 7* DIMENSION M(15)
00103 8* DIMENSION X(2**N)
00104 9* DIMENSION X(2)
00105 10* COMPLEX X, WK, HOLD, Q
00106 11* LX=2**N
00107 12* DO 10 I=1,N
00112 13* M(I)=2**(N-I)
00114 14* DO 40 L=1,N
00117 15* NBLOCK=2**(L-1)
00120 16* LBLOCK=LX/NBLOCK
00121 17* LBHALF=LBLOCK/2
00122 18* K=0
00123 19* DO 40 IBLOCK=1,NBLOCK
00126 20* FK=K
00127 21* FLX=LY
00130 22* V=SIGN*6.2831853071796*FK/FLX
00131 23* WK=CMPLX(COS(V),SIN(V))
00132 24* ISTART=LBLOCK*(IBLOCK-1)
00133 25* DO 20 I=1,LBHALF

```

```

26* J=I*START+I
27* JM=J+LB*HALF
28* Q=X(JH)*WK
29* X(JH)=X(J)-Q
30* X(J)=X(J)+Q
31* CONTINUE
32* DO 30 I=2,N
33* II=I
34* IF (K.LT.M(II)) 60 TO 40
35* K=K-M(II)
36* M=K+M(II)
37*
38* M=0
39* DO 70 J=1,LX
40* IF (K.LT.J) 60 TO 50
41* HOLD=X(J)
42* X(J)=X(K+1)
43* X(K+1)=HOLD
44* DO 60 I=1,N
45* II=I
46* IF (K.LT.M(II)) 60 TO 70
47* K=K-M(II)
48* M=K+M(II)
49* IF (SIGN.LT.C.O) RETURN
50* DO 80 I=1,LX
51* X(II)=X(II)/FLX
52* RETURN
53* END

```

NLOGN

00136
00137
00140
00141
00142
00143
00145
00150
00151
00153
00155
00160
00161
00164
00166
00167
00170
00171
00174
00175
00177
00201
00203
00205
00210
00212
00212
00213
END FOR

3MDG,P PEAK

SUBROUTINE PEAK ENTRY POINT 000035

STORAGE USED: CODE(1) 000043; DATA(0) 000017; BLANK COMMON(2) C40041

EXTERNAL REFERENCES (BLOCK, NAME)

0003 NHQUS
0004 NIQ2S
0005 NEHR3S

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001	000006	1126	0000	000001	20F	0002	030026	AVES1	0002	040027	CUT	0002	030001	DBRANG	
0002	000000	00ATA	0002	030024	EXIT	0002	040031	FN	0002	030012	FPB	0002	030020	FSAMP	
0002	040030	H	0000	I	000000	I	0002	030014	IDSH	0002	030015	IFFT	0002	030016	ILN
0002	030023	IMOVE	0000	000007	INJPS	0002	030011	IOP	0002	030017	ITD	0002	040026	IVER	
0002	040040	JSTART	0002	030022	KFILE	0002	030013	ROF	0002	040032	SAMP1	0002	040033	SAMP2	
0002	040034	SAMP3	0002	040035	SCALE	0002	030005	SD	0002	030025	SL	0002	030000	SR	
0002	030010	SSEC	0002	030006	TAPE	0002	020000	TEMP1	0002	040036	TIM	0002	030021	TIMAX	
0002	030007	TFRIS	0002	030003	XIJ	0002	R	030004	XMAX	0002	030002	XNSAMP	0002	040037	XTIME

```

00100 1* CXXXX SUBROUTINE TO DETERMINE LARGEST VALUE IN DATA ARRAY
00100 2* CXXXX DATA = ONE-DIMENSIONAL ARRAY
00100 3* CXXXX MK = NUMBER OF POINTS IN DATA
00100 4* CXXXX XMAX = ABSOLUTE PEAK AMPLITUDE
00100 5* C
00100 6* CXXXX SUBROUTINE SUBC28(PEAK)
00100 7* C
00101 8* SUBROUTINE PEAK (DATA, KK)
00103 9* COMMON DDATA(8192), TEMP1(4096), SR, DBRANG, XNSAMP, XIJ, XMAX
00104 10* COMMON SD, TAPE, TFRIS, SSEC, IOP, FPB, POF, IDSH, IFFT, ILN, ITD
00105 11* COMMON FSAMP, TIMAX, KFILE, IMOVE, EXIT, SL, AVES1(4096), IVER
00106 12* COMMON CUT, H, FN, SAMP1, SAMP2, SAMP3, SCALE, TIM, XTIME, JSTART
00107 13* DIMENSION DATA(1)
00110 14* XMAX=0.0
00111 15* DO 10 I=1, KK
00114 16* IF (ABS(DATA(I)).GT.XMAX) XMAX=ABS(DATA(I))
00116 17* 10 CONTINUE
00120 18* WRITE (6,20) XMAX
00123 19* RETURN
00124 20* C
00125 21* C 20 FORMAT (//,10X,'XMAX =',F10.4,/)
00125 22* C
00125 23* END
END FOR

```

PEAK

QMDG,P PLOT01

DATE 091677

PAGE

2

SUBROUTINE PLOT01 ENTRY POINT 000632

STORAGE USED: CODE(1) 000634; DATA(0) 000213; BLANK COMMON(2) 040041

EXTERNAL REFERENCES (BLOCK, NAME)

0003 SYMBOL
0004 NUMBER
0005 AXES
0006 PLOT
0007 NEPR33

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001	000111	10L	0001	000441	20L	0001	000561	30L	0001	000616	40L	0002	030026	AVES1		
0002	R	040027	CUT	0002	R	030001	DRRANG	0002	000000	DDATA	0000	R	000005	DS		
0000	R	000006	DSL	0002	030024	EXIT	0000	R	000002	FILE	0002	R	040031	FN		
0002	R	030020	FSAMP	0002	R	040030	H	0002	030014	IDSH	0002	030015	IFFT	030012	FPB	
0002	I	040040	JSTART	0000	000207	INJPS	0002	030011	IOP	0002	I	030017	IYD	040026	IVER	
0002	R	040033	SAMP2	0002	I	030022	KFILE	0002	R	030013	ROF	0002	R	040032	SAMP1	
0002	030000	SR	0002	030010	SSEC	0002	R	040035	SCALE	0002	R	030005	SD	030025	SL	
0002	R	040036	TIM	0002	030021	TIMAX	0000	R	000003	START	0002	R	030006	TAPF	020000	TEMP1
0002	030004	XMAX	0002	R	030002	XNSAMP	0002	R	040037	XTIME	0002	R	030007	TIFRIS	030003	XIJ

SUBROUTINE PLOT01

COMMON DDATA(8192),TEMP1(4096),SR,DRRANG,XNSAMP,XIJ,XMAX
COMMON SD,TAPE,TIFRIS,SSEC,IOP,FPB,ROF,IDSH,IFFT,ILN,IYD
COMMON FSAMP,TIMAX,KFILE,IMOVE,EXIT,SL,AVES1(4096),IVER
COMMON CUT,H,FN,SAMP1,SAMP2,SAMP3,SCALE,TIM,XTIME,JSTART
DEL=SCALE INCREMENT
TIM1=XTIME/10
DEL=ROF/(10.0*SCALE)

CALL SYMBOL (0.0,1.2,-21,27)FREQUENCY RESPONSE ANALYSTS,(90.0,27)
CALL SYMBOL (0.2,2.2,-14,21)DATA TAKEN FROM TAPE ,(90.0,21)
CALL NUMBER (999.0,999.0,C.14,TAPE,90.0,1)
CALL SYMBOL (999.0,999.0,0.14,6H FILE ,90.0,6)
CALL NUMBER (999.0,999.0,C.14,TIM,90.0,-1)
IF (TIM.GE.KFILE) GO TO 10
CALL SYMBOL (999.0,999.0,0.14,4H TO ,90.0,4)
FILE=KFILE

10 CALL NUMBER (999.0,999.0,0.14,FILE,90.0,-1)
CALL SYMBOL (0.7,-1.3,0.14,6H FILTER,90.0,6)
CALL SYMBOL (0.9,-1.3,0.14,6H VALUES,90.0,6)
CALL SYMBOL (1.1,-1.3,0.14,3HCUT,90.0,3)
CALL NUMBER (999.0,999.0,0.14,CUT,90.0,-1)
CALL SYMBOL (1.3,-1.3,0.14,2HH=,90.0,2)

00101 1*
00103 2*
00104 3*
00105 4*
00106 5*
00106 6*
00107 7*
00110 8*
00111 9*
00112 10*
00113 11*
00114 12*
00115 13*
00116 14*
00120 15*
00121 16*
00122 17*
00123 18*
00124 19*
00125 20*
00126 21*
00127 22*

DFOR,US M.PLOT02
FOR E3AN-09/16/77-02:41:03 (5,6)

SUBROUTINE PLOT02 ENTRY POINT 000370

STORAGE USED: CODE(1) 000375; DATA(0) 000033; BLANK COMMON(2) 040041

EXTERNAL REFERENCES (BLOCK, NAME)

0003 PLOT
0004 NERR3S

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001	000257	10L	0001	000164	137G	0001	000266	20L	0001	000334	30L	0001	000356	40L
0002	030026	AVES1	0002	040027	CUT	0002	R 030001	DBRANG	0000	P 000004	DD	0002	R 000000	DDATA
0002	030024	EXIT	0002	040031	FN	0002	030012	FPB	0002	030020	FSAMP	0002	040030	H
0000	Y 000006	I	0002	030014	IDSH	0002	030015	IFFT	0002	030016	ILN	0002	030023	IMOVE
0000	000022	INJPS	0002	I 030011	IOP	0002	030017	ITD	0002	I 040026	IVER	0002	040040	JSTART
0002	030022	KFILE	0002	030013	ROF	0000	R 000000	SAMPT	0000	R 000001	SAMPT1	0002	040032	SAMP1
0002	R 040033	SAMP2	0002	R 040034	SAMP3	0002	040035	SCALE	0002	030005	SD	0002	030025	SL
0002	030000	SR	0002	030010	SSEC	0000	R 000005	SUB	0002	030006	TAPE	0002	020000	TEMP1
0002	040036	TIM	0002	030021	TIMAX	0002	030007	TIFRIS	0000	R 000002	XI	0002	R 030003	XIJ
0000	R 000003	XITER	0000	R 000011	XI1	0002	030004	XMAX	0002	030002	XI	0002	R 040037	XTIME
0000	R 000010	XI	0000	R 000007	X2									

00101 1* SUBROUTINE PLOT02

00101 2* CXXXX SEE NOTES IN GREEN HAND BOOK CALLED 'DAILY

00101 3* CXXXX NOTES' AND ON PAGE 11 DATED DEC 16 1976

00101 4* CXXXX YOU WILL FIND HOW THE PERAMITERS WHERE PICKED

00101 5* CXXXX PROGRAM FOR EVEN PLOTTING INFORMATION

00101 6* CXXXX TAPE=IS THE NUMBER GIVER TO THE SDAS TAPE

00101 7* CXXXX DBRANG=DB RANGE TO BE USED BETWEEN TIME MARKS.

00101 8* CXXXX XIJ=UNIT INCREMENT TO ADVANCE THE PLOTTER

00103 9* COMMON DDATA(18192),TEMP1(4096),SR,DBRANG,XNSAMP,XIJ,XMAX

00104 10* COMMON SD,TAPE,TIFRIS,SSEC,IOP,FPB,ROF,IDSH,IFFT,ILN,ITD

00105 11* COMMON FSAMP,TIMAX,KFILE,IMOVE,EXIT,SL,AVES(14096),IVER

00106 12* COMMON CUT,H,FN,SAMP1,SAMP2,SAMP3,SCALE,TIM,XTIME,JSTART

00107 13* SAMPT=0.0

00110 14* IF (XIJ.EQ.0) SAMPT=SAMP1+1.0

00112 15* IF (XIJ.GT.0.5) SAMPT=2*SAMP1+SAMP2*(XIJ-1.0)+1.1

00114 16* IF (IVER.EQ.1.AND.XIJ.GE.1) SAMPT=SAMP2*(XIJ-1.0)

00116 17* SAMPT1=SAMP1

00117 18* IF (XIJ.GT.0.5) SAMPT1=SAMP3

00121 19* XI=SAMPT-(DDATA(1)/DBRANG)*SAMP1

00122 20* IF (XI.GT.SAMPT1) XI=SAMPT1+SAMPT

00124 21* IF (IVER.EQ.1.AND.XIJ.GE.1) XI=2*SAMP1+1.1+SAMP3

00126 22* XITER=0.0

00127 23* DD=(DDATA(1)/DBRANG)*SAMP1

00130 24* IF (DDATA(1).GT.SAMPT1) DD=SAMPT1

```

250 00132 IF (IVER.EQ.1.AND.XIJ.GE.1) XITER=SAMP2*(XIJJ-1.0)+DD
260 00134 CALL PLOT (XI,XITER,3)
270 00135 SUB=10.0/IOP
280 00136 WRITE(6,90005)SUB,IOP,FP8,XIJ
290 00135 C 90005 FORMAT(30X,'PLOT02',//,5X,'SUB=',F10.5,2X,'IOP=',I5,5X,
300 00135 C *FP8=',F10.1,2X,'XIJJ=',F10.1,/)
310 00136 DO 20 I=1,IOP
320 00141 X2=I-1.0
330 00142 XI=SUB*X2
340 00143 IF (IVER.EQ.1.AND.XIJ.GE.1) XI=SAMP1+2+1.1+XI+SAMP3
350 00143 C IF (I.EQ.2.OR.I.EQ.IOP) WRITE(6,90010)XI,X2
360 00143 C 90010 FORMAT(/,10X,'XI=',F10.4,10X,'X2=',F10.4,)
370 00145 DDATA(II)=(-DDATA(II)/DBRANG)*SAMP1
380 00146 IF (DDATA(II).GT.SAMP1) DDATA(II)=SAMP1
390 00150 DDATA(II)=DDATA(II)+SAMP1
400 00151 IF (IVER.EQ.0.OR.XIJ.LT.1) GO TO 10
410 00153 CALL PLOT (XI,DDATA(II),2)
420 00154 GO TO 20
430 00155 10 CALL PLOT (DDATA(II),XI,2)
440 00156 20 CONTINUE
450 00160 IF (SAMP2.EQ.SAMP3) XI1=SAMP1+SAMP1
460 00162 IF (IVER.EQ.0.OR.XIJ.LT.1) GO TO 30
470 00164 IF (SAMP2.LE.SAMP3) CALL PLOT (XI,SAMP1,3)
480 00166 IF (SAMP2.LE.SAMP3) CALL PLOT (XI,SAMP1,2)
490 00170 GO TO 40
500 00171 30 IF (SAMP2.LE.SAMP3) CALL PLOT (XI1,10.0,3)
510 00173 IF (SAMP2.LE.SAMP3) CALL PLOT (XI1,10.0,2)
520 00175 40 RETURN
530 00175 C
540 00176 END
550 END FOR

```

BFOR,US N.SDAS
FOR E3AB-09/16/77-02:41:06 (5.6)

SUBROUTINE SDAS ENTRY POINT 000166

STORAGE USED: CODE(1) 000213; DATA(0) 001326; BLANK COMMON(2) 000000

EXTERNAL REFERENCES (BLOCK, NAME)

0003 NTRAN
0004 HEADER
0005 DECODE
0006 NUDUS
0007 NI02S
0010 NERR3S

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001	000031	10L	0001	000050	20L	0001	000057	30L	0001	000067	40L	0001	000141	50L
0001	000156	60L	0000	001273	70F	0000	001235	80F	0000	001232	90F	0000	000000	INDATA
0000	001316	INJPS	0000	001230	1ST	0000	001270	K	0000	001272	L	0000	001271	LREC

```

00100 CXXXX SUBROUTINE SDAS CREATED BY T. MERO 11/74 TO READ THE DATA TAPE
00101 CXXXX PRODUCED BY CODE 6222'S SEISMIC DATA ACQUISITION SYSTEM.
00102 CXXXX IUNIT = INPUT TAPE DRIVE UNIT
00103 CXXXX IPR = 1 IF HEADER DATA IS TO BE PRINTED, 0 IF NOT
00104 CXXXX DATA = DECODED OUTPUT DATA ARRAY
00105 CXXXX KK = NUMBER OF SAMPLES IN DATA
00106 CXXXX IF A TAPE READ ERROR OCCURS KK BECOMES THE NTRAN STATUS WORD.
00107 CXXXX SDAS USES SUBROUTINES HEADER AND DECODE
00108 C
00109 SUBROUTINE SDAS (IUNIT,IPR,DATA,KK,KFILE)
00110 DIMENSION INDATA(332,2), IST(2), IHEAD(3), IDATA(27)
00111 DIMENSION DATA(1)
00112 CXXXX READ HEADER FROM TAPE.
00113 N=1
00114 CALL NTRAN (IUNIT,2,3,IHEAD(1),IST(K))
00115 IF (IST(K).EQ.-1) CALL NTRAN (IUNIT,22)
00116 IF (IST(K).GT.0) GO TO 20
00117 10 KK=IST(K)
00118 WRITE (6,70) KFILE, KK
00119 CALL NTRAN (IUNIT,22)
00120 GO TO 60
00121 20 IF (IPR.EQ.0) GO TO 30
00122 CXXXX BREAK DOWN HEADER RECORD
00123 CALL HEADER (IHEAD,LREC, IDATA)
00124 CXXXX K IS I/O BUFFER POINTER AND KK IS NUMBER OF SAMPLES READ.
00125 30 KK=0
00126 CXXXX READ DATA RECORD. USE DOUBLE BUFFERING TO SAVE I/O TIME.
00127 CALL NTRAN (IUNIT,2,332,INDATA(1,1),IST(1))

```

```

00127 29* 40 IF (IST(K).EQ.-1) CALL NTRAM (IUNIT,22)
00128 30* IF (IST(K).LT.1) GO TO 10
00131 31* CXXXX L IS BUFFER POINTER FOR PROCESSING
00133 32* L=K
00133 33* CXXXX CHECK FOR FULL RECORD
00134 34* IF (IST(K).LT.332) GO TO 50
00134 35* CXXXX IF K=1, MAKE K=2. IF K=2, MAKE K=0
00136 36* IF (K.GE.2) K=C
00140 37* K=K+1
00140 38* CXXXX READ NEXT DATA RECORD INTO SECOND PART OF ARRAY INDATA.
00141 39* CALL NTRAM (IUNIT,2,332,INDATA(1,K),IST(K))
00141 40* CXXXX DECODE DATA.
00142 41* 50 CALL DECODE (IST,L,INDATA,DATA,KK)
00143 42* IF (IST(L).LT.332) GO TO 60
00145 43* GO TO 40
00146 44* 60 RETURN
00146 45* C
00147 46* 70 FORMAT (//,10X,'TAPE READ ERROR AT FILE NUMBER',I6,10X,'NTRAM STAT
00147 47* 1US WORD =',I8,/)
00147 48* C
00150 49* END
END FOR

```

ØMUG,P TAPER

FOR US W.TAPER
FOR E3AB-09/16/77-02:41:09 (5,6)

SUBROUTINE TAPER ENTRY POINT 000246

STORAGE USED: CODE(1) 000264; DATA(0) 000046; BLANK COMMON(2) 040041

EXTERNAL REFERENCES (BLOCK, NAME)

0003 MERR2S
0004 COS
0005 EXP
0006 MERR3S

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001	000101	10L	0001	00054	1226	0001	000112	20L	0001	000115	30L	000140	40L				
0001	000147	50L	0001	000166	60L	0001	000205	70L	0001	000214	80L	030026	AVESI				
0000	R	000003	BAND	0002	040027	CUT	0002	030001	0BRANG	0002	000000	00ATA	030024	EXIY			
0002	040031	FN	0002	030012	FPB	0002	030020	FSAMP	0002	040030	M	0000	I	000010	I		
0000	I	000002	IBAND	0000	I	000013	IDEV	0002	030014	IDSH	0002	030015	IFFT	0000	I	000001	IFO
0000	I	000006	IJ1	0000	I	000007	IJ2	0002	030016	ILN	0002	030023	IMOVE	0000	I	000021	INJPS
0002	030011	IOP	0000	I	000005	ITAPER	0002	030017	ITD	0002	040026	IVER	0000	I	000011	J	
0002	040040	JSTART	0002	030022	KFILE	0000	R	000000	PI	0002	030013	ROF	0002	040032	SAMP1		
0002	040033	SAMP2	0002	040034	SAMP3	0002	040035	SCALE	0002	030005	SD	0002	030025	SL			
0002	030000	SR	0002	030010	SSEC	0002	030006	TAPE	0002	030000	TEMP1	0002	040036	TIM			
0002	030021	TIMAX	0002	030007	TIFRIS	0000	R	000012	W	0002	030003	XIJ	0002	030004	XMAX		
0002	030002	XNSAMP	0000	R	000004	XTAPER	0002	040037	XTIME								

00101
00101
00101
00101
00103
00104
00105
00106
00107
00108
00111
00112
00113
00114
00115
00116
00117
00120
00121
00124
00125
00127

SUBROUTINE TAPER (NP21,KFIL,IHI,LOW)

C SUBROUTINE TAPER MULTIPLIES FREQUENCY RESPONSE FUNCTION BY SOME FILTER
C CONTOUR.

COMMON DDATA(8192),TEMP1(4096),SR,DRRANG,XNSAMP,XIJ,XMAX
COMMON SD,TAPE,TIFRIS,SSEC,IOP,FPB,ROF,IDSH,IFFT,ILN,ITD
COMMON FSAMP,TIMAX,KFILE,IMOVE,EXIT,SL,AVESI(4096),IVER
COMMON CUT,M,FM,SAMP1,SAMP2,SAMP3,SCALE,TIM,XTIME,JSTART
IF (KFIL.LE.0) RETURN
PI=3.1415926535898
IF0=(IMI+LOW)/2
IBAND=IMI-LOW+1
BAND=FLOAT(IBAND)
XTAPER=-1+IBAND
ITAPER=INT(XTAPER)
IJ1=(LOW+ITAPER)
IJ2=(IMI-ITAPER)
DO 90 I=1,NP21
J=2+I-1
IF (1.6E.LOV.AND.I.LE.IMI) GO TO 10
W=0.

```

22* 60 TO 80
23* 10 60 TO (30,60,70,20), KFIL
24* C RECTANGULAR TAPER
25* C
26* C
27* 20 W=1.
28* 60 TO 80
29* C COSINE TAPER
30* C
31* C
32* 30 IF (I.67.IJ1) 60 TO 40
33* W=.5-.5*COS((PI*FLOAT(I-LOW))/XTAPER)
34* 60 TO 80
35* 40 IF (I.6E.IJ2) 60 TO 50
36* W=.
37* 60 TO 80
38* 50 W=.5-.5*COS((PI*FLOAT((HI-I))/XTAPER)
39* 60 TO 80
40* C GAUSSIAN FILTER
41* C DEFINE THE HALF BANDWIDTH AS THE 2SIGMA POINT
42* C AREA AT 2 SIGMA EQUALS .955
43* C
44* C
45* 60 IDEV=I-IFO
46* W=EXP(FLOAT(-8*IDEV*IDEV)/FLOAT((IBAND*IBAND)))
47* 60 TO 80
48* C TRIANGULAR FILTER W= (1-2X/8W)
49* C
50* 70 W=(1-.2*FLOAT(IDEV)/FLOAT(1BAND))
51* 80 DDATA(J)=DDATA(J)*W
52* J=J+1
53* DDATA(J)=DDATA(J)*W
54* 9C CONTINUE
55* RETURN
56* C
57* END
END FOR

```

AMDG,P VOLT

SUBROUTINE VOLT ENTRY POINT C0C123

STORAGE USED: CODE(1) 000131; DATA(10) 000027; BLANK COMMON(2) 0*00041

EXTERNAL REFERENCES (BLOCK, NAME)

0003 SQRT
0004 ALOG10
0005 MERR3S

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001	000011	1126	0001	00053	20L	0001	00061	30L	0001	000104	40L	000110	50L		
0002	030026	AVES1	0002	040027	CUT	0002	030001	DBRANG	0000	R	000004	DD	000000	DDATA	
0000	I	000001	I	0002	040031	FN	0002	030012	FPB	0002	030020	FSAMP	040030	H	
0000	I	000010	INJPS	0000	I	000000	INX	0002	030015	IFFT	0002	030016	ILN	030023	IMOVE
0000	I	000003	J	0002	040040	JSTART	0002	040002	JX	0002	030017	ITD	040026	IVER	
0002	040032	SAMP1	0002	040033	SAMP2	0002	040034	SAMP3	0002	030022	KFILE	0002	030013	ROF	
0002	030025	SL	0002	030000	SR	0002	030010	SSEC	0002	040035	SCALE	0002	030005	SO	
0002	040036	TIM	0002	030021	TIMAX	0002	030010	SSEC	0002	030006	TAPE	0002	020000	TEMP1	
0002	030002	XNSAMP	0002	040037	XTIME	0002	030007	TTFRIS	0002	030003	XIJ	0002	030004	XMAX	

```

00101 1* SUBROUTINE VOLT (NP)
00103 2* REAL ILN
00104 3* COMMON DDATA(8192),TEMP1(4096),SR,DBRANG,XNSAMP,XIJ,XMAX
00105 4* COMMON SD,TAPE,TTFRIS,SSEC,IOP,FPB,ROF,IDSH,IFFT,ILN,ITD
00106 5* COMMON FSAMP,TIMAX,KFILE,IMOVE,EXIT,SL,AVES1(4096),IVER
00107 6* COMMON CUT,H,FM,SAMP1,SAMP2,SAMP3,SCALE,TIM,XTIME,JSTART
00110 7* INX=2*NP-1
00111 8* DO 20 I=1,INX,2
00114 9* JX=(I+1)/2
00115 10* J=I+1
00116 11* DD=SQRT(DDATA(I)**2+DDATA(J)**2)
00117 12* IF (ILN.E0.1) GO TO 30
00121 13* IF (DD) 40,40,10
00124 14* 10 DDATA(JX)=20*(ALOG10(DD))
00125 15* 20 CONTINUE
00127 16* GO TO 50
00130 17* 30 IF (DDATA(I).LT.0) DDATA(JX)=-DD
00132 18* IF (DDATA(I).GE.0) DDATA(JX)=DD
00134 19* GO TO 20
00135 20* 40 DDATA(JX)=-160.0
00136 21* GO TO 20
00137 22* 50 CONTINUE
00140 23* RETURN
00140 24* C

```

VOLT
00141 25+
END FOR
END

0M06,P ZERO

FOR US M-ZERO
FOR E3AB-09/16/77-02:41:15 (5,6)

SUBROUTINE ZERO ENTRY POINT 00G026

STORAGE USED: CODE(1) 000034; DATA(0) 000011; BLANK COMMON(2) 000000

EXTERNAL REFERENCES (BLOCK, NAME)

0003 MERR35

STORAGE ASSIGNMENT (BLOCK, TYPE, RELATIVE LOCATION, NAME)

0001 000013 1076 0000 I 000000 I 0000 000002 INJPS

```

00101 1* SUBROUTINE ZERO (LX,X)
00102 2* DIMENSION X(LX)
00103 3* C FOR COMPLEX VERSION REMOVE THE C FROM COL 1 OF NEXT CARD
00104 4* C COMPLEX X
00105 5* IF (LX.LE.0) RETURN
00106 6* DO 10 I=1,LX
00107 7* X(I)=0.0
00108 8* RETURN
00109 9* C
00110 10* END FOR

```

UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

REPORT DOCUMENTATION PAGE		READ INSTRUCTIONS BEFORE COMPLETING FORM
1. REPORT NUMBER NORDA Technical Note 14	2. GOVT ACCESSION NO.	3. RECIPIENT'S CATALOG NUMBER
4. TITLE (and Subtitle) Marine Seismic Display Enhancement Program Final Report Volume II Processing Software	5. TYPE OF REPORT & PERIOD COVERED Final	
	6. PERFORMING ORG. REPORT NUMBER	
7. AUTHOR(s) Bruce E. Eckstein	8. CONTRACT OR GRANT NUMBER(s)	
9. PERFORMING ORGANIZATION NAME AND ADDRESS Naval Ocean Research and Development Activity Naval Oceanographic Laboratory NSTL Station, MS 39529	10. PROGRAM ELEMENT, PROJECT, TASK AREA & WORK UNIT NUMBERS 63704N/0118/300	
11. CONTROLLING OFFICE NAME AND ADDRESS Naval Ocean Research and Development Activity Naval Exploratory Development Office NSTL Station, MS 39529	12. REPORT DATE December 1977	
	13. NUMBER OF PAGES	
14. MONITORING AGENCY NAME & ADDRESS (if different from Controlling Office)	15. SECURITY CLASS. (of this report)	
	15a. DECLASSIFICATION/DOWNGRADING SCHEDULE	
16. DISTRIBUTION STATEMENT (of this Report) Approved for public release: Distribution Unlimited		
17. DISTRIBUTION STATEMENT (of the abstract entered in Block 20, if different from Report)		
18. SUPPLEMENTARY NOTES This report is Volume II of a three volume series for the final report on Marine Seismic Display Enhancement Program.		
19. KEY WORDS (Continue on reverse side if necessary and identify by block number) Marine Seismic profiling, Filtering, Weiner Filtering Marine Seismic data, Marine Seismic software		
20. ABSTRACT (Continue on reverse side if necessary and identify by block number) This document explains six software programs developed to enhance display of digitally recorded seismic data. The first two programs are digital filters which remove undesired frequency content from seismic data. The third program vertically stacks several records with the same source to hydrophone array distance resulting in improved signal-to-noise. The fourth program is an optimum least squares filter commonly known as the "Weiner Filter". The fifth program develops a band limited zero-phase time domain pulse with defined		

DD FORM 1473
1 JAN 73

EDITION OF 1 NOV 68 IS OBSOLETE
S/N 0102-014-6601

UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE(When Data Entered)

frequency content. The sixth program develops a spectral analysis routine for time series data by use of a fast fourier transform method. A complete listing of the program for implementation on the UNIVAC 1108 is provided and the required changes for implementation on the CDC 6600 are given.

UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE(When Data Entered)