


MICROCOPY RESOLUTION TEST CHART
 NATIONAL BUREAU OF STANDARDS-1963-A

2

ASD-TR-84-5032, Vol 1

AUTOMATIC DYNAMIC AIRCRAFT
MODELER (ADAM)
VOLUME 1



Hugh Griffis
Nuclear Survivability Group
System Survivability Branch
ASD/ENSSS
Wright-Patterson AFB OH 45433-6503

January 1985

Final Report Period 1 March 1984 - 30 September 1984

Approved for public release; distribution is unlimited

DTIC
ELECTED
MAR 14 1985
S B

AD-A151 410

DTIC FILE COPY

DEPUTY FOR ENGINEERING
AERONAUTICAL SYSTEMS DIVISION
AIR FORCE SYSTEMS COMMAND
WRIGHT-PATTERSON AIR FORCE BASE, OHIO 45433-6503


85 03 06 648

NOTICE


When Government drawings, specifications, or other data are used for any purpose other than in connection with a definitely related Government procurement operation, the United States Government thereby incurs no responsibility nor any obligation whatsoever; and the fact that the government may have formulated, furnished, or in any way supplied the said drawings, specifications, or other data, is not to be regarded by implication or otherwise as in any manner licensing the holder or any other person or corporation, or conveying any rights or permission to manufacture use, or sell any patented invention that may in any way be related thereto.

This report has been reviewed by the Office of Public Affairs (ASD/PA) and is releasable to the National Technical Information Service (NTIS). At NTIS, it will be available to the general public, including foreign nations.

This technical report has been reviewed and is approved for publication.




HUGH GRIFFIS, Survivability Engineer
System Survivability Branch
Systems Analysis Division
Directorate of Systems Engineering



FRANK CAMPANILE, Chief
System Survivability Branch
Systems Analysis Division
Directorate of Systems Engineering

FOR THE COMMANDER



FRANKLIN P. FINIZIO, Chief
Systems Analysis Division
Directorate of Systems Engineering

If your address has changed, if you wish to be removed from our mailing list, or if the addressee is no longer employed by your organization please notify ASD/ENSSS, W-PAFB, OH 45433 to help us maintain a current mailing list

Copies of this report should not be returned unless return is required by security considerations, contractual obligations, or notice on a specific document.

REPORT DOCUMENTATION PAGE

1a. REPORT SECURITY CLASSIFICATION Unclassified		1b. RESTRICTIVE MARKINGS	
2a. SECURITY CLASSIFICATION AUTHORITY		3. DISTRIBUTION/AVAILABILITY OF REPORT Approved for public release; distribution is unlimited.	
2b. DECLASSIFICATION/DOWNGRADING SCHEDULE			
4. PERFORMING ORGANIZATION REPORT NUMBER(S) ENSS-85-1		5. MONITORING ORGANIZATION REPORT NUMBER(S) ASD-TR-84-5032, Vol I	
6a. NAME OF PERFORMING ORGANIZATION System Survivability Branch	6b. OFFICE SYMBOL (If applicable) ASD/ENSSS	7a. NAME OF MONITORING ORGANIZATION System Survivability Branch ASD/ENSSS	
6c. ADDRESS (City, State and ZIP Code) Wright-Patterson AFB OH 45433-6503		7b. ADDRESS (City, State and ZIP Code) Wright-Patterson AFB OH 45433-6503	
8a. NAME OF FUNDING/SPONSORING ORGANIZATION	8b. OFFICE SYMBOL (If applicable)	9. PROCUREMENT INSTRUMENT IDENTIFICATION NUMBER	
8c. ADDRESS (City, State and ZIP Code)		10. SOURCE OF FUNDING NOS.	
		PROGRAM ELEMENT NO.	PROJECT NO.
		TASK NO.	WORK UNIT NO.
11. TITLE (Include Security Classification) Automatic Dynamic Aircraft Modeler (ADAM) Vol I		AFSD0190	
12. PERSONAL AUTHOR(S) Hugh Griffis			
13a. TYPE OF REPORT Final	13b. TIME COVERED FROM Mar 84 to Sept 84	14. DATE OF REPORT (Yr., Mo., Day) 85, Jan, 7	15. PAGE COUNT 31
16. SUPPLEMENTARY NOTATION Users Manual, Vol I; Demonstrated Problems Manual, Vol II; Programmers Manual, Vol III			
COSATI CODES		18. SUBJECT TERMS (Continue on reverse if necessary and identify by block number)	
FIELD	GROUP	SUB GR.	
19. ABSTRACT (Continue on reverse if necessary and identify by block number) <p>The following manual is a description of the input required for Automatic Dynamic Aircraft Modeler (ADAM). ADAM is designed to generate NASTRAN structural models with minimal data or knowledge. The model generated by ADAM includes the executive, case control, and bulk data decks. The model is setup for eigenvalue analysis with the appropriate plotting commands.</p>			
20. DISTRIBUTION/AVAILABILITY OF ABSTRACT UNCLASSIFIED UNLIMITED <input checked="" type="checkbox"/> SAME AS RPT <input type="checkbox"/> DTIC USERS <input type="checkbox"/>		21. ABSTRACT SECURITY CLASSIFICATION Unclassified	
22a. NAME OF RESPONSIBLE INDIVIDUAL Hugh Griffis		22b. TELEPHONE NUMBER (Include Area Code) (513) 255-2821	22c. OFFICE SYMBOL ASD/ENSSS

TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>
I	Introduction	1
II	Input Parameters Format	2
III	Definitions of Input Parameters	5
IV	Appendix A - Non Structural Mass	22
V	Appendix B - Skin Tapering	23
VI	Appendix C - Mode Shape Chart	24
VII	Appendix D - Flow Diagram	25
VIII	Appendix E - Job Control Language	26

DTIC
ELECTRONIC
S MAR 14 1985

B



Accession	
NTIS	✓
PER CALL JC	
Availability Codes	
Dist	Special
A-1	

LIST OF ILLUSTRATIONS

<u>Figure</u>	<u>Title</u>	<u>Page</u>
1	Body Geometric Definitions	6
2	Body Boundary Conditions	8
3	Wing Geometric Definitions	11
4	Wing Boundary Conditions	15
5	Composite Fiber Orientation	20
6	Skin Tapering	23
7	Mode Shape Chart	24
8	Flow Diagram	25

I Introduction

ADAM's documentation is in three volumes: Users Manual, Demonstrated Problems Manual, and Programers Manual. Users Manual contains the input format and description of variables. Demonstrated Problems Manual contains example inputs to ADAM, example outputs of the summary table, and plots of the NASTRAN models generated by ADAM. The Programers Manual contains a listing of ADAM.

Input is in four groups and is illustrated in Appendix D. Group A states the number and type of components. Group B contains all body data. Group C contains all wing data. Group D contains concentrated point mass data. Group B and C has structural and non-structural distributed panel/rod mass data (see Appendix A).

ADAM's output, tape 21, is a complete NASTRAN model. The NASTRAN model is designed for Normal Modes analysis. A plot file is automatically generated so that the first ten eigenvectors or modeshapes can be plotted. A summary table of the input with user warning messages and a card count are on tape 6.

11 INPUT PARAMETERS FORMAT

GROUP	STEP	PARAMETERS	FORMAT
<u>GROUP A</u>	1	ERROR	11F6.2
	2	NBODY, NHING, NMASS	4(I2,4X)
<u>GROUP B</u>	3	TITLE	8A10
	4	X0,Y0, Z0	11F6.2
	5	NANGLE, NFRAME	4(I2,4X)
	6	XFRAME, CAMBER	11F6.2
	7	(ANGLE(I), I=1, NANGLE)	11F6.2
	8	(RADOUT(I), I=1, NANGLE)	11F6.2
	9	(RADIN(I), I=1, NANGLE)	11F6.2
	10	IDOF, IKIPAN, IKIPFR, NCG	4(I2, 4X)
	11	PGAUGE, PE, PNU, PMASS	F6.2,E6.1,F6.2,E6.1
12	RGAUGE, RE, RNU, RMASS, (RTYPE(I), I=1, NANGLE)	F6.2,E6.1,F6.2,E6.1,11A1	
13	SGAUGE, SE, SNU, SMASS, (STYPE(I), I=1, NFRAME)	F6.2,E6.1,F6.2,E6.1,11A1	
14	CGAUGE, CE, CNU, CMASS, XNSM	F6.2,E6.1,F6.2,2E6.1	

IF STEPS 6 THRU 9 ARE REPEATED NFRAME TIMES (DEFINED ON STEP 5), THEN GO TO STEP 10, OTHERWISE GO TO STEP 6 B.

IF STEPS 3 THRU 14 ARE REPEATED NBODY TIMES (DEFINED ON GROUP A STEP 2), THEN GO TO GROUP C, OTHERWISE GO TO 3 B.

GROUP C	3	TITLE	8A10
4		XO, YO, ZO, CRO, SO, ALO, ATO, ANGO, WNGDIH	11F6.2
5		NRB, NSP	4(I2,4X)
6		(ANRB, I=1, NRB)	11F6.2
7		(RN(I), I=1, NRB)	11F6.2
8		(SP(I), I=1, NSP)	11F6.2
9		NSYM, ZTYPE	4(I2,4X)
10		(Z1(I,1), I=1, NSP)	11F6.2
11		(Z1(I,NRB), I=1,NSP)	11F6.2
IF NSYM=-1 (DEFINED ON STEP 9), THEN GO TO STEP 14, OTHERWISE GO TO STEP 12 P.			
12		(Z2(I,1) I=1, NSP)	11F6.2
13		(Z2(I,NRB), I=1,NSP)	11F6.2
14		IDOF, IKIPRB, IKIPSP, ISKIN, IRRROT	5(I2,4X)
15		PGAUGE, PE, PNU, PMASS	F6.2,E6.1,F6.2,E6.1
16		RGauge, RE, RNU, RMASS, (RTYPE(I), I=1, NRB)	F6.2,E6.1,F6.2,F6.1,11A1
17		SGAUGE, SE, SNU, SMASS, (STYPE(I), I=1, NSP)	F6.2,E6.1,F6.2,E6.1,11A1
18		CGAUGE, CE, CNU, CMASS, XNSM, DGAUGE, EGAUGE	F6.2,E6.1,F6.2,2E6.1,2F6.2
IF CGAUGE < 0 (DEFINED ON STEP 18), THEN GO TO STEP 19, OTHERWISE GO TO NEXT NOTE.			
19		NELT, TTH, BTH	2I,4X,?F6.2
20		(TTHICK(I), I=1, NELT)	11F6.2
21		(BTHICK(I), I=1, NELT)	11F6.2

22 (TTHETA(I), I=1, NELT) 11F6.2
 23 (BTHETA(I), I=1, NELT) 11F6.2
 24 EX, EY, XYNU, YXNU, G33 2E6.2,2F6.2,E6.2


IF STEPS 3 THRU 24 ARE REPEATED NMING TIMES (DEFINED ON GROUP A STEP 2), THEN GO TO GROUP D,
 OTHERWISE GO TO STEP 3 C.

<u>GROUP D</u>		TITLE	8A10
3			
4	XA, YA, ZA, XYZM, AI11, AI21, AI22, AI31, AI32, AI33		11E6.2

IF STEP 4 IS REPEATED NMASS TIMES (DEFINED ON GROUP A STEP 2), THEN STOP, OTHERWISE GO TO STEP 4 D.

III DEFINITIONS OF INPUT PARAMETERS

<u>GROUP</u>	<u>STEP</u>	<u>PARAMETER</u>	<u>DEFINITIONS IN ORDER OF USE</u>
<u>GROUP A</u>	1	ERROR	COMBINES GRID POINTS WHICH ARE + ERROR DISTANCE APART. WARNING, IF ERROR IS TOO LARGE UNDESIRE COMBINATION WILL RESULT. TAPE 6 SUMMARY TABLE DENOTES ERROR IS TOO LARGE WHEN "ELEMENT DEGENERATES INTO A TRIANGLE" IS PRINTED.
	2	NBODY	TOTAL NUMBER OF BODY SECTIONS MODELED.
		NWING	TOTAL NUMBER OF WING SECTIONS MODELED.
		NMASS	TOTAL NUMBER OF MASS POINTS MODELED.
<u>GROUP B</u>	3	TITLE	USER COMMENT CARD FOR EACH BODY.
	4	XO	X-COORDINATE TO POSITION FRAMES.
		YO	Y-COORDINATE TO POSITION FRAMES.
		ZO	Z-COORDINATE TO POSITION FRAMES.
	5	NANGLE	NUMBER OF ANGLES PER FRAME (<22).
		NFRAME	NUMBER OF FRAMES (<22).
	6	XFRAME	X LOCATION OF FRAME RELATIVE TO XO. Z LOCATION OF CENTER RELATIVE TO ZO.
7	CAMBER	ANGLE (IN DEGREES) WHEN LONGERONS ARE DEFINED (POSITIVE Z AXIS IS 0 DEGREES).	



Isometric View of Section AA-BB

FIGURE 1 BODY GEOMETR DEF . TIONS

8 RADOUI(I) OUTER RADIUS OF FRAME.
9 RADIN(I) INNER RADIUS OF FRAME.

IF STEPS 6 THRU 9 ARE REPEATED NFRAME TIMES (DEFINED ON STEP 5), THEN GO TO STEP 10, OTHERWISE
GO TO STEP 6 B.

10 IDOF DEGREES OF FREEDOM REQUIRED FOR ASET1 CARDS WHICH USES
 GUYAN REDUCTION.

X=1, Y=2, Z=3

GUYAN REDUCTION NOT USED FOR RIGID BODIES.

IF IDOF=7, THEN GENERATE SPC1 CARDS FOR A FIXED BODY.

IF IDOF=8, THEN GENERATE ASET1 AND SPC1 CARDS FOR A
CENTERLINE BODY, WITH SYMMETRIC BOUNDARY CONDITIONS.

IF IDOF=9, THEN GENERATE ASET1 AND SPC1 CARDS FOR A

CENTERLINE BODY, WITH ANTI-SYMMETRIC BOUNDARY CONDITIONS.

IKIPAN THE NUMBER OF LONGERONS SKIPPED. SKIPPED LONGERONS DO NOT HAVE
 AN ACTIVE DEGREE OF FREEDOM, SEE APPENDIX C.


IKIPFR THE NUMBER OF FRAMES SKIPPED. SKIPPED FRAMES DO NOT HAVE
 AN ACTIVE DEGREE OF FREEDOM, SEE APPENDIX C.

NCG FRAME NUMBER TO BE FIXED. CENTER OF GRAVITY IS AT THIS POINT.

11 PGAUGE CROSS - SECTIONAL AREA OF EACH POST, FRAME AND LONGERONS
 CAPS (USE .1 INCH FOR TYPICAL AIRCRAFTS).

AI21	MOMENT OF INERTIA	(I21) DEFAULT IS 0.0 .
AI22	MOMENT OF INERTIA	(I22) DEFAULT IS 0.0 .
AI31	MOMENT OF INERTIA	(I31) DEFAULT IS 0.0 .
AI32	MOMENT OF INERTIA	(I32) DEFAULT IS 0.0 .
AI33	MOMENT OF INERTIA	(I33) DEFAULT IS 0.0 .

IF STEP 4 IS REPEATED NMASS TIMES (DEFINED ON GROUP A STEP 2), THEN STOP, OTHERWISE GO TO STEP 4 D.



Top view of wing planform. The stacking order and offset from the neutral axis is not used for in-plane analysis. The fiber orientation angle for each layer is used and is described from the reference angle TH.

FIGURE 5 COMPOSITE FIBER ORIENTATION

21 BTHICK(1) THICKNESS (IN) OF EACH LAYER FOR BOTTOM SKIN.

22 TTHETA(1) FIBER ORIENTATION ANGLE (IN DEGREES) OF EACH LAYER FOR TOP SKIN.

23 BTHETA (1) FIBER ORIENTATION ANGLE (IN DEGREES) OF EACH LAYER FOR BOTTOM SKIN.

24 EX ELASTIC MODULUS IN THE DIRECTION OF THE X MATERIAL AXIS.

EY ELASTIC MODULUS IN THE DIRECTION OF THE Y MATERIAL AXIS.

XYNU POISSON'S RATIO FOR TRANSVERSE STRAIN IN THE Y-DIRECTION WHEN STRESS IS APPLIED IN THE X-DIRECTION.

YXNU POISSON'S RATIO FOR TRANSVERSE STRAIN IN THE X-DIRECTION WHEN STRESS IS APPLIED IN THE Y-DIRECTION.

NOTE: (EX/YXNU = EY/YXNU)

G33 SHEAR MODULUS.

IF STEPS 3 THRU 24 ARE REPEATED NNING TIMES (DEFINED GROUP A ON STEP 2), THEN GO TO GROUP D, OTHERWISE GO

GROUP D 3

TITLE USER COMMENT CARD, FOR ALL MASSES.

4

XA ACTUAL X LOCATION OF MASS.

YA ACTUAL Y LOCATION OF MASS.

ZA ACTUAL Z LOCATION OF MASS.

XYZM MASS (LBS-SEC²/IN).

AI11 MOMENT OF INERTIA (I11) DEFAULT IS 0.0 .

IF STYPE (I) = 0, THEN NO ELEMENT IS GENERATED FOR THIS SPAR LOCATION.

IF STYPE (I) = 0, THEN A ELEMENT IS GENERATED FOR THIS SPAR LOCATION.

CGUAGE THICKNESS OF TOP INBOARD SKIN (USE CGUAGE < 0. FOR COMPOSITE SKINS), SEE APPENDIX B.

CE MODULUS OF ELASTICITY (USE 10.3E6 FOR TYPICAL AIRCRAFT MATERIALS) (USE 0. FOR COMPOSITE SKINS).

CNU POISSON'S RATIO (USE 0.33 FOR TYPICAL AIRCRAFT MATERIAL) (USE 0. FOR COMPOSITE SKINS).

CMASS MASS (USE 2.5E-4 LBS-SEC²/IN⁴ FOR TYPICAL AIRCRAFT MATERIAL).

XNMS NON STRUCTURAL MASS DENSITY (LBS-SEC²/IN⁴), SEE APPENDIX A.

DGUAGE THICKNESS OF TOP OUTBOARD SKIN, SEE APPENDIX B.

EGUAGE THICKNESS OF BOTTOM INBOARD SKIN, SEE APPENDIX B.

IF C GUAGE < 0, (DEFINED ON STEP 18), THEN GO TO STEP 19, OTHERWISE GO TO NEXT NOTE.

19 NELT NUMBER OF ELEMENTS IN LAY UP (≤ 11)

TTH REFERENCE ANGLE (IN DEGREES) FOR TOP SKIN FROM POSITIVE X AXIS.

BTH REFERENCE ANGLE (IN DEGREES) FOR BOTTOM SKIN FROM POSITIVE X AXIS.

20 TTHICK(1) THICKNESS (IN) OF EACH LAYER FOR TOP SKIN.

RGUAGE THICKNESS OF EACH RIB.
 RE MODULUS OF ELASTICITY (UAW 1 .3E6 FOR TYPICAL AIRCRAFT MATERIALS).
 RNU POISSON'S RATIO (USE 0.33 FOR TYPICAL AIRCRAFT MATERIALS)
 RMASS MASS DENSITY (USE 2.5E-4 1BS-SEC²/IN⁴ FOR TYPICAL AIRCRAFT MATERIALS).
 RTYPE(1) SKIP SHEAR PANEL FOR THE Ith RIB; NUMBERING STARTS WITH TIP RIB.

IF RTYPE (I) = 0, THEN NO ELEMENT IS GENERATED FOR THIS RIB LOCATION.

IF RTYPE (I) = 1, THEN AN ELEMENT IS GENERATED FOR THIS RIB LOCATION.

SGUAGE THICKNESS OF EACH SPAR.
 SE MODULUS OF ELASTICITY (USE 10.3 E6 FOR TYPICAL AIRCRAFT MATERIALS).
 SNU POISSON'S RATIO (USE .033 FOR TYPICAL AIRCRAFT MATERIALS).
 SMASS MASS DENSITY (USE 2.5E-41BS-SEC²/IN⁴ FOR TYPICAL AIRCRAFT MATERIALS).
 STYPE SKIP SHEAR PANEL FOR THE Ith SPAR; NUMBERING STARTS WITH THE TRAILING EDGE SPAR.

IKIPRB THE NUMBER OF RIBS SKIPPED. SKIPPED RIBS DO NOT HAVE AN ACTIVE DEGREE OF FREEDOM, SEE APPENDIX C.

IKIPSP THE NUMBER OF SPARS SKIPPED. SKIPPED SPARS DO NOT HAVE AN ACTIVE DEGREE OF FREEDOM, SEE APPENDIX C.

ISKIN NUMBER OF SKIN SURFACES TO INCLUDE IN THE ACTIVE DEGREE OF FREEDOM.
 IF ISKIN =2, THEN THE UPPER AND LOWER SKINS ARE INCLUDED.
 IF ISKIN =1, THEN THE UPPER SKIN ONLY IS INCLUDED.


IRBROT RIB ROTATION INDICATOR.
 IF IRBOT = 1, THEN THE FIRST RIB WILL NOT ROTATE.
 IF IRBOT = 0, THEN ALL RIBS ARE ROTATED.

PGAUGE CROSS - SECTIONAL AREA OF EACH POST, SPAR AND RIB CAPS. (USE .1 INCH FOR TYPICAL AIRCRAFT).

PE MODULUS OF ELASTICITY (USE 10.3E6 FOR TYPICAL

PNU POISSON'S RATIO (USE 0.33 FOR TYPICAL AIRCRAFT MATERIALS

PMASS MASS DENSITY (USE 2.5E-4 LBS-SEC² /IN⁴ FOR TYPICAL AIRCRAFT MATERIALS).



Cross section view looking from leading to trailing edge of wing section. The arrows, \downarrow , denote the direction of the active degree of freedom. The squares, \square , denote the apex. The dots, \bullet , denote the point is fixed. If IDOF is equal to 8, 9 or 10, the apex must be on the centerline.

FIGURE 4 WING BOUNDARY CONDITIONS

Z DIRECTION, AND IDOF =2 FOR VERTICAL TAILS BENDING IN THE
Y DIRECTION).

X=1, Y=2, Z=3,

GUYAN REDUCTION NOT USED FOR WING BOX CARRY THRU.

IF IDOF=7, THEN GENERATE SPC1 CARDS FOR A WING BOX CARRY
THRU WHICH IS CONNECTED TO A CENTERLINE BODY AND
CONNECTED TO A WING. LAST TWO RIBS ARE FREE, ALL OTHERS ARE
FIXED. THE (NRB-1)TH RIB IS CONNECTED TO THE CENTERLINE
BODY AND THE (NRB)TH RIB IS CONNECTED TO A WING.

WHEN IDOF=8, 9, OR 10, THEN WNGDIH=+90 DEGREES. THE TOP
SURFACE IS ROTATED TO THE CENTERLINE. ALL TOP SURFACE
Z1(I,1) VALUES SHOULD EQUAL 0.0.

IF IDOF=8, THEN GENERATE SPC1 AND ASET1 CARDS FOR A
CENTERLINE WING, WITH SYMMETRIC BOUNDARY CONDITIONS.

IF IDOF=9, THEN GENERATE SPC1 AND ASET1 CARDS FOR A
CENTERLINE WING, WITH ANTI-SYMMETRIC BOUNDARY CONDITIONS.

IF IDOF=10, THEN GENERATE SPC1 CARDS FOR A CENTERLINE WING
BOX CARRY THRU WHICH IS CONNECTED TO A CENTERLINE BODY AND
CONNECTED TO A CENTERLINE WING. LAST TWO RIBS ARE FREE, ALL
OTHERS ARE FIXED. THE (NRB-1)TH RIB IS CONNECTED TO THE
CENTERLINE BODY AND THE (RNB)TH RIB IS CONNECTED TO A
CENTERLINE WING.

FRACTION OF THE CHORD, REFERENCED FROM THE LEADING EDGE).

9 NSYM OPTION TO HAVE A SYMMETRICAL STRUCTURAL BOX:

IF XSYM = -1, THEN ZTOP = -ZBOTTOM.

IF ZSYM = 0, THEN ZBOTTOM DESCRIBED BY STEPS 10 AND 11.

ZTYPE OPTION TO SUPPLY AN ACTUAL/SCALED Z-COORDINATES:

IF ZTYPE = 1, THEN USE ACTUAL Z-COORDINATES.

IF ZTYPE = 0, THEN NONDIMENSIONAL Z-COORDINATES ARE GIVEN AND INTERNALLY ARE MULTIPLIED BY THE CHORD.

10 Z1(I, 1) ARRAY OF Z-COORDINATES FOR THE TOP SURFACE FOR THE FIRST

RIB IN THE STRUCTURAL BOX (AIRFOIL SHAPE).

11 Z1(I, NRB) ARRAY OF Z-COORDINATES FOR THE TOP SURFACE FOR THE LAST RIB
IN THE STRUCTURAL BOX (AIRFOIL SHAPE).


IF NSYM = -1 (DEFINED ON STEP 9), THEN GO TO STEP 14, OTHERWISE GO TO STEP 12 C.

12 Z2(I,1) ARRAY OF Z-COORDINATES FOR THE BOTTOM SURFACE FOR THE
FIRST RIB IN THE STRUCTURAL BOX.

13 Z2(I, NRB) ARRAY OF Z-COORDINATES FOR THE BOTTOM SURFACE FOR THE LAST
RIB IN THE STRUCTURAL BOX.

14 IDOF DEGREES OF FREEDOM REQUIRED FOR ASET1 CARDS WHICH USES
GUYAN REDUCTION. (USE IDOF=3 FOR WINGS BENDING IN THE

CRO	ROOT CHORD OF THE WING.
SO	SEMI-SPAN OF THE WING.
ALO	LEADING EDGE SWEEP ANGLE (IN DEGREES).
ATO	TRAILING EDGE SWEEP ANGLE (IN DEGREES).
ANGO	ANGLE (IN DEGREES) WHICH RIBS MAKE WITH THE X-AXIS. (ANGO = 0.0 IF THE RIBS ARE PARALLEL TO THE X-AXIS AND A POSITIVE NUMBER, OTHERWISE.)
WNGDIH	WING DIHEDRAL ANGLE (IN DEGREES) ROTATED ABOUT APEX. IF WING DIHERAL IS NEGATIVE THE APEX MUST BE ON THE BOTTOM SURFACE. IF WING DIHERAL IS POSITIVE THE APEX MUST BE ON THE TOP SURFACE. IF WNGDIH EQUALS +90 DEGREES THE WING IS A VERTICAL WING.
NRB	TOTAL NUMBER OF RIBS IN THE STRUCTURAL BOX (<22).
NSP	TOTAL NUMBER OF SPARS IN THE STRUCTURAL BOX (<22). (USE ODD NUMBERS FOR NRB AND NSP TO HAVE ACTIVE DEGREES OF FREEDOM ON WING BOX EDGES).
ANRB(I)	ARRAY WHICH SPECIFIES THE RIB ANGLE (IN DEGREES), REFERENCED FROM FIRST SPAR AT RIB(I)). RIB(I) IS ROTATED ANGO DEGREES FROM THE X-AXIS AND MODIFIED BY ANRB(I).
RN(I)	ARRAY WHICH SPECIFIES THE LOCATIONS OF THE RIBS (AS FRACTIONS OF THE SPAN, REFERENCED FROM THE ROOT CHORD).
SP(I)	ARRAY WHICH SPECIFIES THE LOCATIONS OF THE SPAR (AS DECIMAL



Top view of wing planform. If pt.1 is rotated such that pt.1 equals pt.2, the quadrilaterals degenerate into triangles.

FIGURE 3 WING GEOMETRIC DEFINITIONS

MATERIALS).

STYPE SKIP SHEAR PANEL FOR THE i th FRAME; NUMBERING STARTS WITH THE TRAILING EDGE FRAME.

IF STYPE (I) = 0, THEN NO ELEMENT IS GENERATED FOR THIS FRAME LOCATION.

IF STYPE (I) = 1, THEN AN ELEMENT IS GENERATED FOR THIS FRAME LOCATION.

THICKNESS OF SKIN.

MODULUS OF ELASTICITY (USE 10.3E6 FOR TYPICAL AIRCRAFT MATERIALS).

POISSON'S RATIO (USE 0.33 FOR TYPICAL AIRCRAFT MATERIAL).

MASS DENSITY (USE 2.5E-4 LBS-SEC²/IN⁴ FOR TYPICAL AIRCRAFT MATERIAL).

NON STRUCTURAL MASS DENSITY (LBS-SEC²/IN⁴), SEE APPENDIX A

IF STEPS 3 THRU 14 ARE REPEATED NBODY TIMES (DEFINED ON GROUP A, STEP 2), THEN GO TO GROUP C, OTHERWISE GO TO STEP 3 B.

USER COMMENT CARD, FOR EACH WING.

X-COORDINATE OF THE APEX POINT OF THE WING (OR TAIL).

Y-COORDINATE OF THE APEX POINT OF THE WING (OR TAIL).

Z-COORDINATE OF THE APEX POINT OF THE WING (OR TAIL).

CGAUGE

CE

CNU

CMASS

XNSM

TITLE

X0

Y0

Z0

GROUP C 3

4

PE MODULUS OF ELASTICITY (USE 10.3E6 FOR TYPICAL AIRCRAFT MATERIALS).

PNU POISSON'S RATIO (USE 0.33 FOR TYPICAL AIRCRAFT MATERIALS).

PMASS MASS DENSITY (USE 2.5E-4 LBS-SEC²/IN⁴ FOR TYPICAL AIRCRAFT MATERIALS).

RGAGE THICKNESS OF EACH STRINGER.

RE MODULUS OF ELASTICITY (USE 1 .3E6 FOR TYPICAL AIRCRAFT MATERIALS).

RNU POISSON'S RATIO (USE 0.33 FOR TYPICAL AIRCRAFT MATERIALS).

RMASS MASS (USE 2.5E-4 LBS-SEC²/IN FOR TYPICAL AIRCRAFT MATERIALS).

RTYPE(I) SKIP SHEAR PANEL FOR THE Ith RIB; NUMBERING STARTS WITH FIRST LONGERONS.

IF RTYPE(I) = 0, THEN NO ELEMENT IS GENERATED FOR THIS LONGERONS LOCATION.

IF RTYPE (I) = 1, THEN A ELEMENT IS GENERATED FOR THIS LONGERONS LOCATION.

SGAUGE THICKNESS OF EACH FRAME.






SE MODULUS OF ELASTICITY (USE 10.3 E6 FOR TYPICAL AIRCRAFT MATERIALS).

SNU POISSON'S RATIO (USE 0.33 FOR TYPICAL AIRCRAFT MATERIALS)

SMASS MASS DENSITY (USE 2.5E-4 LBS-SEC²/IN⁴ FOR TYPICAL AIRCRAFT MATERIALS).

12

13



User defined active degree of freedom:

- 1 for X direction
- 2 for Y direction
- 3 for Z direction

All points are fixed

$$\text{IDOF} = 1, 2, 3 \quad \text{IDOF} = 7$$

The centerline is fixed in the X and Y direction.

Centerline has active degree of freedom in Z direction. All other points have an active degree of freedom in the Y direction.

$$\text{IDOF} = 8$$

The centerline is fixed in the X and Z direction.

Centerline has active degree of freedom in Y direction. All other points have an active degree of freedom in the Z direction.

$$\text{IDOF} = 9$$

The arrows, \blacktriangledown , denote the direction of the active degree of freedom. The squares, \square , denote APEX. The dots, \bullet , denote the point is fixed.

FIGURE 2 BODY BOUNDARY CONDITIONS


APPENDIX A

Non Structural Mass Density, XNSM is used in Group B and C. This parameter is designed to distribute non structural mass based upon the volume of wings or body.


The input to ADAM is:

$$\frac{\text{density}}{\text{gravity}} = \frac{\text{lbs/in}^3}{\text{in/sec}^2} = \frac{.1}{386}$$

ADAM calculates the thickness for wings:



ADAM calculates the thickness for bodies:



The input to NASTRAN for homogenous skins is:

$$(XNSM) * (\text{Thickness}) = (\text{lbs} - \text{sec}^2/\text{in}^3)$$

The input to NASTRAN for composite skins is:

$$(XNSM) * (\text{Thickness}/N_{elt}) = (\text{lbs} - \text{sec}^2/\text{in}^3) \text{ where } N_{elt} \text{ equals the number of stacked elements.}$$

NASTRAN internally distributes the mass to grid points:

$$(\text{lbs} - \text{sec}^2/\text{in}^3) * (\text{in}^2) = (\text{lbs} - \text{sec}^2/\text{in})$$

APPENDIX B




FIGURE 6 SKIN TAPERING

APPENDIX C




FIGURE 7 MODE SHAPE CHART

APPENDIX D




FIGURE 8 FLOW DIAGRAM

APPENDIX E

Execution of ADAM on CDC at WPFB:

/ Attach, BADAM/UN=E780403

/ Get, Data=Your File

/ BADAM

The NASTRAN data is on Tape 21.

The input summary table is on Tape 6.

Execution of EZPL on CDC at WPFB:

/ Attach, EZPL=EZPLTEK/UN=D740292

/ Rewind, Tape21

/ Copy, Tape21, Tape5

/ Rewind, Tape5

/ EZPL

END

FILMED

4-85

DTIC