

LOAN DOCUMENT

PHOTOGRAPH THIS SHEET

①

DTIC ACCESSION NUMBER

LEVEL

INVENTORY

Operations & Maintenance Manual . . .

DOCUMENT IDENTIFICATION

Oct 97

DISTRIBUTION STATEMENT A
Approved for Public Release
Distribution Unlimited

DISTRIBUTION STATEMENT

ACCESSION FOR	
NTIS	GRAM
DTIC	TRAC
UNANNOUNCED	
JUSTIFICATION	
BY	
DISTRIBUTION/	
AVAILABILITY CODES	
DISTRIBUTION	AVAILABILITY AND/OR SPECIAL
<i>A-1</i>	

DISTRIBUTION STAMP

DATE ACCESSIONED

DATE RETURNED

20001214 097

DATE RECEIVED IN DTIC

REGISTERED OR CERTIFIED NUMBER

PHOTOGRAPH THIS SHEET AND RETURN TO DTIC-FDAC

H
A
N
D
L
E

W
I
T
H

C
A
R
E

**OPERATIONS AND MAINTENANCE MANUAL
FOR EXPANDED BIOVENTING SYSTEM**

SITE SS-41

FORMER BUILDING NO. 93 (FUEL PUMPING STATION NO. 3)

CHARLESTON AIR FORCE BASE

CHARLESTON, SOUTH CAROLINA

PREPARED FOR:

AIR FORCE CENTER FOR ENVIRONMENTAL EXCELLENCE

TECHNOLOGY TRANSFER DIVISION

BROOKS AIR FORCE BASE

SAN ANTONIO, TEXAS

AND

437 CES/CEV

CHARLESTON AIR FORCE BASE

CHARLESTON, SOUTH CAROLINA

OCTOBER 1997

AQM01-03-0527

DEFENSE TECHNICAL INFORMATION CENTER REQUEST FOR SCIENTIFIC AND TECHNICAL REPORTS

Title AFCEE Collection

1. Report Availability (Please check one box)

- This report is available. Complete sections 2a - 2f.
- This report is not available. Complete section 3.

2a. Number of Copies Forwarded

Leach

2b. Forwarding Date

July/2000

2c. Distribution Statement (Please check ONE box)

DoD Directive 5230.24, "Distribution Statements on Technical Documents," 18 Mar 87, contains seven distribution statements, as described briefly below. Technical documents MUST be assigned a distribution statement.

- DISTRIBUTION STATEMENT A:** Approved for public release. Distribution is unlimited.
- DISTRIBUTION STATEMENT B:** Distribution authorized to U.S. Government Agencies only.
- DISTRIBUTION STATEMENT C:** Distribution authorized to U.S. Government Agencies and their contractors.
- DISTRIBUTION STATEMENT D:** Distribution authorized to U.S. Department of Defense (DoD) and U.S DoD contractors only.
- DISTRIBUTION STATEMENT E:** Distribution authorized to U.S. Department of Defense (DoD) components only.
- DISTRIBUTION STATEMENT F:** Further dissemination only as directed by the controlling DoD office indicated below or by higher authority.
- DISTRIBUTION STATEMENT X:** Distribution authorized to U.S. Government agencies and private individuals or enterprises eligible to obtain export-controlled technical data in accordance with DoD Directive 5230.25, Withholding of Unclassified Technical Data from Public Disclosure, 6 Nov 84.

2d. Reason For the Above Distribution Statement (in accordance with DoD Directive 5230.24)

2e. Controlling Office

HQ AFUEG

2f. Date of Distribution Statement Determination

15 Nov 2000

3. This report is NOT forwarded for the following reasons. (Please check appropriate box)

- It was previously forwarded to DTIC on (date) and the AD number is
- It will be published at a later date. Enter approximate date if known.
- In accordance with the provisions of DoD Directive 3200.12, the requested document is not supplied because:

Print or Type Name

Laura Peña

Telephone

210-536-1431

Signature

Laura Peña

(For DTIC Use Only)

AQ Number

1401-03-0527

TABLE OF CONTENTS

	<u>Page</u>
SECTION 1 - INTRODUCTION	1-1
SECTION 2 - SYSTEM DESCRIPTION.....	2-1
2.1 Blower System	2-1
2.2 Monitoring and Flow Control Equipment	2-1
2.2.1 Monitoring Gauges	2-1
2.2.2 Flow Control Equipment	2-2
SECTION 3 - SYSTEM MAINTENANCE	3-1
3.1 Blower/Motor.....	3-1
3.2 Air Filter.....	3-1
3.3 Maintenance Schedule	3-1
3.4 Major Repairs.....	3-2
SECTION 4 - SYSTEM MONITORING	4-1
4.1 Blower Performance Monitoring	4-1
4.1.1 Vacuum/Pressure	4-1
4.1.2 Temperature	4-1
4.2 Monitoring Schedule.....	4-1
4.3 Reporting Monitoring Results	4-1
APPENDIX A Record Drawings	
APPENDIX B Regenerative Blower Information	
APPENDIX C Data Collection Sheets	

SECTION 1

INTRODUCTION

This Operations and Maintenance (O&M) Manual has been created as a guide for monitoring and maintaining the performance of the expanded bioventing blower systems and vent well plumbing at Site SS-41 (Former Building No. 93 Fuel Pumping Station 3), Charleston AFB, South Carolina. Record drawings of the expanded bioventing system installed at Site SS-41 are provided in Appendix A.

Bioventing is the forced injection of fresh air, or withdrawal of soil gas, to enhance the supply of oxygen in subsurface soils to promote *in situ* bioremediation of organic fuel compounds. A blower system is used to inject air into the soil, thereby supplying fresh atmospheric air (containing approximately 20.8 percent oxygen) to fuel-contaminated soils. Once oxygen is provided to the subsurface, existing soil bacteria aerobically metabolize the fuel residuals. Aerobic biodegradation is much more efficient than anaerobic biodegradation, which occurs in oxygen-depleted soils.

A pilot-scale bioventing system was installed and operated by Parsons ES at the site from July 1994 through August 1995. The pilot scale system consisted of two vertical vent wells (VWs) and four multi-depth soil vapor monitoring points (MPs) installed on the west side of the former underground storage tank (UST) system. Pilot test monitoring results showed that a large portion of the site was not being affected by the air injection, especially areas north and east of the pilot-scale system.

Parsons ES designed and installed a full-scale bioventing system to address the soil oxygen deficiency in areas with remaining soil contamination that were not treated by the pilot-scale system. The full-scale air injection bioventing system consists of two air injection blowers, ten new vertical VWs, ten new soil gas MPs, and associated piping. Existing pilot system VWs and MPs were incorporated into the full-scale system. The new system was installed at the site from February, 1997 through May, 1997. The air injection rates of the full-scale bioventing system were optimized at each vent well to assure adequate aeration of contaminated soils to promote aerobic biodegradation. Soil gas monitoring performed in May and June 1997, after several weeks of operating the new VWs, indicates the majority of the area designated for bioventing treatment is receiving sufficient oxygen. Most of these subsurface soils are receiving oxygen concentrations greater 15%, although several locations have shown less significant increases in soil gas oxygen content.

Charleston AFB personnel are responsible for routine monitoring of the bioventing system. Parsons ES has trained Charleston AFB personnel on the maintenance requirements of this plan. If significant problems are encountered with the operation of the system, Parsons ES should be notified so repairs can be made. Under the Extended Bioventing Project Option 1, Parsons ES is responsible for system repair for a 1-year period after system startup. Parsons ES will retain responsibility for system repair until May 1998. Should the bioventing system cease to operate or develop a significant problem, please call the Parsons ES Site Manager, Mr. Grant Watkins, at (919) 677-0080, or Mr. John Ratz, at (303) 831-8100. If the system ceases to operate, first have a base electrician verify that adequate power is being supplied to the bioventing system blower motor prior to notifying Parsons ES.

SECTION 2

SYSTEM DESCRIPTION

2.1 BLOWER SYSTEM

Two Gast® R5125Q blowers, each powered by a 2-horsepower direct drive motor, were installed at Site SS-41 on April 24-25, 1997. Each blower was installed in a separate enclosure, with both enclosures located on a single concrete pad. The R5125Q blower is rated as having a maximum flow rate of 160 standard cubic feet per minute (scfm) at open flow and a maximum pressure rating of 55 inches of water. As installed, the blower on the south side of the concrete pad (blower #1) provides air to five vent wells (VW-2 through VW-6) located on the south and east portions of the site. The blower on the north side of the concrete pad (blower #2) supplies air to six vent wells (VW-7 through VW-12), located primarily on the north and west sides of the site.

During initial system startup on May 9, 1997, blower #1 was producing an estimated flow rate of 15 actual cubic feet per minute (acfm) at a pressure of 34 inches of water. Blower #2 was started at a flow rate of 16.5 acfm at a pressure of 34 inches of water. The air injection flow rates were increased at both blowers on May 21-22, 1997 after soil gas monitoring indicated that some areas were not receiving adequate concentrations of soil gas oxygen. Final blower readings representative of longer term system performance were obtained on June 10, 1997. On that date, blower #1 (wells VW-2 through VW-6) was injecting air at 56 acfm at 29 inches of water pressure. Air flow rates to the individual wells ranged from a minimum of 1.9 acfm at VW-3 to a maximum of 22.1 acfm at VW-5. Blower #2 (wells VW-7 through VW-12) was operating at 43 acfm total air flow at 51 inches of pressure. Air flow rates to individual wells connected to the blower #2 ranged from 1.8 acfm at VW-9 to 17.8 acfm at combined wells VW-8/VW-12. Flow was optimized to each VW based on 1) the degree of hydrocarbon contamination present within soils in the vicinity of each VW, 2) the amount of oxygen measured at surrounding MPs following four weeks of operation, and 3) limitations to air injection due to variations in site physical characteristics. Generally, higher flow rates at lower pressures are observed in soils on the south and east part of the site. Air injection flow rates are lower and injection pressures generally are higher on the north end of the site.

The blower systems include an inlet air filter to remove any particulates which are entrained in the inlet air stream and several valves and monitoring gauges which are described in Section 2.2. A schematic of the expanded blower systems installed at Site SS-41 is shown in Appendix A. Corresponding blower performance curves and relevant service information are provided in Appendix B. Blower system data collection sheets for use by base personnel are provided in Appendix C.

2.2 MONITORING AND FLOW CONTROL EQUIPMENT

2.2.1 Monitoring Gauges

The bioventing system is equipped with vacuum, pressure, and temperature gauges, and air velocity measurement ports. Gauges have been installed on the air injection system at the

following locations: a vacuum gauge in the inlet piping and pressure and temperature gauges in the outlet piping on each blower.

2.2.2 Flow Control Equipment

Manual and automatic flow control valves (FCVs) have been installed on the bioventing blower systems. Manual FCVs have been installed in the piping leading to each VW to enable the flow rate to each VW to be adjusted individually. An automatic FCV, or pressure relief valve (PRV), is used to protect each blower system from burning out if pressures rise due to pipe blockage. The PRV is set to bleed off flow at a preset pressure and thus prevent blower outlet pressure from ever exceeding the rated pressure.

An additional FCV (bleed valve) has been installed to control the total air flow out of each blower by releasing excess air flow to the atmosphere. The FCVs have been set by Parsons ES personnel to deliver a calculated amount of air to each VW and should not be adjusted unless directed to do so by Parsons ES personnel.

Each blower systems has also been equipped with air flow measurement ports. These ports consist of brass bushings installed in the outlet piping leading to each VW. These bushings, which should be plugged during system operation, allow the insertion of a thermal anemometer for the measurement of air velocity. These ports are used by Parsons ES for system optimization and should not be opened unless air flow measurements are being collected.

Although the blower systems installed at Site SS-41 are relatively maintenance free, periodic system maintenance is required for proper operation and long life. Recommended maintenance procedures and schedule are described in detail in the instruction manuals included in Appendix B and briefly summarized in this section.

Filter inspection must be performed with the system turned off. Do not change the flow control valve settings (valves have been pre-set for a specific flow rate) before re-starting the blower.

SECTION 3

SYSTEM MAINTENANCE

3.1 BLOWER/MOTOR

The blowers and their motors are relatively maintenance free and should not require any maintenance during the operational period. Both the blowers and motors have sealed bearings and do not require lubrication.

3.2 AIR FILTER

To avoid damage caused by passing solids through the blower, an air filter has been installed in-line before each blower. The paper filter element is accompanied by a polyurethane foam pre-filter. The filter should be checked weekly for the first 2 months of operation. A facility employee should determine the best schedule for filter replacement based on the first 2 months of system monitoring. The polyurethane pre-filters can be washed with lukewarm water and a mild detergent. Paper filter elements should never be washed, and should be disposed of and replaced as necessary. When the vacuum drop across the filter increases by approximately 5 inches of water compared to the vacuum when the filter was new, a dirty filter element should be suspected. Cleaning or replacement of the filter should then be performed. The initial vacuum when the filter element was new was 9 inches of water on Blower #1 (wells VW2-VW6) and 5 inches of water on Blower #2 (VW7-VW12). Therefore, the filters should be cleaned or replaced when the vacuum increases to 14 and 10 inches of water for each blower, respectively. Typical filter element replacement intervals range from 3 to 6 months.

To remove the filter, turn the system off by pushing the electrical disconnect switch (on the adjacent electrical utility pole) to the "off" position. Then, loosen the three clamps or the wing nut on the filter top, lift the metal top off the air filter, and lift the air filter element from the metal housing. Remove the polyurethane pre-filter (if applicable) and wash before replacing.

The filter element is manufactured by Solberg Manufacturing, Inc. in Itasca, Illinois. Their toll free telephone number is 1-800-451-0642. Additional filters can also be obtained through Parsons ES. The Parsons ES contacts are Mr. Grant Watkins, at (919) 677-0080, and Mr. John Ratz, at (303) 831-8100. The part number for the replacement filter element is 30P. Four spare air filter elements have been placed inside each blower enclosure.

3.3 MAINTENANCE SCHEDULE

The following maintenance schedule is recommended for the blower systems. During the initial few months of operation more frequent monitoring is recommended to ensure that any startup problems are quickly corrected. A daily drive-by inspection is recommended during the initial 2 weeks of operation to ensure that the blower system is still operating with no unusual sounds. Thereafter, monitoring inspections every 2 weeks are recommended (see Section 4). Preprinted data collection sheets have been provided to the facility. Extra data collection sheets for recording maintenance activities are provided in Appendix C.

Maintenance Item Maintenance Frequency

Filter Check once every 2 weeks, wash or replace as necessary (see Section 3.3).
Inlet vacuums exceeding 14 inches of water (blower #1) or 10 inches of
water (blower #2) indicates that the filters require cleaning or replacement.

3.4 MAJOR REPAIRS

Regenerative blowers are very reliable when properly maintained. Occasionally, however, a motor or blower will develop a serious problem. If a blower system fails to start, and a qualified electrician verifies that power is available at the blower or starter, Parsons ES should be contacted to arrange for repairs. The Parsons ES contacts are Mr. Grant Watkins, at (919) 677-0080, and Mr. John Ratz, at (303) 831-8100. Parsons ES is responsible for major repairs during the first year of operation.

SECTION 4

SYSTEM MONITORING

4.1 BLOWER PERFORMANCE MONITORING

To monitor the blowers' performance, the vacuum, pressure, and temperature will be measured. These data should be recorded every 2 weeks on a data collection sheet (provided in Appendix C). All measurements should be taken at the same time while each system is running. Because the systems are noisy inside the enclosures, hearing protection should be worn at all times.

4.1.1 Vacuum/Pressure

With hearing protection in place, unlock and open the blower enclosure (the enclosure lids should be supported by the two metal pipes located inside each of the enclosures). Record all vacuum and pressure readings directly from the gauges (in inches of water) for each blower. Record the measurements on the data collection sheet.

4.1.2 Temperature

With hearing protection in place, open the blower enclosures and record the temperature readings directly from the gauges in degrees Fahrenheit (°F). Record the measurements on a data collection sheet (provided in Appendix C). The temperature change can be converted to degrees Celsius (°C) using the formula $^{\circ}\text{C} = (^{\circ}\text{F} - 32) \times 5/9$. Temperatures of the operating blower systems have varied from about 120-150 °F and will change slightly (decrease) once the enclosure lids are opened.

4.2 MONITORING SCHEDULE

The following monitoring schedule is recommended for these systems. During the initial month of operation, more frequent monitoring is recommended to ensure that any start up problems are quickly corrected. Data collection sheets have been provided to assist your data collection and are included in Appendix C.

<u>Monitoring Item</u>	<u>Monitoring Frequency</u>
Vacuum/Pressure	Once every 2 weeks.
Temperature	Once every 2 weeks.

4.3 REPORTING MONITORING RESULTS


System monitoring data sheets should be faxed to the Parsons ES Site Manager, Mr. Grant Watkins (919) 677-0080, once every 2 months. However, if a significant change in the system temperatures or pressures are noted (such as a significant drop or increase in pressure) please call Mr. Watkins immediately. A significant change in system temperature or pressure may be indicative of a problem with the air delivery system or blower.

APPENDIX A
RECORD DRAWINGS

RECORD DRAWINGS FOR
EXPANDED BIOVENTING SYSTEM
SITE SS-41
CHARLESTON AIR FORCE BASE
 PREPARED FOR
AFCEE
JULY 1997

DRAWING INDEX

DRAWING NO.	DESCRIPTION
G-0.1	TITLE SHEET AND SITE LAYOUT
G-0.2	LEGEND AND STANDARD TRENCH DETAILS
G-0.3	VENT WELL AND MONITORING POINT STANDARD DETAILS
G-0.4	BLOWER P & ID
G-0.5	BLOWER PIPING LAYOUT DETAIL
G-0.6	BLOWER SHED FIELD INSTALLATION DETAIL AND BLOWER SHED CONSTRUCTION DETAILS




SITE LAYOUT
SCALE: 1"=30'



PARSONS ENGINEERING SCIENCE, INC. Denver, Colorado (303) 831-8100		AIR FORCE CENTER FOR ENVIRONMENTAL EXCELLENCE (AFCEE) EXPANDED BIOVENTING SYSTEM SITE SS-41 CHARLESTON AIR FORCE BASE	DRAWING NO G-0.1 REV B
Job No. 726876.28242 Designed RLF Drawn JH Checked Reviewed Approved Reg No.	Date 7/11/97 7/19/96	Description RECORD DRAWING 65% DESIGN	By


Rev	Date	Description
B	7/11/97	RECORD DRAWING
A	7/19/96	55X DESIGN

Job No. 726876-28242
 Drawn: JH
 Checked: RAE
 Approved: [Signature]




MONITORING POINT NO.	BOREHOLE DEPTH (T BGS)	UPPER SCREEN INTERVAL (T BGS)	LOWER SCREEN INTERVAL (T BGS)
MPE	7.5	4 - 4.5	6.8 - 7.3
MPF	8	4.5 - 5	7.25 - 7.75
MPG	7.9	4.1 - 4.6	7.1 - 7.6
MPH	6.7	3.8 - 4.1	6.1 - 6.6
MPI	5.7	4.3 - 5.4	NA
MPJ	5.2	4.5 - 5.2	NA
MPK	5.5	4.8 - 5.3	NA
MPL	3.2	4.3 - 4.8	NA
MPM	3.2	2.5 - 3	NA
MPN	5.7	4.8 - 5.3	NA

2. MONITORING POINT (MP) DETAIL
 SCALE: NTS



- NOTES:
- ALL VW's HAD 10 feet NOMINAL SCREEN LENGTH, EXCEPT FOR WELL VW-12 WHICH HAD 5 feet OF SCREEN.
 - WELL VW-8 WAS EQUIPPED WITH 1 1/2" GATE VALVE ON PIPING INSIDE WELL VAULT.

1. VENT WELL (VW) DETAIL
 SCALE: NTS



LEGEND

- ① INLET AIR FILTER - SOLBERG F-30P-150, REPLACEMENT ELEMENT TOP
- ② VACUUM GAUGE - GAST® A4497, 2 1/2" DIA, 0-60" H₂O, 1/4" NPT, LM
- ③ BLOWER - GAST® 2.0HP R5125Q-50, 100 CFM AT 50" H₂O PRESSURE
- ④ TEMPERATURE GAUGE - ASHROFT, 0-250°F, 1/2" NPT, CBM (Part No. Z4606 FROM GRANGER)
- ⑤ PRESSURE GAUGE - WKA 611.10, 2 1/2" DIA., 0-100" H₂O, 1/4" NPT, LM (Part No. 8851810)
- ⑥ AUTOMATIC PRESSURE RELIEF VALVE - GAST® AG258, SET TO RELEASE AT 60" H₂O PRESSURE
- ⑦ MANUAL PRESSURE RELIEF (BLEED) VALVE - 1 1/2" GATE
- ⑧ FLOW MEASURING PORT FITTED WITH PLUG (1/4" x 1/8" NPT BRASS REDUCING BUSHING, 1/8" NPT BRASS PLUG)
- ⑨ FLOW CONTROL VALVE - 1 1/2" GATE
- ⑩ DISCONNECT SWITCH

1 BLOWER PIPING AND INSTRUMENTATION DIAGRAM

SCALE: NTS

Date	Rev	Date	Description
7/19/96	A	7/19/96	65X DESGN
7/11/97	B	7/11/97	RECORD DAMNG

Job No. 726976-28242
 Designed RAF
 Drawn MW
 Checked
 Reviewed
 Approved
 Reg No.
 Denver, Colorado
PARSONS ENGINEERING SCIENCE, INC.
 (303) 851-8100

AIR FORCE CENTER FOR ENVIRONMENTAL EXCELLENCE (AFCEE)
 EXPANDED BIOVENTING SYSTEM
 CHARLESTON AIR FORCE BASE

DRAWING NO	REV
G-0.4	B

BLOWER P & ID

Job No.	72676, 28242
Designed By	RAF
Drawn By	MW
Checked	
Reviewed	
Approved	
Reg No.	7/19/96
Rev	B
Date	7/11/97
Description	RECORD DRAWING
By	





PARSONS ENGINEERING SCIENCE, INC.
 Denver, Colorado (303) 831-8100

AIR FORCE CENTER FOR ENVIRONMENTAL EXCELLENCE (AFCEE)
 EXPANDED BIOVENTING SYSTEM SITES SS-41
 CHARLESTON AIR FORCE BASE

LAYOUT DETAIL
BLOWER PIPING

DRAWING NO. **G-0.5**
 REV. **B**

- NOTES:
1. SHOP CORE HOLES TO PIPING DIMENSIONS
 2. ALL PIPING 1 1/2" DIA. GALVANIZED STEEL, UNLESS OTHERWISE NOTED
 3. SEE DRAWING G-0.6 FOR BLOWER BUILDING DETAILS
 4. PROVIDE 24" MIN CLEARANCE BETWEEN BLOWER SHEDS




Rev	Date	Description
A	7/19/96	85% DESIGN
B	7/17/97	RECORD DRAWING

PARSONS ENGINEERING SCIENCE, INC.
 Denver, Colorado (303) 851-8100


AIR FORCE CENTER FOR ENVIRONMENTAL EXCELLENCE (AFCEE)
 EXPANDED BIOVENTING SYSTEM
 SITE SS-41
 CHARLESTON AIR FORCE BASE

BLOWER SHED FIELD INSTALLATION DETAIL AND BLOWER SHED CONSTRUCTION DETAILS

DRAWING NO **G-0-6** REV **B**




SIDE ELEVATION



FRONT ELEVATION


- NOTES:
- 2' x 2' FRAME CONSTRUCTION
 - FLOOR CONSTRUCTED OF 3/4" EXTERIOR GRADE PLYWOOD
 - ROOF CONSTRUCTED OF 1/2" EXTERIOR GRADE PLYWOOD COVERED WITH PVC VINYL CORRUGATED ROOFING

BLOWER SHED CONSTRUCTION DETAIL
 3/4" = 1'-0"



BLOWER SHED FIELD INSTALLATION DETAIL
 NOT TO SCALE

- NOTES:
- INSTALLED BUILDING CENTRAL ON CONCRETE SLAB WITH ORIENTATION AS SHOWN
 - FIELD SECURED BLOWER SHED TO CONCRETE SLAB AT LOCATIONS BY EXTERIOR ANGLE BRACKETS. BRACKETS SECURED TO SHED WITH WOOD SCREWS AND TO CONCRETE SLAB WITH 4" ANCHOR BOLTS.



TYPICAL MANIFOLD DISCHARGE PIPING LAYOUT
 NOT TO SCALE

APPENDIX B

REGENERATIVE BLOWER INFORMATION

Gast Manufacturing Corp.
P.O. Box 97
Benton Harbor, MI 49023-0097
(616) 926-6171

Model R5125Q-50

Motor Specifications

<u>Phase</u>	<u>HZ</u>	<u>HP</u>	<u>Voltage</u>	<u>Full Load Amps</u>
1	50	2	115 / 230	25 / 12.5

Overall Dimensions

<u>Height</u>	<u>Width</u>	<u>Depth</u>	<u>Net Weight</u>
13.78 in 350 mm	15.50 in 445 mm	13.56 in 344 mm	77 lb 35 kg

Performance

<u>Maximum Vacuum</u>	<u>Maximum Pressure</u>	<u>Maximum Flow</u>
60 inH2O 149 mbar	55 inH2O 137 mbar	160 cfm 272 m³h



SOIL VAPOR EXTRACTION PUMPS - REGENERATIVE BLOWERS

Product Specifications

Model Number	Phase	Hz	Motor Specifications			Max Vac		Max Pressure		Max Flow		Net. Wt.	
			Voltagess	HP	Full Load Amps	"H ₂ O mbar	"H ₂ O mbar	cfm	m ³ /h	lbs	kg		
R3105N-50	Single	50	110/220-240	.33	3-8/1.9-2.0	28	70	31	77	43	73	52	24
		60	115/208-230	0.5	5.2/2.9-2.6	40	100	43	107	53	90		
R4110N-50	Single	50	110/220-240	0.6	9.2/5.2-4.6	35	87	38	95	74	126	60	28
		60	115/208-230	1.0	11.4/6.2-5.6	48	120	51	127	92	156		
R4310P-50	Three	50	220/380	0.6	3.2/1.6	35	87	38	95	74	126	58	27
		60	208-230/460	1.0	3.4-3.3/1.65	48	120	51	127	92	156		
R4P115N-50	Single	50	110/220-240	1.0	15.2/7.6-8	40	100	45	112	112	190	79	36
		60	115/208-230	1.5	18.2/9.7-9.1	60	149	65	162	133	226		
R5125Q-50	Single	60	115/230	2.0	25/12.5	60	149	55	137	160	272	77	35
R5325R-50	Three	50	190-220/380-415	1.5	5.0-4.4/2.5-2.6	47	117	50	125	133	226	75	34
		60	208-230/460	2.0	6.0-5.6/2.8	60	149	65	162	160	272		
R6130Q-50	Single	50	220-240	2.5	14.7-13.5	65	162	75	187	182	309	129	59
		60	230	3.0	16.3	70	174	60	149	215	365		
R6340R-50	Three	50	190-220/380-415	3.0	14.4-13.4/7.2-6.8	65	162	75	187	180	306	112	51
		60	208-230/460	4.0	13-12/6	80	199	100	249	215	365		
R6P155Q-50	Single	50	220-240	4.0	20.8-19.1	65	162	80	199	235	399	243	110
		60	230	5.5	29.9	85	212	95	237	280	476		
R6P355R-50	Three	50	190-220/380-415	4.5	14.9-11/7.45-5.8	65	162	80	199	232	394	233	105
		60	208-230/460	6.0	20-18/9	85	212	100	249	280	476		
R7100R-50	Three	50	190-220/380-415	8.0	20.8-18.9/10.4-9.5	72	179	80	199	350	595	297	134
		60	208-230/460	10.0	26.5-24/12	90	224	90	224	420	714		

NOTICE: Performance specifications subject to change without notice.

VACUUM





Free software identifies best Gast blowers for soil and groundwater remediation

Now you can size and select regenerative blowers and accessories for soil and groundwater remediation systems faster, easier and more accurately than ever before. Gast remediation system engineering software does the job and it is yours for the asking. The 3-1/2-inch IBM-compatible disk calculates performance when the blower is operating with both a vacuum and pressure load at the same time. The programs will also compensate for changes in performance from altitude and temperature, helping you identify the optimum Gast blowers for your application.


Call 1-800-952-4278 to receive your free remediation system engineering software.

PRESSURE




SOIL VAPOR EXTRACTION PUMPS - REGENERATIVE BLOWERS


Model R3



Models R6P, R7




Models R4, R4P, R5, R6



Model	Metric (mm)			U.S. Imperial (inches)											
	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
R3105N-50	131	25	12.20	3.25	3.03	11.06	12.75	1.94	3.88	8.06	8.12	9.38	10.15	-	.53
R4110N-50	157	43	15.30	3.75	2.85	12.44	12.31	1.98	3.96	8.86	8.93	10.00	11.73	6.88	.44
R4310P-50	157	43	14.03	3.75	2.84	12.44	12.31	1.98	3.96	8.86	8.93	10.00	11.73	6.88	.44
R4P115N-50	177	47	17.41	4.50	3.25	13.93	13.31	2.38	4.75	10.25	10.31	11.75	13.6	6.88	.60
R5125Q-50	178	46	17.50	4.50	3.58	14.22	13.56	2.38	4.75	10.25	10.31	11.75	13.78	6.81	.59
R5325R-50	178	46	16.66	4.50	3.58	14.22	13.56	2.38	4.75	10.25	10.31	11.75	13.78	7.19	.59
R6130Q-50	197	49	20.13	5.50	3.85	15.89	15.30	2.46	4.92	11.38	11.42	12.96	15.38	8.56	.52
R6340R-50	197	49	18.82	5.50	3.85	15.89	15.17	2.46	4.92	11.38	11.42	12.96	15.34	8.56	.52
R6P155Q-50	248	80	23.7	5.51	5.39	17.25	16.87	2.50	5.00	-	11.42	12.80	18.21	10.12	.50
R6P355R-50	248	80	21.80	5.51	5.39	17.25	16.87	2.50	5.00	-	11.42	12.80	18.21	10.12	.50
R7100R-50	274	92	22.72	8.50	8.33	21.46	18.00	3.94	7.88	-	14.76	16.14	20.02	10.12	.56

Notice: Specifications subject to change without notice.

REGENAIR® R5 Series



MODEL R5325A-2
65" H₂O MAX. PRESSURE, 160 CFM OPEN FLOW

PRODUCT FEATURES

- Oilless operation
- TEFC motor mounted
- Can be mounted in any plane
- Rugged construction/low maintenance

COMMON MOTOR OPTIONS

- 115/208-230V, 60 Hz, single phase
- 208-230/460V, 60 Hz; 190-220/380-415V, 50 Hz, three phase
- 575V, 60 Hz, three phase

RECOMMENDED ACCESSORIES


- Pressure gauge AE133
- Filter AG338
- Muffler AJ121D
- Relief valve AG258

Various brand name motors are used on any model at the discretion of Gast Mfg. Corp.

Important Notice:

Pictorial and dimensional data is subject to change without notice.

Product Dimensions Metric (mm) U.S. Imperial (inches)





Product Specifications

Model Number	Motor Specs	Full Load Amps	HP	RPM	Max Pressure		Max Flow		Net Wt.	
					"H ₂ O	mbar	cfm	m ³ /h	lbs.	kg
R5325A-2	190-220/380-415-50-3	6.6-6.7/3.3-3.5	1.35	2850	50	125	133	226	65	29,5
	208-230/460-3	6.9/3.45	2.5	3450	65	162	160	272		
R5125-2	115/208-230-60-1	22.4/12.4-11.2	2.5	3450	60	149	160	272	73	33,1


Product Performance (Metric U.S. Imperial)

Black line on curve is for 60 cycle performance.
Blue line on curve is for 50 cycle performance.





*Recommended maximum duty.

---- Intermittent duty only.



Post Office Box 97
Benton Harbor, Michigan 49023-0097
Ph: 616/926-6171
Fax: 616/925-8288

Maintenance Instructions for Gast Standard Regenerative Blowers



For original equipment manufacturers
special models, consult your local distributor

Gast Rebuilding Centers

Gast Mfg. Corp.
2550 Meadowbrook Rd.
Benton Harbor MI. 49022
Ph: 616/926-6171
Fax: 616/925-8288

Gast Mfg Corp.
505 Washington Avenue
Carlstadt, N. J. 07072
Ph: 201/933-8484
Fax: 201/933-5545


Brenner Fledler & Assoc.
13824 Bentley Place
Cerritos, CA. 90701
Ph: 213/404-2721
Fax: 213/404-7975

Wainbee, Limited
121 City View Drive
Toronto, Ont. Canada M9W 5A9
Ph: 416/243-1900
Fax: 416/243-2336

Wainbee, Limited
215 Brunswick Drive
Pointe Claire, P.Q. Canada H9R 4R7
Ph: 514/697-8810
Fax: 514/697-3070

Gast Mfg. Co. Limited:
Halifax Rd, Cressex Estate
High Wycombe, Bucks HP12 3SN
Ph. 44 494 523571
Fax: 44 494 436588

Japan Machinery Co. Ltd.
Central PO Box 1451
Tokyo 100-91 Japan
Ph: 813/3573-5421
Fax: 813/3571-7865



STOCK MODELS

Part Name	R1	R2	R3	R4	R5	R6	R6P	R6PP/R6PS	R7
#1 Cover	AJ101A	AJ101B	AJ101C	AJ101D	AJ101EQ	AJ101F	AJ101K	(2)AJ101KA	AJ101G
#2 Stopnut	BC187	BC187	BC181	BC181	BC181	BC181	BC181	(2)BC182	BC183
#3 Impeller	AJ102A	AJ102BQ	AJ102C	AJ102D	AJ102E	AJ102FR	AJ102K	(2)AJ102KA	AJ102GA
#4 Square Key	AH212C	AH212	AB136A	AB136D	AB136	AB136	AB136	(2)AB136	AC628
#5 Shlm Spacer (s)	AJ132	AE686-3	AJ109	AJ109	AJ109	AJ116A	AJ116A	AJ116A	AJ110
#6 Retaining Ring	AJ145	AJ145	AJ149	AJ149					
#7 Housing	AJ103A	AJ103BQ	AJ103C	AJ103DR					
#8 Muffler Box				AJ103DR	AJ103E	AJ103F	AJ103K	AJ103KD	AJ103GA
#9 Spring					AJ104E	AJ104F			
#10A Foam	(4)AJ112A	(4)AJ112B	(4)AJ112C	AJ113DR	AJ113DQ	AJ113FQ	AJ113FQ		AJ113G
#10B Foam		(2)AJ112BQ	(2)AJ112CQ	(4)AJ112DS	(4)AJ112ER	(6)AJ112F	(8)AJ112K		(8)AJ112GA
#11 Muffler Extension/ Adapter Plate	AJ106H	AJ106BQ	AJ106CQ	(2)AJ112DR	(2)AJ112EQ				
Shlm Kit	K396	K396		AJ106DQ	AJ106EQ	AJ106EQ	AJ104K		AJ104GA K395

MOTOR CHART

REGENAIR MODEL NUMBER	MOTOR NUMBER	MOTOR SPECIFICATIONS			PHASE
		60 HZ VOLTS	50 HZ VOLTS		
R1102	J111X	115/208-230	110/220-240	1	
R1102C	J112X	115		1	
R2103	J311X	115/208-230	110/220	1	
R2105	J411X	115/208-230	110/220	1	
R2303A	J310	208-230/460	220/380-415	3	
R2303F	J313	208-230	220	3	
R3105-1/R3105-12	J411X	115/208-230	110/220-240	1	
R3305A-1/R3305A-13	J410	208-230/460	220/380-415	3	
R4110-2	J611AX	115/208-230	110/220-240	1	
R4310A-2	J610	208-230/460	220/380-415	3	
R5125-2	J811X	115/208-230		1	
R5325A-2	J810X	208-230/460	220/380-415	3	
R6125-2	J811X	115/208-230		1	
R6325A-2	J810X	208-230/460	220/380-415	3	
R6335A-2	J910X	208-230/460	220/380-415	3	
R6150J-2	J1013	230		1	
R6350A-2	J1010	208-230/460	220/380-415	3	
R6P335A	J910X	208-230/460	220/380-415	3	
R6P350A	J1010	208-230/460	220/380-415	3	
R6P355A	J110A	208-230/460	220/380-415	3	
R7100A-2	J1210B	208-230/460	220/380-415	3	
R6PP/R6PS3110M	JD1100	208-230/460	220/380-415	3	

* No lubrication needed at start up. Bearings lubricated at factory.

* Motor is equipped with alemite fitting. Clean tip of fitting and apply grease gun. Use 1 to 2 strokes of high quality ball bearing grease.

Consistency	Type	Typical Grease
Medium	Lithium	Shell Dolum R

Hours of service per year	Suggested Relube Interval
5,000	3 years
Continual Normal Application	1 year
Seasonal service motor idle for 6 months or more	1 year beginning of season 6 months

Continuous-high ambient, dirty or moist applications.

All performance figures relate to stock models. A few high pressure units may be available. Consult your local distributor.

Regenair Model Number	PRESSURE						Maximum Pressure "H ₂ O"
	0"H ₂ O	20"H ₂ O	40"H ₂ O	60"H ₂ O	80"H ₂ O	100"H ₂ O	
R1	26	14					28
R2	42	26					38
R3105-1	52	38	14				42
R3105-12	52	36	23				55
R3305A-13	52	36	23				55
R4	90	70	50				52
R5	145	130	100				65
R6125-2	200	180					35
R6325A-2	200	180	152				40
R6335A-2	205	175	155	135			70
R6350A-2	200	180	150	130	110	80	105
R6P335A	290	250					30
R6P350A	300	260	230	200			60
R6P355A	300	260	230	200	160		90
R7100A-2	420	380	340	310	280	230	115
R6PP311OM	485	452	420	380	330		95
R6PS311OM	265	258	252	244	236	226	170


Regenair Model Number	VACUUM					Maximum Vacuum "H ₂ O"
	0"H ₂ O	20"H ₂ O	40"H ₂ O	60"H ₂ O	80"H ₂ O	
R1	25	14				26
R2	40	22				34
R3105-1	50	34	9			40
R3105-12	51	34	20			50
R3305A-13	51	34	20			50
R4	82	62	39			48
R5	140	115	90	50		60
R6125-2	190	155	125			45
R6325A-2	190	155	125			45
R6335A-2	190	150	125	100		75
R6350A-2	190	180	150	100	70	90
R6P335A	270	230				37
R6P350A	280	240	210	170		70
R6P355A	280	240	210	170	100	86
R7100A-2	410	350	300	250	170	90
R6PP311OM	470	425	375	320	220	80
R6PS311OM	240	225	210	195	175	130

*This number indicates the maximum static pressure differential recommended (with cooling air still flowing through unit). In general, units 1hp or less can be dead headed. Check with local representative or distributor to verify which models apply.

Operation of the blower above the recommended maximum duty will cause premature failure due to the build up of heat damaging the components.

Performance data was determined under the following conditions:

- 1) Unit in a temperature stable condition.
- 2) Test conditions: Inlet air density at 0.075lbs. per cubic foot. (20°C(68°F), 29.92 in. Hg(14.7PSIA)).
- 3) Normal performance variations on the resistance curve within +/- 10% of supplied data can be expected.
- 4) Specifications subject to change without notice.
- 5) All performance at 60Hz operation.



Post Office Box 97
Benton Harbor, MI. 49023-0097
Ph: 616/926-6171
Fax: 616/925-8288

70-6100
F2-205/8/92
Rev: E

INSTALLATION AND OPERATING INSTRUCTIONS FOR GAST HAZARDOUS DUTY REGENAIR BLOWERS

This instruction applies to the following models ONLY: R3105N-50, R4110N-50, R4310P-50, R4P115N-50, R5125Q-50, R5325R-50, R6130Q-50, R6P155Q-50, R6350R-50, R6P355R-50 and R7100R-50.

Gast Authorized Service Facilities are Located in the locations listed below

Gast Manufacturing Corporation
505 Washington Avenue
Carlstadt, N. J. 07072
Ph: 201/933-8484
Fax: 201/933-5545

Gast Manufacturing Corporation
2550 Meadowbrook Road
Benton Harbor, MI. 49022
Ph: 616/926-6171
Fax: 616/925-8288

Brenner Fiedler & Associates
13824 Bentley Place
Cerritos, CA. 90701
Ph: 310/404-2721
Ph: 800/843-5558
Fax: 310/404-7975

Wainbee Limited
215 Brunswick Blvd.
Pointe Claire, Quebec
Canada H9R 4R7
Ph: 514/697-8810
Fax: 514/-697-3070

Wainbee Limited
5789 Coopers Ave.
Mississauga, Ontario
Canada L4Z 3S6
Ph: 416/243-1900
Fax: 416/243-2336

Japan Machinery
Central PO Box 1451
Toyko 100-91, Japan
Ph: 813 3573-5421
Fax: 813 3571-7896

Gast Manufacturing Co. Ltd.
Halifax Road, Cressex Estate
High Wycombe, Bucks HP12 3SN
England
Ph: 44 494 523571
Fax: 44 494 436588.

OPERATING AND MAINTENANCE INSTRUCTIONS

SAFETY

This is the safety alert symbol. When you see this symbol personal injury is possible. The degree of injury is shown by the following signal words:

- ▲ DANGER** Severe injury or death will occur if hazard is ignored.
- ▲ WARNING** Severe injury or death can occur if hazard is ignored.
- ▲ CAUTION** Minor injury or property damage can occur if hazard is ignored.

Review the following information carefully before operating.

GENERAL INFORMATION

This instruction applies to the following models ONLY: R3105N-50, R4110N-50, R4310P-50, R4P115N-50, R5125Q-50, R5325R-50, R6130Q-50, R6P155Q-50, R6350R-50, R6P355R-50 and R7100R-50. These blowers are intended for use in Soil Vapor Extraction Systems. The blowers are sealed at the factory for very low leakage. They are powered with a U.L. listed electric motor Class 1 Div. 1 Group D motors for Hazardous Duty locations. Ambient temperature for normal full load operation should not exceed 40° C (105° F). For higher ambient operation, contact the factory.

Gast Manufacturing Corporation may offer general application guidance: however, suitability of the particular blower and/or accessories is ultimately the responsibility of the user, not the manufacturer of the blower.

INSTALLATION

DANGER Models R5325R-50, R6130Q-50, R6350R-50, R5125Q-50, R6P155Q-50, R6P355R-50 AND R7100R-50 use Pilot Duty Thermal Overload Protection. Connecting this protection to the proper control circuitry is mandated by UL674 and NEC501. Failure to do so could result in a **EXPLOSION**. See pages 3 and 4 for recommended wiring schematic for these models.

▲ WARNING Electric shock can result from bad wiring. A qualified person must install all wiring, conforming to all required safety codes. Grounding is necessary.

▲ WARNING This blower is intended for use on soil vapor extraction equipment. Any other use must be approved in writing by Gast Manufacturing Corp. Install this blower in any mounting position. Do not block the flow of cooling air over the blower and motor.

PLUMBING - Use the threaded pipe ports for connection only. They will not support the plumbing. Be sure to use the same or larger size pipe to prevent air flow restriction and overheating of the blower. When installing fittings, be sure to use pipe thread sealant. This protects the threads in the blower housing and prevents leakage. Dirt and chips are often found in new plumbing. Do not allow them to enter the blower.

NOISE - Mount the unit on a solid surface that will not increase the sound. This will reduce noise and vibration. We suggest the use of shock mounts or vibration isolation material for mounting.

ROTATION - The Gast Regenair Blower should only rotate clockwise as viewed from the electric motor side. The casting has an arrow showing the correct direction. Confirm the proper rotation by checking air flow at the IN and OUT ports. If needed reverse rotation of three phase motors by changing the position of any two of the power line wires.

OPERATION

▲ WARNING Solid or liquid material exiting the blower or piping can cause eye damage or skin cuts. Keep away from air stream.

▲ WARNING - Gast Manufacturing Corporation will not knowingly specify, design or build any blower for installation in a hazardous, combustible or explosive location without a motor conforming to the proper NEMA or U. L. standards. Blowers with standard TEFC motors should never be utilized for soil vapor extraction applications or where local state and/or Federal codes specify the use of explosion-proof motors (as defined by the National Electric Code, Articles 100,500 c1990).

▲ CAUTION Attach blower to solid surface before starting to prevent injury or damage from unit movement. Air containing solid particles or liquid must pass through a filter before entering the blower. Blowers must have filters, other accessories and all piping attached before starting. Any foreign material passing through the blower may cause internal damage to the blower.

▲ CAUTION Outlet piping can burn skin. Guard or limit access. Mark "CAUTION Hot Surface. Can Cause Burns". Air temperature increases when passing through the blower. When run at duties above 50 in. H₂O, metal pipe may be required for hot exhaust air. The blower must not be operated above the limits for continuous duty. Only models R3105N-50, R4110N-50 and R4310P-50 can be operated continuously with no air flowing through the blower. Other units can only be run at the rating shown on the model number label. Do not Close off inlet (for vacuum) to reduce extra air flow. This will cause added heat and motor load. Blower exhaust air in excess of 230°F indicates operation in excess of rating which can cause the blower to fail.

ACCESSORIES ...Gast pressure gauge AJ496 and vacuum gauges AJ497 or AE134 show blower duty. The Gas pressure/vacuum relief valve, AG258, will limit the operating duty by admitting or relieving air. It also allows full flow through the blower when the relief valve closes.

SERVICING


⚠ WARNING To retain their sealed construction they should be serviced by Gast authorized service centers ONLY. These models are sealed at the factory for very low leakage.

⚠ WARNING Turn off electric power before removing blower from service. Be sure rotating parts have stopped. Electric shock or severe cuts can result. Inlet and exhaust filters attached to the blower may need cleaning or replacement of the elements. Failure to do so will result in more pressure drop, reduced air flow and hotter opera-

tion of the blower. The outside of the unit requires cleaning of dust and dirt. The inside of the blower also may need cleaning to remove foreign material coating the impeller and housing. This should be done at a Gast Authorized Service Center. This buildup can cause vibration, failure of the motor to operate or reduced flow.


KEEP THIS INFORMATION WITH THIS BLOWER. REFER TO IT FOR SAFE INSTALLATION, OPERATION OR SERVICE.

MOTOR WIRING DIAGRAM FOR R4110N-50 & R3105N-50



>>* WARNING
THIS MOTOR IS THERMALLY PROTECTED AND WILL AUTOMATICALLY RESTART WHEN PROTECTOR RESETS. ALWAYS DISCONNECT POWER SUPPLY BEFORE SERVICING.


MOTORS WIRING DIAGRAM FOR R4310P-50



TO REVERSE ROTATION, INTERCHANGE THE EXTERNAL CONNECTIONS TO ANY TWO LEADS.

>>* WARNING
THIS MOTOR IS THERMALLY PROTECTED AND WILL AUTOMATICALLY RESTART WHEN PROTECTOR RESETS. ALWAYS DISCONNECT POWER SUPPLY BEFORE SERVICING.

MOTORS WIRING DIAGRAM FOR R5325R-50, R6350R-50, R6P355R-50, & R7100R-50




TO REVERSE ROTATION, INTERCHANGE THE EXTERNAL CONNECTIONS TO ANY TWO LEADS.

THERMOSTATS (TO CUSTOMER CONTROL CIRCUIT)


TO REVERSE ROTATION, INTERCHANGE THE EXTERNAL CONNECTIONS TO ANY TWO LEADS.

MOTOR WIRING DIAGRAM FOR R5125Q-50 & R4P115N-50



— THERMOSTAT
— THERMOSTAT

LOW VOLTAGE




— THERMOSTAT
— THERMOSTAT

HIGH VOLTAGE

* R5125Q-50 BLOWERS PRODUCED AFTER SEPTEMBER 1992 (SER. NO. 0992) DO NOT HAVE MOTOR LEADS 5 & 8.


MOTOR WIRING DIAGRAM FOR R6130Q-50 & R6P155Q-50

CONNECT THERMOSTAT TO MOTOR PROTECTION CIRCUIT



— THERMOSTAT
— THERMOSTAT

CONNECTION FOR THERMOSTAT MOTOR PROTECTION




THERMOSTATS TO BE CONNECTED IN SERIES WITH CONTROL AS SHOWN. MOTOR FURNISHED WITH AUTOMATIC THERMOSTATS RATED A.C. 115-600V. 720VA

ACCESSORIES

Moisture Separators

Moisture separators remove liquids from the gas stream in a vacuum process, helping protect the blower from corrosion and a buildup of mineral deposits.

Part No.	Liq. Cap. (gal.)	A(dia.)	Dim. B	C(NPT)	D(dia.)	Dim. E	Dim. F
RMS160	10	14.8"	37.5"	2"	2"	7.5"	26.6"
RMS200	19	19.7"	35"	2"	2"	7.5"	26.6"
RMS300	19	19.7"	35"	2.5"	2.5"	7.5"	26.6"
RMS400	40	24"	44"	3"	3"	9.7"	29"



Part No.	Product Type	Description	Used On
RMS160	Moisture separator	10 gallon liquid carrying capacity	R3, R4, R4P, R5 Blowers
RMS200	Moisture separator	19 gallon liquid carrying capacity	R4, R4P, R5, R6 Blowers
RMS300	Moisture separator	19 gallon liquid carrying capacity	R5, R6, R6P Blowers
RMS400	Moisture separator	40 gallon liquid carrying capacity	R6P, R7 Blowers
—	Float switch	Consult factory for appropriate style	RMS Series-Separators


Filters

Since the blower impeller passes very close to the housing, it is always wise to have an in-line or inlet filter to ensure trouble free life.

In-line (for vacuum)

Part No.	Dim. A	Dim. B	Dim. C	Dim. D	Dim. E
AJ151C	7.38"	6.81"	4.62"	1-1/4" FPT	1-1/4" FPT
AJ151D	7.38"	6.81"	4.62"	1-1/2" FPT	1-1/2" FPT
AJ151E	8.75"	10.25"	5.00"	2" FPT	2" FPT
AJ151G	8.00"	10.25"	5.50"	2-1/2" FPT	2-1/2" FPT
AJ151H	14.00"	26.50"	18.13"	3" MPT	3" MPT
AJ151L	14.00"	27.13"	18.50"	4" MPT	4" MPT

MPT = Male Pipe Thread FPT = Female Pipe Thread All are heavy-duty for high amounts of particulates. Inlet filters for REGENAIR® blowers are drip-proof when mounted as shown.




For Vacuum Service

AJ151C	In-line filter	10 micron filter (replacement element AJ135E)	R3 Blower, R1H
AJ151D	In-line filter	10 micron filter (replacement element AJ135E)	R4, R4P, R3H Blowers, R2H
AJ151E	In-line filter	10 micron filter (replacement element AJ135F)	R5, R4H Blowers
AJ151G	In-line filter	10 micron filter (replacement element AJ135G)	R6, R6P Blowers, R7H, R8H, R9H
AJ151H	In-line filter	10 micron filter (replacement element AJ135C)	R7 Blower
AJ151L	In-line filter	10 micron filter (replacement element AJ135C)	R8M Blower

Inlet (for pressure units only)

Part No.	Dim. A	Dim. B	Dim. C
AJ126C	6.00"	7.12"	1-1/4" MPT
AJ126D	7.70"	7.25"	1-1/2" MPT
AJ126F	10.63"	4.81"	2" FPT
AJ126G	10.00"	13.12"	2-1/2" MPT
AJ126L	10.00"	14.62"	4" MPT

MPT = Male Pipe Thread FPT = Female Pipe Thread All are heavy-duty for high amounts of particulates. Inlet filters for REGENAIR® blowers are drip-proof when mounted as shown.



For Compressor-Inlet

AJ126C	Inlet filter	10 micron filter (replacement element AJ134C)	R3 Blower, R1H, 2067, 2567
AJ126D	Inlet filter	10 micron filter (replacement element AJ134E)	80 Series, 6066, 1290, R4, R4P, R5, R3H Blowers
AJ126F	Inlet filter	25 micron filter (replacement element AG340)	R6, R6P, R4H Blowers
AJ126G	Inlet filter	10 micron filter (replacement element AJ135A)	R7 Blower, R7H, R8H
AJ126L	Inlet filter	10 micron filter (replacement element AJ135H)	R8H Blower
AL355	Inlet filter	10 micron filter	0823

ACCESSORIES




Pressure-Vacuum Gauge

To monitor the system performance so maximum duties are not exceeded. Using two gauges (one on each side of the filter) is a great way to know when the filter needs servicing.

AJ497	Vacuum gauge	0-60" H ₂ O, 1/4" NPT connection	Blowers
AE134	Vacuum gauge	0-160" H ₂ O, 1/4" NPT connection	Blowers
AE134F	Vacuum gauge	0-15" HG, 1/4" NPT connection	H Series Blowers
AA644B	Pressure gauge	0-30 psi, 1/4" NPT	80 Series, 2567, 2067, 6066, 0823
AE133	Pressure gauge	0-160" H ₂ O, 1/4" NPT connection	Blowers
AE133A	Pressure gauge	0-200" H ₂ O, 1/4" NPT connection	Blowers
AE133F	Pressure gauge	0-15 psi, 1/4" NPT connection	R3H, R4H Blowers
AJ496	Pressure gauge	0-60" H ₂ O, 1/4" NPT connection	SVE Blowers

Check Valve


Designed to prevent back-wash of fluids that would enter the blower. Also prevents air back-streaming if needed. Can be mounted with discharge either vertical or horizontal. Valve will open with 3" of water pressure.



AH326D	Check valve	1-1/2" NPT (3" H ₂ O cracking pressure)	Blowers
AH326F	Check valve	2" NPT (3" H ₂ O cracking pressure)	Blowers
AH326G	Check valve	2-1/2" NPT (3" H ₂ O cracking pressure)	R7 Blower

Relief Valve

By setting a relief valve at a given pressure/vacuum you can ensure excessive duties will not harm the blower or products in your application.



AG258



AN225




PV Series

AA307	Relief valve	For pressure, 3/4" NPT, adjustable 2-25 psi	6066, 2567 Series
AA600	Relief valve	For pressure, 3/8" NPT, adjustable 2-30 psi	0823
AG258	Relief valve	1-1/2" NPT adjustable 30-170" H ₂ O, vac. or press., 200 CFM max.	Blowers
AG258F	Relief valve	2-1/2" NPT adjustable for higher flows, vacuum or pressure	Blowers
PV065	Relief valve	For pressure, pre-set for 6.5 psi, 1-1/4" NPT connection (60Hz)	R3H Blower
PV072	Relief valve	For pressure, pre-set for 7.2 psi, 1-1/4" NPT connection (60Hz)	R3H Blower
PV084	Relief valve	For pressure, pre-set for 8.4 psi, 1-1/4" NPT connection (50Hz)	R4H Blower, R8H, R9H
PV091	Relief valve	For pressure, pre-set for 9.1 psi, 1-1/4" NPT connection (50Hz)	R4H Blower, R9H
PV098	Relief valve	For pressure, pre-set for 9.8 psi, 1-1/4" NPT connection (50Hz)	R7H Blower
PV102	Relief valve	For pressure, pre-set for 10.2 psi, 1-1/4" NPT connection (60Hz)	R7H Blower
AN225	Relief valve	15-45 cfm, 3/4" NPT connection, adjustable 0-20 psi	2080, 3080, 4080 Series

Service Kit

If pump performance on rotary vane models diminishes, installation of the Service Kit replacement parts will have it performing like new again.




K479A	Service Kit	Includes items for unit repair	0823 Model
K504	Service Kit	Includes items for unit repair	6066, 1290 (uses 2)
K583	Service Kit	Includes items for unit repair	2567 Models
K584	Service Kit	Includes items for unit repair	2080, 3080, 4080 Models
K585	Service Kit	Filter/Muffler Kit only	2080, 3080, 4080 Models

North American Representatives and Distributors

A substantial stock of vacuum pumps, compressors, air motors, parts and accessories are carried by the offices listed below.

- (A) Distributor-plant-use sales only.
- (B) Manufacturers Representative - O.E.M. and plant-use sales.
- (C) Gast warehouse and sales office - O.E.M. and plant-use sales.
- (D) Gast service center.



- ① James E. Watson & Co.
29 Doran Ave.
Marietta, GA 30060
Ph. 404/422-1154

James E. Watson & Co.
Birmingham, AL
Ph. 205/663-6678

James E. Watson & Co.
Nashville, TN
Ph. 615/331-5716
- ③ Franklin Electrofluid Co., Inc.
(B) 3854 Watman
Memphis, TN 38118
Ph. 901/362-7504
Ph. 1-800-238-7500

Franklin Electrofluid Co., Inc.
8900 Crystal Hill Road
North Little Rock, AR 72113
AR only 1-800-272-5665
Ph. 501/771-4170

Franklin Electrofluid Co., Inc.
5609 South 14th Street
Ft. Smith, AR 72901
Ph. 501/646-7448
Ph. 1-800-264-7406
- ④ Brenner-Fiedler & Assoc., Inc.
(B,D) 13824 Bentley Place
Cerritos, CA 90701
Ph. 310/404-2721 &
Ph. 714/521-6280
Ph. 1-800-843-5558

Brenner Fiedler & Assoc., Inc.
(B) San Diego, CA
Ph. 619/232-9152
Ph. 1-800-843-5558

Brenner Fiedler & Assoc., Inc.
(B) 2117 South 48th Street #102
Tempe, AZ 85282
Ph. 1-800-638-0394
- ⑤ TECO Pneumatic, Inc.
(B) 1069 Serpentine Lane
Pleasanton, CA 94566
Ph. 510/426-8500
- ⑥ Fiero Fluid Power, Inc.
(B) Suite 104
10515 East 40th Ave.
Denver, CO 80239
Ph. 303/373-2600

Fiero Fluid Power, Inc.
(B) 2155 South Main
Salt Lake City, UT 84115
Ph. 801/467-4622
- ⑦ Ohlheiser Corp.
(B) 17 Rose Ave.
West Hartford, CT 06133-0332
Connecticut only 203/953-7632
New England States 1-800-858-9368
- ⑧ **GAST**
Gast Mfg. Corp.
(C,D) Eastern Sales Office
505 Washington Ave.
Carlstadt, NJ 07072
Ph. 201/933-8484
Ph. 212/563-1870 (NYC)

Dees Corp.
(A) 8860 Kelso Dr.
Baltimore, MD 21221
Ph. 410/574-2900

Die-A-Matic, Inc.
(A) 119 Brown St.
Pittston (Wilkes-Barre), PA 18640
Ph. 717/655-6831

Die-A-Matic, Inc.
(A) 650 N. State St.
York, PA 17403
Ph. 717/846-9300

Van-Air & Hydraulics, Inc.
(A) Philadelphia, PA
Ph. 215/923-2575

Van-Air & Hydraulics, Inc.
(A) 525 E. Woodlawn Ave.
Maple Shade, NJ 08052
Ph. 609/779-7300

- ② Gulf Controls Corp.
(B) 5201 Tampa West Blvd.
Tampa, FL 33614
Ph. 813/884-0471
Ph. 1-800-282-9125
- ⑩ **GAST**
Gast Midwestern Sales Office
(C) 755 N. Edgewood
Wood Dale, IL 60191
Ph. 708/860-7477
- ⑫ D & F Distributors
(B) 6309 Ulrich Avenue
Louisville, KY 40219
Ph. 502/968-0107
Ph. 1-800-45-PUMPS

D & F Distributors, Inc.
(B) 1144 Indy Court
Evansville, IN 47711
Ph. 812/867-2441
Ph. 1-800-45-PUMPS
- ⑬ John Henry Foster Co. Inc.
(B) 4700 Lebourget Drive
St. Louis, MO 63134-0820
Ph. 314/427-0600
Ph. 1-800-444-0522
- ⑭ Isaacs Fluid Power Equipment Company
(B) 8746 East 33rd Street
Indianapolis, IN 46226
Ph. 317/898-3486

Isaacs Fluid Power Equipment Company
Ft. Wayne, IN
Ph. 219/747-9804

Isaacs Fluid Power Equipment Company
1023 E. Fourth St.
Dayton, OH 45402
Ph. 513/228-7774

Isaacs Fluid Power Equipment Company
(B) 1840 Amberlawn Dr.
Cincinnati, OH 45237
Ph. 513/761-8855

Isaacs Fluid Power Equipment Company
(B) 929 Eastwind Drive, Suite 205
Westerville, OH 43081
Ph. 614/895-8540
- ⑮ Skarda Equipment Co., Inc.
(B) 2563 Famam
Omaha, NE 68131
Ph. 1-800-228-9750
Ph. 402/422-0430

Skarda Equipment Co., Inc.
(B) 3545 Third Ave.
Marion, IA 52302
Ph. 1-800-228-9750

Skarda Equipment Co., Inc.
Des Moines, IA
Ph. 1-800-228-9750

Skarda Equipment Co., Inc.
(B) 10139 Kaw Dr.
Edwardsville, KS 66113
Ph. 1-800-228-9750

Skarda Equipment Co., Inc.
(B) 313 N. Mathewson
Wichita, KS 67214
Ph. 1-800-228-9750
- ⑯ D & L Pumps, Inc.
(B) 2845 Sharon Street
Kenner, LA 70062
Ph. 504/467-2490
- ⑰ William H. Nash Co., Inc.
(B) 23910 Freeway Park Drive
Farmington Hills, MI 48335
Ph. 810/477-5800
- William H. Nash Co., Inc.
(B) 4134 36th Street S.E.
Grand Rapids, MI 49512
Ph. 616/949-4900

William H. Nash Co., Inc.
Flushing, MI
Ph. 810/732-7272
- ⑱ Midwest Machine Tool Supply
230 Commerce Circle South
Minneapolis, MN 55432
Ph. 612/571-3550
Ph. 1-800-327-9523
- ⑲ Kinequip, Inc.
(B) 365 Old Niagara Falls Blvd.
Buffalo, NY 14228-1636
Ph. 716/694-5000
Ph. 1-800-982-8894

Kinequip, Inc.
Johnstown, NY
Ph. 1-800-982-8894

Kinequip, Inc.
(B) Rochester, NY
Ph. 716/272-1590
Ph. 1-800-982-8894

Kinequip, Inc.
(B) Syracuse, NY 13211
Ph. 315/458-4115
Ph. 1-800-982-8894
- ⑳ Hydraulic & Pneumatic Sales
(B) 11100 Park Charlotte Blvd.
Charlotte, NC 28241
Ph. 704/588-3234
- ㉑ RAF Fluid Power, Inc.
(B) 23775 Mercantile Road
Cleveland, OH 44122-5990
Ph. 216/464-8990
- ㉒ Southwestern Controls
(B) 9912 B. East 45th Place
Tulsa, OK 74146-4752
Ph. 918/663-6777
Ph. 1-800-658-1570

Southwestern Controls
(B) 6720 Sands Point
Houston, TX 77074
Ph. 713/777-2626
Ph. 1-800-444-9368

Southwestern Controls
(B) 8808 Sovereign Row
Dallas, TX 75247
Ph. 214/638-4266
Ph. 1-800-444-9367

Southwestern Controls
(B) 859 Isom Road
San Antonio, TX 78216-4035
Ph. 210/340-4111
- ㉔ Allegheny Fluid Power, Inc.
(B) 112 Douglas Road
Sewickley, PA 15143
Ph. 412/367-5894
- ㉕ Mesa Equipment & Supply Company
(B) 3820 Commons, N.E.
Albuquerque, NM 87109
Ph. 505/345-0284

Mesa Equipment & Supply Company
(B) 1342 Lomaland Drive
El Paso, TX 79935
Ph. 915/594-1414

- ⑳ C.A. Weaver Co., Inc.
(B) 2420 Grenoble Road
Richmond, VA 23294
Ph. 804/672-6501

C.A. Weaver Co., Inc.
(B) 7562 Hi Tech Rd.
Roanoke, VA 24019
Ph. 703/563-9761

C.A. Weaver Co., Inc.
(B) 2430 Alabama Avenue
Norfolk, VA 23513
Ph. 804/857-8700
- ㉑ Air-Oil Products Corp.
6353 Sixth Ave. South
Seattle, WA 98108-3437
Ph. 206/767-7750
Ph. 1-800-282-2672
Fax: 206/762-4736

Air-Oil Products Corp.
(B) 2400 E. Burnside St.
Portland, OR 97214
Ph. 503/234-0866
Ph. 1-800-242-2672

Air-Oil Products Corp.
(B) 865 Conger Street
Eugene, OR 97401
Ph. 503/485-2022
Ph. 1-800-322-2672
- ㉒ Fluid System Components Inc.
(B) 3154 Gross St.
Green Bay, WI 54307
Ph. 414/337-0234

Fluid System Components Inc.
(B) 2315 South 170th Street
New Berlin, WI 53151-2701
Ph. 414/827-2700
- ㉓ J.E.M. Fluid Power, Inc.
(B) 2182 Dam Rd.
West Branch, MI 48661
Ph. 517/345-1180
- ㉔ **GAST**
Gast Mfg. Corp.
(C) 2300 Highway M-139
Benton Harbor, MI 49023-0097
Ph. 616/926-6171
- ㉕ C & F Machinery
(A) 91-060 Hanua Street
Kapolei, Hawaii 96707-1777
Ph. 808/682-1541
- ㉖ Garness Industries, Inc.
(B) 6317 Nielson Way
Anchorage, AK 99518
Ph. 907/562-2933
- ㉗ CANADA
ONTARIO
Wainbee Ltd.
Windsor
Ph. 1-800-265-0929

Wainbee Ltd.
(B) 1590 Liverpool Court
Ottawa, Ontario K1B 4L2
Ph. 613/744-1720
- Wainbee Ltd.
(A,D) 5789 Coopers Ave.
Mississauga, Ontario L4Z 3S6
Ph. 905/568-1700
Fax: 905/568-0083

Wainbee Ltd.
(B) Unit 14
65 Trillium Park Place
Kitchener, Ont. N2E 1X1
Ph. 519/748-5391

Wainbee Ltd.
(B) 1909 Oxford Street East, Unit 45
London, Ont. N5V 4L9
Ph. 519/451-6266
Fax: 519/451-5566

QUEBEC

Wainbee Ltd.
(A,D) 215 Brunswick Blvd.
Pointe Claire, P.Q. H9R 4R7
Ph. 514/697-8810

Wainbee Ltd.
(B) 1990 Quest Blvd. Charest
Quebec City, P.Q. G1N 4K8
Ph. 418/683-1956

Wainbee Ltd.
(B) 1932 St. Paul Blvd.
Chicoutimi, P.Q. G7K 1H2
Ph. 418/698-4884

BRITISH COLUMBIA

Wainbee Ltd.
(B) 2231 Vauxhall Place
Richmond, B.C. V6V 1Z5
Ph. 604/278-4288
Ph. 1-800-663-9829

ALBERTA

Wainbee Ltd.
(B) 10336 59th Avenue
Edmonton, Alta. T6H 1E6
Ph. 403/434-9528

Wainbee Ltd.
(B) 7407 44th St. S.E.
Calgary, Alta. T2C 3C8
Ph. 403/236-1133

MANITOBA

Wainbee Ltd.
(B) 1393 Border St. #4
Winnipeg, Man. R3H 0N1
Ph. 204/632-4558
Ph. 1-800-663-1393

MARITIME PROVINCES

Wainbee Ltd.
(B) 10 Thornhill Drive, Suite #5
Dartmouth, Nova Scotia
Halifax B3B 1S1
Ph. 902/468-1787
Ph. 1-800-667-1787

SASKATOON

Wainbee, Ltd.
437 34th Street
Saskatoon, Sask. S0S 0S9
Ph. 306/652-1433

NORTH BAY

Wainbee, Ltd.
1954 Main Street West
North Bay, Ont. P1B 8K5
Ph. 705/472-4244
Ph. 1-800-461-9534



CONVERSION CHARTS

PRESSURE CONVERSION TABLE

Lbs. Per Sq. Inch	Atmospheres	Inches of Mercury	Millimeters of Mercury	Inches of Water	Meters of Water	Milli Bars	Kilopascals
1	.0680	2.036	51.71	27.73	.7037	69.0	6.895
14.70	1	29.92	760	407	10.33	1013.3	101.36
.4912	.0334	1	25.4	13.6	.3452	33.86	3.387
.0193	.001315	.03937	1	.5358	.0136	1.33	.13307
.0361	.00246	.0735	1.868	1	.0254	2.49	.24891
1.422	.0967	2.895	73.55	39.37	1	97.98	9.8047
14.50	.0009869	.02953	.750	.4018	.01021	1	.09998
.145	.00986	.29529	7.4996	4.0174	.10206	10.01	1

VOLUME FLOW CONVERSION TABLE

cfm	cfh	gpm	m ³ h	l/s
1	60	7.4805	1.6990	.47195
1/60	1	.12468	.02832	.007866
.13368	8.0208	1	.22712	.06309
.58858	35.315	4.4029	1	1/3.6
2.1189	127.13	15.850	3.6	1

Power and Heat Flow Conversion Table

hp(U.S.)	ft.lb/min	Btu/hr	Btu/min	W	kcal/min
1	33000	2544.4	42.407	745.70	10.686
.000030303	1	.07710	.001285	.02260	.0003238
.0003930	12.969	1	1/60	.29307	.004200
.02358	778.17	60	1	17.584	.25200
.00134	44.254	3.4121	.05687	1	.01433
.09358	3088.0	238.10	3.9683	69.780	1

Temperature Conversion Chart

°C = $\frac{5}{9}(\text{°F} - 32)$

Absolute Kelvin = °C + 273.15

°F = $(\frac{9}{5}\text{°C}) + 32$

Rankine °F = +459.67

TABLE EXAMPLE:

To Convert 100 °C to °F look up 100 read left

To Convert 100 °F to °C look up to 100 read right

to °F	From	to °C
-148.0	-100	-73.33
-130.0	-90	-67.78
-112.0	-80	-62.22
-94.0	-70	-56.67
-76.0	-60	-51.11
-58.0	-50	-45.56
-40.0	-40	-40.00
-36.4	-38	-38.89
-32.8	-36	-37.78
-29.2	-34	-36.67
-25.6	-32	-35.56
-22.0	-30	-34.44
-18.4	-28	-33.33
-14.8	-26	-32.22
-11.2	-24	-31.11
-7.6	-22	-30.00
-4.0	-20	-28.89
-0.4	-18	-27.78
+3.2	-16	-26.67
+6.8	-14	-25.56
+10.4	-12	-24.44
+14.0	-10	-23.33
+17.6	-8	-22.22
+21.2	-6	-21.11
+24.8	-4	-20.00
+28.4	-2	-18.89
+32.0	0	-17.78
+35.6	+2	-16.67
+39.2	+4	-15.56
+42.8	+6	-14.44
+46.4	+8	-13.33

to °F	From	to °C
+50.00	+10	-12.22
+53.6	+12	-11.11
+57.2	+14	-10.00
+60.8	+16	-8.89
+64.4	+18	-7.78
+68.0	+20	-6.67
+71.6	+22	-5.56
+75.2	+24	-4.44
+78.8	+26	-3.33
+82.4	+28	-2.22
+86.0	+30	-1.11
+89.6	+32	0.00
+93.2	+34	+1.11
+96.8	+36	+2.22
+100.4	+38	+3.33
+104.0	+40	+4.44
107.6	42	5.56
111.2	44	6.67
114.2	46	7.78
118.4	48	8.89
122.0	50	10.00
125.6	52	11.11
129.2	54	12.22
132.8	56	13.33
136.4	58	14.44
140.0	60	15.56
143.6	62	16.67
147.2	64	17.78
150.8	66	18.89
154.4	68	20.00
158.0	70	21.11

to °F	From	to °C
161.6	72	22.22
165.2	74	23.33
168.8	76	24.44
172.4	78	25.56
176.0	80	26.67
179.6	82	27.78
183.2	84	28.89
186.8	86	30.00
190.4	88	31.11
194.0	90	32.22
197.6	92	33.33
201.2	94	34.44
204.8	96	35.56
208.4	98	36.67
212.0	100	37.78
230.0	110	43.33
248.0	120	48.89
266.0	130	54.44
284.0	140	60.00
302.0	150	65.56
320.0	160	71.11
338.0	170	76.67
356.0	180	82.22
374.0	190	87.78
392.0	200	93.33
410.0	210	98.89
428.0	220	104.44
446.0	230	110.00
464.0	240	115.56
482.0	250	121.11

Warranty

REGARDLESS OF CAUSE, if a product you buy from this brochure does not work right, Gast will repair or replace it once, at no charge, for up to one year from the date of shipment from the factory. In the course of repair or replacement, Gast may send you written recommendations on how to prevent a problem from happening again. Gast reserves the right to withdraw this warranty if you do not follow these recommendations. Customer is responsible for freight charges both to and from Gast in all cases. This warranty does not apply to electric motors, electrical controls, and gasoline engines, which Gast obtains from other manufacturers. A motor or engine carries only the warranty of the company that makes it.

THIS WARRANTY IS EXCLUSIVE AND IS IN LIEU OF ALL OTHER WARRANTIES, WHETHER WRITTEN, ORAL OR IMPLIED, INCLUDING THE WARRANTY OF MERCHANTABILITY AND OF FITNESS FOR ANY PARTICULAR PURPOSE. GAST'S LIABILITY IS IN ALL CASES LIMITED TO THE REPLACEMENT PRICE OF ITS PRODUCT. GAST SHALL NOT BE LIABLE FOR ANY OTHER DAMAGES, WHETHER CONSEQUENTIAL, INDIRECT, OR INCIDENTAL, ARISING FROM THE SALE OR USE OF ITS PRODUCTS.

Gast's sales personnel may modify this warranty, but only by signing a specific, written description of any modifications.

DISCLAIMER

The information presented in this catalog is based on technical data and test results of nominal units. It is believed to be accurate and is offered as an aid in the selection of Gast products. It is the user's responsibility to determine suitability of the product for his intended use and the user assumes all risk and liability whatsoever in connection therewith.

APPENDIX C
DATA COLLECTION SHEETS

